

### **CONNECT TRANSIT - NORMAL**

# SERVICE MANUAL XCELSIOR® DIESEL 40FT. TRANSIT BUS



This service manual is effective for only those coaches with the following Identification Numbers:

#### **SR1950**

Vehicle Identification Number	Unit Number
5FYD8FV10FB047637	1501
5FYD8FV12FB047638	1502
5FYD8FV14FB047639	1503
5FYD8FV10FB047640	1504
5FYD8FV12FB047641	1505





To Our Valued Customer,

New Flyer Industries Canada ULC is pleased to provide you and your property with this technical manual prepared specifically for your new order of buses.

Our goal is to provide our customer with comprehensive, accurate and easy to use technical manuals that are designed to present information in a clear and concise manner. The information contained in this manual is not generic and is derived from your bus build specifications only.

Throughout the preparation of this manual, we have applied rigid technical publications specifications to ensure that you receive a high quality product that will serve you well for many years to come. Every effort has been expended to ensure that the information and data within are accurate and technically correct. All illustrations have been drawn to represent easy-to-view, comprehensive and clear assemblies and sub-assemblies.

If you discover any omissions or have any suggestions for changes or improvements, please do not hesitate to write or fax us your information on the tear-away sheet provided at the back of this manual.

It is our sincerest hope and intent that you find this manual useful and a reliable source of information.

Yours truly,

Mike D. Monsigneur Director of Publications

NEW ELVER Publications

M. Moringneur

Aftermarket 76-630 Kernaghan Ave. Winnipeg, Manitoba Canada R2C 5G1

Tel: (204) 982-8437 Fax: (204) 667-5769



### COPYRIGHT © 2015 NEW FLYER INDUSTRIES CANADA ULC. ALL RIGHTS RESERVED.

No part of this manual and/or data herein may be reproduced or transmitted in any form or by any means, electronic or mechanical, including photocopying, recording, or information recording and retrieval systems, for any purpose, without the express written permission of New Flyer Industries Canada ULC.

"New Flyer" is a tradename of "New Flyer Industries Canada ULC"

The information contained in this manual is updated periodically. While great care is taken in compiling the information contained in this manual, New Flyer Industries Canada ULC cannot assume liability for losses of any nature arising from any errors and/or omissions.

The information and specifications contained throughout this manual are up to date at the time of publication. New Flyer Industries Canada ULC reserves the right to change the content of this manual at anytime without notice.

Printed in Canada





#### NOTE:

The National Highway Traffic Safety Administration (NHTSA) has requested that the following statement be provided for your information.

If the property believes that its vehicle has a defect which could cause a crash or could cause injury or death, inform the National Highway Traffic Safety Administration (NHTSA) in addition to notifying New Flyer Industries Canada ULC.

If NHTSA receives similar complaints, it may open an investigation, and if it finds that a safety defect exists in a group of vehicles, it may order a recall and remedy campaign. However, NHTSA cannot become involved in individual problems between you and New Flyer Industries Canada ULC.

To contact NHTSA either call the Auto Safety Hotline toll-free at 1-888-327-4236 (or 366-0123 in the Washington, DC area) or write to: NHTSA, U.S. Department of Transportation, Washington, DC 20590. Other information about motor vehicle safety can be obtained from the Hotline.



### **Vehicle Patent Information**

This New Flyer product and its components, and methods of manufacturing thereof, may be protected by one or more of the following patents, design registrations and patent applications. In addition, such products, components, and/or methods may be protected by one or more patent and design applications which may have not been published as of the date of this manual, in the United States, Canada, and elsewhere. Please direct all inquiries to our Corporate Offices. For a current listing of applicable patents, please refer to our Legal Notice at our corporate website, http://www.newflyer.com.

New Flyer Products	Patents, Patent Applications, Design Registrations & Design Applications
Xcelsior <sup>®</sup> Bus <sup>1</sup>	U.S.: 6,343,908; 6,397,965; 6,416,094; 6,556,899; 6,611,739; 6,681,174; 6,695,366; 8,109,551; 8,548,669; D637520; D639712; D660761; D678818; D680670; D687593; D692360; published applications 2012/ 0161469; 2013/0181679
	Canada: 2,317,237; 2,455,153; 2,652,352; 2,794,822; 2,825,732; design registrations 129599; 132413; 132414; 132415; 132416; 132417; 133389; 133391; 133392; 133598; 133599; 133600; 133645; 133646; 133647; 133648; 133649; 133650; 133651; 136,266; 139456; 139757
MiDi <sup>®</sup> Bus <sup>1</sup>	U.S.: 6,343,908; 6,556,899; 6,611,739; 6,681,174; 6,556,899; 6,611,739; 6,681,174; 8,548,669
	Canada: 2,306,413; 2,689,744
Invero <sup>®</sup> Bus <sup>1</sup>	U.S.: 6,257,652; 6,340,202; 6,343,908; 6,375,249; 6,397,965; 6,416,094; 6,416,116; 6,556,899; 6,611,739; 6,681,174; 6,695,366; 6,726,271; 8,548,669
	Canada: 2,297,618; 2,297,623; 2,297,625; 2,297,719; 2,306,413; 2,317,237; 2,455,153
High Floor Bus <sup>1</sup>	U.S.: 6,343,908; 6,397,965; 6,416,094; 6,556,899; 6,611,739; 6,681,174; 6,695,366; 8,548,669
	Canada: 2,317,237; 2,455,153
Low Floor Bus <sup>1</sup>	U.S.: 6,343,908; 6,397,965; 6,416,094; 6,556,899; 6,611,739; 6,681,174; 6,695,366; 8,548,669
	Canada: 2,317,237; 2,455,153



New Flyer Products	Patents, Patent Applications, Design Registrations & Design Applications
Electric Bus	U.S.: published application 2013/0181679
	Canada: 2,794,822
Passenger Ramps	U.S.: 6,343,908
	Canada: 2,306,413
Energy Absorbing Bumpers	U.S.: 6,416,094; 6,695,366
	Canada: 2,455,153
Engine Mounts	U.S.: 6,397,965
	Canada: 2,317,237
New Flyer Connect™ Products & Services	U.S.: 6,556,899; 6,611,739; 6,681,174; 6,556,899; 6,611,739; 6,681,174; 8,548,669
	Canada: 2,689,744



#### INTRODUCTION

#### **Purpose**

The purpose of this Service Manual is to present information and procedures required to properly service and maintain your New Flyer vehicles.

#### **Service Personnel Responsibilities**

All personnel involved in the service of the vehicle should be acquainted with this manual.

#### **Organization of the Service Manual**

This manual is divided into major sections. A tab on the first page of each major section indicates the section number and title. The first page following the tab page is the section table of contents.

This manual and any manufacturers/vendors manuals should be referred to when servicing or maintaining the vehicles with the Vehicle Identification Numbers listed.

#### **Additional Manuals & Publications**

New Flyer urges service technicians to read this publication carefully, as well as obtain other manuals dealing with components of the vehicle. In the sections dealing with the vehicle specifics the suggested manuals for reading and referencing have been recommended.

#### **Liability Disclaimer**

In the preparation of this manual, New Flyer Industries Canada ULC has incorporated and/or compiled service information and maintenance procedures/instructions sourced from manufacturers/vendors of parts and components used in the manufacturing of this vehicle. Therefore, New Flyer Industries Canada ULC shall not be liable for omissions/missing data.

It is not the intention of this manual to instruct service technicians in using common sense, basic skills and rules of service/repair. The information and specifications throughout this manual are up to date at time of publication. New Flyer reserves the right to change the content of this manual at anytime without notice.



#### SAFETY

#### **Danger, Warnings, Cautions & Notes**

Four types of headings are used in this manual to attract your attention. They appear in the text as follows:



Indicates a hazardous situation which, if not avoided, will result in death or serious injury.



Used when an operating procedure or practice, if not correctly followed, could result in personal injury or loss of life.



Used when an operating procedure or practice, if not strictly observed, could result in damage to or destruction of equipment.

#### ™NOTE:

Is used to provide additional information that requires special attention by the operator.

IT IS YOUR RESPONSIBILITY to be completely familiar with the warnings and cautions described in this service manual.

These warnings and cautions advise against the use of specific troubleshooting methods that can result in personal injury, damage to the equipment or cause the equipment to be unsafe. It is, however, important to understand that these warnings and cautions are not exhaustive.

New Flyer Industries could not possibly know, evaluate and advise service technicians of all conceivable ways in which service/maintenance/troubleshooting might be done or of the possible hazardous consequences of each way. Consequently, New Flyer Industries has not undertaken any such broad evaluation.



Accordingly, ANYONE WHO USES A SERVICE/MAINTENANCE/TROUBLE-SHOOTING PROCEDURE OR TOOLS NOT RECOMMENDED BY New Flyer Industries CANADA ULC MUST first be thoroughly satisfied that neither personal safety nor equipment safety will be jeopardized by the troubleshooting procedures selected.

Proper service and repair are important to the safe, reliable operation of the equipment. The service/maintenance/troubleshooting procedures recommended by New Flyer Industries and described in this manual are effective methods for carrying out service procedures. Some of these troubleshooting procedures require the use of special tools. The special tools should be used when and as recommended.

#### **Special Tools**

Special tools and equipment mentioned throughout the text are specifically designed to perform certain repair requirements beyond the scope of normal tools.

Contact New Flyer Parts if these special tools are not able to be obtained locally.

#### **Vehicle Identification**

To aid New Flyer personnel that is serving you, please have the appropriate V.I.N. (vehicle identification number) information. This information can be obtained from the V.I.N. sticker normally located in the front upper portion of the driver's compartment.



#### **Abbreviations**

The following is an explanation of the different abbreviations which are used.

A/R	As Required	CVSA Commercial Vehicle Safety Alliance
ABS	Anti-lock Braking System	cwclockwise
AC	alternating current	D Delivery Port (Air Schematic)
AC	Air Conditioning	DbDecibel
ACTM	Alternating Current Traction Motor	DCdirect current
AF	Auxiliary Functions	DC Double Check Valve (Air Schematic)
AGA	American Gas Association	DC Door Control
AGC	Automatic Gain Control	DEDiesel Electric
AMDT	Advanced Mobile Data Terminal	DEFDiesel Exhaust Fluid
amp	ampere	DELDelivery
ANSI	American National Standards Institute	DOTDepartment of Transport
APC	Automatic Passenger Counter	DPDTDouble Pole Double Throw
APS	Auxiliary Power System	DPFDiesel Particulate Filter
ASTM	American Society for Testing and Materials	DPIM Dual Power Inverter Module
ATC	Automatic Traction Control	DPST Double Pole Single Throw
AVA	Automatic Vehicle Annunciation (Voice Annunciator)	DPTTDouble Pole Triple Throw
AVL	Automatic Vehicle Locator	DSDriver's Signal (Electrical Schematic)
BLK	Black	DSDriver's Seat (Air Schematic)
BRV	Brake Release Valve	DV Drain Valve
BTU	British Thermal Unit	DVMDigital Volt Meter
CAC	Charge Air Cooler	DVRDigital Video Recorder
CAN	Controller Area Network	EAS Electric Alternator System
CB	Circuit Breaker	EBR Emergency Brake Release Valve
CC	Climate Control	ECM Electronic Control Module
CCA	Cold Cranking Amps	ECP Electronics Cooling Package (BAE Hybrid Buses)
ccw	counter clockwise	ECU Electronic Control Unit
cfm	cubic feet per minute	ELExterior Lighting
CGA		ENG Engine
CLASST	MContact-Less Acoustic Sensing System	EPROM Electronic Programmable Read Only Memory
cm	centimeter	EPU Emergency Power Unit
CNG	Compressed Natural Gas	ES Electrical Schematic
CONT	Control Port (Air Schematic)	ESSEnergy Storage System
CONT		EVAP Evaporator
CP	Communication Provision	EXH Exhaust Port (Air Schematic)
cs	Curbside	FAP Fuel Absolute Pressure
CSK	Countersunk	FET Field Effect Transistor
CV	Check Valve	FPT Female Pipe Thread



FRT         Front (Air Schematic)         LNG         Liquefied Natural Gas           FS         Fire Suppression System         Ltd         Luth         Luth         Luth         Low Voltage           FSS         Fire Suppression System         LV         Leveling Valve (Air Schematic)         Ltd         Leveling Valve (Air	FRT	Fuel Regulated Temperature	LKLift & Kneeling
FSS	FRT	Front (Air Schematic)	LNGLiquefied Natural Gas
Te-lb.	FS	Fire Suppression	LtdLimited
ft.         foot or feet         m.         meter           GEN.         Generator         M/B         Minimum Buy           GI.	FSS	Fire Suppression System	LVLow Voltage
GEN         Generator         W/B         Minimum Buy           GI	ft-lb	foot pound	LVLeveling Valve (Air Schematic)
GI         General Information         mA         Milliamp           GND         Ground         MAP         Manifold Absolute Pressure           GOV         Governor         MAWP         Maximum Allowable Working Pressure           GPS         Global Positioning System         max         maximum           HF         High Temperature         MDT         Mobile Data Terminal           HV         High Temperature         MDT         Mobile Data Terminal           HVV         Heating Ventilation & Air Conditioning         min         millimeter           HVB         Hybrid         MODV         Modulating Valve (ABS)           HYB         Hydraulic         MPT         Made Pipe Thread           HZ         Hertz, cycles per second         MSDS         Material Safety Data Sheet           I/O         Input/Output         NFPA         National Fire Protection Association           ID         Inside Diameter         NGV         Natural Gas Vehicle           IDS         Information Display System         NHTSA         National Highway Traffic Safety Administration           IGN         Information Display System         NHTSA         National Highway Traffic Safety Administration           IR         International Standardor Organization         NPT <td>ft</td> <td>foot or feet</td> <td>m meter</td>	ft	foot or feet	m meter
GND. Ground MAP Maximum Allowable Pressure GOV. Governor GPS. Global Positioning System max. maximum Allowable Working Pressure max. maximum HF High Floor MDS Methane Detection System HT High Teloor MDS Methane Detection System HV High Voltage min. minimum millimeter HVAC Heating Ventilation & Air Conditioning mm. millimeter HYB Hybrid MODV Modulating Valve (ABS) HYD. Hydraulic MSS Material Safety Data Sheet HZ Hertz, cycles per second MSDS Material Safety Data Sheet HZ Hertz, cycles per second MSDS Material Safety Data Sheet HZ Hertz, cycles per second MSDS Material Safety Data Sheet HZ Hertz, cycles per second MSDS Material Safety Data Sheet HZ Hertz, cycles per second MSDS Material Safety Data Sheet HZ Hertz, cycles per second MSDS Material Safety Data Sheet HZ Hertz, cycles per second MSDS Material Safety Data Sheet HZ Hertz, cycles per second MSDS Material Safety Data Sheet HZ Hertz, cycles per second MSDS Material Safety Data Sheet HZ Hertz, cycles per second MSDS Material Safety Data Sheet HZ Hertz, cycles per second MSDS Material Safety Data Sheet HZ Hertz, cycles per second MSDS Material Safety Data Sheet HZ Hertz, cycles per second MSDS Material Safety Data Sheet HZ Hertz, cycles per second MSDS Material Safety Data Sheet HZ Hertz, cycles per second MSDS Material Safety Data Sheet HZ NFPA National Fipe Protead Safety Data Sheet HZ NFPA National Fipe Protead Safety Data Sheet NFPA National Fipe Thread MSDS MSDA NATIONAL MATERIAL NATIONAL PROTECTION NATIONAL MSDA NATIONAL MSDA MSDA NATIONAL PROTECTIONAL NATIONA	GEN		M/BMinimum Buy
GOV. Governor GPS	GI	General Information	mA Milliamp
GPS. Global Positioning System HF	GND	Ground	MAPManifold Absolute Pressure
HF High Floor HIGH Flo	GOV		MAWP Maximum Allowable Working Pressure
HT	GPS	Global Positioning System	max maximum
HV High Voltage min. minimum HVAC Heating Ventilation & Air Conditioning mm. millimeter HYB. Hybrid MODV Modulating Valve (ABS) HYD. Hydraulic MPT Male Pipe Thread Hz. Hertz, cycles per second MSDS Material Safety Data Sheet I/O Input/Output NFPA. National Fire Protection Association ID. Inside Diameter NGV Natural Gas Vehicle IDS Information Display System NHTSA National Highway Traffic Safety Administration IGN Interior Lighting Nm. National Lubricating Grease Institute IL. Interior Lighting NMM National Highway Traffic Safety Administration NCI National Lubricating Grease Institute IN. National Highway Traffic Safety Administration NCI National Lubricating Grease Institute NMM National Highway Traffic Safety Administration NCI National Lubricating Grease Institute NMM National Highway Traffic Safety Administration NCI National Lubricating Grease Institute NMM National Highway Traffic Safety Administration NCI National Display System NCI National Pipe Thread NCI National Pipe Thread ISG Integrated Starter Generator (BAE Hybrid Buses) NPT National Pipe Thread Fine NCI Nort Sold Separately NCU Integrated Vehicle Logic Unit NCS Integrated Vehicle Copic Unit NCS Integrated Vehicl	HF	High Floor	MDS Methane Detection System
HVAC Heating Ventilation & Air Conditioning mm millimeter HYB	HT	High Temperature	MDTMobile Data Terminal
HYB	HV	High Voltage	min minimum
HYD. Hydraulic MPT. Male Pipe Thread Hz. Hertz, cycles per second MSDS. Material Safety Data Sheet I/O Input/Output NFPA National Fire Protection Association ID. Inside Diameter NGV. Natural Gas Vehicle IDS. Information Display System NHTSA. National Highway Traffic Safety Administration IGN. Ignition NLGI National Lubricating Grease Institute IL. Interior Lighting Nm Newton Meter in-lb. Inches Inch pound NOX. Nitrous Oxide IN. National Pipe Thread Fine ISO. Integrated Starter Generator (BAE Hybrid Buses) NPT National Pipe Thread Fine ISO. Integrated Vehicle Logic Unit IVS Integrated Vehicle Logic Unit IVS Integrated Vehicle Logic Unit IVS Integrated Vehicle System ODK. Operator's Display Keyboard WC Intermittent Wiper Control OEM. Original Equipment Manufacturer JB. Junction Block Kg. Kilogram ORFS O-Ring Face Seal km Kilometer Kg. Kilogram ORFS O-Ping Face Seal km Kilomatt PA Integrated Vehicle Logic Unit INTEGRATION OF Pressure Port (Air Schematic) kW Kilowatt PA Push to Talk Logic Module LDB Logid Crystal Display PCS Propulsion Control System (BAE Hybrid Buses) PCM Propulsion Control System (BAE Hybrid Buses) PCM PCS Propulsion Control System (BAE Hybrid Buses) PCM PCS PCS Propulsion Control System (BAE Hybrid Buses) PCM PCS PCS Propulsion Control System (BAE Hybrid Buses) PCM PCS PCS Propulsion Control System (BAE Hybrid Buses) PCM PCS PCS Propulsion Control System (BAE Hybrid Buses) PCM PCS PCS Propulsion Control System (BAE Hybrid Buses) PCM PCS PCS Propulsion Control System (BAE Hybrid Buses) PCM PCS PCS Propulsion Control System (BAE Hybrid Buses) PCM PCS	HVAC	Heating Ventilation & Air Conditioning	mm millimeter
Hz       Hertz, cycles per second       MSDS       Material Safety Data Sheet         I/O       Input/Output       NFPA       National Fire Protection Association         ID       Inside Diameter       NGV       Natural Gas Vehicle         IDS       Information Display System       NHTSA       National Highway Traffic Safety Administration         IGN       Ignition       NLGI       National Highway Traffic Safety Administration         IGN       International Lubricating Grease Institute         IL       International Lubricating Grease Institute         IN       Newton Meter         In-Ib       NM       Newton Meter         IN       Newton Meter       NPT       National Pipe Thread         ISG       Integrated Starter Generator (BAE Hybrid Buses)       NPT       National Pipe Thread Fine         ISO       Integrated Vehicle Logic Unit       OCU       Operator Control Unit         IVLU       Integrated Vehicle Logic Unit       OCU       Operator's Display Keyboard         IWC       Integrated Voice System       ODK       Operator's Display Keyboard         IWC       Integrated Voice System       ODK       Operator's Display Keyboard         IWC       Integrated Voice System       OFB       OP Fing Boss <th< td=""><td>HYB</td><td>Hybrid</td><td>MODVModulating Valve (ABS)</td></th<>	HYB	Hybrid	MODVModulating Valve (ABS)
I/O       Input/Output       NFPA       National Fire Protection Association         ID       Inside Diameter       NGV       Natural Gas Vehicle         IDS       Information Display System       NHTSA       National Highway Traffic Safety Administration         IGN       Ignition       NLGI       National Lubricating Grease Institute         IL       Interior Lighting       Nm       Newton Meter         in-lb       inch pound       NOX       Nitrous Oxide         IN       inch or inches       NPT       National Pipe Thread         ISG       Integrated Starter Generator (BAE Hybrid Buses)       NPTF       National Pipe Thread Fine         ISO       International Standards Organization       NSS       Not Sold Separately         IVLU       Integrated Vehicle Logic Unit       OCU       Operator Control Unit         IVS       Integrated Voice System       ODK       Operator's Display Keyboard         IWC       Integrated Vehicle Logic Unit       OCU       OPerator's Display K	HYD	Hydraulic	MPT Male Pipe Thread
ID. Inside Diameter INGV. Natural Gas Vehicle IDS. Information Display System INHTSA. National Highway Traffic Safety Administration IGN. Ignition IGN. Interior Lighting INLGI INLG	Hz	Hertz, cycles per second	MSDSMaterial Safety Data Sheet
IDS. Information Display System NHTSA National Highway Traffic Safety Administration IGN. Ignition NLGI National Lubricating Grease Institute IL. Interior Lighting Nm. Newton Meter In-lb. Inch pound NOX Newton Meter NoX Newton Meter In-lb. Inch pound Inch pound NOX NoX Newton Meter In-lb. Newton Meter NoX NoX NoX Newton Meter In-lb. NoX NoX NoX Newton Meter In-lb. NoX	I/O	Input/Output	NFPANational Fire Protection Association
IGN.       Ignition       NLGI       National Lubricating Grease Institute         IL.       Interior Lighting       Nm       Newton Meter         In-lb.       inch pound       NOX       Nitrous Oxide         IN.       inch pound       NOX       National Pipe Thread         ISG.       Integrated Starter Generator (BAE Hybrid Buses)       NPTF.       National Pipe Thread Fine         ISO.       International Standards Organization       NSS       Not Sold Separately         IVLU       Integrated Vehicle Logic Unit       OCU       Operator Control Unit         IVS       Integrated Voice System       ODK       Operator's Display Keyboard         IWC       Intermittent Wiper Control       OEM       Original Equipment Manufacturer         JB       Junction Block       ORB       O-Ring Boss         Kg       Kilogram       ORFS       O-Ring Face Seal         km       Kilogram       ORFS       O-Ring Face Seal         km       Kilowatt       OTS       Oil Temperature Sensor         kP       Kilowatt       PA       Pressure Port (Air Schematic)         kWh       Kilowatt hour       PAL       Push to Talk Logic Module         L/B       Local Buy       PBSS       Push Button Shift Sele	ID	Inside Diameter	NGV Natural Gas Vehicle
IL       Interior Lighting       Nm       Newton Meter         in-lb.       inch pound       NOX       Nitrous Oxide         IN.       inch or inches       NPT       National Pipe Thread         ISG.       Integrated Starter Generator (BAE Hybrid Buses)       NPTF       National Pipe Thread Fine         ISO.       International Standards Organization       NSS       Not Sold Separately         IVLU       Integrated Vehicle Logic Unit       OCU       Operator Control Unit         IVS       Integrated Voice System       ODK       Operator's Display Keyboard         IWC       Intermittent Wiper Control       OEM       Original Equipment Manufacturer         JB       Junction Block       ORB       O-Ring Boss         Kg       Kilogram       ORFS       O-Ring Face Seal         km       Kilometer       OTS       Oil Temperature Sensor         kP       Kilowatt       P       Pressure Port (Air Schematic)         kW       Kilowatt hour       PAL       Push to Talk Logic Module         L/B       Local Buy       PBSS       Push Button Shift Selector         LCD       Liquid Crystal Display       PC       Personal Computer         LED       Light Emitting Diode       PCS       Propulsi	IDS	Information Display System	NHTSA National Highway Traffic Safety Administration
in-lb	IGN	Ignition	NLGI National Lubricating Grease Institute
IN.       inch or inches       NPT       National Pipe Thread         ISG       Integrated Starter Generator (BAE Hybrid Buses)       NPTF       National Pipe Thread Fine         ISO       International Standards Organization       NSS       Not Sold Separately         IVLU       Integrated Vehicle Logic Unit       OCU       Operator Control Unit         IVS       Integrated Voice System       ODK       Operator's Display Keyboard         IWC       Intermittent Wiper Control       OEM       Original Equipment Manufacturer         JB       Junction Block       ORB       O-Ring Boss         Kg       Kilogram       ORFS       O-Ring Face Seal         km       Kilometer       OTS       Oil Temperature Sensor         kP       Kilopascal       P       Pressure Port (Air Schematic)         kW       Kilowatt       PA       Public Address         kWh       Kilowatt hour       PAL       Push to Talk Logic Module         L/B       Local Buy       PBSS       Push Button Shift Selector         LCD       Liquid Crystal Display       PC       Personal Computer         LCD       Light Emitting Diode       PCS       Propulsion Control System (BAE Hybrid Buses)         LEL       Lower Explosive Limit	IL	Interior Lighting	Nm Newton Meter
ISG. Integrated Starter Generator (BAE Hybrid Buses) ISO International Standards Organization ISO International Standards Organization IVLU Integrated Vehicle Logic Unit IVS Integrated Voice System IWC Intermittent Wiper Control JB Junction Block IKIlogram IKIlometer IKILome	in-lb	inch pound	NOXNitrous Oxide
ISO International Standards Organization NSS	IN	inch or inches	NPTNational Pipe Thread
IVLU       Integrated Vehicle Logic Unit       OCU       Operator Control Unit         IVS       Integrated Voice System       ODK       Operator's Display Keyboard         IWC       Intermittent Wiper Control       OEM       Original Equipment Manufacturer         JB       Junction Block       ORB       O-Ring Boss         Kg       Kilogram       ORFS       O-Ring Face Seal         km       Kilometer       OTS       Oil Temperature Sensor         kP       Kilopascal       P       Pressure Port (Air Schematic)         kW       Kilowatt       PA       Push to Talk Logic Module         L/B       Local Buy       PBSS       Push Button Shift Selector         LCD       Liquid Crystal Display       PC       Personal Computer         LED       Light Emitting Diode       PCS       Propulsion Control System (BAE Hybrid Buses)         LEL       Lower Explosive Limit       PGM       Pocket Gateway Module	ISG	Integrated Starter Generator (BAE Hybrid Buses)	NPTFNational Pipe Thread Fine
IVS Integrated Voice System ODK Operator's Display Keyboard IWC Intermittent Wiper Control OEM Original Equipment Manufacturer JB Junction Block ORB O-Ring Boss Kg Kilogram ORFS O-Ring Face Seal km Kilometer OTS Oil Temperature Sensor kP Kilopascal P Pressure Port (Air Schematic) kW Kilowatt PA Public Address kWh Kilowatt hour PAL Push to Talk Logic Module L/B Local Buy PBSS Push Button Shift Selector LCD Liquid Crystal Display PC Personal Computer LED Light Emitting Diode PCS Propulsion Control System (BAE Hybrid Buses) LEL Lower Explosive Limit PGM Pocket Gateway Module	ISO	International Standards Organization	NSSNot Sold Separately
IWC       Intermittent Wiper Control       OEM       Original Equipment Manufacturer         JB       Junction Block       ORB       O-Ring Boss         Kg       Kilogram       ORFS       O-Ring Face Seal         km       Kilometer       OTS       Oil Temperature Sensor         kP       Kilopascal       P       Pressure Port (Air Schematic)         kW       Kilowatt       PA       Public Address         kWh       Kilowatt hour       PAL       Push to Talk Logic Module         L/B       Local Buy       PBSS       Push Button Shift Selector         LCD       Liquid Crystal Display       PC       Personal Computer         LED       Light Emitting Diode       PCS       Propulsion Control System (BAE Hybrid Buses)         LEL       Lower Explosive Limit       PGM       Pocket Gateway Module	IVLU	Integrated Vehicle Logic Unit	OCU Operator Control Unit
JB       Junction Block       ORB       O-Ring Boss         Kg       Kilogram       ORFS       O-Ring Face Seal         km       Kilometer       OTS       Oil Temperature Sensor         kP       Kilopascal       P       Pressure Port (Air Schematic)         kW       Kilowatt       PA       Public Address         kWh       Kilowatt hour       PAL       Push to Talk Logic Module         L/B       Local Buy       PBSS       Push Button Shift Selector         LCD       Liquid Crystal Display       PC       Personal Computer         LED       Light Emitting Diode       PCS       Propulsion Control System (BAE Hybrid Buses)         LEL       Lower Explosive Limit       PGM       Pocket Gateway Module	IVS	Integrated Voice System	ODK Operator's Display Keyboard
Kg       Kilogram       ORFS       O-Ring Face Seal         km       Kilometer       OTS       Oil Temperature Sensor         kP       Kilopascal       P       Pressure Port (Air Schematic)         kW       Kilowatt       PA       Public Address         kWh       Kilowatt hour       PAL       Push to Talk Logic Module         L/B       Local Buy       PBSS       Push Button Shift Selector         LCD       Liquid Crystal Display       PC       Personal Computer         LED       Light Emitting Diode       PCS       Propulsion Control System (BAE Hybrid Buses)         LEL       Lower Explosive Limit       PGM       Pocket Gateway Module	IWC	Intermittent Wiper Control	OEMOriginal Equipment Manufacturer
km       Kilometer       OTS       Oil Temperature Sensor         kP       Kilopascal       P       Pressure Port (Air Schematic)         kW       Kilowatt       PA       Public Address         kWh       Kilowatt hour       PAL       Push to Talk Logic Module         L/B       Local Buy       PBSS       Push Button Shift Selector         LCD       Liquid Crystal Display       PC       Personal Computer         LED       Light Emitting Diode       PCS       Propulsion Control System (BAE Hybrid Buses)         LEL       Lower Explosive Limit       PGM       Pocket Gateway Module	JB	Junction Block	ORBO-Ring Boss
kP       Kilopascal       P       Pressure Port (Air Schematic)         kW       Kilowatt       PA       Public Address         kWh       Kilowatt hour       PAL       Push to Talk Logic Module         L/B       Local Buy       PBSS       Push Button Shift Selector         LCD       Liquid Crystal Display       PC       Personal Computer         LED       Light Emitting Diode       PCS       Propulsion Control System (BAE Hybrid Buses)         LEL       Lower Explosive Limit       PGM       Pocket Gateway Module	Kg	Kilogram	ORFSO-Ring Face Seal
kW       Kilowatt       PA       Public Address         kWh       Kilowatt hour       PAL       Push to Talk Logic Module         L/B       Local Buy       PBSS       Push Button Shift Selector         LCD       Liquid Crystal Display       PC       Personal Computer         LED       Light Emitting Diode       PCS       Propulsion Control System (BAE Hybrid Buses)         LEL       Lower Explosive Limit       PGM       Pocket Gateway Module	km	Kilometer	OTSOil Temperature Sensor
kWh       Kilowatt hour       PAL       Push to Talk Logic Module         L/B       Local Buy       PBSS       Push Button Shift Selector         LCD       Liquid Crystal Display       PC       Personal Computer         LED       Light Emitting Diode       PCS       Propulsion Control System (BAE Hybrid Buses)         LEL       Lower Explosive Limit       PGM       Pocket Gateway Module	kP	Kilopascal	P Pressure Port (Air Schematic)
L/B     Local Buy     PBSS     Push Button Shift Selector       LCD     Liquid Crystal Display     PC     Personal Computer       LED     Light Emitting Diode     PCS     Propulsion Control System (BAE Hybrid Buses)       LEL     Lower Explosive Limit     PGM     Pocket Gateway Module	kW	Kilowatt	PAPublic Address
LCD Liquid Crystal Display PC Personal Computer  LED PCS Propulsion Control System (BAE Hybrid Buses)  LEL Lower Explosive Limit PGM PCM PCS Pocket Gateway Module	kWh	Kilowatt hour	PALPush to Talk Logic Module
LED	L/B	Local Buy	PBSSPush Button Shift Selector
LEL	LCD	Liquid Crystal Display	PCPersonal Computer
	LED	Light Emitting Diode	PCSPropulsion Control System (BAE Hybrid Buses)
LHPhillips Head	LEL	Lower Explosive Limit	PGM Pocket Gateway Module
	LH	Left-Hand	PHPhillips Head



PMB	Parts Manual Bulletin	SCUSystem Control Unit (BAE Hybrid Buses)
PN	Primary Network	SMBService Manual Bulletin
PPM	Parts Per Million	SPDT Single Pole Double Throw
ppm	parts per million	SPSTSingle Pole Single Throw
PPV	Parking Brake Control Valve	SPTTSingle Pole Triple Throw
PR	Pressure Reducing Valve	SRAM Static Random Access Memory
PRD	Pressure Relief Device	SS Streetside
PRV	Pressure Relief Valve	SVSafety Valve
PS	Power & Starting (Electrical Schematic)	SWGStandard Wire Gauge
psi	pounds per square inch	TCMTraction Control Module
psig	pounds per square inch, gauge	TpgTapping
PUR	Purge	Transv Transverse
QR	Quick Release	TRNSDCRTransducer
R	Reservoir Port (Air Schematic)	UHFUltra High Frequency
RAD	Radiator	UNC Unified National Coarse (thread)
RDV	Rotary Dump Valve	UNFUnified National Fine (thread)
REGEN	Regeneration	UNLDRUnload (Air Schematic)
RH	Right-Hand	VACVolt Alternating Current
ROM	Read Only Memory	VCMVehicle Control Module
RPM	Revolutions per Minute	VDCVolt Direct Current
S	Supply Port (Air Schematic)	VINVehicle Identification Number
SAE	Society of Automotive Engineers	VMM Vansco Multiplexing Module
SBCV	Spring Brake Control Valve	W/CWheelchair
SCF	Standard Cubic Feet	WCLH Windshield Wiper Control Left-Hand (Air Schematic)
SCFH	Standard Cubic Feet per Hour	WCRH Windshield Wiper Control Right-Hand (Air Schematic)
SCFM	Standard Cubic Feet per Minute	WDWiring Diagram
SCR	Selective Catalytic Reduction	WIF Water in Fuel
SCU	Speedometer Control Unit	WLAN Wireless Local Area Network



#### **Indexes**

#### REVISION INDEX

This index is supplied only with an update package. It lists all pages which have been revised. Insert this index as a first page of the Index Section.


#### SECTION INDEX

This index is located in the Index Section. It lists all sections and their corresponding section numbers.

#### ALPHABETICAL INDEX

This is located after the Section Index. This index of subjects is alphabetically sorted for ease of use.

#### **Vehicle Orientation**





### **Revision Index**

Property: Connect Transit - Normal	SR1950
Publication Type: Service Manual	Manual Issue Date: Jul 27 2015
Current Revision Indicated by:	

Rev	Section/Pages Affected	Date





### **Section Index**

TITLE	SECTION
General Information	GI
Preventive Maintenance	PM
Front Axle & Suspension	1
Rear Axle & Suspension	2
Steering System	3
Engine System	4
Transmission System	5
Cooling System	6
Fuel System	7
Air System	8
Electrical System	9
HVAC System	10
Structures & Chassis	11
Interior Panels & Applied Parts	12
Exterior Panels & Applied Parts	13
Windows	14
Access Doors & Panels	15
Entrance & Exit Doors	16
Seating & Stanchions	17
Destination Signs	18
Driver's Controls	19
Wheelchair Ramp	20





## **Alphabetical Index**

#### Α

A/C Fail Indicator (Red)	19-2
ABS Electronic Control Unit (ECU)	
ABS Electronic Control Unit (ECU)	
ABS Fail Indicator (Amber)	19-4
ABS Sensor Holder Installation	2-124
ABS Switch	19-26
ABS Troubleshooting	1-79
ABS Troubleshooting	2-128
Accelerator Control	
Accelerator Treadle	19-24
Access Compartments	GI-23
Accessories, Suspension & Leveling Syster	n 8-10
Accessories, Suspension, Leveling &	
Kneeling System Components	8-89
Actuating Lever Replacement	3-20
Actuation Switch	
Adjustment Procedure	16-24
Adjustment Procedure	
Adjustment	
Adjustment	2-89
Adjustment	8-3 <sup>-</sup>
Adjustment	
Adjustment	
Adjustments	
Advanced Parameters	
Advertising Panels	
Aft Panel Closed Position Stop Adjustment.	16-22
After Engine Warm-Up	6-3
Aftertreatment Exhaust Piping	.PM-1
Agent Cylinder Assembly	
Air Circulation	
Air Compressor Discharge Lines	
Air Compressor Troubleshooting	8-18
Air Dryer	.PM-88
Air Dryer	
Air Dump Pressure Switch Input	
Air Filter Replacement	.PM-57
Air Filter Restriction Indicator Inspection	.PM-56
Air Intake & Air Cleaner Assembly	
Air Intake & Air Cleaner Troubleshooting	
Air Intake Piping	.PM-1

Air Leakage Test - Valve Installed	8-93
Air Leakage Test - Valve Removed	8-93
Air Line Replacement	8-52
Air Lines & Fittings	
Air Lumbar Adjustments	
Air Lumbar Bag Replacement	17-5
Air Pressure Gauges	
Air Springs	
Air Strainer	
Air Supply	
Air Supply	
Air Switch Replacement	
Air System Functional Tests	
Air System Functional Tests	
Air System	
Air Tank Drain Valve Locations	
Air Tank Installation	GI-27
Air Tanks	8-47
Air Tanks	
Air Tilt Bag Replacement	17-4
Aisle Lights Specifications	9-75
Aisle Lights Switch	
Aisle Lights Troubleshooting	9-75
Aisle Lights	
Alarm Indicators	10-15
Alignment	
Allison B400 Transmission Manuals	
Allison B400R Transmission	
Alternator Bearing Replacement	PM-87
Alternator Resistance Values	
Alternator Special Tools Chart	9-30
Alternator Special Tools	
Alternator Specifications	
Alternator Troubleshooting	9-12
Alternator	
Aluminum	
Amerex Fire Suppression Manuals	4-63
Anti-Compounding	8-70
Antifreeze	
Anti-Lock Braking System (ABS) Operation.	8-6
Anti-Spill System	7-8
Application Conditions	
Application Equipment	13-30



Application Method	13-9	Bike Hack General Maintenance	
Application Method	13-9	Inspection	
Application		Bike Rack Inspection	PM-10
Applying: Loss of Air in the No. 2 Circuit	t 8-60	Bike Rack Servicing	13-47
Applying: Normal Operation - No. 1		Bike Rack System	13-46
Circuit Portion	8-60	Bleeding Power Steering Hydraulic System	n3-42
Applying: Normal Operation - No. 2		Blink Code Diagnostics & Troubleshooting	1-80
Circuit Portion	8-60	Blink Code Diagnostics & Troubleshooting	2-129
Areas of Structure Hidden by Paneling.	11-17	Blower Assembly Replacement	10-19
Armature		Bolt Torque Specifications	
Attaching Lifting Device	2-38	Booster Pump Specifications	
Austenitic or Ferritic Stainless Steel to		Booster Pump Troubleshooting	
Carbon Steel Welding Procedure	11-7	Booster Pump	
Austenitic Stainless Steel to Austenitic		Booster Pump	
Stainless Steel Welding Procedure	11-7	Brake & Accelerator Interlocks	
Auto Plunger Repair		Brake Application Pressure Transducer	
Automatic Adjustment Inspection		Specifications	8-77
Automatic Adjustment Inspection		Brake Application Pressure Transducer	
Automatic Drain Valve Operation		Brake Application Pressure Transducer	
Automatic Passenger Counter (APC)		Brake Caliper & Carrier Assembly	
System	9-86	Brake Caliper & Carrier Assembly	
Automatic Plunger Adjustment		Brake Disc Inspection	
Automatic Regeneration		Brake Disc Inspection	
Automatic Vehicle Announcement & Aut		Brake Disc Removal & Installation	
Vehicle Locator (AVA/AVL) System		Brake Disc	
Auto-Neutral		Brake Disc	
Axle Shaft		Brake Foot Valve	
Axie Silait	2-12	Brake Interlock Control System	
		Brake Interlock System	
В		Brake Pad Clearance Inspection	
D		Brake Pad Clearance Inspection	
		·	
Back Recline Adjustment		Brake Pad Wear Inspection	
Back Tilt Adjustment	17-3	Brake Pad Wear Inspection	
Backlash Adjustment	2-58	Brake Pads	
Backup Battery	4-58	Brake Pads	
Balance	8-66	Brake System Components	٥-၁૩
Balanced: No. 1 Circuit Portion	8-60	Brake Tank Pressure Sending Units	0.04
Balanced: No. 2 Circuit Portion	8-60	Specifications Conding Units	
Ball Bearing Replacement	10-37	Brake Tank Pressure Sending Units	
Ball Joint End Lift Measurement	3-26	Brake Tank Pressure Sending Units	
Ball Joint Replacement	3-27	Brake Treadle Assembly & Brake Valve	
Batteries Specifications	9-54	Brake Treadle	
Batteries	9-54	Brake Valve Actuator	
Battery Access	15-10	Breather Valve Replacement	
Battery Compartment		Brush Inspection	
Battery Disconnect Switch Access		Brush Installation	
Battery Disconnect Switch		Brush Removal	
Battery System		Brushes & Holders	
Battery System		Bumpers	
Bearing Preload Adjustment		Bushing Replacement	
<b>5 7 1 1 1 1 1 1 1 1 1 1</b>		Butyl Tape Sealant (Grey)	13-6



#### C

Caging Brake Chamber	2-29
Caliper Guide Pin Inspection	
Caliper Guide Pin Inspection	
Caliper Guide Pins	
Caliper Guide Pins	
Camber Angle	
Camera Event Marker	
CAN Cable Troubleshooting	
CAN Cable Troubleshooting	
Capacity Test	
Caster Angle	
Ceiling Panel Replacement	
Ceiling Panels	
Center Link & Tie Rod Ends	
Centering Device Assembly & Installation.	
Centering Device Assembly	
Chain Pulling Procedure	
Charge Air Cooler & Piping	
Charge Cycle	8-35
Charging Spring Brake Actuators above	0.00
107 psi	8-69
Charging Spring Brake Actuators below	
107 psi	
Charging System	
Charging the Battery	
Check Engine Indicator (Amber)	
Check Valve Replacement	
Checking & Adjusting Friction Coefficient	
Checking & Setting ABS Sensor Gap	
Circuit Board/Heat-Sink Replacement	
Clamp Ring Assembly	
Clamp Ring Assembly	
Clamp Ring Assembly	
Clamp Ring Installation	
Clamp Ring Installation	
Clamp Ring Installation	
Clamp Ring Removal	
Clamp Ring Removal	
Clamp Ring Removal	
Cleaning & Lubrication	
Cleaning Vinyl	
Cleaning Woven Fabric	
Cleaning	6-16

Cleanliness Practices	
Cleanup	
Clear Count Data	16-17
Clear Mode	1-80
Clear Mode	2-129
Clear System Data	
Clear Times	
Clearcoat	
Climate Control Switch	
Close Cushion Length	10 20
(20-50% of teeter lever rotation)	16-16
Close Cushion Start	10-10
(20-50% of teeter lever rotation)	16 16
,	
Close Door	
Close Speed	
Coatings & Cleaners	
Code Entry	
Cold Check	
Commutator End Frame	
Component Assembly	
Component Diagnosis	10-24
Component Diagnosis	10-31
Composite Flooring	12-17
Compressor & Governor Operation	8-3
Compressor Head Torque Specifications.	
Compressor Installation	
Compressor Mounts	
Compressor Removal	
Compressor Specifications	
Compressor	
Condenser Operation Test	
Conditional Maintenance	
Connecting Housing Assembly	
Connecting Housing Assembly	
Connecting Rod Adjustment	
Connecting Rod Adjustment	
Connecting Rod Assemblies	
Connecting Rods & Rod End Bearings	
Contact on Tooth Root	
Contact on Tooth Tip	
Contamination/Incorrect Fluid	
Control Connectors	
Control Console	
Control Panel	4-55
Controller Inputs & Output Status	16-11
Controller Inputs	
Controller Outputs	
Controller Status	
Controller Testing	
Controller	
Coolant Circulation	



Coolant Circulation		Determining Drive Pinion Gear Installation	
Coolant Filter & Conditioner		Depth	
Coolant Filter ReplacementP		Device Nomenclature	
Coolant Level Sensors		Diagnostic Mode	
Coolant LevelP		Diagnostic Mode	
Coolant Recovery Tank Specifications		Diagnostic Program	
Coolant Recovery Tank		Diagnostic Trouble Code Check	
CoolantP		Dial Switch Removal	19-31
Cooling System Flushing		Diesel Exhaust Fluid (DEF) Indicator	
Cooling System Pressure TestP	M-62	(Amber)	
Cooling System	6-2	Diesel Exhaust Fluid (DEF) Tank	
Cooling SystemP		Diesel Exhaust Fluid Fill Access	
Cooling SystemP	M-87	Diesel Exhaust Fluid Fill Access	GI-23
Corrosion Protection	. 11-9	Diesel Exhaust Fluid Filter	. PM-75
Corrosion Treatment	. 11-9	Diesel Exhaust Fluid Specifications	
Corrosion Warranty Inspection	11-15	Diesel Exhaust Fluid	4-45
Crankcase Breather ElementP	M-70	Diesel Fuel	7-18
Crankcase Breather TubeP	M-11	Diesel Particulate Filter (DPF)	4-20
Crown Gear Contact Pattern	. 2-60	Differential Carrier	2-37
Cummins ISL (2015) Manuals	. 4-63	Differential	2-41
Cummins ISL 9.0L (EPA 2015) Engine	4-2	Dimming Adjustments	9-77
Curbside Mirror		Disassembly, Cleaning & Repair	8-45
Cutting	. 11-5	Disc Brake Caliper Inspection	
Cylinder Damping InspectionP	M-30	Disc Brake Pad Inspection	. PM-19
Cylinder Head Components		Discharge Nozzles	4-55
,		Discharge Tubes	
		Display Screen	
D		Disposal & Cleaning	
		DMAS Display	
D 0 Covernor	N 70	Door Closed Input	
D-2 GovernorP		Door Closed	
Daily Preventive Maintenance		Door Closed	16-6
Damaged Release Bolt Installation		Door Command Input	
Damaged Release Bolt Installation		Door Component Replacement	
Dash Fan Speed Switch		Door Component Replacement	
Data Parameters		Door Controller Specifications	
DC-4 Double Check ValveP		Door Controller	
Decomposition Reactor	. 4-30	Door Controller	
DEF Tank Filling		Door Cycling Window	
DEF Tank Inlet FilterP		Door Emergency Release	
DEF Tank Specifications		Door Fully Closed Output	
DEF TankP		Door Fully Open Output	
Default Gap Setting		Door Glass	
Defroster Access		Door Manual Control Valve	
Defroster Air Recirculation Control		Door Master Switch Troubleshooting	
Defroster Fan Control		Door Master Switch	
Defroster Temperature Control		Door Master Switch	
Delivery Leakage Test		Door Not Closed	
Desiccant Cartridge Replacement		Door Not Closed	
Destination Signs		Door Obstruction Signal Output	
Destination Signs	GI-22	Door Operator Proximity Switches	
		= - 3 p	



Door Operator Proximity SwitchesF	M-94	Driver's Seat	PM-45
Door Panel Adjustments	16-33	Driver's Side Mirror	13-36
Door Panel Alignment	16-19	Driver's Vent	
Door Panel Height Adjustment	16-21	Driver's Window	14-7
Door Panel Lower Brush & Upper Portal		Driver's Door Controller	PM-93
Splash Guard Adjustment	16-24	Driver's Heater/Defroster	PM-61
Door Panel Top & Bottom Seal		Driver's Window	PM-43
AssembliesP	M-93	Driveshaft Access	15-6
Door Panels	16-28	Driveshaft Removal	GI-47
Door PanelsP		Driveshaft Specifications	2-140
Door Pocket Seals	16-24	Driveshaft	2-139
Door Power Up Operation	16-31	Driveshaft	PM-21
Door Power Up Operation	. 16-6	Dump Count Data	16-17
Door Safety Features		Dump Log Files	
Door Sensitive Edge Inspection & TestP	M-83	Dump System Files	16-17
Door Shaft Levers & Mounting HardwareP	M-90		
Door Shaft/Arm Assemblies & Bearings		_	
Door Speed Adjustments	16-24	E	
Door Speed Adjustments	16-35		
Door State		E-6 Brake Valve	8-58
Door System InspectionP	M-89	Egress Assembly Securement	
Door Test Box		Egress Assembly Securement	
Door Test Box	16-35	Electric Horn	
Doors	GI-22	Electrical Connections	
Double Check Valve		Electrical Hazards	
Drag Link Specifications		Electrical Power Generation	
Drag Link		Electrical Starting System Troubleshooting	
DrainP		Electrical Starting System	
Draining	6-4	Electrical System Schematics	
Drilling Procedure	12-15	Electrical System	
Drilling Procedure		Electronic Accelerator	
Drive Assembly	. 9-45	Electronic Control Modules	
Drive Housing		Electronic Fluid Level Check	
Drive Pinion Gear Housing	. 2-62	Emergency & Parking Brake System	0 20
Drive Sprockets, Chain, & Pivot Plate		Components	8-82
Installation	20-20	Emergency Air Release Valve	
Drive Sprockets, Chain, & Pivot Plate		Emergency Boost Charge	
Removal		Emergency Brake Application & Modulation	
Driver Alert Box		Emergency Brake Release Control Valve	
Driver/Vehicle Monitoring System	. 9-83	Emergency Brake Release Valve	
Driver's Climate Controls		Emergency Brake Release	
Driver's Door Control		Emergency Exit Window Operation	
Driver's Floor Heat		Emergency Exit Window Operation	
Driver's Heater/Defroster Compartment	GI-23	Emergency Exit	
Driver's Heater/Defroster InspectionP		Emergency Information	
Driver's Heater/Defroster	10-19	Emergency Operation Test	
Driver's Light Switch		Emergency Release Control Valve	
Driver's Locker Access	. 15-8	- Entrance Door	GI-8
Driver's Seat (USSC Evolution G2A)		Emergency Release Control Valve	
Troubleshooting		- Exit Door	GI-0
Driver's Seat (USSC Evolution G2A)	. 17-2	_/// DO01	GI 3



Emergency Release Input16-8	Exit Door Emergency Release Operation	8-1
Emergency Release Output16-10	Exit Door Floor Heater Troubleshooting	10-30
Emergency Release Solenoid Output 16-10	Exit Door Sensitive Edges	GI-4
Emergency Release16-25	Exit Door Shaft & Arm Assembly	PM-92
Emergency/Parking Brake & Check Valve	Exterior Access Doors	15-10
Integrity Test8-14	Exterior Check	PM-9
Emergency/Parking Brake System8-8	Exterior Lights	9-64
Engine & Accessories4-2	Exterior Mirrors	13-36
Engine & Radiator6-4	Exterior Panels	13-3
Engine & Transmission Access 15-4	Exterior Panels	GI-2
Engine Access15-10	Exterior Panels	PM-46
Engine Compartment Access Door	Exterior Views	GI-20
InspectionPM-81	Eyes	10-5
Engine Compartment Line Routing	Eyes	10-5
InspectionPM-53	•	
Engine CompartmentGI-23		
Engine Coolant 6-3	F	
Engine Drive BeltsPM-65		
Engine Fan Fault (Amber)19-6	F1 & AC Connector Replacement	0.10
Engine Mount Replacement4-9	Fast Charging	
Engine MountsPM-63	Ferritic SS to Ferritic SS or Ferritic SS to	9-50
Engine Oil & Filter ChangePM-31		44 (
Engine Oil Change IntervalsPM-32	Austenitic SS Welding Procedure	
Engine Specifications4-2	Fiberglass Panels	
Engine Struts4-13	Fiberglass Panels	
Engine Switch Box4-50	Fiberglass	
Engine Warm-Up6-3	FiberglassField Coils	
Engineered Machined Products (EMP)	Fill	
Manual 6-28		
Enter Button19-8	Filler Cap Cleaning	PIVI-3
Entrance Door Adjustment Procedure 16-19	Filler Cap with Pressure Control & Relief Valve	6 10
Entrance Door Emergency Release		
Operation 8-11	Filling & Deaeration	
Entrance Door Emergency Release 16-25	Filling Battery	
Entrance Door Manual Control Valve19-26	Final Inspection	
Entrance Door Shaft & Arm AssemblyPM-91	Final Installation	
Entrance Door Solenoid ValvesPM-93	Finger Board	
Entrance Mechanism Access 15-2	Finger Board	
Epoxy Primer 13-30	Fire Extinguisher	
Escape ExitsGI-6	Fire Extinguisher	
Exclamation Symbol (Red or Amber)19-7	Fire Extinguisher	
Exhaust & Aftertreatment System	Fire Extinguisher	
Exhaust Filter Switch19-26	Fire Extinguisher	
Exhaust Malfunction Indicator (Amber) 19-6	Fire Suppression System Troubleshooting	
Exhaust or Release8-66	Fire Suppression System	
Exhaust Regen Needed Indicator (Amber) 19-5	Fire Suppression System	
Exhaust SystemPM-36	Fire Suppression System	
Exhaust Tubes, Exhaust Flex Connector	Fire Suppression System	
& Exhaust Blankets4-41	Fire Suppression System	
Existing Structure11-10	Fire Suppression System	
Exit Door Adjustment Procedure	Fire Suppression System	PIVI-94



Fire Suppression System	PM-95	Front Brake Circuit Pressure Switch	8-76
First Aid		Front Brake Circuit Pressure Switch	GI-29
First Aid	4-47	Front Brake System	1-48
Five Year Preventive Maintenance	PM-94	Front Brake System	8-4
Flat Towing	GI-41	Front Dash Panels	12-4
Flexplate Attachment to Torque Conver	ter	Front Destination Sign Access	15-2
Housing		Front Destination Sign	18-5
Floor Covering		Front Disc Brakes Specifications & Wear	
Floor Covering		Limits	
Floor Heaters Specifications		Front Disc Brakes	
Floor Heaters		Front Door Close Obstruction	16-6
Floor Heaters		Front Door Open Obstruction	
Floor Heaters		Front End Alignment	
Flooring Installation		Front End Alignment	
Flooring Removal		Front End Alignment	
Flooring Specifications		Front Frame & Rotor	
Flooring		Front Frame	
Fluid & Lubrication Guide		Front Jacking Procedure	
Fluid & Lubrication Points		Front Kneeling Operation	
Fluid Level Gauge		Front Mask Panel Installation	
Foot Operated Controls		Front Mask Panels	
Force Cured		Front Mount Installation	
Fore & Aft Panel Open Stop Adjustment		Front Mount Removal	
Forster Manual		Front Onboard Diagnostic Connector	
Four Year Preventive Maintenance		Front Radius Rod Troubleshooting	
Four-Way Hazard Lights Switch		Front Radius Rods	
Frame Repriming		Front Shock Absorber Troubleshooting	
Frame Tubing Internal Coating		Front Shock Absorbers Specifications	
Freezing		Front Shock Absorbers	
Frequency of Inspection		Front Suspension Torque Specifications	
Front & Rear Axles & Suspension		Front Suspension	1-34
Front & Rear Brake Chambers		Front Wheel Alignment Specifications	
Front & Rear Exciter Leads		Front Wheelchair Restraints	
Front ABS Modulator Valve		Frostbite	
Front ABS Pulse Generating Wheel	1-76	Fuel Contaminants	7-19
Front ABS Speed Sensor		Fuel Filler Access	
Front Air Springs Specifications		Fuel Hoses	PM-83
Front Air Springs		Fuel Level Sending Unit	7-10
Front Anti-Lock Braking System (ABS) &		Fuel Lines & Flexible Hoses	
Components		Fuel System Leak Test	
Front Axle & Suspension		Fuel System Priming	
Front Axle Setback		Fuel System	
Front Axle Special Tools Chart		Fuel Tank	
Front Axle Special Tools		Fuel Tank	
Front Axle Specifications		Fuel Tank	
Front Axle		Function Readout Display	
Front Brake Chambers Specifications		Fuse Box Access	
Front Brake Chambers		Fusebox Assembly	
Front Brake Chambers		Fusebox Torque Chart	



#### G

Gap Hider Cover Replacement	3-21
Gas Metal Arc Welding (GMAW)	11-7
Gas Metal Arc Welding (GMAW)	11-7
Gas Spring Disposal	15-1
Gear Pairing Numbers	
Gelcoat Finish	
Gelcoat Surface Repair	. 13-26
General Cleaning	PM-45
General Panel Replacement	. 13-12
General Stainless Steel Welding Procedure	11-6
General Welding Procedures	11-5
General	9-90
Glossary Of Acronyms	8-2
Governor Cut-Out & Compressor Test	8-13
Governor D-2	
Greasing Hub Unit Wheel Bearings	
Grounding Wires	PM-17

#### Hub Removal with Hydraulic Puller.....1-16 Hub Unit Installation.....1-18 Hub Unit Removal.....1-15 HVAC Center Cover Access ......15-8 HVAC Display Module Controls ......10-15 HVAC Return Air Filter......PM-51 HVAC System Safety......10-1 HVAC Unit Specifications......10-10 HVAC Unit......10-8 Hydraulic Fluid ...... PM-83 Hydraulic Operation ......20-3 Hydraulic Power Pack & Cylinder Specifications ......20-27 Hydraulic Power Pack & Cylinder Troubleshooting......20-27 Hydraulic Power Pack & Cylinder .....20-27 Hydraulic Puller Tool Assembly ......1-17 Hydraulic System Diagnosis ......20-7 Hydraulic System Flushing......20-7 Hydraulic System ......3-43

#### Н

Haldex Tandem Air Dryer Troubleshooting.	8-41
Haldex Tandem Air Dryer	
Handling	4-46
Hazard Lights Switch Indicator	
Headlight Aim	
Headlight Aiming (Alternate Procedure)	
Headlight Aiming	9-68
Headlight Dimmer Switch	19-24
Headlights	9-64
Heater Coil Replacement	10-21
Heater/Defroster Specifications	10-19
Heater/Defroster Troubleshooting	10-22
Heating & Cooling Indicators	10-15
Heating/Air Conditioning Systems	
High Beam Indicator (Blue)	19-7
High Exhaust Temp Indicator (Amber)	19-6
Hinge & Cover Installation	
Hinge & Cover Removal	
Hoisting & Related Safety Information	
Hoisting & Related Safety Information	
Hoisting the Vehicle	
Horn Ring Lubrication	
Horns & Warning Alarms	
Hose Clamp Torque Specifications	
Hot Check	
Hot Engine Indicator (Red)	
Hub Adapter Installation	5-12



Installing Drive Pinion Gear Housing	J1939 J7 Connector (door position)
Installing Roller Bearing2-69 Installing Seat on Riser17-4	1
Installing Shims2-6	- Reypau Switches18-3
Installing Tapered Roller Bearings2-5	7 King Fin bearing & Sear installation1-31
Installing Transmission Output Drive Yoke5-12	Ning I in bearing & Sear Removal1-29
Installing Transmission Cutput Brive Toke 5-12	
Instrument Panel & Side ConsolePM-8	King i iii installation1-20
Instrument Panel	King Pin Removal1-23
Instrument Panel19-2	Thee indicator (Amber)19-7
Instrument Panel	Kneer Switch19-14
Instrument Repairs19-2	7 Kneeling Systemo-12
Instrumentation & Controls	Nileeling valve i on Designations94
Insulation Foam SafetyGI-	Kneeling Valve8-94 Knob Replacement3-18
Insulation Foam SafetyPM-	Kilob neplacement5-16
Intelligaire III Control System Diagnostics 10-19	5
IntelligAIRE III Control System10-14	4
Interior & Exterior Access DoorsPM-4	3 <b>L</b>
Interior Access Doors15-2	
Interior Lights9-73	
Interior Mirrors13-40	
Interior Panel Replacement	
Interior Panels12-5	
Interior PanelsPM-46	
Interlock Solenoid Valve Specifications8-34	· ·
Interlock Solenoid Valve	· <u>-</u>
Interlock System GI-4 Introduction	· ·
Introduction 13-1	
Introduction 3-4	· ·
Introduction PM-	· ~
Invalid for Display Codes	=
invalid for Dioplay Codeo	LED Lighting Board9-79
	Lens9-78
J	Lens9-79
<u> </u>	Level Control Valve Replacement7-9
Id Vaina Americaintes (Vainas)	Leveling Valve Air Flow 8-10
J1 Voice Annunciator (Vapor)	J Loveling Valves 8-80
J11Power and Motor (Vapor)	I H Kick Panel Replacement 12-8
J12 Quadrature Encoder (Vapor)	Liabilities & Disclaimers14-2
J13 USB Port16-1 J1939 CAN Interface10-1	I III AAANIAR/BACAIVAR INSIAIIAIIAA
U-15	Lifting the VehicleGI-34



Lighting GI-1	7 Master Run Switch	19-19
Lighting GI-22		GI-46
Line Condition InspectionPM-53		3-15
Line Routing InspectionPM-54		
Load from File16-10	6 Mechanical Steering Stop Adjustment	3-5
Loading	7 Mechanism	. PM-48
Locating Air Leaks in Fuel Lines7-10	6 Meritor Wabco Manual	1-88
Locking Slotted Nut2-30	Meritor Wabco Manual	2-145
Locking Slotted Nut2-30	6 Message Display Screen	19-8
Loctite-567 Pipe Sealant13-	7 Metric Capscrews & Nuts	GI-53
Logic Power Input16-8	8 Minimum Vehicle Ground Clearance	GI-46
Loosening Slotted Nut2-10	6 Mirror Heater Button	19-22
Low Coolant Indicator (Amber)19-	7 Mirror Servicing	13-40
Low Fuel Indicator (Amber)19-2	2 Mirrors	13-36
Low Oil Indicator (Red)19-	6 Mirrors	. PM-46
Lower Door Shaft Pivot BearingPM-90	0 Miscellaneous Controls	19-25
Lower Horizontal Shaft 3-22	2 Mode Button	19-7
Lower Horizontal Shaft 3-22	2 Monthly Preventive Maintenance	. PM-13
Lower Kick Panel Replacement 12-10	Motor Bearing Replacement	10-35
Lower Radius Rod Bushing Replacement 1-39		
Lower Radius Rod Specifications1-38	·	
Lower RH Dash Panel Replacement12-5		10-38
Lowering Pressure Setting8-50	0 Mounting Passenger Seats	17-8
Lubricants & Quantities 3-4		
Lubrication 9-3		
LubricationPM-22		
LubricationPM-49	9 Multiplexing System	9-2
	Multiplexing System	
	, •	
M		
	- N	
Machining 1-7	1	
Machining2-11		4-39
Main Air Supply System Components8-10		
Main Air Supply System8-		
Main Frame Assembly Installation14-1		
Main Frame Assembly Installation	•	8-10
Main Frame Assembly Installation	•	
Main Frame Assembly Removal14-1	•	
Main Frame Assembly Removal14-23	•	8-11
Main Frame Assembly Removal14-3		
Main Frame Assembly	· ·	
Main Frame Assembly		
Main Frame Assembly		2-3
Main Sidewall Panel Replacement		
Maintenance & Replacement1-0		
Maintenance & Replacement2-		
MAN Axle Approved GreasesPM-10	1	
MAN Axle Approved Mineral OilsPM-10	Odometer/nodimeter bisplay Screen	
Manual Operation20-4	J OII OHECK I TOCEUUTE	
Mariaa Operation20-1	Oil Contamination	5-8



Oil Side6-	-16 Panel Removal	13-10
Oil Storage & Handling5	5-6 Parameter Settings	16-11
Oil/Water Separator Specifications8-		
Oil/Water Separator8-		
Oil/Water SeparatorPM-		
Oil/Water SeparatorPM-		
Open Cushion Length	Parking Brake/Stop Light Switch	
(20-50% of teeter lever rotation) 16-		
Open Cushion Start	Parking Brakes	
(20-50% of teeter lever rotation) 16-		
Open Door 16-		
Open Speed16-		
Operating & Leakage Check8-	<del>_</del>	
Operating & Leakage Test8-		
Operating & Leakage Test8-		
Operating & Leakage Test8-		
Operating & Leakage Test8-	·	
Operating & Leakage Test8-		
Operating & Leakage Test8-		
Operating Check8-		
Operating Check8-		
Operating Mechanism Assembly20-		
Operating Mechanism Disassembly20-		
Operating Mechanism Installation20-	-	
Operating Mechanism Removal20-		
Operating Test8-		
Operating TestPM-		
Operation & Leakage Test8-		
Operation of Integral Check Valve8-		
Operational CheckPN		
Operator Orientation16-	•	
Outer Bearing Outer Race Installation2-		
Outer Bearing Outer Race Removal2-		
Outer Tapered Roller Bearing Installation 2-		
Outer Tapered Roller Bearing Removal 2-	<u> </u>	8-71
Output Configuration16-		
Overhauling16-		
Overview9-	<u> </u>	
	Preparation	
	Preprimed Aluminum	
P	Preprimed Finish	
	Pressure Filling	
D.A. Missauch and Ossitals	Proceure Police Valve Penlacement	
P.A. Microphone Switch	Proceuro Switches	
Page Codes9-	-92 Drocouro Cwitoboo	
Painting Procedures & Preparation	-20 Proventing Algae Contamination	
Panel Applications	Provention	
Panel Lights Dimmer Switch19-	-14 Preventive Maintenance Guide	



Preventive Maintenance	PM-2	Radiator Access	15-10
Primary (Suction) Fuel Filter		Radiator Compartment	GI-23
Replacement	PM-33	Radiator External Cleaning	PM-87
Primary (Suction) Fuel Filter		Radiator Internal Cleaning	PM-87
Primary (Suction) Fuel Filter	PM-81	Radiator	PM-12
Primary (Suction) Fuel Filter	PM-86	Radiator	PM-16
Primary Fuel Filter Specifications	7-11	Radiator	PM-38
Primary Fuel Filter Troubleshooting	7-13	Radiator	PM-86
Primary Fuel Filter	7-11	Radiator/Charge Air Cooler Specification	s6-10
Primer Application	11-12	Radiator/Charge Air Cooler Troubleshoot	ting
Primer	13-29	& Repair	6-12
Product ID	16-12	Radiator/Charge Air Cooler	6-8
Prognostics	5-22	Radius Rods	PM-42
Proper Oil Level	5-6	Raised Towing	GI-43
Properties	13-6	Raising & Securing the Vehicle	GI-45
Properties	13-7	Raising Front Suspension	8-12
Properties	13-8	Raising Pressure Setting	8-50
Properties	13-8	Raising The Vehicle	GI-33
Properties	13-9	Ramp Mechanism Final Adjustments	20-26
Properties	13-9	Ramp Mechanism Initial Adjustments	20-25
Proximity Switch Operation	20-4	Ramp Operating Mechanism	20-12
Proximity Switch Testing	20-8	Ramp Plate Installation	20-19
Public Address Switch	19-16	Ramp Plate Removal	20-14
Pulley & Fan	9-17	Ramp Power Pack Installation	20-25
Pulley & Fan	9-28	Ramp Power Pack Removal	
Pulling from the Back		Ramp Switch	
Pulling from the Front		Reading Schematics	9-91
Pump Assembly & Installation		Rear ABS Modulator Valve	
Pump Cleaning & Inspection	10-34	Rear ABS Pulse Generating Wheel &	
Pump Operation		Rear ABS Pulse Generating Wheel & Radial Seal	2-126
Pump Removal & Disassembly	10-34	Rear ABS Speed Sensor & Sensor Holde	
Purge Cycle		Rear Air Springs Specifications	
Push Button Shift Selector		Rear Air Springs	
		Rear Axle & Suspension	2-2
		Rear Axle Anti-Lock Braking System (AB	
Q		& Components	
<del></del>		Rear Axle Breather Tube	PM-52
QR-1 Quick Release Valve	0.71	Rear Axle Oil Change	PM-67
QR-1 Quick Release Valve	_	Rear Axle Oil Change	
QS Encoder		Rear Axle Operating Conditions	
QS Home		Rear Axle Shaft Removal	GI-47
QS Preload		Rear Axle Special Tools Chart	2-130
Quarterly Preventive Maintenance		Rear Axle Special Tools	
		Rear Axle Specifications	
Quick Door Linkage Adjustment	10-23	Rear Axle Thrust Angle	
		Rear Axle	
D		Rear Brake Chambers Specifications	
R		Rear Brake Chambers	
		Rear Brake Chambers	
R-14 Brake Relay Valve	PM-80	Rear Brake System	
R-14 Relay Valve	8-66	Rear Brake System	



Rear Bulkhead Panel	12-13	Remote Mirror Control Switches	19-21
Rear Cover	9-18	Removal & Installation	2-126
Rear Cover	9-27	Removal of BVA from Brake Valve	8-65
Rear Disc Brakes Specifications &		Removal/Installation	16-26
Wear Limits	2-93	Removing Bearing Caps & Adjusters	2-43
Rear Disc Brakes	2-93	Removing Bearing Inner Race	
Rear Door Close Obstruction	16-31	Removing Breather Connection	
Rear Door Open Indicator (Red)	19-2	Removing Crown Gear & Differential Cover	
Rear Electronic Equipment Compartme		Removing Differential Carrier	
Access		Removing Differential from Housing	
Rear Exciter & Bearing Removal		Removing Differential Pinion & Side Gears	
Rear Exterior Access		Removing Drive Pinion Gear Housing	
Rear Jacking Procedure		Removing Inner Bearing Outer Race	
Rear Lower Radius Rod Specifications		Removing Inner Tapered Roller Bearing	
Rear Mount Installation		Removing Input Flange Shield	
Rear Mount Removal		Removing Input Flange	
Rear Panel Access		Removing Outer Bearing Outer Race	
(Streetside & Curbside)	15-9	Removing Radial Shaft Seal	
Rear Radius Rod Troubleshooting		Removing Roller Bearing	
Rear Radius Rods		Removing Seat from Riser	
Rear Route Sign		Removing Slotted Nut	
Rear Seal & Adapter		Removing Tapered Roller Bearings	
Rear Shock Absorbers Specifications		(Hydraulic Method)	2-46
Rear Shock Absorbers		Removing Tapered Roller Bearings	
Rear Suspension Torque Specifications		(Mechanical Method)	2-48
Rear Suspension		Repair Materials	
Rear Upper Radius Rod Specifications		Repair	
Rear Wheel Hub		Repair	
Rear Wheelchair Restraints		Repairs for Non-Undercoated Areas	
Reassembly		Repairs for Undercoated Areas	
Recommended Drying & Curing Time		Replacement Procedure	
Recommended Rivet Drill Size		Replacement Structure	
Recommended Rivet Drill Sizes		Replacement	
Record Keeping		Reservoir Supply Leakage Test	
Rectifier & Rear Frame Separation		Reservoir	
Rectifier & Rear Frame		Reset Controller	
Reduced Engine Load At Stop (RELS)		Retaining Ring Installation	
Refrigerant Circulation		Retaining Ring Removal	
Refrigerant Hazards		Retarder Accumulator	
Refrigerant Oil Hazards		Retarder Applied	
Refrigerant Oil		Retarder Deactivated	
Refrigerant		Retarder Off Indicator (Red)	
Reinforcing		Retarder Operation	
Release Bolt		Retarder Operation	
Release Bolt		Retarder Switch	
Release Handle Installation		Return Air Grille & HVAC Access	
Release Handle Installation		RH Lower Dash Panel Access	
Release Handle		Ride Height	
Release Handle		Ride Height	
Releasing: No. 1 Circuit Portion		Rivets	
Releasing: No. 2 Circuit Portion		Rivets	
		-	



Rod & Pawl Replacement	3-19	Service & Towing Air Supply	8-3
Roof Cap Overlay Installation		Service Application with Loss of Primary	
Roof Cap Overlay	13-23	Circuit	
Roof Hatches		Service Application with Loss of Secondary	
Roof Panels Installation	13-20	Circuit	
Roof Panels		Service Brake Application	
Roof Vent/Hatch	PM-44	Service Brake Application	8-5
Roof Vent/Hatches	15-13	Service Brake Interlock	16-5
Rotor & Exciters	9-24	Service Brakes	2-118
Rotor Removal	9-20	Set Point Up & Down Buttons	10-15
Rotor/Front Frame Assembly & Stator	9-26	Setup & Basic Parameters	
Routing ABS Sensor Electrical Harness	2-125	Shaft & Rotor Assembly	
Run-In Maintenance		Shaft & Rotor Disassembly	
RV-1 Pressure Reducing Valve		Shelf Life	
RV-3 Pressure Reducing Valve		Shielded Metal Arc Welding (SMAW)	
RV-3 Pressure Reducing Valve		Shielded Metal Arc Welding (SMAW)	
gg		Shift Inhibits	
		Shift Lever Housing	
S		Shift Selector Operation	
<u> </u>		Shift Selector Operation	
		Shift Selector Troubleshooting	
S1 Solenoid		Shock Absorber Inspection	
S2 Solenoid		SI (Metric) Conversion Factors	
Safety Equipment		Side Console Access	
Safety Equipment		Side Console Panel	
Safety Triangle		Side Console Switch Panel	
Safety Valve Replacement		Side Console	
Sash Assembly Installation		Side Destination Sign Window	
Sash Assembly Removal		Side Destination Sign	
Sash Assembly		Side Emergency Window	
Save to File		Side Non-Emergency Window	
Save to Flash		Side Panel Installation	
SC Panel Assembly Replacement		Side Pier Panels	
SC-1 Single Check Valve		Side Windows	
SCR Dosing Supply Unit		Side Wildows	
Screen & Filter Inspection		Sidewall Panels	
Screwing on Slotted Nut		Sika-205 Cleaner	
Sealants, Caulk & Adhesives		Sika-206G&P Primer	
Seat Back Cover Replacement		Sikaflex-201 Polyurethane Sealant	
Seat Cushion Replacement	17-5	Sikaflex-221 Elastic Adhesive/Sealant	
Seat Height Adjustment	17-3	Sikaflex-221 Elastic Auriestve/Sealant	
Secondary (Pressure) Fuel Filter		Silent Alarm Switch	
Replacement			
Secondary Fuel Filter Specifications	7-15	Single Check Valve	
Secondary Fuel Filter		Six Month Preventive Maintenance	
Selective Catalytic Reduction (SCR)		Six Year Preventive Maintenance	
Access	15-11	Skid Plate	
Selective Catalytic Reduction Unit (SCR)	4-26	Skin	
Sensitive Edge Input		Slide Adjustment	
Sensitive Edges		Slides & Slide Handle Replacement	
Serial Port Setup		Slotted Nut Removal	
·		Slow Charging	9-56



Solenoid Testing	20-8	Steering System	3-2
Solenoid	9-46	Step 1 (home position)	16-23
Speaker Select Switch	19-17	Step 1 (home position)	16-35
Special Tool Assembly	1-13	Step 2 (door close preload)	16-23
Special Tool Assembly	2-49	Step 2 (door close pre-load)	16-35
Specific Gravity (Hydrometer) Test	9-58	Step 3 (encoder calibration)	16-23
Speed Interlock Input	16-8	Step 3 (encoder calibration)	16-35
Speedometer	19-8	Stop Door Cycle	16-17
Splash Guards	13-35	Stop Engine Indicator (Red)	19-4
Splash Guards	PM-45	Stop Engine Override Switch	19-23
Spot & Stain Removal	17-10	Stop Lights Indicator (Red)	19-6
Spot & Stain Removal	17-9	Stop Request Indicator (Red)	19-2
Spot Primer	13-29	Stop Request Sign Access	15-8
Spring Brake (Parking/Emergency Brake	e)2-118	Storage	4-46
Spring Brake Release	8-5	Storage	7-18
Spring Brake Release	GI-47	Storing	16-45
Spring Loaded Brakes	8-8	Straightening	11-5
SR-7 Spring Brake Modulating Valve	8-68	Structural Panel Types	13-10
SR-7 Spring Brake Modulating Valve	PM-79	Structure	GI-20
ST-1 Safety Valve	8-49	Structures & Chassis	11-2
ST-1 Safety Valve	PM-79	Studs	1-7
Stainless Steel	13-11	Studs	2-9
Stainless Steel	13-28	Subframe Assembly Securement	14-11
Stanchions & Grab Rails	PM-46	Subframe Assembly Securement	
Stanchions & Grabrails	17-11	Subframe Assembly	14-11
Standard Operating Features	GI-17	Subframe Assembly	14-19
Start Door Cycle	16-17	Subframe Installation	14-10
Start Push Button	19-22	Subframe Installation	14-11
Starter Circuit Inspection	9-38	Subframe Installation	14-18
Starter No-Load Test	9-38	Subframe Installation	14-19
Starter Solenoid Switch Troubleshooting	g 9-39	Subframe Removal	14-11
Starting	GI-18	Subframe Removal	14-17
Stationary Regeneration	4-25	Subframe Removal	14-19
Stator Housing Separation		Subframe Removal	14-9
Stator Housing		Subframe Spacer Installation	14-10
Steel Primed with PPG Red/Grey Prime	r 13-11	Subframe Spacer Installation	
Steering & Horn	19-34	Subframe Spacer Removal	14-10
Steering Column	3-15	Subframe Spacer Removal	14-18
Steering Damper Specifications		Subframe Spacer	
Steering Damper		Subframe Spacer	
Steering Damper		Substrate Preparation & Bonding	13-11
Steering Driveshafts		Substrate Treatment Preparation	
Steering Driveshafts		Sump Plug & Seal	
Steering Gearbox Access		Supplemental Coolant Additives	
Steering Knuckle Axial Play Check		Support Arm Grip Installation	
Steering Knuckle		Support Arm Servicing	
Steering Knuckle		Surface Preparation	
Steering Miter Box Specifications		Surface Preparation	
Steering Miter Box		Surge Tank Access	
Steering Stops		Surge Tank Compartment	
Steering System Inspection		Surge Tank Specification	



Surge Tank	6-19	Toe-In Adjustment	3-13
Suspension & Leveling Valves		Toggle Switch Replacement	
System Configuration Code		Topcoat (DCC)	
System Configuration Code		Topcoat (Deltron Base Coat/Clearcoat)	
System Diagnostic Data		Torque Converter Adapter Installation	
System Fuel Tanks		Torque Information	
System Pre-Test		Tough Stain & Graffiti Removal	
0,01011111011001	10	Towing Adapter Installation	
		Towing Safety	
Т		Transmission Cooler	
1		Transmission Filters	
		Transmission Fluid	
Tappet & Rubber Boot		Transmission Inspection	
Tappet & Rubber Boot			
Tappet Rubber Boot Inspection		Transmission Join-Up & Alignment Transmission Oil Maintenance	
Tappet Rubber Boot Inspection	2-102		
Telescoping Spline Lubrication	PM-28	Transmission Specifications	
Temperature Indicator Specifications	9-60	Transmission System	
Temperature Indicator	9-60	Transmission Troubleshooting	
Ten Year Preventive Maintenance	PM-95	Transmission	
Test Equipment Required	16-45	Troubleshooting Tips	
Testing - Electrical	16-45	Trough Cover Replacement	
Testing - Mechanical	16-45	Turn Indicators (Green)	
Testing after Reassembly		Turn Signal Switches	
Testing		Twelve Year Preventive Maintenance	
Testing		TwinVision Manual	
Testing		Two Year Preventive Maintenance	PM-87
Testing			
Testing			
Text Messages		U	
Theory of Operation			
Thermo King Manuals		U.S. Customary Bolts & Capscrews Torqu	ıe
Thread Sealant		Values	
Three Year Preventive Maintenance		Uncaging Brake Chamber	
Throttle Interlock		Uncaging the Brake Chamber	
Tie Bar Assembly Installation		Under Body Inspection	
Tie Bar Assembly Installation		Under Body Inspection	
Tie Bar Assembly Removal		Undercoating Application	
Tie Bar Assembly Removal		Universal Joint Lubrication	
Tie Bar Assembly		Unloading	
Tie Bar Assembly		Unlocking Slotted Nut	
Tie Bar Removal		Unlocking Slotted Nut	
Tie Bar Removal		Unprimed Aluminum	
Tie Rod Arms & Steering Arm		Upholstery Care	
Tightening Crown Gear Mounting Bolts		Upholstery Maintenance	
Tightening Slotted Nut		Upper Corner Pillar Access	
Tightening Slotted Nut		Upper Corner Pillar Access	
Tire Specifications		Upper Door Shaft Pivot Bearings	
Tire Specifications		Upper Guide Rubber Boot Inspection	
Tires		Upper Guide Rubber Boot Inspection	
Tires		Upper LH Dash Panel Replacement	
1053	Z-O	CONCLETE DASILE AUCH DEUTAGEMENT	1/-/



Upper Radius Rod Specifications Upper RH Dash Panel Replacement Upper Roller Guide, Brackets, & Bearing	12-6	Voltage Regulator	9-32
Upper Vertical Shaft	-	W, X	
Upper Vertical Shaft		<del>*************************************</del>	
Uses		W/C Ramp Indicator (Red)	19-7
Uses		W/C Stop Request Indicator (Amber)	
Uses		Wabco Twin Cylinder Air Compressor	
Using Fiberglass Cloth		Wait to Start Indicator (Amber)	
Using Fiberglass Paste	13-25	Warning Alarms	
		Warning Alarms	
~ #		Warranty Limitation	
V		Washer System Troubleshooting	
		Water Side	
Vacuum Formed Plastic Components	PM-45	Weekly Preventive Maintenance	
Valve Pack Replacement		Weld Inspection	
Vansco Manuals		Welding Electrode Selection	
Vapor/NFI Slide Glide Entrance Door		Welding Electronic Precautions	
Vapor/NFI Slide Glide Exit Door		Welding Procedures	
Vehicle Cooling/Heating System		Welding Procedures	
Vehicle Evacuation & Shutdown		Welding	
Vehicle Heating System Bypass		Wheel Alignment Adjustments	
Vehicle Operation Safety Procedures		Wheel Assemblies	
Vehicle Removal from Ditch		Wheel Assemblies	
Vehicle Safety Systems		Wheel Bolts	
Vehicle Specifications		Wheel Bolts	
Vehicle Towing		Wheel Flange Installation	
Vehicle Wiring Check		Wheel Flange Removal	
Vehicle Wiring Check		Wheel Hub Removal	
Vendor Service Information		Wheel Hub	
Vendor Service Information		Wheelchair Ramp Inspection	
Vendor Service Information		Wheelchair Ramp Pump	
Vendor Service Information		Wheelchair Ramp Troubleshooting	
Vendor Service Information		Wheelchair Ramp	
Vendor Service Information		Wheelchair Ramp	
Vendor Service Information		Wheelchair Ramp	
Vendor Service Information		Wheelchair Restraint System	
Ventilation		Wheelchair Tie-Down & Occupant	17-13
		Restraints	DM 10
Verify from File		Wheelchair Tie-Down & Occupant	F IVI- I U
Video Surveillance SystemVideo Surveillance System		Restraints	DM 46
Video System Controller		Wheels & Tires Inspection	
Video System		Wheels Wheels	
Visual Inspection			
VMM 1615 Troubleshooting		WIFI Radio Mobile Network / Direct Con	
VMM 1615		Network Palago System	
Voltage Equalizer Specifications		Windows	
Voltage Equalizer Testing		Windows	
Voltage Equalizer		Windows	
Voltage Regulator Troubleshooting	9-33	Windshield Washer	13-43



Windshield Wiper & Washer 13-41 Windshield Wiper & Washer PM-45 Windshield Wiper 13-41 Windshield 14-4 Wiper/Washer Controls 19-14 Wire Codes 9-91 Wire Colors 9-91	7,500 Miles (12,000 km) Pr Maintenance
Y	Maintenance
Yearly Preventive MaintenancePM-83	30,000 Miles (48,000 km) F Maintenance
Z	Maintenance48,000 Miles (77,200 km) F Maintenance
Zone Select Button	54,000 Miles (87,000 km) F Maintenance
Numerical References	60,000 Miles (96,000 km) F Maintenance
3M-550 Fast Cure Adhesive/Sealant with Accelerator AC61	Maintenance

7,500 Miles (12,000 km) Preventive	
Maintenance	PM-56
12,000 Miles (19,300 km) Preventive	
Maintenance	PM-60
15,000 Miles (24,000 km) Preventive	
Maintenance	PM-62
18,000 Miles (29,000 km) Preventive	
Maintenance	PM-63
24,000 Miles (38,600 km) Preventive	
Maintenance	PM-64
30,000 Miles (48,000 km) Preventive	
Maintenance	PM-65
36,000 Miles (58,000 km) Preventive	
Maintenance	PM-66
48,000 Miles (77,200 km) Preventive	
Maintenance	PM-68
54,000 Miles (87,000 km) Preventive	
Maintenance	PM-69
60,000 Miles (96,000 km) Preventive	
Maintenance	PM-70
75,000 Miles (120,700 km) Preventive	
Maintenance	PM-72
96,000 Miles (154,500 km) Preventive	
Maintenance	PM-72
150,000 Miles (241,400 km) Preventive	
Maintenance	PM-73
200,000 Miles (321,000 km) Preventive	
Maintenance	PM-74



# **General Information**

	SAFETY	GI-1
	1.1. Safety Procedures	GI-1
	1.2. Insulation Foam Safety	
	1.3. Vehicle Operation Safety Procedures	
	1.4. Safety Equipment	
	1.5. Vehicle Safety Systems	
	1.5.1. Video Surveillance System	
	1.5.2. Fire Suppression System	
	1.5.3. Exit Door Sensitive Edges	
	1.5.4. Interlock System	GI-4
2.	EMERGENCY INFORMATION	GI-5
	2.1. Vehicle Evacuation & Shutdown	GI-5
	2.2. Escape Exits	GI-6
	2.2.1. Side Windows	
	2.2.2. Roof Hatches	
	2.2.3. Emergency Release Control Valve - Entrance Door	
	2.2.4. Emergency Release Control Valve - Exit Door	GI-9
3.	VEHICLE SPECIFICATIONS	GI-10
•		
4.	STANDARD OPERATING FEATURES	GI-17
-		_
-	4.1. Brake & Accelerator Interlocks	GI-17
-	4.1. Brake & Accelerator Interlocks4.2. Lighting	GI-17 GI-17
-	4.1. Brake & Accelerator Interlocks	Gl-17 Gl-17 Gl-17
-	4.1. Brake & Accelerator Interlocks	Gl-17 Gl-17 Gl-17 Gl-18
-	4.1. Brake & Accelerator Interlocks	GI-17 GI-17 GI-17 GI-18 GI-18
-	4.1. Brake & Accelerator Interlocks 4.2. Lighting 4.3. Transmission 4.4. Starting 4.5. Warning Alarms 4.6. Wheelchair Ramp	GI-17 GI-17 GI-17 GI-18 GI-18
-	4.1. Brake & Accelerator Interlocks	GI-17 GI-17 GI-17 GI-18 GI-18
-	4.1. Brake & Accelerator Interlocks 4.2. Lighting 4.3. Transmission 4.4. Starting 4.5. Warning Alarms 4.6. Wheelchair Ramp 4.7. Multiplexing System  EXTERIOR VIEWS	GI-17 GI-17 GI-17 GI-18 GI-19 GI-19
4.	4.1. Brake & Accelerator Interlocks 4.2. Lighting 4.3. Transmission 4.4. Starting 4.5. Warning Alarms 4.6. Wheelchair Ramp 4.7. Multiplexing System  EXTERIOR VIEWS 5.1. Structure	Gl-17 Gl-17 Gl-17 Gl-18 Gl-19 Gl-20
4.	4.1. Brake & Accelerator Interlocks 4.2. Lighting 4.3. Transmission 4.4. Starting 4.5. Warning Alarms 4.6. Wheelchair Ramp 4.7. Multiplexing System  EXTERIOR VIEWS	Gl-17 Gl-17 Gl-17 Gl-18 Gl-19 Gl-20
4.	4.1. Brake & Accelerator Interlocks 4.2. Lighting 4.3. Transmission 4.4. Starting 4.5. Warning Alarms 4.6. Wheelchair Ramp 4.7. Multiplexing System  EXTERIOR VIEWS 5.1. Structure	GI-17 GI-17 GI-17 GI-18 GI-19 GI-20 GI-21



	5.5. Lighting	GI-22
	5.6. Destination Signs	GI-22
	5.7. Access Compartments	GI-23
	5.7.1. Engine Compartment	GI-23
	5.7.2. Diesel Exhaust Fluid Fill Access	GI-23
	5.7.3. Upper Corner Pillar Access	
	5.7.4. Battery Compartment	
	5.7.5. Surge Tank Compartment	
	5.7.6. Radiator Compartment	
	5.7.7. Driver's Heater/Defroster Compartment	GI-23
6.	INSTRUMENT PANEL	GI-24
	6.1. Description	GI-24
7.	SIDE CONSOLE PANEL	GI-25
• •	7.1. Description	
	7.1. Description	GI-20
8.	AIR TANK INSTALLATION	GI-27
	8.1. Description	GI-27
9.	AIR TANK DRAIN VALVE LOCATIONS	GL28
J.	9.1. Description	
	9.1. Description	GI-20
10	. PRESSURE SWITCHES	GI-29
	10.1. Front Brake Circuit Pressure Switch	GI-29
	10.1.1. Description	GI-29
	10.1.2. Operation	
	10.2. Brake Application Pressure Transducer	GI-29
	10.2.1. Description	
	10.2.2. Operation	GI-29
	10.3. Parking Brake/Stop Light Switch	GI-30
	10.3.1. Description	GI-30
	10.3.2. Operation	
	10.4. Brake Tank Pressure Sending Units	
	10.4.1. Description	
	10.4.2. Operation	GI-31
11	. BRAKE INTERLOCK CONTROL SYSTEM	GI-32
• •	11.1. Description	
	11.1. Description	GI-32
12	RAISING THE VEHICLE	
	12.1. Safety Procedures	GI-33
	12.2. Lifting the Vehicle	
	12.3. Hoisting the Vehicle	
	12.4. Jacking the Vehicle	



12.4.1. Front Jacking Procedure	GI-37
12.4.2. Rear Jacking Procedure	GI-39
13. VEHICLE TOWING	GI-40
13.1. Towing Safety	GI-40
13.2. Description	
13.2.1. Flat Towing	
13.2.1.1.Preparation	
13.2.1.2.Towing Adapter Installation	
13.2.2. Raised Towing	GI-43
13.2.2.1.Preparation	
13.2.2.2.Lift Adapter/Receiver Installation	
13.2.2.3.Raising & Securing the Vehicle	
13.2.2.4.Maximum Lifting Height	
13.3. Driveshaft Removal	
13.4. Rear Axle Shaft Removal	
13.5. Spring Brake Release	GI-47
13.6. Vehicle Removal from Ditch	GI-48
13.6.1. Chain Pulling Procedure	GI-48
13.6.1.1.Pulling from the Front	GI-48
13.6.1.2.Pulling from the Back	GI-48
14. TORQUE INFORMATION	GI-49
14.1. Bolt Torque Specifications	GI-49
14.2. U.S. Customary Bolts & Capscrews Torque Values	
14.3. Metric Capscrews & Nuts	
14.4. Pipe Plugs (NPFT)	GI-53
15. SI (Metric) CONVERSION FACTORS	GI-54





### 1. SAFETY

# 1.1. Safety Procedures

This section of the service manual contains procedures which require the mechanics to strictly observe safety procedures in order to ensure personal and equipment safety.



DO NOT perform any maintenance on roof-mounted components unless equipment is in place to prevent fall hazards. Ensure maintenance personnel use approved lift platforms or scaffolding and wear approved safety harness when working on the roof of the vehicle.

Always ensure that the vehicle is appropriately hoisted and blocked for procedures which require elevating the vehicle. Be aware of the limitations of the blocking equipment, and always ensure that the jarring and shaking created by component removal and installation procedures does not overload the blocks, or cause the vehicle to become unstable.

Certain procedures may require the vehicle be operated in an elevated position in order to accurately troubleshoot and diagnose a problem. If the vehicle must be running while elevated, become familiar with the repair area prior to starting the engine. Take special care in noting areas which will become hot, electrically energized, and areas where moving and rotating components are located. Limit the work in these areas as personal and equipment safety is at risk.

For procedures which involve air lines, ensure the line is safely depressurized prior to disconnecting. Disconnecting pressurized lines will cause solid particles

deposited in the line to be uncontrollably propelled, and will also cause the hose end to whip randomly as the air escapes.

During electrical diagnosis procedures an understanding of the vehicle's electric circuits is important to anticipate the results of connecting test equipment. During component removal or installation, ensure the Battery Disconnect switch is in the OFF position.

Failure to follow this procedure may result in personal injury or component failure.

Observe the following procedures involving hydraulic line removal.

- Hydraulic fluid is corrosive and should not be exposed to skin for extensive periods of time.
- Wear eye protection at all times.
- Pressurized lines should not be disconnected until the pressure is safely and controllably released.



Follow all proper safety precautions regarding spray painting. Use a filtering mask with the proper filter cartridges for this type of paint. Wear eye protection and proper protective clothing. The paint booth or work area must be properly ventilated, with filtered exhaust fans removing fumes and over spray. Air make-up induction fans should also be used to supply fresh air to the work area. The painting area should be a safe distance from any source of flame, spark or other means of combustion. Atomized paint, thinner, cleaner and solvent fumes are highly volatile with an extremely low flashpoint that can cause explosive combustion. DO NOT smoke or permit anyone else to smoke in or near the painting area.



# 1.2. Insulation Foam Safety



Insulation foam is installed in the spaces of the frame tubing, between the vehicle inner and outer wall panels. The Insulation Foam is extremely combustible. KEEP OPEN FLAMES AND FLAME SOURCES AWAY FROM THE INSULATION FOAM!

Before performing any work or repairs requiring use of an open flame such as: welding, brazing, acetylene torch cutting or grinding, ensure that the Insulation Foam is either removed from the area being repaired, or is properly shielded from the open flame.

# 1.3. Vehicle Operation Safety Procedures

Do not drive the vehicle if:

- Indicators, instruments or gauges show that a major vehicle operating system is malfunctioning.
- ☐ Exhaust fumes seep into the passenger compartment.
- ☐ Beneath the vehicle, puddles of engine oil, hydraulic fluid, or coolant have formed.
- ☐ Seating stanchions and grab rails are loose or damaged.
- ☐ Driving mirrors are broken, missing or cannot be properly adjusted.
- Any exterior or interior light is broken, discolored, or malfunctioning.

Report the occurrence of any of the above to maintenance personnel so the vehicle can be serviced before beginning revenue service.

- Do not operate the vehicle without fastening the seat-belt.
- Make sure obstructions do not block or interfere with your safe range of driving and operating vision.
- □ Have any debris or garbage removed from the passenger area and the doors. This is important to eliminate any foot obstructions that could cause tripping or falling.
- Make sure all exterior and interior access doors and panels are securely shut and latched.
- Do not smoke around the fuel storage areas, the fuel filling area or during refueling. Do not smoke in areas where fuel, hydraulic fluid, transmission oil or any other flammable fluid has leaked.

# 1.4. Safety Equipment

The following safety equipment is supplied with this vehicle:

- □ Hand-held fire extinguisher Use the extinguisher only after the vehicle is in a safe location, and all passengers are evacuated. Use only if there is no risk to your personal safety. See "Fig. GI-1: Safety Equipment" on page 3.
- ☐ Safety triangles Located inside the equipment box on the curbside wheelhousing. Position the triangles at the front and rear of the vehicle to warn other drivers during emergency situations. See "Fig. GI-2: Safety Triangles" on page 3.






Fig. GI-1: Safety Equipment




Fig. GI-2: Safety Triangles



# 1.5. Vehicle Safety Systems

#### 1.5.1. Video Surveillance System

The vehicle is equipped with a DVR video recorder located in the electronic equipment box. Five cameras are installed in the interior and three camera installed on the exterior of the vehicle.

#### 1.5.2. Fire Suppression System

The vehicle is equipped with a Fire Suppression System. The system protects the passengers and vehicle against fire. If a fire is detected in the engine compartment an extinguishing agent is discharged to suppress the fire.

The Fire Suppression System components that are located in the driver's area include the Manual Actuator switch and control panel.

## ™NOTE:

An alarm sounds and the engine shuts down when the Fire Suppression System is activated.

#### 1.5.3. Exit Door Sensitive Edges

Pressure sensitive rubber seals are mounted to the leading edges of the exit door panels. If they encounter an object or passenger during door closure, an alarm sounds and the doors fully reopen. The doors will again close once they have fully reopened.

#### ™NOTE:

The Interlock System prevents the vehicle from moving until the exit doors have fully closed.

#### 1.5.4. Interlock System

Refer to 4.1. "Brake & Accelerator Interlocks" on page 17 in this section for information on interlock operation.



# 2. EMERGENCY INFORMATION

#### 2.1. Vehicle Evacuation & Shutdown

In the event of an emergency, follow the evacuation and shutdown procedure in the sequence shown:

- 1. Pull the vehicle over to a safe location.
- 2. Apply the parking brake
- 3. Open the front and rear passenger doors.
- 4. Shutdown the vehicle by setting the Master Run switch to the STOP-ENGINE position.
- Direct all passengers to a safe area, away from the vehicle.
- 6. Alert the transit authority of the emergency.



Assess the situation to determine whether it is safe to approach the rear curbside area of the vehicle before proceeding with the following steps.

- Approach the rear curbside area of the vehicle and open the Battery Disconnect access door.
- Shut off all 12/24 VDC electrical power to the vehicle by setting the Battery Disconnect switch to the OFF position. See "Fig. GI-3: Battery Disconnect Switch" on page 5.
- Wait for emergency response personnel to arrive and assist them by providing details of the emergency.




Fig. GI-3: Battery Disconnect Switch



# 2.2. Escape Exits

#### 2.2.1. Side Windows

The windows which function as emergency exits are identified by labels.

To operate the emergency window, pull the red handle down and hold. Push out on the bottom of the window frame. The window will open on hinges at the top of the frame. To close, release the handle and slam window shut. See "Fig. GI-4: Emergency Release Handle" on page 6.




Fig. GI-4: Emergency Release Handle

# **EMERGENCY INFORMATION**

#### 2.2.2. Roof Hatches

The roof hatches are usable as emergency exits. Proceed as follows to operate the emergency exit: See "Fig. GI-5: Roof Hatch Emergency Exit" on page 7.

- 1. Pull the red handle at the rear of the hatch to release the locking mechanism. The
- handle is attached to a cable which will release the retaining pins from the rear hinge.
- 2. Push upward on the rear section of the hatch, allowing it to swing fully open on the front hinges.




Fig. GI-5: Roof Hatch Emergency Exit



# 2.2.3. Emergency Release Control Valve - Entrance Door

The entrance door emergency release control valve is located behind a breakable window in the door mechanism access cover. In an emergency, break the glass to access the control valve knob. Rotate the

knob 90° counter-clockwise to release air pressure from door operator, then push the doors open. As the doors open they activate the header and curb lights. See "Fig. GI-6: Entrance Door Emergency Release" on page 8.




Fig. GI-6: Entrance Door Emergency Release



# 2.2.4. Emergency Release Control Valve - Exit Door

The exit door emergency exit control valve is located to the left of the exit door header, behind a hinged window. In an emergency, pull the glass open to access the control valve knob. Rotate the control valve knob

90° counter-clockwise to release air pressure from the door operator, then push the doors open. As the doors open they activate the header and curb lights, the brake interlocks, and the Rear Door Open indicator. See "Fig. GI-7: Exit Door Emergency Release" on page 9.




Fig. GI-7: Exit Door Emergency Release



# 3. VEHICLE SPECIFICATIONS

# ™NOTE:

Refer to the Major Component Layout when reviewing information in this manual.

	VEHICLE TYPE				
Model	New Flyer XD40 transit bus				
Customer	Connect Transit - SR1950				
Build Year	2015				
	ENGINE				
Engine	Cummins ISL 9L (EPA 2015)				
Horsepower	280 HP				
Torque	900 ft-lb.				
	FUEL				
Fuel	Ultra low sulphur diesel				
Usable Fuel Capacity	125 U.S. gallons (473 liters)				
	TRANSMISSION				
Transmission	Allison B400R				
Transmission Controls	5th Generation				
Self-Contained Retarder	3 stage - 25% accelerator, 66% front brake, 100% rear brake activated				
	DIMENSIONS				
Length (over bumpers)	41 ft. (12.5 m)				
Width	8.5 ft. (2.6 m)				
Height	10.5 ft. (3.2 m)				
Wheelbase	23.6 ft. (7.2 m)				
Turning Radius	43.0 ft. (13.1 m)				
Approach/Departure Angle	9°				
Vehicle Weight (approx.)	28,125 lbs. (12,755 kg)				
Gross Vehicle Weight Rating (GVWR)	43,720 lbs. (19,830 kg)				



A	XLES & SUSPENSION		
Front Axle	MAN VOK-07-F		
Front Gross Axle Weight Rating (GAWR)	14,780 lbs. (6,700 kg)		
Front Axle Ride Height	4" (102 mm)		
Suspension Air Springs	Firestone		
Suspension Shock Absorbers	Koni		
Rear Axle	MAN HY-1350-F (4.56:1)		
Rear Gross Axle Weight Rating	27,760 lbs. (12,590 kg)		
Rear Axle Ride Height	3.8" (97 mm)		
Suspension Air Springs	Firestone		
Suspension Shock Absorbers	Koni		
Driveshaft	Prop Shaft Supply 1710 with crosstooth flange & half-round connections		
	STEERING		
Steering Gear R.H. Sheppard M110 with remote miter box			
Oil Flow	3.6 gal/min		
Pressure Relief	1,850 psi		
Steering Column	Douglas Autotec 9204 Series		
Power Steering Reservoir	Cummins reservoir		
Power Steering Pump	Ixetic		
	WHEELS & TIRES		
Tires	Michelin		
Tire Size	305/70R22.5		
Inflation Pressure	125 psi		
Rim Mounting	10 Bolt hub piloted		
Wheels	Aluminum		
Maximum Load (single tire)	7,760 lbs. @ 125 psi		
Maximum Load (dual tires)	7,121 lbs. @ 125 psi		



	BRAKE SYSTEM
Brakes, Mechanical (front)	Knorr-Bremse SN7000 air-actuated sliding caliper disc brakes
Brakes, Mechanical (rear)	Knorr-Bremse SN7000 air-actuated sliding caliper disc brakes
Service Brake Chamber (front)	MGM
Service Brake Chamber (rear)	MGM
Antilock Braking System (ABS)	Meritor Wabco ABS on all wheels
Parking Brake Application	Spring brake chamber applied with push/pull control valve located on side console
Parking Brake Release	Spring brake chamber released with application of air from push/pull control valve located on side console
Emergency Brake Release	Released with push/pull control valve located on side console
	HVAC SYSTEM
HVAC Unit	Thermo King RLF2-M11 rootop unit
Defroster	Mobile Climate Control
Floor Mounted Heaters	2 Mobile Climate Control in passenger area
	COOLING SYSTEM
Engine Radiator	Engineered Machined Products (EMP) XPL2D - MH9 Radiator/ CAC assembly with Fil-11 pusher-type fans
Transmission Oil Cooler	Rocore oil to water heat exchanger located in the engine compartment
	AIR SYSTEM
Compressor	Wabco twin compressor, 30.4 CFM, 11 tooth
Governor	Bendix D2 narrow band (117 to 131 psi)
Air Dryer	Haldex GEMINI tandem air dryer with 24V heater
S	TARTING SYSTEM
Starter	Delco Remy 42MT, 24 Volt
С	HARGING SYSTEM
Alternator	Engineered Machined Products (EMP) 450
Alternator Voltage	24 Volt
Alternator Current	450 Amp



# **VEHICLE SPECIFICATIONS**

	T				
Alternator Cooling	Air				
Voltage Regulator	Delco-Remy 50 VR				
Voltage Equalizer	Vanner Power Group 12/24 Volt, 80 Amp				
Batteries (2)	East Penn Manufacturing				
Battery Type	Maintainable				
Battery Type	High Cycle				
Battery Group Size	8D				
Battery Charge Voltage	28.5 ± 0.3 Volts				
E	XTERIOR LIGHTING				
Headlights	Integrated unit with 12 Volt LED low beam, H11 incandescent high beam & amber LED turn lights				
Exterior Stop/Tail Lights	12 Volt LED				
Side Turn/Marker Lights	12 Volt LED				
Clearance Lights	12 Volt LED				
II	TERIOR LIGHTING				
Aisle Lights	TCB 24 Volt LED lights with dimmable Gen 3 clever boards				
II	NSTRUMENTATION				
Instrument Panel	Parker-Vansco electronic				
	User programmable inputs, outputs, gauges, telltales & LCD display				
	2 Controller Area Network (CAN) ports for J1939 chassis/ drivetrain networks				
	USB device port for communicating with a PC				
Overhead Recess Panel	Destination sign controller				
	Samsung Tabled with AVA/AVL screen				
	P.A. amplifier				
	Fire Suppression Display Panel & Manual Actuator				
MU	LTIPLEXING SYSTEM				
Multiplexing Module (VMM) System with J1939 Network Communication	Parker-Vansco VMM 1615 modules (6)				



Instrument Panel	Parker-Vansco electronic				
	AVA/AVL SYSTEM				
Driver/Vehicle Monitoring System	New Flyer Connect™ system				
AVA/AVL System	Smart AVA module with Samsung tablet				
PASSEN	GER COUNTING SYSTEM				
Automatic Passenger Counter (APC)	Smart sensor module				
DESTIN	NATION & ROUTE SIGNS				
Sign Control	TwinVision Operator Control Unit (OCU)				
Front Destination	TwinVision smart series				
Side Destination	TwinVision smart series				
Rear Route	TwinVision smart series				
	DOORS				
Entrance Door	Vapor Electric				
Entrance Door Opening Size	Medium				
Limit Switches	Inductive proximity switches				
Exit Door	Vapor Electric				
Exit Door Opening Size	Medium				
Limit Switches	Inductive proximity switches				
Driver's Door Control	5-position door controller located on the side console				
Door Entry Control	Entrance door manual dump valve, located on vertical face of driver's side console				
Passenger Door Control	Exit door driver operated				
	WINDOWS				
General	Dura Automotive System				
Mounting	Flush				
Frame	Black painted aluminum				
Glazing	Tempered glass				
Tinting	Grey, 50% light transmittance				
	Front slider with interior & exterior handles				



# **VEHICLE SPECIFICATIONS**

Glazing	Tempered glass			
Tinting	Green, 75% light transmittance			
Emergency Escape	2 curbside & 4 streetside identified with labels			
	SEATING			
Driver's	USSC Evolution G2A			
Passenger	4ONE Gemini Seats			
Passenger Seating Quantity	40			
Wheelchair Stations	2 (seats fold up & lock)			
FL	OOR & SUBFLOOR			
Subfloor	American Acoustical Products damped composite board			
Flooring	Altro Flooring			
Sealant	Altro			
S	AFETY FEATURES			
Emergency Escape Exits	2 curbside windows identified with labels			
	4 streetside windows identified with labels			
	2 roof hatches			
Fire Extinguisher	5 lb ABC rating			
Fire Extinguisher Location	Driver's barrier			
Safety Triangles Location	Curbside luggage rack, in equipment box			
Entrance Door Emergency Release	Rotary valve located in baseplate above entrance door			
Exit Door Emergency Release	Rotary valve located behind breakable cover, forward of exit door			
Accelerator & Brake Interlocks	Entrance or exit doors are open			
	Exit door emergency release is actuated			
	Vehicle is kneeling			
	Wheelchair ramp is not stowed			
	Parking brake is applied			
	Loss of air pressure at exit door			
	<u> </u>			



# **VEHICLE SPECIFICATIONS**

Fire Suppression System	Amerex Modular III System			
Silent Alarm	Located on side console			
Camera System	Gatekeeper System with 8 cameras			
Video System	Luminator Infotainment system with 2 display monitors			
ACC	ESSIBILITY FEATURES			
Wheelchair Ramp	New Flyer hydraulic unit with patented hydraulic cylinder/chain drive mechanism			
Wheelchair Ramp Width	Flip-out aluminum 32"			
Wheelchair Ramp Slope Ratio	1:7			
Wheelchair Ramp Max. Load Capacity	600 lbs. (272 kg.)			
Kneeling	Front suspension, rapid recovery			

# STANDARD OPERATING FEATURES

# 4. STANDARD OPERATING FEATURES

#### 4.1. Brake & Accelerator Interlocks

Interlocks disable the accelerator and apply the brakes. The interlocks function only when the Master Run switch is in DAY-RUN or NIGHT-RUN position and the Door Master switch is in the ON position.

Interlocks apply if any of the following conditions occur:

	Entrance	or	exit	doors	are	open.
--	----------	----	------	-------	-----	-------

- ☐ Exit door emergency release valve is actuated or there is a loss of air pressure at the exit door.
- Vehicle is kneeling.
- ☐ Wheelchair ramp is not stowed.
- ☐ Parking brake is applied.

The Interlock System is intended to protect passengers from inadvertent vehicle movement. The Door Master switch can be used to disable the system for maintenance purposes or in an emergency.

#### ™NOTE:

The brake treadle drops slightly when the interlock system applies. When the interlocks apply, the multiplexing system logs the application pressure in the brake lines. To release the interlocks, the operator must "push through" the interlock application, exceeding the logged pressure by 10 psi. When released, the treadle will return with the operator's foot to its normal position.

# 4.2. Lighting

- ☐ The aisle lights switch off when the transmission is shifted into reverse [R].
- ☐ The timer circuit switches the aisle lights off after 15 minutes if the vehicle Master Run switch is switched to STOP-ENGINE or NIGHT-PARK and the aisle lights are left on.

- ☐ All exterior lights switch on for 2 minutes if the engine is running, the transmission is in neutral [N], the parking brake is applied and both turn signal switches are pushed simultaneously. The lights are extinguished by shifting the transmission out of neutral [N]. This feature enables one person to test the exterior light system.
- All indicators and aisle lights switch off during starter cranking interval.
- ☐ Retarder operation illuminates the stop lights and stop light indicator.
- Exit door header lights are timed to switch off 15 minutes after the Master Run switch is positioned to NIGHT-PARK and the exit door is open or enabled.
- ☐ Service compartment lights switch off when the Multiplexing System is deactivated to prevent battery drain.
- Daytime running lights illuminate when the Master Run switch is in the DAY-RUN or NIGHT-RUN position. They can only be turned off by switching the Master Run switch to NIGHT-PARK or OFF.

#### 4.3. Transmission

- ☐ Transmission will not shift unless Engine Run switch on engine switch box is set to the FRONT position.
- Transmission will not shift unless brake treadle is pressed.
- ☐ Transmission will not shift unless wheelchair ramp is stowed.
- ☐ Transmission will not shift if there is no air pressure in front door.
- □ Transmission shift selector is operable in all the previous cases if the Door Master switch is set to the OFF position.



# 4.4. Starting

The following conditions must exist when attempting to start the vehicle using the start button located on the driver's side console:

- ☐ Engine Run switch on the engine switch box must be set to the FRONT position.
- ☐ Master Run switch on the driver's side console must be set to either the DAY-RUN or NIGHT-RUN position.
- ☐ Transmission must be in neutral [N].
- Parking brake must be applied.
- ☐ Starter must not be locked out.

The following conditions must exist when attempting to start the vehicle using the engine switchbox start button located in the engine compartment:

- Engine Run switch on the engine switch box must be set to the REAR position.
- ☐ Transmission must be in neutral [N].
- ☐ Parking brake must be applied.
- Starter must not be locked out.

### PNOTE:

It may be necessary to hold the engine switchbox start button for several seconds before the starter begins cranking. This delay will occur if the vehicle has been shutdown for an extended time period and the Multiplexing System needs to be reenergized.

- ☐ The voltage regulator does not energize until the vehicle has been running for 3 seconds.
- ☐ Starter automatically cuts out if the engine is cranked for 14 continuous seconds. The starter can be engaged again to crank the engine after a 60 second cool-down period.
- ☐ To activate fast idle, the Engine Run switch must be set to the FRONT position, the transmission must be in neutral [N], the parking brake applied and the Idle Speed switch on the side console must be set to the FAST position while the engine is running.

☐ The HVAC System cannot be activated unless the engine is started and running and the Fire Detection System does not indicate any faults.

# 4.5. Warning Alarms

An exterior alarm or beeper will sound if any of the following conditions occur:

- ☐ The backup alarm sounds if the transmission is shifted into reverse [R].
- ☐ The backup alarm sounds twice if REAR start is selected.
- ☐ The kneeling/ramp beeper sounds if the vehicle is in the process of kneeling.
- The kneeling/ramp beeper sounds if the wheelchair ramp is being deployed or stowed.
- ☐ The kneeling/ramp beeper sounds if the vehicle is shut down and the parking brake is not applied.
- ☐ The kneeling/ramp beeper sounds if the driver leaves the driver's seat for two seconds and the parking brake is not applied.

A driver's warning buzzer, located behind the instrument panel, sounds if the engine is running and any of the following conditions occur:

- Stop engine The Stop Engine indicator illuminates and the buzzer sounds if the engine ECM has detected a major engine fault. An automatic engine shutdown process will be initiated.
- Low air pressure If any brake air tank falls below 75 psi, an indicator light on the instrument panel will illuminate and the warning buzzer will sound.
- □ Low oil pressure If the engine ECU detects an unsafe oil operating pressure, it will cause the indicator light on the instrument panel to illuminate, the warning buzzer to sound, and initiate an automatic engine shutdown process.
- Low coolant level The low coolant sensor in the surge tank will detect a low coolant level and illuminate the Low Coolant indicator and activate the warning buzzer.



# STANDARD OPERATING FEATURES

Hot engine - If the engine coolant temperature switch detects an unsafe operating temperature, it will cause the Hot Engine indicator to illuminate and the warning buzzer to sound.
Hot transmission - If the Transmission Fluid Temperature switch detects an unsafe operating temperature, it will cause the Hot Transmission indicator to illuminate and warning buzzer to sound.
Engine fire - If the fire detection system activates a warning message will illumi-

☐ Seat Belt (Red) - This message appears on the LCD screen and a buzzer sounds when the driver's seat belt is not buckled and the engine is running.

## 4.6. Wheelchair Ramp

☐ The wheelchair ramp will not work unless the parking brake is on, the transmission is in neutral [N] and the door is open.

# 4.7. Multiplexing System

- ☐ The Multiplexing System remains active for 30 minutes after the Master Run switch is set to the OFF position and the Engine Run switch on the rear engine switch box is set to the FRONT position.
- ☐ The Multiplexing System remains active for 2 hours after the Master Run switch is set to the OFF position and the Engine Run switch on the rear engine switch box is set to the REAR or OFF position.

OFF position.

☐ The exit door emergency release valve is actuated.

nate and the warning buzzer will sound.

☐ The Door Master switch is set to the


- ☐ The exit door sensitive edges are touched when the vehicle is standing and the exit door is not fully open.
- Stop Lamp Fault a message appears on the LCD screen and a warning buzzer sounds when a fault is detected in stop lamp circuit.



# 5. EXTERIOR VIEWS

#### 5.1. Structure

The basic frame structure is a semimonocoque design, which uses high tensile steel plate and tube for structural strength. Full length longitudinal members are used, with cross member pillars, roof bows and bulkheads. All joints are Gas Metal Arc Welded (GMAW). The exterior panels carry no load. Steel tapping plates are GMAW welded to the structure. All fixtures and accessories attached to the structure are drilled and tapped into the tapping plates to maintain the strength of the structure. See "Fig. GI-8: Front Exterior View" on page 20. See "Fig. GI-9: Rear Exterior View" on page 21.



- 1. Engine Air Intake Grille
- 2. Side Marker Light
- 3. Side Destination Sign
- 4. Surveillance Camera
- 5. Exterior Speaker
- 6. HVAC Unit
- 7. Front Destination Sign
- 8. Clearance Marker Lights
- 9. Driver's Lower Vent
- 10. Headlight, Low Beam
- 11. Headlight, High Beam

- 12. Front Turn Light
- 13. Bike Rack
- 14. Defroster/Wiper Access Door
- 15. Kneeling/Ramp Warning Light
- 16. Side Turn Light
- 17. Fuel Filler Access Door
- 18. Hubodometer
- 19. Battery Access Door
- 20. Fusebox Access Door
- 21. Battery Cutoff Switch Access Door
- 22. Diesel Exhaust Fluid Fill Access Door

1950o001a.svg


Fig. GI-8: Front Exterior View



### 5.2. Exterior Panels

The exterior aluminum and fiberglass panels are not part of the basic body structure. The front mask and rear crown panels are molded fiberglass panels. They are secured along the top and sides using

stainless steel rivets and high strength sealant/adhesive. The exterior side and pier panels cover the area below the window opening. The roof is composed of two overlapped fiberglass panels with one hole cut at each end for escape hatches.



- 1. Surveillance Camera
- 2. HVAC Unit
- 3. Side Marker Light
- 4. Muffler Access Door
- 5. Clearance Marker Lights
- 6. Exhaust System Grille
- 7. Rear Route Sign
- 8. Center Stop Light
- 9. Air Cleaner Access Door
- 10. Turn Signal/Tail Light

- 11. Stop/Tail Light
- 12. Backup Light
- 13. Engine Access Door
- 14. License Plate Light
- 15. Radiator Access Door
- 16. Surge Tank Access Door
- 17. Side Turn Light
- 18. Side Console Access Door
- 19. Windshield Washer Filler

1950o002a.svg

Fig. GI-9: Rear Exterior View



#### 5.3. Doors

The entrance and exit doors each consist of two panels fitted with door shafts, roller brackets and glass inserts. Both are slide/ glide style doors. They are opened using the door controller on the driver's side console. A base plate assembly is mounted behind an access panel above each door. Each base plate is equipped with an electric motor which operates a gear assembly connected to a teeter lever on the output shaft. When the door controller is actuated, the electric motor rotates the gear and lever assembly. This action operates connecting rods fastened to the door shaft levers. The levers rotate and the door panels open. A manually operated emergency valve is located next to each door behind a protective cover. Switches on each base plate inform the Multiplexing System of door status. These switches are used as signals for the interlock and wheelchair ramp systems.

#### 5.4. Windows

- ☐ The front windshield consists of three windshield sections that are formed from laminated safety glass and are installed in the front mask apertures.
- ☐ The driver's side window consists of a slide-open sash style window with tinted safety glass and is retained within a clamp style anodized aluminum frame.

Passenger windows are located along both sides of the vehicle and consist of tinted safety glass windows retained within a clamp-type anodized aluminum frame. The curbside window located aft of the entrance door has a clear tint on the upper section of the window to allow for side destination sign visibility.

# 5.5. Lighting

- ☐ The exterior lighting system consists of headlights, turn indicators clearance markers, stop lights, tail lights, backup lights, kneeling lights, and curb lights.
- The interior lighting system consists of an overhead light located in the driver's area and aisle lighting panels located above the side windows on either side of the vehicle.

# 5.6. Destination Signs

The destination sign system consists of:

- Destination sign controller, located in the driver's overhead panel.
- ☐ Front destination sign, located above the windshield
- ☐ Side destination sign, located on the interior of the curbside window, aft of the entrance door.
- ☐ Rear route sign, located on the exterior of the rear panel.



## 5.7. Access Compartments

### 5.7.1. Engine Compartment

The engine access door is located at the rear of the vehicle. The door is equipped with one fixed handle to raise the door, and two assist cylinders to support the door when in the open position. One of the two cylinders is equipped with a safety latch. The door is also equipped with a license plate holder and a license plate lamp.

#### 5.7.2. Diesel Exhaust Fluid Fill Access

A diesel exhaust fluid fill door is located on the curbside rear of the vehicle. The fill access door is a small hinged door mounted in the rear of the fuse box access door. It is held open and closed by a gas strut.

#### 5.7.3. Upper Corner Pillar Access

The upper corner pillar access doors are located on the streetside and curbside at the rear of the vehicle. These access doors are secured with square-key quarter-turn latches at the rear of the vehicle. They are hinged and pivot 90° outward to allow access to the exhaust system and air cleaner.

#### 5.7.4. Battery Compartment

#### □ Battery Tray

The battery tray is a slide out style tray, constructed of acid resistant stainless steel, on stainless steel rollers. Rubber isolation mounts help to isolate the tray from the structure of the vehicle and an isolator pad on the surface of the tray helps to isolate the batteries from the tray. These mounts reduce road vibrations from being transmitted directly to the batteries.

### □ Battery Disconnect Switch

The battery disconnect switch access door is a standard spring loaded door, at the rear of the curbside of the vehicle. The battery system disconnect switch assembly is mounted on the front cover of the fusebox, accessible through or under the right hand access door.

#### ☐ Rear Equipment Box

The rear equipment box, which is accessible through the battery compartment, provides access to the accessory equipment such as; air components, voltage regulator, and assorted fuses.

#### 5.7.5. Surge Tank Compartment

The surge tank access door is spring loaded and is located on the streetside of the vehicle above the engine radiator door. It allows access to the surge tank.

### 5.7.6. Radiator Compartment

The streetside radiator access door uses a stainless steel piano hinge, two 130 lb. gas struts, and two 5/16" quarter-turn square key locks. The radiator door is an aluminum panel with a perforated stainless steel screen.

#### 5.7.7. Driver's Heater/Defroster Compartment

The driver's heater/defroster access door is centered below the two windshield halves on the front mask. It provides access to the heater/defroster and the towing air connections.



## 6. INSTRUMENT PANEL

# 6.1. Description

The instrument panel houses the electronic instrument cluster. The instrument cluster includes gauges, LCD display screen and odometer, telltale indicators, and control buttons. The LCD screen is a

programmable unit with diagnostic capabilities. A USB port is located below the instrument panel which is intended for configuring the instrument cluster using a PC.

The instrument panel is also fitted with controls and switches for operating electrical and mechanical devices. See "Fig. Gl-10: Instrument Panel" on page 24.




Fig. GI-10: Instrument Panel





# 7. SIDE CONSOLE PANEL

# 7.1. Description

The driver's side console is located to the left of the driver's seat, below the driver's side window. The panel is fitted with pneumatic and electrical control devices and switches. The aluminum panel and frame are mounted on a set of slider rails for

ease of access to the electrical and pneumatic connections mounted to the interior of the drawer-like mechanism. Two 50 lb. spring cylinders support the assembly in the raised position. A side console access door, located on the exterior streetside of the vehicle, also gives access to its lower electrical components, and pressure switches. See "Fig. GI-11: Side Console Panel" on page 26.






Fig. GI-11: Side Console Panel



## 8. AIR TANK INSTALLATION

# 8.1. Description

Stainless steel air tanks are mounted behind the interior lighting panels along the sides of the vehicle. They are part of a system which includes the engine air intake and air compressor, the air dryer, muffler tank and wet tank. This system provides air to the suspension, brakes, and accessories. Charging fittings are provided in the engine compartment and under the front bumper to allow remote charging of the air system for vehicle towing. See "Fig. GI-12: Air Tank Installation" on page 27.




Fig. GI-12: Air Tank Installation



# 9. AIR TANK DRAIN VALVE LOCATIONS

# ™NOTE:

Refer to the Preventive Maintenance Section of this manual for air tank drain intervals.

# 9.1. Description

Air system tanks are provided with drain lines which terminate in manual drain valves. These valves are accessible at the lower edge of the vehicle at the locations indicated. See "Fig. GI-13: Air Tank Drain Valve Locations" on page 28. Tanks are drained to remove accumulated moisture from the air system and to protect the tanks from possibility of corrosion.




Fig. GI-13: Air Tank Drain Valve Locations



## 10. PRESSURE SWITCHES

# 10.1. Front Brake Circuit Pressure Switch

### 10.1.1. Description

The Front Brake Circuit Pressure switch is an electro-pneumatic 4 psi non-grounded switch used to signal the Multiplexing System when the front brake circuit application pressure reaches or exceeds 4 psi. It is mounted on the E-6 brake valve and accessed through the side console access door.

The switch is not a serviceable item and must be replaced as a unit if found defective.

### 10.1.2. Operation

When the brakes are applied, air pressure from the brake valve enters the cavity below the switch diaphragm. The air pressure moves the piston until it contacts the leaf spring.

The leaf spring pivots on a fulcrum at 4 psi and snaps a shorting bar which mates with the contact strips. This snap action spring is designed to minimize arcing. The electrical circuit closes, signaling the Multiplexing System.

The Multiplexing System uses the signal from the Front Brake Circuit Pressure switch to activate the brake lights.

# 10.2. Brake Application Pressure Transducer

#### 10.2.1. Description

The brake application pressure transducer is ruggedly constructed of a stainless steel or aluminum cylindrical body that encloses one-piece stainless steel sensing elements. The transducer has threads and wrench surfaces at one end and a sealed electrical connector at the opposite end. It is mounted on the front brake valve panel plate.

### 10.2.2. Operation

The pressure transducers transmit an analog signal to the vehicle's multiplexing system. The multiplexing system converts the analog signal into pressure readings which are used to illuminate the brake lights and signal both the retarder system and the brake interlock system.



## 10.3. Parking Brake/Stop Light Switch

### 10.3.1. Description

The Parking Brake/Stop Light switch is an electro-pneumatic 60 psi non-grounded switch that completes the electrical circuit and illuminates the stop lights when the park brake is applied. It is located on the pressure reducing valve mounted on the front brake panel. The switch can be used with either 12 or 24 volt systems. See "Fig. GI-14: Pressure Switches" on page 30.

The switch is not a serviceable item and must be replaced as a unit if found defective.

#### 10.3.2. Operation

The switch has normally closed contacts which are held open by spring brake release air pressure. Applying the parking brake reduces air pressure in the spring brake release line. When air pressure in the line drops to 60 psi or less, the spring inside the PS4 switch moves against the diaphragm to close the switch contacts and illuminate the stop lights.




Fig. GI-14: Pressure Switches





# 10.4. Brake Tank Pressure Sending Units

#### 10.4.1. Description

The pressure transducers are ruggedly constructed of stainless steel cylindrical bodies that enclose one-piece stainless steel sensing elements. The sensors have threads and wrench surfaces at one end and a sealed electrical connector at the opposite end. They are mounted directly on the brake system air tanks.

### 10.4.2. Operation

The pressure transducers transmit an analog signal to the vehicle's multiplexing system. The multiplexing system converts the analog signal into pressure readings are displayed on individual instrument panel gauges corresponding to each brake system air tank. The LED indicator on the gauge face will illuminate and a warning buzzer will sound if the air pressure drops below 70 psi.



# 11. BRAKE INTERLOCK CONTROL SYSTEM

## 11.1. Description

The brake interlock control system consists of a pressure reducing valve, a solenoid valve and a brake valve actuator. See "Fig. GI-15: Brake Interlock Valves" on page 32.

- ☐ The brake interlock pressure reducing valve receives its air supply from the front or rear brake tank via the emergency/parking brake valve system. The pressure reducing valve is set to regulate the interlock pressure to 70 psi. The outlet of the pressure reducing valve regulator is connected to the brake interlock solenoid valve.
- ☐ The brake interlock solenoid valve is normally closed. When energized by the Multiplexing system, it opens and applies pressure from the brake interlock pressure reducing valve to the brake valve actuator on the E-6 brake valve.

☐ The brake valve actuator on the E-6 brake valve receives air pressure from the pressure reducing valve and the brake interlock solenoid valve and applies the service brakes. This action will mimic a foot application of the brake treadle and will apply both front and rear service brakes.

#### ™NOTE:

The treadle will fall away from the operator's foot when the interlocks apply.

Releasing the interlocks will require the vehicle operator to push through the interlock application. Applying sufficient pressure on the treadle to exceed interlock pressure by 10 psi will release the interlocks and the treadle will return to its normal position.

#### ™NOTE:

Interlock application and release will be accompanied by a text message on the instrument panel LCD screen. Refer to Section 19 in this manual for more information on the instrument panel text messages.




Fig. GI-15: Brake Interlock Valves



# 12. RAISING THE VEHICLE

# 12.1. Safety Procedures

Read this information first, before you attempt to raise the vehicle off the shop floor and set on jack stands. It is important that these instructions and the safety quidelines be closely followed.

Three methods for raising the vehicle for servicing are: lifting with wheel lifts, hoisting with floor hoists and jacking using a specific jacking attachment. These three systems are the only ones endorsed by this manual. All of the working procedures are based on using these systems.



DO NOT use non-standard or makeshift lifting or blocking systems. These could result in the vehicle falling off the lifting or blocking equipment resulting in severe injury or death to working personnel.

DO NOT allow individuals to board vehicle while it is supported solely by a raising device.

DO NOT run engine or engage transmission while vehicle is on raising device.

If left on the raising device for any length of time, ensure safety stands are placed under vehicle at the designated areas and that a filtered shop air supply is connected to vehicle. The auxiliary air pressure prevents suspension system leak down which causes the vehicle to sag and become imbalanced while on the safety stand.



# 12.2. Lifting the Vehicle



Make sure the wheel lift system is set up to simultaneously raise all four wheels.

- Position wheel lift, centering each tire exactly between the lift forks. Make sure each tire is tightened up against the stop. See "Fig. GI-16: Typical Wheel Lifts" on page 34. See "Fig. GI-17: Wheel Placement in Hoist" on page 35.
- Make sure all four wheel lifts are sitting squarely on the floor. Also check that the lift forks at the drive wheels support only one (outside) drive wheel on each side of the drive axle.
- 3. Determine that each tire is squarely seated in the lifting forks before raising. Ensure the wheel lift system is set up to simultaneously lift the four wheel lift points.
- Always inspect above lift area, before raising vehicle to ensure that nothing will interfere with the procedure or cause damage to the vehicle.
- 5. Release parking brake.

#### MOTE:

If system air is depleted, either cage spring brakes or connect a filtered shop air supply, 70 psi minimum, to hold off spring brakes. This will also maintain air suspension system pressure.

- 6. Raise the vehicle high enough to provide adequate working clearance.
- 7. Position a jack stand squarely under each reinforced jacking point on the frame. Each jack stand must have a minimum weight bearing capacity of 12,000 lbs. (5,443 kg).



At this point make sure each jack stand is precisely at the same height and is sitting completely level on the shop floor.

- 8. Raise the contact pad of each jack stand until it positively seats in the jacking point.
- Slowly and carefully lower the wheel lifts until the weight of the vehicle is taken up on the jack stands.




Fig. GI-16: Typical Wheel Lifts






Fig. GI-17: Wheel Placement in Hoist

# 12.3. Hoisting the Vehicle

 Position vehicle over hoist and align hoist posts and adapter pads so these will contact the designated points. See "Fig. GI-18: Typical Center Post Hoist" on page 36. Note hoisting points:

- ☐ At Rear hoist on suspension beams below axle.
- ☐ At Front hoist on hoisting points.
- Raise hoist posts just enough so that hoist adapter pads positively contact the axle hoist points.
- Release parking brake.

#### ™NOTE:

If system air is depleted, either cage spring brakes or connect a filtered shop air supply, 70 psi minimum, to hold off spring brakes. This will also maintain air suspension system pressure.

- Always inspect above hoist area, before raising the vehicle to ensure that nothing will interfere with the procedure or cause damage to the vehicle.
- 5. Ensure that hoist adapter pads are still properly located, then raise vehicle.
- Raise front and rear of vehicle at the same rate, maintaining correct level at all times.
- 7. Raise the vehicle high enough to provide adequate working clearance.
- 8. Engage hoist safety locks.






Fig. GI-18: Typical Center Post Hoist

 Position a jack stand squarely under each reinforced jacking point on the frame. Each jack stand must have a minimum weight bearing capacity of 12,000 lbs. (5,443 kg). See "Fig. GI-19: Jack Stand" on page 37.



At this point make sure each jack stand is precisely at the same height and is sitting completely level on the shop floor.

- 10. Raise the contact pad of each jack stand until it positively seats in the jacking point.
- 11. Slowly and carefully lower the center post hoists until the weight of the vehicle is taken up on the jack stands.



DO NOT position jack stands under rear axle suspension beam.






Fig. GI-19: Jack Stand

#### 12.4. Jacking the Vehicle



DO NOT attempt to jack the vehicle on an incline, or rough or uneven surface.

#### 12.4.1. Front Jacking Procedure

A chassis tube assembly is located rearward of the front wheels of your New Flyer vehicle. A jacking adapter assembly available from NFI, is installed into this tube assembly when the front of the vehicle requires jacking. See "Fig. GI-20: Jacking Adapter" on page 38.

- 1. Apply the park brake.
- 2. Place blocks behind the rear wheels.
- On the side requiring jacking, install the jacking adapter as follows:
  - a. Locate the chassis tube assembly.
  - b. Install the jacking adapter.
  - c. Secure the jacking adapter by installing the locking pin through both the chassis tube and the jacking adapter.
  - d. Insert the hairpin cotter to secure the locking pin.
- Using a 10" bottle jack on a stable, level surface, jack the front side of the vehicle as follows:
  - a. Position the bottle jack under the jacking adapter point A.
  - b. Raise the bottle jack to its maximum height.
  - Place support blocks under the chassis tube assembly.
  - d. Lower the bottle jack to rest the chassis tube assembly on the blocks.
  - e. Position the bottle jack under the jacking adapter point B.
  - f. Raise the bottle jack to a sufficient height for the required repair.
  - g. Place additional support blocks under the chassis tube assembly.
  - h. Lower the bottle jack to rest the chassis tube assembly on the blocks.



- 5. Lower the vehicle using the jacking adapter and bottle jack as follows:
  - a. Position the bottle jack under the jacking adapter point B.
  - b. Raise the bottle jack to free the support blocks.
  - c. Remove support blocks.
  - d. Lower the bottle jack to 1/2" before its lowest position.
  - e. Place support blocks under the chassis tube assembly.
  - f. Lower the bottle jack to rest the chassis tube assembly on the blocks.
  - g. Position the bottle jack under the jacking adapter point A.
  - h. Raise the bottle jack to free the support blocks.
  - i. Remove support blocks.
  - j. Lower and remove the bottle jack.
- 6. Remove the jacking adapter from the chassis tube assembly.
- 7. Remove the blocks from behind the rear wheels.
- 8. Lower the vehicle onto the blocks and proceed with the required repair.




Fig. GI-20: Jacking Adapter



#### 12.4.2. Rear Jacking Procedure



DO NOT attempt to jack the vehicle on an incline or on a rough or uneven surface.

- 1. Apply the park brake.
- 2. Ensure the front wheels are facing forward.
- 3. Place blocks in front of the front wheels.
- Using a 10" bottle jack on a stable, level surface, jack the rear side of the vehicle as follows:
  - a. Locate the appropriate jack stand point under the frame rail at the rear of the vehicle. See "Fig. GI-21: Jacking (hoisting) Points & Stand Placement" on page 39.

- Position the bottle jack under the jack stand point.
- c. Raise the bottle jack to a sufficient height for the required repair.
- d. Place support blocks under the frame
- e. Lower the bottle jack to rest the frame rail on the support blocks.
- Lower the vehicle using the bottle jack as follows:
  - a. Position the bottle jack under the jack stand point.
  - b. Raise the bottle jack to free the support blocks.
  - c. Remove the support blocks.
  - d. Lower and remove the bottle jack.
- Remove the blocks from in front of the front wheels.




Fig. GI-21: Jacking (hoisting) Points & Stand Placement



# 13. VEHICLE TOWING



Failure to comply with the safety precautions in this section could result in personal injury or vehicle damage. ALWAYS follow the recommended procedures.

#### ™NOTE:

The operator of the towing vehicle is ultimately responsible for safely securing and towing the vehicle. Ensure that the operator of the towing vehicle is aware of the safety requirements and towing procedures contained in this section.

# 13.1. Towing Safety

- ☐ Follow all State (provincial in Canada) and local traffic regulations.
- A vehicle safety restraint system must be used that is independent of the primary lifting and towing attachments.
- ☐ All loose or protruding parts of a damaged vehicle should be secured prior to towing.

- Do not go under a vehicle which is being lifted by the towing equipment, unless the vehicle is adequately supported by safety stands or appropriate blocking.
- No towing operation should be attempted for any reason which jeopardizes the safety of the operator, wrecker, bystanders or other motorists.
- Do not exceed the recommended maximum speed of 35 mph (55 km/h) while towing.
- ☐ Reduce speed over uneven roads, railway tracks or other obstacles.
- □ Do not exceed the maximum front and minimum rear clearance specifications when the vehicle is raised. Refer to 13.2.2.4. "Maximum Lifting Height" on page 46 and Refer to 13.2.2.5. "Minimum Vehicle Ground Clearance" on page 46 in this section for dimensions and measuring methods.
- ☐ The vehicle being towed must have its steering secured with the wheels positioned straight ahead.
- ☐ If the vehicle being towed is not equipped with an electrical plug for operating the vehicle tail lights, a light bar must be placed at the rear bumper of the towed vehicle.



# 13.2. Description



Care must be taken to ensure that the vehicle will not suffer structural or drive train damage as a result of towing. The driveshaft or both rear axle shafts must be removed when towing, regardless of distance or speed traveled. Damage to the transmission/drive unit may occur if the vehicle is towed without first removing the driveshaft or rear axles.

The New Flyer vehicle can be towed from the front using either the flat or raised method. Refer to 13.2.1. "Flat Towing" on page 41 in this section for flat towing procedures. Refer to 13.2.2. "Raised Towing" on page 43 in this section for raised towing procedures. New Flyer recommends the flat towing method to minimize the likelihood of damage to the vehicle. Extra care must be taken when using the raised towing method to ensure adequate ground clearance at the rear of the vehicle. Rear towing is not recommend due to insufficient ground clearance at the front of the vehicle and the problem of locking the front wheels in a straight position.

# ™NOTE:

Consult your local Transit Authority for any specific towing procedures and use them carefully in conjunction with the recommended towing procedures contained within this section.

#### 13.2.1. Flat Towing

#### 13.2.1.1.Preparation

- Prepare the vehicle for towing by removing either the driveshaft or both rear axle shafts. Refer to 13.3. "Driveshaft Removal" on page 47 and Refer to 13.4. "Rear Axle Shaft Removal" on page 47 in this section for procedure.
- Obtain an approved towing adapter kit if one is not already provided. The towing adapter used for flat towing consists of two L-shaped brackets, clevis pins and cotter pins. Refer to your New Flyer Parts Manual for towing adapter ordering information.

#### ™NOTE:

The towing adapters mount into receivers in the front frame of the vehicle and provide the proper offset and clearance to allow the attachment of towing equipment.



#### 13.2.1.2. Towing Adapter Installation

- Install each tow adapter into a receiver and locate with a clevis pin. See "Fig. GI-22: Towing Adapter" on page 42.
- 2. Secure each clevis pin with a cotter pin.
- 3. Attach the towing vehicle equipment to the tow eye of each towing adapter. The method used will vary depending on the type of towing equipment available.
- Secure the towing vehicle to the tow adapters. The method used will vary depending on the type of towing equipment available.

- Attach two safety restraint chains from the towing vehicle to a fixed location on the towed vehicle. See "Fig. GI-23: Safety Chain" on page 43.
- Connect the towing vehicle air line and electrical harness to the respective tow connectors on the towed vehicle.

### ™NOTE:

An auxiliary air supply must be provided to the vehicle being towed to release the spring brakes and maintain suspension height. The auxiliary air supply should be a minimum of 100 psi.




Fig. GI-22: Towing Adapter




Fig. GI-23: Safety Chain

### 13.2.2. Raised Towing

#### 13.2.2.1.Preparation

- Prepare the vehicle for towing by removing either the driveshaft or both rear axle shafts. Refer to 13.3. "Driveshaft Removal" on page 47 and Refer to 13.4. "Rear Axle Shaft Removal" on page 47 in this section for procedure.
- 2. Obtain an approved towing adapter kit if one is not already provided. The towing adapter kit used for raised towing is a peg and socket configuration that consists of

two U-shaped lift adapters that attach to the towed vehicle and two lift receivers that slide onto the towing vehicle crossbar. Refer to your New Flyer Parts Manual for towing adapter ordering information.

#### MOTE:

The towing adapters mount into receivers in the front frame of the vehicle and provide the proper offset and clearance to allow the attachment of towing equipment. The towing adapters are designed to work with Century 9055 Wrecker towing equipment.



### 13.2.2.2.Lift Adapter/Receiver Installation

- 1. Install the lift adapters onto the towed vehicle as follows:
  - a. Slide lift adapter into vehicle receiver and locate with a clevis pin.
- b. Secure each clevis pin with a cotter pin.
- 2. Install the lift receivers onto the towing vehicle crossbar and slide into position so that they align with the towed vehicle lift adapters. See "Fig. GI-24: Lift Receiver Installation" on page 44.




Fig. GI-24: Lift Receiver Installation



#### 13.2.2.3. Raising & Securing the Vehicle

- Position the wrecker's lifting boom with the lift receivers in place under the pegs of the lift adapters. See "Fig. GI-25: Securing Lift Receivers to Lift Adapters" on page 45.
- Slowly raise the boom until the socket on the lift receivers engage the pegs on the lift adapters. Make any necessary adjustments to the lift receiver positions to ensure proper engagement.
- Continue to raise the lifting boom until the lift adapters are fully engaged into the receivers.
- 4. Insert the lock pin through the lift adapters.
- 5. Raise the front wheels to the height recommended for the specific vehicle being towed and check vehicle ground clearance. Refer to 13.2.2.4. "Maximum Lifting Height" on page 46 and Refer to 13.2.2.5. "Minimum Vehicle Ground Clearance" on page 46 in this section for recommended limits.
- Connect the towing vehicle air line and electrical harness to the respective tow connectors on the towed vehicle.

### ™NOTE:

An auxiliary air supply must be provided to the vehicle being towed to release the spring brakes and maintain suspension height. The auxiliary air supply should be a minimum of 100 psi.

- Attach two safety restraint chains from the towing vehicle to a fixed location on the towed vehicle.
- Check to ensure that all clevis and cotter pins are properly inserted, towing equipment is fully engaged and safety chains are clear of the vehicle body before final raising and towing the vehicle.
- 9. Secure the steering system as follows:
  - a. Rotate the steering wheel to position the wheels in the straight ahead position.
  - Secure the steering system in this position by looping the driver's seat belt around the lower portion of the steering wheel and clipping it into the seat belt buckle. See "Fig. GI-26: Securing Steering System" on page 46.




Fig. GI-25: Securing Lift Receivers to Lift Adapters






Fig. GI-26: Securing Steering System

# 13.2.2.4.Maximum Lifting Height

Maximum raised height, as measured from the bottom of the front tire to the ground must not exceed 9.0 inches (22.8 cm).

#### 13.2.2.5.Minimum Vehicle Ground Clearance

Rear bumper clearance must not be less than 12.5 inches (31.75 cm) as measured from the bottom of the bumper to the ground. See "Fig. GI-27: Rear Bumper Clearance Measurement" on page 46.




Fig. GI-27: Rear Bumper Clearance Measurement



#### 13.3. Driveshaft Removal

#### ™NOTE:

This procedure describes removing the driveshaft from the interior of the vehicle which eliminates jacking the vehicle and placing it onto supports.

#### ™NOTE:

Removal of axle shafts is not recommended by the axle manufacturer due to the likelihood of debris entering the axle housing while towing the vehicle.

- Check that the vehicle is on solid ground and is safe to enter.
- 2. Place safety triangles on the road to warn approaching vehicles.
- Remove the driveshaft access door and driveshaft plate. Refer to Section 15 of this manual for procedure.
- 4. Remove the driveshaft and pull it through the access opening.
- Reinstall the access plate to keep debris out of vehicle
- 6. Setup the towing equipment and retrieve the safety triangles.

#### 13.4. Rear Axle Shaft Removal



The axle shafts or the driveshaft must be removed before towing the vehicle.

- Remove the ten M6 bolts that retain the axle shaft to the hub and carefully slide out the axle shaft.
- Seal the axle housing opening using a commercially available cover plate.
- Protect the axle shaft and temporarily store inside the vehicle while being towed.
- 4. Repeat procedure for opposite axle shaft.
- 5. Vehicle is now ready for towing.

# 13.5. Spring Brake Release

#### ™NOTE:

The following procedure is required to mechanically release the emergency/parking spring brake during towing if the brakes cannot otherwise be released using air pressure.

- Locate the release bolt in the center of the brake chamber.
- Cage the rear brake chamber by unscrewing the release bolt. Do not exceed a force of 74 ft-lb. (100 Nm) during caging. The chamber is caged when the head of the release bolt extends approximately 1.36 ± 0.12" beyond the surface of the brake chamber.



#### 13.6. Vehicle Removal from Ditch

#### 13.6.1. Chain Pulling Procedure



DO NOT use a chain connected directly to the front or rear bumpers to pull the vehicle.

# 13.6.1.1.Pulling from the Front

- Connect a chain hook onto one side of each tow adapter pin hole, in the front structural tow connectors, located behind the front bumper.
- 2. Protect the front bumper during pulling with a 4" x 4" or equivalent wood block placed between the chains and the bottom of the front bumper.

3. With the assistance of a driver to steer the vehicle, release the parking brake and pull the vehicle from the ditch.

#### 13.6.1.2. Pulling from the Back

- Connect a chain hook onto each tow pin located in each main rail behind the rear bumper.
- Protect the rear bumper during pulling with a 4" x 4" or equivalent wood block placed between the chains and the bottom of the rear bumper.
- 3. With the assistance of a driver to steer the vehicle, release the parking brake and pull the vehicle from the ditch.



# 14. TORQUE INFORMATION

# 14.1. Bolt Torque Specifications

Always use bolts and nuts with the same torque values and strength as those being replace. Damage to parts and systems can be caused by using bolts and nuts with the wrong specifications.

Bolts and capscrews are identified by either numbers or radial lines on the head.

- □ U.S. customary bolts and capscrews have radial lines on the head to indicate the SAE Grade Number. A (SAE) Grade 8 bolt or capscrew head will have 6 radial lines. A (SAE) Grade 5 bolt or capscrew will have 3 radial lines.
- Metric capscrews and nuts have a Commercial Steel Class Grade Number such as: 8.8, 10.9, 12.9 on the capscrew head or on the surface of the nut. A higher number indicates greater tensile strength.

The following are examples of capscrew identification specifications:

Metric

Bolt, M8 - 1.25 x 25 mm Lg.			
M8	1.25	25 mm	
Major Thread Diameter in Millimeters	Thread Distance in Millimeters	Length in Millimeters	

#### **U.S. Customary**

Bolt, 5/16" - 18 x 1 1/2" Lg.			
5/16"	18	1 1/2"	
Major Thread Diameter in Inches	Number of Threads per Inch	Length in Inches	

#### ™NOTE:

ALWAYS use specific torque values if such are stated in text or accompanying illustrations. Use the torque values in this chart if specific torque values are not specified. If the ft-lb. value is less than 10 ft-lb., converting to in-lb. will allow using a in-lb. torque wrench to produce a more accurate reading. As an example: 6 ft-lb. = 72 in-lb.

The torque values in the charts are noted for SAE Grade 8 or 5 bolts, capscrews and nuts, cadmium plated with hardened washers and non-lubricated threads. The ft-lb. torque value is shown first, with Nm torque value in brackets.



Before torquing a bolt or nut, clearly identify the type, size and grade. Overtorquing or under-torquing threaded fasteners can damage the components and/or the bolts and nuts. Personal and component safety hazards can be caused by loose, elongated or sheared bolts, capscrews and nuts.



# 14.2. U.S. Customary Bolts & Capscrews Torque Values

# U.S. CUSTOMARY BOLTS & CAPSCREW TORQUE VALUES Grade 8 - Capscrew, Bolt, Nut

		o - Capsciew, i		
Thread Size	M	lin.	Ma	ax.
in.	ft-lb.	Nm	ft-lb.	Nm
1/4	*110	13	*120	14
5/16	*215	24	*240	27
3/8	35	48	40	54
7/16	60	82	65	88
1/2	90	125	100	135
9/16	125	170	140	190
5/8	175	240	190	260
3/4	300	410	330	450
7/8	475	645	525	710
1	725	985	800	1085
1 1/8	1050	1425	1175	1600
1 1/4	1475	2000	1625	2200
1 3/8	2000	2720	2200	2980
1 1/2	2600	3530	2850	3870
1 5/8	3450	4680	3800	5150
1 3/4	4300	5830	4800	6500
1 7/8	5500	7450	6100	8300
2	6500	8800	7200	9800

<sup>\* =</sup> in-lb. Torque Value

# ™NOTE:

All torque values are dry unless otherwise noted.



# U.S. CUSTOMARY BOLTS & CAPSCREW TORQUE VALUES Grade 8 - 12 Pt. Hex & Socket Head

Thread Size	N	lin.	Ma	ax.
in.	ft-lb.	Nm	ft-lb.	Nm
1/4	*130	15	*145	16
5/16	*270	31	*300	34
3/8	45	61	50	68
7/16	70	95	75	102
1/2	110	150	120	160
9/16	150	205	165	225
5/8	210	285	230	310
3/4	360	490	400	540
7/8	600	815	650	880
1	900	1220	1000	1360
1 1/8	1300	1770	1450	1970
1 1/4	1850	2510	2000	2720
1 3/8	2450	3330	2700	3660
1 1/2	3150	4270	3450	4680
1 5/8	4150	5630	4600	6240
1 3/4	5100	6920	5700	7730
1 7/8	6500	8800	7200	9800
2	7800	10600	8600	11700

\* = in-lb. Torque Value

### ™NOTE:

All torque values are dry unless otherwise noted.



# U.S. CUSTOMARY BOLTS & CAPSCREW TORQUE VALUES Grade 5 - Capscrew, Bolt, Nut

Thread Size	М	in.	М	ax.
in.	ft-lb.	Nm	ft-lb.	Nm
1/4	*80	9	*90	10
5/16	*180	21	*200	23
3/8	25	34	28	38
7/16	40	54	45	61
1/2	65	88	70	95
9/16	90	125	100	135
5/8	125	170	140	190
3/4	220	300	245	330
7/8	330	450	360	490
1	475	645	525	710
1 1/8	650	880	720	975
1 1/4	900	1220	1000	1360
1 3/8	1200	1630	1350	1830
1 1/2	1500	2040	1650	2240
1 5/8	2000	2720	2200	2980
1 3/4	2500	3390	2750	3730
1 7/8	3150	4270	3500	4750
2	3800	5150	4200	5700

\* = in-lb. Torque Value

### ™NOTE:

All torque values are dry unless otherwise noted.



# 14.3. Metric Capscrews & Nuts

METRIC CAPSCREWS & NUTS						
Thread Size	Grad	e 8.8	Grade	e 10.9	Grade	e 12.9
mm	ft-lb.	Nm	ft-lb.	Nm	ft-lb.	Nm
6	*60	9	*108	14	*108	14
7	*108	14	14	18	18	23
8	18	25	23	32	27	36
10	30	40	45	60	50	70
12	55	70	75	105	95	125
14	85	115	120	160	145	195
16	130	180	175	240	210	290
18	170	230	240	320	290	400
20	310	420	398	540	478	648

<sup>\* =</sup> in-lb. Torque Value

# ™NOTE:

All torque values are dry unless otherwise noted.

# 14.4. Pipe Plugs (NPFT)

PIPE PLUGS (NPFT)				
Thread Size (in.)	ft-lb.	Nm		
1/8	14 to 18	10 to 13		
1/4	19 to 24	14 to 18		
3/8	24 to 31	18 to 23		
1/2	31 to 39	23 to 29		
3/4	45 to 56	33 to 41		
1	102 to 127	75 to 94		
1 1/4	129 to 161	95 to 119		
1 1/2	149 to 187	110 to 138		



# 15. SI (Metric) CONVERSION FACTORS

U.S. customary or U.S. customary to metric.

Consult the chart below for conversion factors to change metric units of measure to

SI (Metric) CONVERSION FACTORS				
Conversion	From	То	Conversion Factor	
Torque	ft-lb.	Nm	(ft-lb.) x 1.356	
	Nm	ft-lb.	(Nm) x .7376	
Torque	in-lb.	Nm	(in-lb.) x 0.112	
	Nm	in-lb.	(Nm) x 8.85	
Air Pressure	psi	kPa	(psi) x 6.895	
	kPa	psi	(kPa) x 0.145	
Measure	inches millimeters	millimeters inches	(in.) x 25.4 (mm) x 0.039	
Measure	inches centimeters	centimeters inches	(in.) x 2.54 (cm) x 0.394	
Measure	feet	meters	(ft.) x 0.304	
	meters	feet	(m) x 3.28	
Measure	miles	kilometers	(miles) x 1.609	
	kilometers	miles	(km) x .621	
Temperature	Fahrenheit	Celsius	(°F -32°) ÷ 1.8	
	Celsius	Fahrenheit	(°C x 1.8) + 32°	
Volume - fluid	pints	liters	(pts.) x 0.473	
	liters	pints	(l) x 2.01	
Volume - fluid	quarts	liters	(qts.) x 0.946	
	liters	quarts	(l) x 1.06	
Fuel Performance	m/g	km/l	(m/g) x 0.425	
	km/l	m/g	(km/l) x 2.353	
Volume - fluid	gallons	liters	(gal.) x 3.785	
U.S.	liters	gallons	(l) x .264	
Volume - fluid	gallons	liters	(gal.) x 4.546	
Imp.	liters	gallons	(l) x .220	
Volume - Displacement	cubic inches	liters	(in <sup>3</sup> ) x 0.016	
	liters	cubic inches	(l) x 61.02	
Volume - Displacement	cubic feet	liters	(ft <sup>3</sup> ) x 28.3	
	liters	cubic feet	(l) x 0.0353	
Weight	ounces	grams	(oz.) x 28.35	
	grams	ounces	(gr.) x 0.035	
Weight	pounds	kilograms	(lb.) x 0.454	
	kilograms	pounds	(kg.) x 2.204	
Density	lb/gal	kg/l	(lb/gal) x 0.119	
	kg/l	lb/gal	(kg/l) x 8.46	



# **Preventive Maintenance**

1.	SAFET	Υ	PM-1
	1.1. Safe	ety Procedures	PM-1
		ulation Foam Safety	
2.	PREVE	NTIVE MAINTENANCE	PM-2
	2.1. Intr	oduction	PM-2
		ar Axle Operating Conditions	
		n-In Maintenance	
		nditional Maintenance	
		ventive Maintenance Guide	
		ly Preventive Maintenance	
	2.6.1.		
	2.6.2.	Operational Check	
	2.6.3.	Wheelchair Ramp	
	2.6.4.	Wheelchair Tie-Down & Occupant Restraints	
	2.6.5.	Bike Rack Inspection	
	2.6.6.	Floor Covering	
	2.6.7.	Crankcase Breather Tube	
	2.6.8.	Aftertreatment Exhaust Piping	
	2.6.9.	Air Intake Piping	
		Fire Suppression System	
		ekly Preventive Maintenance	
		Radiator	
	2.7.2.	, (	
		nthly Preventive Maintenance	
	2.8.1.	Bike Rack General Maintenance Inspection	
	2.8.2.	Air Tanks	
	2.8.3.	Fire Suppression System	
	2.8.4.	Fire Extinguisher	
	2.9. Qua	arterly Preventive Maintenance	PM-16
	2.9.1.	Radiator	PM-16
		9.1.1. Inspection	
		9.1.2. Power Washing	
		9.1.3. Grounding Wires	
		9.1.4. System Diagnostic Data	
	•	00 Miles (9,600 km) Preventive Maintenance	
	2.10.1	Disc Brake Pad Inspection	PM-19



2.10.2. Wheels & Tires Inspection	PM-19
2.10.3. Transmission Inspection	
2.10.4. Driveshaft	PM-21
2.10.4.1.Inspection	PM-21
2.10.4.2.Lubrication	PM-22
2.10.5. Steering System Inspection	PM-22
2.10.6. Steering Driveshafts	
2.10.6.1.Inspection	PM-25
2.10.6.2.Universal Joint Lubrication	PM-27
2.10.6.3.Telescoping Spline Lubrication	PM-28
2.10.7. Steering Damper	PM-29
2.10.7.1.Cylinder Damping Inspection	PM-30
2.10.8. Engine Oil & Filter Change	PM-31
2.10.8.1.Engine Oil Change Intervals	PM-32
2.10.9. Primary (Suction) Fuel Filter Replacement	PM-33
2.10.10.Secondary (Pressure) Fuel Filter Replacement	PM-35
2.10.10.1.Fuel System Priming	PM-36
2.10.11.Exhaust System	PM-36
2.10.12.DEF Tank	PM-37
2.10.12.1.Filler Cap Cleaning	PM-37
2.10.13.Cooling System	PM-38
2.10.13.1.Radiator	PM-38
2.10.13.2.Coolant Level	PM-39
2.10.13.3.Antifreeze	
2.10.13.4.Supplemental Coolant Additives	
2.10.14.Shock Absorber Inspection	
2.10.15.Ride Height	PM-41
2.10.16.Air Springs	
2.10.17.Front & Rear Axles & Suspension	PM-41
2.10.18.Radius Rods	. PM-42
2.10.19.Air System Functional Tests	PM-42
2.10.20.Driver's Window	PM-43
2.10.21.Window Emergency Release System	PM-43
2.10.22.Interior & Exterior Access Doors	PM-43
2.10.23.Roof Vent/Hatch	PM-44
2.10.23.1.Coatings & Cleaners	PM-44
2.10.24.Splash Guards	PM-45
2.10.25. Windshield Wiper & Washer	PM-45
2.10.26.Driver's Seat	
2.10.27.Passenger Seats	
2.10.27.1.General Cleaning	
2.10.27.2.Tough Stain & Graffiti Removal	
2.10.27.3.Vacuum Formed Plastic Components	
2.10.27.4.Upholstery Care	PM-46
2.10.28.Stanchions & Grab Rails	PM-46
2.10.29.Wheelchair Tie-Down & Occupant Restraints	PM-46
2.10.30.Interior Panels	PM-46
2.10.31.Exterior Panels	PM-46
2.10.32.Mirrors	. PM-46
2.10.33.Battery System	



2.10.34.Wheelchair Ramp Inspection	PM-48
2.10.34.1.Mechanism	
2.10.34.2.Skid Plate	PM-49
2.10.34.3.Lubrication	
2.10.35.Driver's Heater/Defroster Inspection	
2.10.36.Floor Heaters	
2.10.37.HVAC Return Air Filter	PM-51
2.10.38.Rear Axle Breather Tube	
2.10.38.1.Breather Valve Replacement	
2.10.39.Engine Compartment Line Routing Inspection	PM-53
2.10.39.1.Line Condition Inspection	
2.10.39.2.Line Routing Inspection	
2.11. 7,500 Miles (12,000 km) Preventive Maintenance	PM-56
2.11.1. Air Filter Restriction Indicator Inspection	PM-56
2.11.2. Air Filter Replacement	PM-57
2.11.2.1.Removal	PM-58
2.11.2.2.Inspection	
2.11.2.3.Installation	
2.11.3. Charge Air Cooler & Piping	PM-59
2.12. 12,000 Miles (19,300 km) Preventive Maintenance	PM-60
2.12.1. Electronic Accelerator	PM-60
2.12.2. Driver's Heater/Defroster	PM-61
2.12.3. Floor Heaters	PM-61
2.13. 15,000 Miles (24,000 km) Preventive Maintenance	PM-62
2.13.1. Cooling System Pressure Test	
2.13.2. Coolant Filter Replacement	
2.14. 18,000 Miles (29,000 km) Preventive Maintenance	
2.14.1. Engine Mounts	
2.14.1. Engine Mounts	
2.15. 24,000 Miles (38,600 km) Preventive Maintenance	
2.15.1. Brake Treadle Assembly & Brake Valve	
2.16. 30,000 Miles (48,000 km) Preventive Maintenance	
2.16.1. Fuel Tank	PM-65
2.16.2. Engine Drive Belts	PM-65
2.17. 36,000 Miles (58,000 km) Preventive Maintenance	PM-66
2.17.1. Disc Brake Caliper Inspection	PM-66
2.17.2. Power Steering Fluid	
2.17.3. Rear Axle Oil Change	
2.17.3.1.Drain	
2.17.3.2.Fill	PM-67
2.18. 48,000 Miles (77,200 km) Preventive Maintenance	PM-68
2.18.1. Front End Alignment	
2.18.2. Front & Rear Brake Chambers	
2.18.2.1.Front Brake Chambers	
2.18.2.2.Rear Brake Chambers	
2.19. 54,000 Miles (87,000 km) Preventive Maintenance	
2.19.1. Rear Axle Oil Change	
2.20. 60,000 Miles (96,000 km) Preventive Maintenance	
2.20. 00,000 whies (30,000 km) Preventive Maintenance	PIVI-/U



2.20.1. Fuel rank	
2.20.2. Air Compressor Discharge Lines	PM-70
2.20.3. Crankcase Breather Element	PM-70
2.20.3.1.Removal	PM-70
2.20.3.2.Inspection & Cleaning	PM-71
2.20.3.3.Installation	
2.21. 75,000 Miles (120,700 km) Preventive Maintenance	PM-72
2.21.1. Transmission Filters	
2.22. 96,000 Miles (154,500 km) Preventive Maintenance	
2.22.1. Front End Alignment	
2.23. 150,000 Miles (241,400 km) Preventive Maintenance	
2.23.1. Transmission Fluid	
2.24. 200,000 Miles (321,000 km) Preventive Maintenance	PM-74
2.24.1. Muffler Particulate Filter	PM-74
2.24.2. Diesel Exhaust Fluid Filter	PM-75
2.24.2.1. Removal	PM-75
2.24.2.2.Cleaning & Inspection	PM-75
2.24.2.3.Installation	
2.24.3. DEF Tank Inlet Filter	PM-77
2.25. Six Month Preventive Maintenance	PM-79
2.25.1. D-2 Governor	PM-79
2.25.2. PR-2 Pressure Protection Valve	
2.25.3. ST-1 Safety Valve	
2.25.4. SR-7 Spring Brake Modulating Valve	
2.25.4.1.Operating Test	
2.25.4.2.Leakage Test	
2.25.5. SC-1 Single Check Valve	
2.25.6. DC-4 Double Check Valve	
2.25.7. RV-1 Pressure Reducing Valve	
2.25.8. RV-3 Pressure Reducing Valve	
2.25.9. R-14 Brake Relay Valve	
2.25.10.Brake Foot Valve	
2.25.11.Oil/Water Separator	
2.25.12.Steering Knuckle	
2.25.13.Engine Compartment Access Door Inspection	
2.25.14.Fire Suppression System	
2.25.15.Primary (Suction) Fuel Filter	
2.25.16.Power Steering Miter Box	
2.26. Yearly Preventive Maintenance	
2.26.1. Door Sensitive Edge Inspection & Test	PM-83
2.26.2. Fuel Hoses	
2.26.3. Wheelchair Ramp Pump	PM-83
2.26.3.1. Hydraulic Fluid	
2.26.3.2.Screen & Filter Inspection	
2.26.4. Instrument Panel & Side Console	PM-85
2.26.5. Fire Extinguisher	
2.26.6. QR-1 Quick Release Valve	PM-85
2 26 7 Air Strainer	PM-85



2.26.8. Radiator	PM-86
2.26.9. Headlight Aim	PM-86
2.26.10.Oil/Water Separator	PM-86
2.26.11.Primary (Suction) Fuel Filter	PM-86
2.27. Two Year Preventive Maintenance	PM-87
2.27.1. Cooling System	PM-87
2.27.1.1.Coolant	
2.27.1.2.Radiator External Cleaning	PM-87
2.27.1.3.Radiator Internal Cleaning	PM-87
2.27.2. Alternator Bearing Replacement	
2.27.3. Air Dryer	
2.27.4. Fire Suppression System	
2.27.5. Door System Inspection	
2.27.5.1.Connecting Rods & Rod End Bearings	
2.27.5.2.Door Shaft Levers & Mounting Hardware	
2.27.5.3.Upper Door Shaft Pivot Bearings	
2.27.5.5.Upper Roller Guide, Brackets, & Bearings	
2.27.5.6.Entrance Door Shaft & Arm Assembly	
2.27.5.7.Exit Door Shaft & Arm Assembly	
2.27.5.8.Door Panels	
2.27.5.9.Door Panel Top & Bottom Seal Assemblies	PM-93
2.27.5.10.Door Operator Proximity Switches	
2.27.5.11.Entrance Door Solenoid Valves	
2.27.5.12.Driver's Door Controller	
2.28. Three Year Preventive Maintenance	
2.28.1. Under Body Inspection	
2.29. Four Year Preventive Maintenance	PM-94
2.29.1. Air Dryer	PM-94
2.30. Five Year Preventive Maintenance	PM-94
2.30.1. Door Operator Proximity Switches	PM-94
2.30.2. Door Component Replacement	PM-94
2.31. Six Year Preventive Maintenance	
2.31.1. Fire Suppression System	
2.31.2. Fire Extinguisher	
2.31.3. Booster Pump	
2.32. Ten Year Preventive Maintenance	
2.32.1. Door Component Replacement	
2.33. Twelve Year Preventive Maintenance	
2.33.1. Fire Extinguisher	
2.33.2. Fire Suppression System	
2.34. Fluid & Lubrication Points	
2.35. Fluid & Lubrication Guide	
2.35.1. MAN Axle Approved Mineral Oils	
2.35.2. MAN Axle Approved Greases	PM-101





# 1. SAFETY

# 1.1. Safety Procedures

This section of the service manual contains procedures which require the mechanics to strictly observe safety procedures in order to ensure personal and equipment safety.

Always ensure that the vehicle is appropriately hoisted and blocked for procedures which require elevating the vehicle. Be aware of the limitations of the blocking equipment, and always ensure that the jarring and shaking created by component removal and installation procedures does not overload the blocks, or cause the vehicle to become unstable.

Certain procedures may require the vehicle be operated in an elevated position in order to accurately troubleshoot and diagnose a problem. If the vehicle must be running while elevated, become familiar with the repair area prior to starting the engine. Take special care in noting areas which will become hot, electrically energized, and areas where moving and rotating components are located. Limit the work in these areas as personal and equipment safety is at risk.

For procedures which involve air lines, ensure the line is safely depressurized prior to disconnecting. Disconnecting pressurized lines will cause solid particles deposited in the line to be uncontrollably propelled, and will also cause the hose end to whip randomly as the air escapes.

During electrical diagnosis procedures an understanding of the vehicle's electric circuits is important to anticipate the results of connecting test equipment. During component removal or installation, ensure the Battery Disconnect switch is in the OFF position.

Failure to follow this procedure may result in personal injury or component failure.

Observe the following procedures involving hydraulic line removal.

- Hydraulic fluid is corrosive and should not be exposed to skin for extensive periods of time
- Wear eye protection at all times.
- Pressurized lines should not be disconnected until the pressure is safely and controllably released.



Follow all proper safety precautions regarding spray painting. Use a filtering mask with the proper filter cartridges for this type of paint. Wear eye protection and proper protective clothing. The paint booth or work area must be properly ventilated, with filtered exhaust fans removing fumes and over spray. Air make-up induction fans should also be used to supply fresh air to the work area. The painting area should be a safe distance from any source of flame, spark or other means of combustion. Atomized paint, thinner, cleaner and solvent fumes are highly volatile with an extremely low flashpoint that can cause explosive combustion. DO NOT smoke or permit anyone else to smoke in or near the painting area.

#### 1.2. Insulation Foam Safety



Insulation foam is installed in the spaces of the frame tubing, between the vehicle inner and outer wall panels. The Insulation Foam is extremely combustible. KEEP OPEN FLAMES AND FLAME SOURCES AWAY FROM THE INSULATION FOAM!

Before performing any work or repairs requiring use of an open flame such as: welding, brazing, acetylene torch cutting or grinding, ensure that the Insulation Foam is either removed from the area being repaired, or is properly shielded from the open flame.



# 2. PREVENTIVE MAINTENANCE

#### 2.1. Introduction

The transit authority is responsible for the performance of all scheduled maintenance as outlined in this preventive maintenance manual to maintain the New Flyer vehicle warranty. New Flyer reserves the right to deny warranty coverage on claims due to lack of maintenance, misuse, abuse or neglect.

The maintenance intervals indicated in this manual are based upon average vehicle use and typical operating conditions. Unusual vehicle operating conditions, such as geographic environmental conditions, will require service at more frequent intervals. It is the customer's responsibility based upon experience with localized environmental conditions and local regulations to determine if more frequent intervals are required. If you are unsure, please contact your New Flyer Customer Service Technical Support representative.

All the described maintenance operations must be performed by qualified personnel using standard shop practices. All replacement parts used for maintenance services or repairs must be OEM parts or parts with equivalent quality and performance. Use of inferior parts will void the warranty. Warranty claims in question must be supported by preventive maintenance records.

Consumable maintenance items such as (but not limited to) lights, light bulbs, lamps,

belts, bushings, and items with progressive wear characteristics, lubricants, fluids, filters, hoses, wiper blades and tires are not covered by warranty.

Refer to the illustrations included with this section as a guide to location of servicing points.

For compliance to warranties covering the following equipment, refer to complete preventive maintenance intervals and procedures contained in the applicable vendor supplied information:

_	gc
	Transmission
	HVAC Unit
	Fire Suppression System

☐ Fngine

# 2.2. Rear Axle Operating Conditions

The rear axle oil change interval is determined by operating conditions that affect the temperature of the oil in the axle. The following criteria have been established to assess the severity of the conditions under which the axle will be operated:

- Moderate Region this description will apply to all regions where the average monthly temperature does not exceed 25°C (77°F) for more than two months of the year.
- ☐ Hot Region this description will apply to all regions where the average monthly temperature exceeds 25°C (77°F) for more than two months of the year.



### 2.3. Run-In Maintenance

Certain procedures described in this section are designed to ensure a smooth vehicle run-in process. Perform the following procedures as part of vehicle run-in. Thereafter, Refer to 2.5. "Preventive Maintenance Guide" on page 4 in this section for regularly scheduled maintenance intervals on this equipment.

- Wheels Check wheel torque upon receipt of vehicle. Refer to Section 1 and 2 of this manual for torque specifications and sequence.
- Driveshaft Lubricate upon receipt of vehicle. Refer to 2.10.4. "Driveshaft" on page 21 in this section for lubrication procedure.
- □ Rear Axle Change oil upon receipt of vehicle, Check oil level after first 3,000 miles (4,800 km). Refer to Section 2 of this manual for oil drain and fill procedure. Refer to 2.35. "Fluid & Lubrication Guide" on page 97 in this section for fluid specification.

### 2.4. Conditional Maintenance

The following items are subject to maintenance on a conditional basis and do not have a specific interval assigned against the maintenance requirement:

- □ Rear Axle Oil Filter Replace the rear axle oil filter whenever the differential is removed from the axle housing. Refer to Section 2 of this manual for replacement procedure.
- □ Rear Axle Wheel Bearings Repack wheel bearings and hub cavity with grease whenever the wheel bearings or grease seals are being serviced. Refer to 2.35. "Fluid & Lubrication Guide" on page 97 in this section for grease specification. Refer to Section 2 of this manual for grease repacking procedure.



# 2.5. Preventive Maintenance Guide

INTERVALS (Daily - Monthly)		
DAILY	WEEKLY	MONTHLY
Exterior Check	Radiator	Bike Rack General Maintenance Inspection
Operational Check	Primary (Suction) Fuel Filter	Air Tanks
Wheelchair Ramp		Fire Suppression System
Wheelchair Tie-Down & Occupant Restraints		Fire Extinguisher
Bike Rack Inspection		
Floor Covering		
Crankcase Breather Tube		
Aftertreatment Exhaust Piping		
Air Intake Piping		
Fire Suppression System		

INTERVALS (Quarterly - 7,500 mi.)		
QUARTERLY	6,000 mi. (9,600 km)	7,500 mi. (12,000 km)
Radiator	Disc Brake Pad Inspection	Air Filter Restriction Indicator Inspection
	Wheels & Tires Inspection	Air Filter Replacement
	Transmission Inspection	Charge Air Cooler & Piping
	Driveshaft	
	Steering System Inspection	
	Steering Driveshafts	
	Steering Damper	
	Engine Oil & Filter Change	
	Primary (Suction) Fuel Filter Replacement	



INTERVALS (Quarterly - 7,500 mi.)		
QUARTERLY	6,000 mi. (9,600 km)	7,500 mi. (12,000 km)
	Secondary (Pressure) Fuel Filter Replacement	
	Exhaust System	
	DEF Tank	
	Cooling System	
	Shock Absorber Inspection	
	Ride Height	
	Air Springs	
	Front & Rear Axles & Suspension	
	Radius Rods	
	Air System Functional Tests	
	Driver's Window	
	Window Emergency Release System	
	Interior & Exterior Access Doors	
	Roof Vent/Hatch	
	Splash Guards	
	Windshield Wiper & Washer	
	Driver's Seat	
	Passenger Seats	
	Stanchions & Grab Rails	
	Wheelchair Tie-Down & Occupant Restraints	
	Interior Panels	
	Exterior Panels	
	Mirrors	
	Battery System	



INTERVALS (Quarterly - 7,500 mi.)		
QUARTERLY	6,000 mi. (9,600 km)	7,500 mi. (12,000 km)
	Wheelchair Ramp Inspection	
	Driver's Heater/Defroster	
	Floor Heaters	
	HVAC Return Air Filter	
	Rear Axle Breather Tube	
	Engine Compartment Line Routing Inspection	

INTERVALS (7,500 - 18,000 mi.)		
12,000 mi. (19,300 km)	15,000 mi. (24,000 km)	18,000 mi. (29,000 km)
Electronic Accelerator	Cooling System Pressure Test	Engine Mounts
Driver's Heater/Defroster	Coolant Filter Replacement	Power Steering Filter
Floor Heaters		

INTERVALS (24,000 - 36,000 mi.)		
24,000 mi. (38,600 km)	30,000 mi. (48,000 km)	36,000 mi. (58,000 km)
Brake Treadle Assembly & Brake Valve	Fuel Tank	Disc Brake Caliper Inspection
	Engine Drive Belts	Power Steering Fluid
		Rear Axle Oil Change (Hot Region Only - see NOTE at the end of this chart)



INTERVALS (48,000 - 60,000 mi.)		
48,000 mi. (77,200 km)	54,000 mi, (87,000 km)	60,000 mi. (96,000 km)
Front End Alignment	Rear Axle Oil Change (Moderate Region Only - see NOTE at the end of this chart)	Fuel Tank
Front & Rear Brake Chambers		Air Compressor Discharge Lines
		Crankcase Breather Element

INTERVALS (75,000 - 150,000 mi.)		
75,000 mi. (120,700 km)	96,000 mi. (154,500 km)	150,000 mi. (241,400 km)
Transmission Filters	Front End Alignment	Transmission Fluid

INTERVALS (200,000 mi Yearly)		
200,000 mi. (321,000 km)	6 MONTHS	YEARLY
Muffler Particulate Filter	D-2 Governor	Door Sensitive Edge Inspection & Test
Diesel Exhaust Fluid Filter	PR-2 Pressure Protection Valve	Fuel Hoses
DEF Tank Inlet Filter	ST-1 Safety Valve	Wheelchair Ramp Pump Hydraulic Fluid
	SR-7 Spring Brake Modulating Valve	Instrument Panel & Side Console
	SC-1 Single Check Valve	Fire Extinguisher
	DC-4 Double Check Valve	QR-1 Quick Release Valve
	RV-1 Pressure Reducing Valve	Air Strainer
	RV-3 Pressure Reducing Valve	Radiator
	R-14 Brake Relay Valve	Headlight Aim
	Brake Foot Valve	Oil/Water Separator
	Oil/Water Separator	Primary (Suction) Fuel Filter
	Steering Knuckle	



INTERVALS (200,000 mi Yearly)		
200,000 mi. (321,000 km)	6 MONTHS	YEARLY
	Engine Compartment Access Door Inspection	
	Fire Suppression System	
	Primary (Suction) Fuel Filter	
	Power Steering Miter Box	

INTERVALS (2 - 5 Years)			
2 YEARS	3 YEARS	4 YEARS	5 YEARS
Cooling System	Under Body Inspection	Air Dryer	Door Operator Proximity Switches
Alternator Bearing Replacement			Door Component Replacement
Air Dryer			
Fire Suppression System			
Door System Inspection			

INTERVALS (6 - 12 Years)				
6 YEARS	10 YEARS	12 YEARS		
Fire Suppression System	Door Component Replacement	Fire Extinguisher		
Fire Extinguisher		Fire Suppression System		
Booster Pump				

# ™NOTE:

Moderate regions are defined as geographic locations where the average monthly temperature does not exceed 25°C (77°F) for more than two months of the year.

Hot regions are defined as geographic locations where the average monthly temperature exceeds 25°C (77°F) for more than two months of the year.



## **Daily Preventive Maintenance**

#### 2.6. **Daily Preventive Maintenance** Window and windshield visibility. Windshield wipers and washer. **Exterior Check** 2.6.1. Destination signs. Wheels are undamaged and studs and Front and rear doors. nuts are secure. Exit door sensitive edge. Tires correctly inflated. Wheelchair ramp. Vehicle is level. Interior and exterior lights. Exterior panels are undamaged. Steering column. No fluid leaks exist under vehicle. Door master switch. No fluid leaks exist at axles. Headlights. Surge tank coolant level is correct. Door manual air release valve. ☐ Power steering reservoir level is correct. Passenger signals. ☐ Engine and transmission fluid levels are correct. Instrument panel gauges. ☐ Fuel tanks are full. ☐ Brake pedal. Diesel exhaust fluid tank is full. Parking brake. ☐ Accelerator. 2.6.2. Operational Check Transmission shift selector. Start the vehicle and check the following for correct condition and operation. ☐ Air system charges to 125 psi within 5 minutes if system is fully depleted. ☐ Low air warning indicator and buzzer. ™NOTE: Instrument panel indicators. If any of these systems do not operate cor-□ Turn signals. rectly, or if a fault indicator illuminates, DO NOT drive the vehicle. Refer to Section 19 Door control. of this manual for details on the correct Mirror condition and adjustment. operation of all vehicle controls.



### 2.6.3. Wheelchair Ramp

Inspect the wheelchair ramp area for cleanliness on a regular basis depending on operating conditions. Exposure to salt, sand, or slush during the winter months may require inspection on a daily basis. Likewise, operating in gritty, dusty conditions during the summer months will require more frequent inspections. Clean any dirt or foreign matter from the ramp, hinge, and operating shaft areas. Inspect the recessed area between the floor and ramp for any accumulation of debris. Manually deploy and stow the ramp to check for smooth operation. Inspect hinge for binding or distortion. Repair or replace hinge as necessary.

## 2.6.4. Wheelchair Tie-Down & Occupant Restraints



If the vehicle was involved in an impact situation, significant enough to have the vehicle towed, then the wheelchair tie-downs, occupant restraints, and anchorages that were in use at the time should be replaced.

The following items should be inspected on a daily basis:

- Check belt retractor mechanism by extending and releasing belt. Ensure belt retractor operates as designed and functions smoothly.
- Inspect belts to ensure webbing is not cut, frayed, damaged, or contaminated by polishes, oils, or chemicals.
- Operate buckles and any locking or release mechanisms. Ensure mechanisms operate smoothly and release completely.

☐ Ensure all floor anchors are secure and free of obstructions, debris and dirt. Tighten mounting hardware as required.

### ™NOTE:

If any mounting hardware requires tightening or adjustment, the fastener must be removed to have the threads cleaned and Loctite 243 reapplied/

- Ensure all wall anchors for belts are properly secured and allow proper freedom of movement.
- Ensure floor surface in wheelchair restraint area is undamaged and free of any condition which would impede use of equipment.
- Ensure the belts are kept clean and recoiled within the retractor when not in use.
- Ensure all labels detailing use of restraint equipment are undamaged and clearly legible.

### 2.6.5. Bike Rack Inspection

Inspect the bike rack on a daily basis as follows:

- Check hex cap nuts for security. Tighten as required.
- Check for presence of end plugs. Replace if missing or damaged.
- ☐ Check for presence of bolts on support arms. Replace as required.
- ☐ Check for presence of magnets which are used for stowing hook arms.
- ☐ Ensure that the hook arms slide smoothly and self stow on magnets.
- Ensure that the latch releases easily without binding.
- ☐ Ensure that the rack pivots freely and locks in both the deployed and stowed position.

## **Daily Preventive Maintenance**

### 2.6.6. Floor Covering



DO NOT clean the vehicle interior with pressure washing equipment. This type of cleaning causes excessive soaking of the floor covering and can result in separation of the rubber floor covering from the floor substrate, warping or deterioration of the floor substrate, and possible damage to floor mounted equipment such as floor heaters.

Inspect the interior flooring for cleanliness on a regular basis depending on operating conditions. Exposure to salt, sand, or slush during the winter months may require inspection on a daily basis.

- ☐ Vacuum or sweep the floor area daily to remove surface soil before it becomes embedded in the rubber floor covering.
- □ Wash the floor using a mild detergent and a minimum amount of water to avoid soaking seams and edge areas.
- □ Visually inspect rubber flooring for gouges, cracks, seam separation, lifting, or any other damage. Refer to Section 12 of this manual for floor covering repair procedures.



Damaged rubber flooring covering must be repaired immediately to prevent water intrusion and subsequent damage to the wood flooring.

#### 2.6.7. Crankcase Breather Tube

Check breather tube for kinks, dents, or other damage. Also check inside of tube for sludge, debris, or ice formation (in freezing conditions). Clean or replace tube as required

### 2.6.8. Aftertreatment Exhaust Piping

Inspect exhaust aftertreatment system for leaks cracks, and loose connections. Inspect for leaks at V-band connections and tighten clamps as necessary.

### 2.6.9. Air Intake Piping

Inspect air intake tubes and hoses, for evidence of wear, punctures, or other damage. Inspect for loose connections and tighten clamps as necessary.

### 2.6.10. Fire Suppression System

Check the operational status of the fire suppression system on a daily basis:

- ☐ Inspect the control panel and confirm that the SYSTEM OK green LED is illuminated.
- Confirm that the FIRE, RELAY RESET, and SERVICE SYSTEM LED's are extinguished

### ™NOTE:

DO NOT operate the vehicle if either the FIRE, RELAY RESET, or SERVICE SYSTEM LED's are illuminated. Contact service personnel to investigate the cause.



### 2.7. Weekly Preventive Maintenance

### 2.7.1. Radiator

Test the function of the fan reverse switch and LED indicator on a weekly basis or any time service work is being performed in the engine compartment. Operating the fan reverse switch will not only clear debris from the radiator core, but will also confirm operation of the LED indicator which is used to display diagnostic fault codes. If any active fault codes are indicated, refer to Section 6 of this manual for trouble-shooting and vendor information.

### 2.7.2. Primary (Suction) Fuel Filter

### ™NOTE:

The frequency at which water should be drained from the fuel filter will be determined by operating conditions that would allow moisture or condensation to enter the fuel system. The drain interval may need to be adjusted dependent on the

amount of water collected during the inspection.

Drain any accumulated water from the fuel filter on a weekly basis as follows:

- 1. Set the Battery Disconnect switch to the OFF position.
- Open the vent cap located on top of the clear cover.
- Place a suitable plastic or metal container of at least 8 ounces capacity beneath the drain valve at the base of the fuel filter.
- 4. Open the drain valve and allow any water to drain out of the fuel filter. Close the drain valve as soon as clean fuel begins to flow out of the drain. Drain the least amount of fuel as possible.
- 5. Hand-tighten the vent cap.
- Start the engine and operate at fast idle for at least one minute to purge any air from the system.

## **Monthly Preventive Maintenance**

### 2.8. Monthly Preventive Maintenance

## 2.8.1. Bike Rack General Maintenance Inspection

Inspect the bike rack on a monthly basis as part of general maintenance. In addition to the general maintenance inspection, perform specific servicing and repairs resulting from the monthly general maintenance inspection. Refer to Section 13 of this manual for specific servicing and repair procedures.

- ☐ Ensure that the rack swings freely between stowed and deployed positions.
- Ensure that the release latch functions easily without binding in the release position.
- ☐ Ensure that the release latch locks securely in both the stowed and deployed positions.
- Ensure that the support arm hinge permits the support arm to raise and lower without binding.
- ☐ Ensure that the support arm magnet contacts and retains the support arm. Adjust magnet position as required.

- Ensure that the support arm hooks pull out smoothly, stop at the stop screw, slide easily into the stowed position, and self stow on the magnet when released.
- ☐ Check the pivot bolt assemblies to ensure they are tight.
- ☐ Check pivot bolt bronze oilite bushings for wear or cracks. Replace as necessary.
- Check that all mounting bracket fasteners are tight, including the hardware for the support strap, quadrant, pivot plate to bracket pieces, and bracket pieces to vehicle bumper/structure.
- □ Two black plastic end plugs are installed in the main frame of the rack located near the ends of the lowering tube.
- ☐ Check torsion spring wear pad for excessive wear or loose attachment to frame.
- Check torsion spring pivot bolts for tightness.
- ☐ Ensure that the instruction labels are intact and legible. Replace any damaged or illegible labels. Clean the bike rack surface with isopropyl alcohol before applying new label.
- ☐ Inspect stainless steel surfaces for evidence of surface rust. Use naval jelly to remove rust.



### 2.8.2. Air Tanks

It is recommended that all air tanks be drained monthly and a record of the contents collected be recorded. Performing these inspections on a regular basis will establish trend monitoring to assess the performance of the compressor (excessive oil passing) and air dyer (saturated desiccant cartridge).

The following factors can influence that amount of water collected and should be taken into consideration before making an assessment:

- An outside air source was used to charge the system and did not pass through the air dryer.
- Exceptionally high air usage, exceeding 25% compressor duty cycle due to either heavy accessory demand or system leakage
- □ Daily temperature range exceeds 30°F (17°C) resulting in condensation. Under these conditions the presence of small amounts of moisture is normal and should not be considered as an indication that the air dryer is not functioning properly.

### MOTE:

A small amount of oil in the system is not unusual and should not be considered a reason to replace the desiccant cartridge. Oil stained desiccant can function adequately.

Perform the air tank drain and collection process as follows:

- Obtain Bendix BASIC test kit P/N 5013711 or equivalent.
- 2. Park the vehicle on level ground and chock the wheels.
- 3. Place the collection cup at each drain valve and slowly drain the air tank. Repeat this process for all air tanks and collect total contents in a single collection cup.
- Allow contents in collection cup to settle and assess whether fluid is primarily water, oil, or an emulsion.

- Evaluate volume collected as follows:
  - a. More than one unit of oil in a 30 day period will require the desiccant cartridges to be changed and is considered cause for further inspection of the air compressor. Worn pistons or rings will allow oil bypass and may require repair if amount of oil bypassed is excessive. Also inspect compressor discharge line for excessive carbon buildup.
  - More than one unit of water or emulsion will be cause to conduct an air system leakage test. Refer to Section 8 of this manual for procedure.
  - More than five units of water in a 30 day period indicates unsatisfactory air dryer performance. Replace air dryer desiccant cartridges.

### 2.8.3. Fire Suppression System

- Open access door behind streetside light panel, opposite the exit door, to access gauge. See "Fig. PM-1: Fire Suppression Cylinder Inspection" on page 15.
- Check pressure gauge on agent cylinder to ensure it is in the operating (green) range.
- Check all nameplates and instructional labels for legibility.
- Check physical condition of all components for mechanical damage and security of mounting.
- Check nozzles of agent cylinder. Nozzle outlets must be free of obstructions. Blowoff caps must be intact and secure.
- ☐ Ensure pull pin on manual actuator is in place.
- ☐ Test the alarm and LED functions by pressing the diamond-shaped "PRESS TO TEST" button on the face of the control panel. The alarm should sound and all LED's should illuminate.

## ™NOTE:

The "Push to Test" function will not cause a system discharge.




Fig. PM-1: Fire Suppression Cylinder Inspection

### 2.8.4. Fire Extinguisher

Inspect the fire extinguisher every month as follows:

- ☐ Ensure the fire extinguisher is securely mounted in its proper location.
- ☐ Check that the safety pin lock is installed.
- ☐ Ensure that the hose is in good condition and the nozzle is not obstructed.
- ☐ Confirm that the cylinder pressure indicated on the gauge is within the green operating range.



# 2.9. Quarterly Preventive Maintenance

### 2.9.1. Radiator

### ™NOTE:

The inspection interval is dependent on local operating conditions. Exposure to harsh conditions such as salt, dirt, and debris may require more frequent inspections. Operating in a less harsh environment, in combination with regular fan reversal operation, may allow for extended inspection intervals.

Inspect and clean the radiator on a quarterly basis or more frequently if operating under harsh conditions.

### 2.9.1.1. Inspection

- Check hose connections and tighten clamps as necessary. Cracked, swollen or deteriorated hoses must be replaced.
- Check radiator and charge air cooling cores for leaks and for accumulation of dirt which obstructs air passage. As required, operate the fan reverse button on the engine gauges panel to assist in removing debris from the cores. Repair all cooling system leaks immediately. See "Fig. PM-2: Radiator Inspection" on page 18.
- 3. Inspect the radiator mountings and tighten mounting bolts when necessary.
- Inspect for clearance between fan blades and radiator core and fan shroud.
- Inspect air recirculation seals at baffles around radiator assembly. Seals must be in good condition.
- 6. Inspect fan blades for cracks, broken tips, or other damage.
- Inspect charge air cooler hoses and piping for leaks, holes, cracks, or loose connections.
- Inspect the fan main harness and system controller electrical connectors to ensure they are clean and properly connected. Ensure harness is properly routed and secured. Open the connectors and inspect

terminals for dirt or corrosion. Clean as necessary with contact cleaner and a stiff bristle brush. Reapply a small amount Dow Corning DC4 dielectric grease on the top of the female connector and reconnect.

Repair or replace any defective part. Refer to Section 6 of this manual for procedure.

### 2.9.1.2. Power Washing



DO NOT use excessive pressure or place washer wand within close proximity to radiator/CAC core when power washing otherwise damage to the fins could result. Use a pressure of less than 1200 psi to power wash and maintain a minimum distance of 9 inches from the cores. DO NOT direct power wash at product or safety labels.



The use of steam cleaning or pressure washing equipment can force moisture into electrical connectors and cause corrosion of the terminals Avoid directing high pressure spray toward any electrical connectors.

### ™NOTE:

Sodium Chloride (rock salt), Calcium Chloride, and Magnesium Chloride are salts used for road surface treatment during the winter months in areas prone to freezing. These salts are highly corrosive and can accumulate on the radiator assembly and must be removed on a regular basis (monthly when salts are applied to the roads).

Power wash the fan side and heat exchanger side of the radiator in accordance with the following instructions. Use an effective detergent, following manufacturer's instructions, and then flush out the cleanser using the reverse fan cycle and low pressure clean water.

## **Quarterly Preventive Maintenance**

- Clean the exterior of the radiator from the engine compartment side on an "as required" basis. Use power wash equipment at reduced pressures, not exceeding 1200 psi, and maintain a safe distance, no closer than 9 inches from the heat exchanger.
- Clean the exterior of the radiator from the streetside of the vehicle on an "as required" basis. Close the screened radiator door and maintain a minimum distance of 12 inches between the wand of the pressure washing equipment and the screened door. Reduce power washing equipment to not exceed 1200 psi.

### ™NOTE:

If the radiator cannot be satisfactorily cleaned to provide proper airflow across the core, then the unit will need to be removed from the vehicle for soaking and cleaning. Refer to 2.27. "Two Year Preventive Maintenance" on page 87 in this section for cleaning and flushing procedure.

### 2.9.1.3. Grounding Wires

### ™NOTE:

The radiator and coolant tubes are grounded to the vehicle frame to minimize any corrosion resulting from electro-potential differences between dissimilar metals and exposure to electrolytic (salt) solutions. It is important that these grounding connections be maintained.

Inspect the coolant supply and return tubes and ensure that the stainless steel clamps with ground wires are clean, free of corrosion, and securely attached to the tubes.



The fan shroud must not be grounded to the vehicle frame unless the coolant pipes are also grounded.

- □ Inspect the aft side of the radiator shroud to ensure that the ground wire connection is clean, free of corrosion, and securely attached.
- Inspect the three ground wire connection points on the streetside main frame rail to ensure that the connections are not corroded and are securely attached.



### 2.9.1.4. System Diagnostic Data

Observe any inactive faults on EMP cooling systems equipped with diagnostic capabilities. Connect the EMPower Con-

nect Service tool to the vehicle diagnostic port and record any inactive faults. Clear faults and check for any recurring faults at subsequent inspections.




Fig. PM-2: Radiator Inspection



## 2.10. 6,000 Miles (9,600 km) Preventive Maintenance

### 2.10.1. Disc Brake Pad Inspection

Visually check brake pad wear every 6,000 miles (9.600km) or every 3 months, whichever occurs first. Refer to "Brake Pad Wear Inspection" in Section 1 and 2 of this manual for inspection procedure.

### 2.10.2. Wheels & Tires Inspection

☐ Visually inspect front tires for unusual tread wear indicating wheels are out of

- alignment, suspension damage has occurred or tires are not properly inflated.
- ☐ Visually check front wheel rims and outside rear wheel rims are not bent, cracked or damaged.
- ☐ Check tires are same make, model and size.
- ☐ Check wheels are balanced.
- ☐ Check wheel nuts are tightened to the specified torques. Refer to Section 1 and Section 2 of this manual for specifications.

### 2.10.3. Transmission Inspection

Every 6,000 miles (9,600 km) inspect the transmission for the following conditions:

- ☐ Loose bolts (transmission to engine attachment and driveline components).
- ☐ Oil leaks (correct immediately).
- □ Worn or frayed electrical harnesses, improper routing. See "Fig. PM-3: Transmission Inspection" on page 20.
- Damaged or loose oil lines.
- Worn or out-of-phase driveline yokes and slip joints.

- Clogged or dirty breather. Replace as required.
- ☐ Transmission fluid that is discolored, has a strong odor, or has exceeded oil analysis limits.
- ☐ Presence of engine coolant in the transmission fluid.

## ™NOTE:

Transmission overhaul is required when the transmission has been contaminated with engine coolant.

☐ Presence of transmission fluid in the engine cooling system.




Fig. PM-3: Transmission Inspection

### 2.10.4. Driveshaft

### ™NOTE:

For initial run-in period, lubricate driveshaft upon receipt of vehicle. Thereafter, lubricate every 6,000 miles (9,600 km).

### 2.10.4.1.Inspection

Inspect the driveshaft as follows:



ALWAYS replace fasteners with new OEM parts. DO NOT reuse bolts, bearing strap, or locking plate.

- ☐ Check for a bent tube, evidence of missing balance weights, or other damage. Remove any buildup of foreign material on the shaft.
- ☐ Check that the lugs (ears) of the yokes on the slip yoke are aligned in the same plane (in phase) with the lugs (ears) of the tube yoke. Disassemble and realign shafts if not found to be in phase.
- □ Visually inspect the torque witness marks on the driveshaft fasteners. If the marks are illegible or misaligned, replace the fasteners with new OEM fasteners, torque to specification, and apply torque witness mark. Refer to Section 2 of this manual for torque procedure and specifications.
- ☐ Inspect locking plate tabs to ensure they are properly bent up and securing the hex bolts on the bearing cups.
- ☐ Check the output shaft of the transmission and the pinion shaft of the drive axle for excessive radial movement.

- ☐ Check for play in the universal joint by inserting a pry bar against the yoke and prying against the universal joint. Any lateral or sideways movement of u-joint cross within the bearing cap exceeding 0.006 inch is cause for rejection.
- ☐ Check for spline wear using a dial indicator and magnetic base mounted on the driveshaft. See "Fig. PM-4: Driveshaft Spline Inspection" on page 21. Manually applying a push/pull force to the yoke as shown. Indicator reading should not exceed 0.015". Excessive movement will necessitate disassembly and further inspection of the driveshaft to determine cause.
- ☐ Inspect driveshaft guard to ensure it is undamaged and securely mounted.
- Inspect driveshaft access door from interior of vehicle to ensure that it is securely latched.




Fig. PM-4: Driveshaft Spline Inspection



### 2.10.4.2.Lubrication

Refer to 2.35. "Fluid & Lubrication Guide" on page 97 in this section for lubricant specification.

### ™NOTE:

For initial run-in period, lubricate driveshaft upon receipt of vehicle and thereafter inspect and lubricate every 6,000 miles (9,600 km).

### **Universal Joint**

- Purge lubricate the universal joint by handpumping grease into the u-joint grease fitting until grease emerges from all four sealing lips. Do not exceed 5,000 psi grease pressure, otherwise the bearings will be over-pressurized. Refer to Fig. PM-5: "Driveshaft Lubrication Points" on page 22
- If grease does not purge from all grease seals, proceed as follows:
  - Use a rubber or brass mallet and tap the yoke ear that is located 180° opposite the cap that won't purge. Regrease the u-joint.
  - b. If the previous step was unsuccessful, hold onto the yoke, and while pushing or pulling the yoke away from the cap that won't purge. Regrease the u-joint.
  - c. If the previous two steps were unsuccessful, loosen the bearing plate bolts 1/16". Regrease the u-joint.
  - d. If the previous three steps were unsuccessful, remove the driveshaft from the vehicle and remove u-joint to inspect for cause of blockage. Replace u-joint if required.



DO NOT apply excessive amounts of grease or use high pressure application when lubricating the telescoping spline. Excessive grease can fill the lube cavity in the yoke end of the tube and could restrict length compensating travel.

### **Telescoping Spline**

Apply no more than one ounce of grease at the grease fitting located on the yoke of the spline shaft. Grease should purge from the pressure relief valve in the cup, as well as the dust cap on the opposite end of the slip yoke.




Fig. PM-5: Driveshaft Lubrication Points

### 2.10.5. Steering System Inspection

### RNOTE:

ALWAYS check wheel alignment following replacement of drag link, center link, or tierod ends or any steering components that were damaged.

- □ Visually inspect all steering components for any evidence of damage. See "Fig. PM-6: Steering Gear Inspection" on page 23.
- ☐ Inspect the steering gear driveshaft for worn u-joints or loose clamp nuts.
- Visually inspect steering gear pitman arm and ensure retaining nut is properly locked.
- ☐ Inspect the tie-rod ends on the drag link, steering idler arm, and center link for excessive play. Use a pry bar to lever the component and inspect for excessive movement. Refer to Section 3 of this manual for specific inspection procedures.

### ™NOTE:

Excessive movement of the tie rod end typically indicates a worn ball socket and the tie-rod end will require replacement. However if movement is due to a loose fit of the tie-rod end tapered pin in the steering arm, do not attempt to re-tighten the castle nut. Remove the tie-rod end and inspect the bore of the steering arm for wear.

□ Perform a visual torque inspection of all steering component fasteners, including the lock nut on the steering stop adjusting bolt. Ensure that the torque witness marks are in alignment. Any fastener that has illegible or missing witness marks should be re-torqued to specification. Refer to Section 3 of this manual for torque specifications.

### ™NOTE:

If the witness marks are no longer aligned, it is an indication that the fastener has loosened and it will be necessary to replace the fastener, torque to specification, and reapply torque witness mark.

Inspect steering gear, hydraulic pump, and hoses for evidence of leakage.



ALWAYS wipe clean the area around the filler cap before removing to prevent contaminants from entering the system.

Inspect hydraulic reservoir fluid level and condition. Replace fluid if dirt, sludge, or water is evident in the system.

### ™NOTE:

If hydraulic fluid appears frothy it is likely that air is trapped in the system and needs to be bled. Refer to Section 3 of this manual for power steering bleeding procedure.

Check for smooth operation while turning the steering system through a full left and full right turn, Ensure that the power steering gear relief valve activates before contacting steering stops. Refer to Section 3 of this manual if steering stop adjustment is required.




Fig. PM-6: Steering Gear Inspection

### 2.10.6. Steering Driveshafts

Inspect and lubricate the upper (vertical) and lower (horizontal) steering driveshafts

every 6,000 miles (9,600 km). See "Fig. PM-7: Steering Driveshaft Inspection" on page 24.




Fig. PM-7: Steering Driveshaft Inspection

### 2.10.6.1.Inspection

The steering driveshaft will exhibit a certain amount of movement when rotated or forced side to side and can be attributed mostly to U-joint movement. The following inspection provides procedures and allowable limits specific to each area of the steering driveshaft. Do not reject the steering driveshaft for overall play unless one or more of the following inspection points exceeds maximum allowable limits.

- 1. Visually inspect the steering driveshafts for any evidence of damage.
- 2. Visually check torque witness marks on clamp fasteners.
- Inspect the U-joints to ensure that all snap rings are installed and fully seated within the groove on the bearing cup. The bearing cup must not protrude any more than 0.105" beyond the surface of the yoke bore. See "Fig. PM-8: Snap Ring Inspection" on page 26.
- 4. Inspect the U-joint cross for end play movement within the bearing cups:
  - a. Restrain the end yoke from moving and apply lateral side to side force on each U-joint. Note the total back and forth movement of the U-joint cross within the bearing cups. Maximum allowable end play is 0.012" (0.30 mm). See "Fig. PM-9: Steering Driveshaft U-Joint Inspection" on page 26.
  - Repeat the previous step on the same U-joint except apply pressure 90° from previous location.

### ™NOTE:

If any of the above readings are suspect, remove the steering driveshaft from the vehicle and clamp the yoke in a vise and measure movement with a dial indicator to confirm.

- Inspect the U-joint for worn needle bearings and/or cross trunnions:
  - a. Apply back and forth rotational force to the yokes on the U-joint and note any relative movement between the U-joint cross and the bearing cups.

 No perceptible movement is allowed. Replace steering driveshaft as an assembly.

### ™NOTE:

U-joints are not field replaceable, but may be serviced by the manufacturer. Contact Prop Shaft Supply in Elkhorn, Wisconsin for further information on driveshaft overhaul.

- Inspect the steering driveshaft end yokes for excessive play:
  - a. Apply lateral side to side force on each end yoke and note the deflection in the area where the end yoke splines are clamped to the attaching component. See "Fig. PM-10: Steering Driveshaft End Yoke Inspection" on page 26.
  - b. Spline movement should be minimal. If the amount of spline movement is questionable, remove the steering driveshaft for closer inspection of the splines as well as the male splines on the attaching component.
- 7. Check for excessive movement or backlash in the telescoping slip-joint:
  - a. Grasp the male and female members of the telescoping slip-joint and apply a back and forth twisting motion while observing or feeling for movement. See "Fig. PM-11: Steering Driveshaft Spline Backlash Inspection" on page 26.
  - Spline movement should be minimal. If the amount of spline movement is questionable, remove the steering driveshaft for closer inspection of the telescoping splines.
- 8. If telescoping slip-joint is disassembled, check the nylon coating on the splines for wear, cuts, gouges, or any other damage.
- If damage is evident, the nylon coating must be stripped from the splines and reapplied. Contact Prop Shaft Supply in Elkhorn, Wisconsin for further information on driveshaft overhaul.






Fig. PM-8: Snap Ring Inspection



Fig. PM-10: Steering Driveshaft End Yoke Inspection




Fig. PM-9: Steering Driveshaft U-Joint Inspection




Fig. PM-11: Steering Driveshaft Spline Backlash Inspection

### 2.10.6.2. Universal Joint Lubrication

- 1. Locate the grease fittings on the universal joints at both ends of the driveshaft.
- Purge lubricate through the grease fittings until fresh grease flows out of all four bearing cup seals. Refer to 2.35. "Fluid & Lubrication Guide" on page 97 in this section for grease specifications. See "Fig. PM-12: Steering Driveshaft Lubrication Points" on page 27.
- If all four bearing cups do not purge lubricate successfully, then it will be necessary
  to remove the steering driveshaft from the
  vehicle and tap the opposite cap or rotate
  the adjacent yoke through its full range of
  motion while applying grease.
- 4. Wipe off excess grease from universal joint.




Fig. PM-12: Steering Driveshaft Lubrication Points

# NEW ELVER

## 6,000 Miles (9,600 km) Preventive Maintenance

### 2.10.6.3. Telescoping Spline Lubrication

- Remove the clamping bolt on one end of the steering driveshaft and compress the shaft completely.
- 2. Locate the grease fitting on the driveshaft slip sleeve and apply grease with 8 to 10 hand pumps.
- Fully extend and compress shaft a few times to ensure grease is applied to full length of spline.
- Completely remove yoke shaft and check the seal of the dust cap. Grease must completely fill between both lips of the seal. See "Fig. PM-13: Steering Driveshaft Seal Inspection" on page 28.
- 5. If dust cap seal is not completely greased, return the yoke shaft to the compressed position and repeat greasing procedure.

### ™NOTE:

Ensure the driveshaft is properly reassembled with alignment arrows facing each other. This will ensure the driveshaft remains in phase.

6. Wipe off excess grease from the slip spline.




Fig. PM-13: Steering Driveshaft Seal Inspection

### 2.10.7. Steering Damper

Inspect the steering damper every 6,000 miles (9,600 km) as follows:

- □ Check for excessive play at ball joints ends. See "Fig. PM-14: Steering Damper Inspection" on page 29.
- Inspect for any external damage to cylinder or piston rod. Replace damper if bent or damaged.
- ☐ Check for evidence of leakage. Replace damper if leaking.
- Inspect condition of protective sleeve on cylinder and ensure it can move freely and extend approximately 2 inches from cylinder.
- ☐ Inspect exterior surfaces for evidence of corrosion. Clean light surface rust, otherwise replace damper if badly corroded.

## ™NOTE:

If maintenance records indicate that the vehicle is experiencing front end steering shimmy, then a cylinder damping inspection should be performed.




Fig. PM-14: Steering Damper Inspection

# NEW ELYER

## 6,000 Miles (9,600 km) Preventive Maintenance

### 2.10.7.1. Cylinder Damping Inspection

- Remove steering damper from vehicle. Refer to Section 3 of this manual for removal procedure.
- 2. Hold the steering damper in a vertical position with the oil chamber at the bottom.
- 3. Extend the piston rod fully by hand.
- Operate the steering damper twice through its full range of travel in both compression and extension strokes.
- Hold the steering damper fully extended in the vertical position for at least one minute.

### ™NOTE:

Ensure that no pressure is applied to the piston rod while it is in the extended vertical position. The plastic protective sleeve should also be in the fully extended position.

- Slowly compress the piston rod into the cylinder while noting both the resistance and distance travelled. Stop compressing the piston once resistance is felt.
- 7. Mark the position of resistance by scribing a line on the plastic protective sleeve that coincides with the position of the metal protective sleeve.
- Retract the piston upwards until the plastic protective sleeve is fully extended. Measure the distance between the edge of the metal protective sleeve and the mark scribed on the plastic protective sleeve. See "Fig. PM-15: Damper Measurement" on page 30.

- The piston rod must not travel more than 0.118 in. (3.0 mm) before damping resistance is felt. Replace steering damper if free travel (slip) exceeds these limits.
- Reinstall steering damper on vehicle. Refer to Section 3 of this manual for installation procedure.




Fig. PM-15: Damper Measurement

### 2.10.8. Engine Oil & Filter Change

### ™NOTE:

Engine oil and filter change intervals are based on average vehicle speed. Refer to 2.10.8.1. "Engine Oil Change Intervals" on page 32 in this section and use whichever interval is the shortest. Oil may be blown out through the crankcase breather if the crankcase is overfilled.

- Run the engine until its operating temperatures reaches 140°F (60°C). Stop the engine.
- 2. Remove the oil drain plug from the bottom of the oil pan. See "Fig. PM-16: Engine Oil Filter" on page 31.
- Allow the oil to drain into a suitable container.
- Clean the area around the oil filter head. Remove the filter and clean the gasket area.

### ™NOTE:

The gasket can stick to the filter head. Ensure it is removed.

- Fill the replacement filter with clean engine oil. Apply a thin film of lubricating oil to the filter gasket and to the gasket sealing surface
- 6. Install the filter on the engine. Follow the directions on the label for correct installation. Do not over-tighten.
- 7. Clean the engine oil pan drain plug threads. Install the drain plug. Torque the plug on installation 60 ft-lb. (81 Nm).
- 8. Fill the engine with new oil. Refer to 2.35. "Fluid & Lubrication Guide" on page 97 in this section for oil specification. Engine capacity is 25.2 quarts U.S. (23.8 liters).
- 9. Start the engine and inspect for leaks at the filter and at the drain plug.
- 10. Stop the engine. Wait 15 minutes to allow the oil to settle. Correct any leaks.
- 11. Check the oil level on the dipstick. Add oil as required to bring the level to the high mark on the dipstick.

### ™NOTE:

Refer to the Cummins Operation & Maintenance Manual for further engine related preventive maintenance operations.




Fig. PM-16: Engine Oil Filter





### 2.10.8.1. Engine Oil Change Intervals

ENGINE OIL CHANGE INTERVALS			
AVERAGE VEHICLE SPEED	INTERVAL		
	Mileage (km)	Operating Hours	Months
10 - 15 mph (16 - 24 km/h)	6,000 (9,600)	500	6
8 - 10 mph (13 - 16 km/h)	5,000 (8,000)	500	6
6 - 8 mph (9.6 - 13 km/h)	4,000 (6,400)	500	6
4 - 6 mph (6.4 - 9.6 km/h)	3,000 (4,800)	500	6
2 - 4 mph (3.2 - 6.4 km/h)	1,500 (2,400)	500	6

## 2.10.9. Primary (Suction) Fuel Filter Replacement

Replace the fuel filter element every 6,000 miles (9,600 km) every six months, or 500 operating hours, whichever comes first. Replace the element earlier if plugging is indicated by the fuel level rising in the filter near the top of the element. See "Fig. PM-17: Engine Fuel Filters" on page 34.

- Place a clean container under the filter.
   Open the drain valve at the base of the
   processor and drain the fuel until it is
   below the level of the collar.
- Close the drain valve and using the filter collar wrench, remove the collar by turning counter-clockwise. Remove the cover and filter element. Remove and retain the large sealing grommet at the base of the element. It will be reused.
- Dispose of the filter element in an environmentally responsible manner, according to applicable government environmental regulations.
- Check to make sure the fuel level is near the top of the elliptical port on the processor.
- After making sure the new O-ring seal is properly positioned at the base of the cover, insert the filter sealing grommet into

the base of the new element. Install the element on the center stud of the processor and replace the cover and collar. Tighten the collar by hand until secure.

### ™NOTE:

To avoid cover or collar damage, DO NOT use the collar wrench or any other tool to tighten the collar.

Remove the vent cap from the top of the clear cover by turning the vent cap counter-clockwise. Fill the clear cover full of clean fuel. Reinstall the vent cap with a new O-ring and tighten by hand only.

### ™NOTE:

To avoid cover or vent cap damage, DO NOT use tools to tighten the vent cap.

Start the engine. When the lubrication system reaches its normal operating pressure, increase engine speed to high idle for 2 to 3 minutes.

### ™NOTE:

The clear filter cover will not fill completely during the engine operation. It will gradually fill over time and the fuel level will rise as the filter media become clogged.






Fig. PM-17: Engine Fuel Filters



### 2.10.10.Secondary (Pressure) Fuel Filter Replacement

Replace the secondary fuel filter every 6,000 miles (9,600 km), six months, or 500 operating hours, whichever occurs first.

### ™NOTE:

The fuel filter is a non-serviceable spin-on type. DO NOT attempt to clean and reuse the filter assembly.



Clean the fuel filter head and surrounding area to prevent the introduction of contaminants into the fuel system.

 Use a filter strap wrench to unscrew the filter assembly from the filter head. Discard the filter. 2. Inspect the filter head to see whether the filter seal ring is stuck to the sealing surface of the filter head. Remove the seal ring with an O-ring pick, if necessary.



DO NOT pre-fill the secondary fuel filter prior to installation. ALWAYS use the engine lift pump to prime the fuel system before starting the engine.

- 3. Inspect new filter to ensure the center seal ring is installed on the filter spud.
- Install the filter in accordance with the instructions provided with the filter. Do not over tighten the filter.
- 5. Prime the fuel system. Refer to 2.10.10.1. "Fuel System Priming" on page 36 in this section for procedure.

# NEW ELVER

## 6,000 Miles (9,600 km) Preventive Maintenance

### 2.10.10.1.Fuel System Priming



DO NOT open the high pressure fuel system with the engine running. High pressure fuel spray can cause serious injury or death.



DO NOT attempt to pre-fill the secondary filter element prior to starting the engine. Filling the filter through the center opening will allow a certain amount of fuel to bypass the 5 micron filter media within the filter, thereby allowing unfiltered fuel into the fuel system and possibly leading to engine fuel pump or injector damage.

Always prime the fuel system prior to starting the engine to avoid excessive cranking intervals, erratic engine operation, or setting engine fault codes. Proceed as follows:

- Locate the engine run switch in the engine compartment and set the switch to the REAR position.
- Allow the engine lift pump to cycle for approximately 30 seconds before it automatically shuts off.

- Reset the run switch from REAR to OFF and then back to REAR position again. The lift pump should cycle for another 30 seconds. Repeat this process three or four times to allow purging all the air from the fuel filter and lines.
- 4. Start the engine and operate at fast idle to purge any remaining air from the system.

### 2.10.11.Exhaust System

Inspect the condition of the exhaust system components every 6,000 miles (9,600 km) as follows:

- ☐ Inspect muffler for any damage to body, sensors, wiring, or mounting brackets.
- ☐ Inspect exhaust blankets for proper installation, ensuring no cuts, tears, or other damage exists.
- ☐ Inspect exhaust tubes for dents, cracks, leaks, or restrictions.
- Inspect exhaust flex connector for proper alignment and any evidence of damage. Refer to Section 4 of this manual for alignment procedure.
- ☐ Ensure all exhaust clamps are properly tightened.
- ☐ Ensure all exhaust system mounting brackets and component fasteners are properly tightened.

### 2.10.12.DEF Tank

### ™NOTE:

The DEF tank inspection interval will be dependent on operating and environmental conditions. Adjust to a more frequent inspection interval if tank exterior is very dirty or if filler cap has a heavy deposit of DEF crystals.

Inspect the DEF tank every 6,000 miles (9,600 km) as follows:

- 1. Inspect security of DEF tank mounts and tightness of fittings, hoses, clamps, and electrical connector.
- Inspect exterior of DEF tank for cleanliness and clean as necessary. Use a low pressure setting and maintain a distance of at least 18" if using pressure wash equipment. DO NOT direct pressure spray at the filler cap/adapter interface.
- Inspect underside of filler cap for a buildup of dirt or DEF crystals. Clean filler cap as necessary. Refer to 2.10.12.1. "Filler Cap Cleaning" on page 37 in this section for cleaning procedure.

### ™NOTE:

The filler cap may be replaced separately if damaged. Refer to your New Flyer Parts Manual for part number.

### 2.10.12.1.Filler Cap Cleaning

- Inspect the immediate area around the filler cap and adapter. Wipe off any accumulations of dirt or crystals from the immediate area so as to prevent contamination from entering the tank when the filler cap is removed.
- 2. Remove the lanyard by sliding the end over the tap on filler cap.
- Rotate the cap counter-clockwise until it comes to a stop. Pull filler cap from DEF tank adapter.
- 4. Place the cap in a pan of clean, warm water filled such that the level of the water is halfway between the bottom of the blue base and the surface of the cap imprinted with the words "DEF ONLY".

### ™NOTE:

Ensure that the cap is not completely immersed in the water as this may affect the venting capabilities of the cap.

- 5. Allow the filler cap to soak in the water for approximately five minutes.
- Remove the filler cap from the water and shake to remove excess water. If any DEF crystals remain on the sealing surface of the cap, wipe the seal with a damp cloth.
- 7. Wipe the tank adapter with a damp cloth and place the filler cap onto the adapter.
- 8. Rotate the filler cap clockwise until the stop is contacted.
- Reattach the lanyard by sliding the small opening of the lanyard over the tap on the cap. Ensure the lanyard is fully seated in the groove of the tab.

# NEW ELVER

## 6,000 Miles (9,600 km) Preventive Maintenance

### 2.10.13.Cooling System

Inspect the coolant fluid level, antifreeze concentration, SCA level, and cooling system components every 6,000 miles (9,600 km),

#### 2.10.13.1.Radiator

- Locate the power and ground studs on the radiator and pull boots back from passthrough stud.
- Wipe grease and any debris from the ring terminal and stud area. Observe if the grease is discolored. If the grease is discolored, thoroughly degrease the area before proceeding.
- 3. Examine the assembly and if corrosion is found, disassemble the ring terminal from the stud and clean the ring terminals and studs with a brass wire brush. Replace any hardware that shows signs of accelerated corrosion. Reassemble and torque to specification. Refer to Section 6 of this manual for assembly torque.

4. Apply 5 grams (5 cc or 1 tsp) of di-electric grease to the power and ground studs on both sides of the pass-through stud. Slide protective rubber boots over exposed nuts and studs. Ensure that the vehicle side power and ground boot is securely snapped onto the bushing to form a seal.

### ™NOTE:

Use Dow Corning DC-4 Electrical Insulating Compound or equivalent. Use a squeeze tube to dispense 5 grams (which is nearly enough to fill the insulation boot) directly onto the stud or into the boot. If grease is dispensed into the boot, squeeze the boot after covering the stud to ensure the grease is worked onto all surfaces of the stud components.

### 2.10.13.2.Coolant Level



DO NOT attempt to open the pressure cap on the surge tank until the system has cooled down and the pressure relief valve has been operated. Opening the pressure cap with pressurized hot coolant can result in scalding injury and loss of coolant.

 Once the system has cooled down, observe the coolant level through the fluid level markings on the recovery tank. The coolant should be between the MIN COLD and MAX COLD lines marked on the recovery tank.

### ™NOTE:

If necessary, the coolant level can be checked while system is hot by observing coolant level through the level markings on the recovery tank. The coolant level should not be above the MAX HOT marking shown on the tank. However, the system must be allowed to cool down before the filter cap is removed.

 Top off coolant to the correct level as required using premix antifreeze. Refer to 2.35. "Fluid & Lubrication Guide" on page 97 in this section for antifreeze specification. See "Fig. PM-18: Surge Tank Inspection" on page 39.




Fig. PM-18: Surge Tank Inspection



### 2.10.13.3.Antifreeze



Overconcentration of antifreeze or use of high-silicate antifreeze can cause engine damage. DO NOT use antifreeze concentrations in excess of 60% or less than 40%.

Use only fully formulated coolants meeting ASTM D6210 specification and Cummins Engineering Standard 14603. Refer to 2.35. "Fluid & Lubrication Guide" on page 97 in this section for coolant specification.

Antifreeze broadens the operating temperature range by lowering the coolant freezing point and raising the boiling point. The corrosion inhibitors protect cooling system components from corrosion and prolong component life.

Use a Refractometer to provide a reliable and accurate measurement of freeze point protection and glycol (antifreeze) concentration. Use pre-mixed anti-freeze of 50% distilled water and 50% ethylene glycol to provide year-round protection of -26°F (-32°F).

### MOTE:

Fleetguard Refractometer, part number CC2806 can be ordered through Cummins Filtration.

Antifreeze should also be checked, on a yearly basis, for contamination such as oil, fuel, grease, solder bloom, silica gel, rust, or scaling. Coolant must be replaced and cooling system cleaned and flushed if contamination is evident. Refer to Section 6 of this manual for basic cleaning and flushing procedures. Also refer to Cummins Operation and Maintenance Manual and Cummins Coolant Requirements and Maintenance Bulletin 3666132 for detailed cleaning and flushing procedures.

### ™NOTE:

Fleetguard Coolant Test Strips can be used to check Sulfate and Chloride levels and can be ordered through Cummins Filtration.

### 2.10.13.4. Supplemental Coolant Additives



Failure to maintain the required SCA concentration level can cause engine damage. DO NOT use sealing additives or soluble oils in the cooling system.

### ™NOTE:

The coolant used in this vehicle is a fully formulated coolant that contains buffering compounds, corrosion inhibitors, and provides liner pitting and scale protection but does not eliminate the need for additive replenishment.

SCA concentration levels must be monitored on a regular basis and maintained between 1.5 and 3.0 units/gal (US). Target concentration level is 2.5 units/gal.

Use Fleetguard coolant test kit, part number CC2602, to check SCA concentration level. Refer to instructions included with the test kit. Refer also to Cummins Operation and Maintenance Manual and Cummins Coolant Requirements and Maintenance Bulletin 3666132 for correct SCA levels and additional information on coolant additives.

If SCA concentration is less than 1.2 units/gal, install a new fully-charged coolant filter of the correct dosage. Refer to your New Flyer Parts Manual for coolant filter part number.

If SCA concentration is greater than 5.0 units/gal, it will be necessary to remove existing coolant filter and replace with a chemical free filter until SCA levels drop to the recommended levels.

### 2.10.14. Shock Absorber Inspection

Every 6,000 miles (9,600 km) check for and replace all shock absorbers damaged or leaking oil. Check the rubber mounting bushings and replace them if worn. Ensure the shock absorber mounting brackets are tight and the shock absorber is not striking or rubbing the frame or some other part of the chassis.

### ™NOTE:

A leaking shock will show clear signs of fluid leaking in streams from the upper seal. These streams can most easily be seen when the shock is fully extended and one inspects as far up the main body of the shock (underneath the dust cover or tube) as possible. Misting shocks are often misdiagnosed as failures. A misting shock will form a film on the entire outside of the shock body. Misting is perfectly normal and a necessary function of the shock.

### 2.10.15.Ride Height

Every 6,000 miles (9,600 km) or after service of air suspension components check the vehicle's ride height. Measure the ride height for the front and rear suspension. Refer to Section 3 of this manual for procedures.

### 2.10.16.Air Springs

### ™NOTE:

The air suspension system requires no lubrication.

☐ Examine air springs assembly for evidence of cracks, punctures, deterioration, or chafing. Replace with new air springs if any damage is evident. Any surface on upper and lower retainers or on piston that touches air springs should be smooth and free of sharp edges that might cause breaks or damage air springs. Check threads on studs.

- Check for air leakage at all air springs upper and lower mountings. Coat mountings with soap and water solution and watch for appearance of soap bubbles. No leakage is permissible. If leakage is evident, rubber air springs must be replaced.
- ☐ Check to see that there is sufficient clearance around the complete circumference of the air spring while at its maximum diameter. Make sure contact doesn't exist between any air system component and the outside diameter of the air spring.
- ☐ Check for tightness on all mounting hardware. Retorque to the proper specifications. Refer to "Suspension Torque Specifications" in Section 1 and 2 of this manual for correct values. Do not overtighten.

### 2.10.17.Front & Rear Axles & Suspension

- ☐ Visually inspect all axle and suspension components for any evidence of damage.
- ☐ Visually inspect all suspension bushings and rubber components for cracks, tears, separation or other damage.
- □ Inspect center link, drag link, and tie-rod ends for excessive play. Use a pry bar to lever the component and inspect for excessive movement. Refer to Section 1 and 2 of this manual for specific inspection procedures.
- □ Perform a visual torque inspection of all axle and suspension fasteners. Ensure that the torque witness marks are in alignment. Any fastener that has illegible or missing witness marks should be retorqued to specification. Refer to Section 1 and 2 of this manual for torque specifications.

### ™NOTE:

If the witness marks are no longer aligned, it is an indication that the fastener has loosened and it will be necessary to replace the fastener, torque to specification, and reapply torque witness mark.

# NEW ELVER

## 6,000 Miles (9,600 km) Preventive Maintenance

### 2.10.18.Radius Rods

### ™NOTE:

The radius rods are of similar configuration except for the upper radius rod on the front axle which does not have tubular construction, replaceable bushings, nor snap-rings. All other inspection criteria apply.

Inspect all radius rods every 6,000 miles (9,600 km) as follows:

- □ Visually inspect torque witness marks on fasteners. If witness marks are not legible, then apply specified torque and paint a witness mark across fastener. Refer to Section 1 & 2 of this manual for torque specifications.
- Visually inspect radius rod tubes for deformation. Replace radius rod as an assembly if tube is deformed.
- ☐ Inspect bushings for wear by using a pry bar. Apply force both axially and laterally while observing movement. Any excessive relative movement between the rubber component of the bushing and the crosspin and/or the eye of the radius rod is cause for bushing replacement.

### ™NOTE:

If axial or lateral movement is suspect, remove radius rod from vehicle and confirm excessive bushing movement by clamping cross-pin in a vise and moving radius rod through its operating range.

- □ Visually inspect rubber component of bushing for cracks or separation. Small cracks are acceptable. Separation of the rubber from the metal cover plate or crosspin is acceptable providing the separation does not exceed 1/3 of the circumference of the bushing.
- Inspect the metal cover plate of the bushing for cracks. Replace bushing if cover plate is cracked.
- ☐ Inspect snap-ring to ensure it is installed and fully seated. Check for shiny wear marks as evidence of snap-ring movement. Replace bushing and inspect condition of snap-ring groove if snap-ring is missing, broken, or has rotated significantly.
- If excessive wear, corrosion or other damage is noted in the snap-ring groove or bore of the radius rod during the course of bushing replacement, then the radius rod should be replaced as an assembly.

### 2.10.19.Air System Functional Tests

Refer to Section 8 of this manual for procedures.

### 2.10.20.Driver's Window

Inspect the driver's window every 6,000 miles (9,600 km) as follows:

- ☐ Slide the forward sash fully aft and ensure the sash slides smoothly and makes contact with the window stop.
- Inspect the condition of the weather-stripping in the lower window channel/track. Clean window channel/track by vacuuming.
- ☐ Inspect the interior and exterior handles to ensure they are securely mounted.

### 2.10.21. Window Emergency Release System

Every 6,000 miles (9,600 km) check and clean the emergency release system of the side windows. The emergency release system must be free of excessive build-up (road salt, dirt and so forth). See "Fig. PM-19: Window Emergency Release" on page 43.

### 2.10.22.Interior & Exterior Access Doors

Every 6,000 miles (9,600 km) lubricate the piano hinges and latch mechanisms. Refer to Sections 12 or 13 of this manual for panel repair procedures.




Fig. PM-19: Window Emergency Release



### 2.10.23.Roof Vent/Hatch

Inspect and clean the roof vent/hatch every 6,000 miles (9,600 km).

- □ At each vehicle cleaning interval use a mild soap and water solution to clean the vent/ hatch surfaces and components. Do not use solvents or petroleum based cleaners or coatings. Do not lubricate its moving parts. Refer to 2.10.23.1. "Coatings & Cleaners" on page 44 in this section for additional information on coatings and cleaners.
- □ Inspect the vent/hatch moving parts every 6,000 miles (9,600 km). Make sure the latches close and fasten securely. The latches must fasten securely, with no slack or looseness. If the attaching hardware cannot be tightened, replace the applicable latch parts using new hardware and fasteners. See "Fig. PM-20: Roof Hatch Inspection" on page 44.
- In cold climates, check daily and remove any accumulated ice and snow that may restrict movement of the vent/hatch.

### 2.10.23.1. Coatings & Cleaners



DO NOT use lubricants, paints, solvents or other coatings such as graffiti deterring sprays or cleaners. These chemicals often contain acetone, ether, lacquer thinner or other solvents that can destroy the high strength properties of many engineering plastics. Any damage, weakening, malfunction or failure of the vent/hatch structure because of using improper coatings or cleaners is the responsibility of the transit property.

Graffiti resistant coatings often leave a sticky residue that interferes with the free movement of the ventilator mechanisms. Some of these coatings also contain solvent bases that will reduce the strength of certain components. Using these types of coatings on vents/hatches is not recommended.

If in doubt about a type of cleaner or coating, apply a very small amount to an obscure, small area of the vent/hatch. Observe how the substance reacts to the surface after a short interval. If the surface starts to craze, soften, discolor or dissolve, DO NOT use it.




Fig. PM-20: Roof Hatch Inspection

#### 2.10.24.Splash Guards

- ☐ Check splash guards every 6,000 miles (9,600 km) for loose bolts and damage.
- ☐ Tighten loose bolts and replace any unserviceable guards.
- ☐ Check that ground clearance is within specifications.

#### 2.10.25. Windshield Wiper & Washer

- ☐ Check wiper operation and condition.
- ☐ Remove any accumulated dirt and grit from the wiper blade.
- ☐ Check that the washer system emits an adequate flow of washer fluid.

#### 2.10.26.Driver's Seat

Inspect the driver's seat every 6,000 miles (9,600 km) as follows:

- Inspect seat mounting points and ensure fasteners are properly tightened.
- Inspect seat belt (if equipped) and ensure webbing is in good condition and belt latches and releases properly.
- Inspect seat track for cleanliness and lubricate if required.
- ☐ Check operation of all seat adjustment controls to ensure they function properly throughout their full range of adjustment.
- Check seat cover for abnormal wear, tears, or deterioration.
- ☐ Clean seat as required using a mild detergent and warm water, followed by a clean water rinse. Do not use harsh chemicals.

#### 2.10.27.Passenger Seats

Inspect the passenger seats every 6,000 miles (9,600 km) as follows:

- Check the mounting hardware for tightness and security. Tighten or replace as required.
- ☐ Inspect seats for rips or tears. Repair, patch or replace as required.

#### 2.10.27.1.General Cleaning

For dirt and general spot removal, fiberglass, composite resin and stainless steel may be cleaned with a non-abrasive, mild household detergent. Test a small, inconspicuous area prior to cleaning. Wipe with a clean, damp cloth and allow to dry.

#### ™NOTE:

Leaving any chemical on fiberglass or composite resin for extended periods can result in damage to the surface. ALWAYS rinse with water after cleaning.

#### 2.10.27.2.Tough Stain & Graffiti Removal

Markings and stains from permanent marker and other compounds like shoe polish or nail polish can be removed from fiberglass, composite resin and stainless steel materials with the following agents (or equivalents):

- ☐ Crown Anti-Vandal Spray 5062 (contains VOC's)
- ☐ TSW9 Plasti-Master (does not contain VOC's)

#### ™NOTE:

For Vision Seats, Scotch-Brite pads can be used to remove graffiti markings and return the surface to its original appearance.

#### 2.10.27.3. Vacuum Formed Plastic Components

Use TSW9 Plasti-Master when removing graffiti markings from vacuum-formed plastic components.



#### 2.10.27.4. Upholstery Care



Extreme care should be taken when selecting a cleaning agent. Solvent-based cleaners should be avoided. Some solutions may leave a residue or discolor the material. Test an inconspicuous area prior to cleaning and follow the manufacturer's directions.

Regularly remove all dust and loose dirt from fabric with a whisk broom or vacuum cleaner. Always begin with lukewarm water and a white cloth for stain removal before applying any cleaning agent. Use foam upholstery cleaner or a mild household detergent and first testing in a small area. Flush the area with water after cleaning.

#### 2.10.28. Stanchions & Grab Rails

Inspect stanchions and grab rails for security of attachment and any evidence of damage. Tighten any loose hardware. Replace any damaged components.

## 2.10.29.Wheelchair Tie-Down & Occupant Restraints

Perform the following activities every 6,000 miles (9,600 km):

- Clean belts as required using mild soap and water. Do not use solvents, chemical solutions or strong detergents. If required, soak belts for several hours in water to loosen dirt. Clean, rinse and dry thoroughly before returning to service.
- ☐ Lubricate the tiedown belt buckles at the hinges being careful not to contaminate the webbing.

#### 2.10.30.Interior Panels

Inspect panels for scuffs, cracks and other forms of damage. Clean panels and repair any defects. Refer to Section 12 of this manual for further information on the interior panels.

#### 2.10.31.Exterior Panels

□ Every 6,000 miles (9,600 km) inspect the sealant and caulking of the exterior panel seams, and wheel-housings. Replace where substance has failed.



Use only the recommended type of sealant, caulk or adhesive. Refer to Section 13 of this manual for recommended type. DO NOT use substitutes.

☐ Clean the entire vehicle thoroughly to inspect for paint condition and for metal corrosion damage. Pay particular attention to the lower panels. Repair any areas with paint failure, or corrosion.

#### ™NOTE:

Increase inspection frequency in freezing weather, due to the effect of road deicing materials (salt, calcium chloride and so forth) on metal.

 Protect painted surfaces with a coating of wax immediately after the vehicle has been cleaned.



When cleaning the painted surfaces of the vehicle, use a cleaning agent that will not harm the acrylic finish or fiberglass panels. (for example soap and water).

#### 2.10.32.Mirrors

Lubricate the pivot arms of all exterior mirrors fitted with grease fittings every 6,000 miles (9,600 km). Lubrications interval may need to be adjusted to suit operating conditions. Locate the grease fitting at the pivot arm and use a hand-operated grease gun to apply approximately 9 pumps of grease or until grease comes out between bracket and arm. Use Mobil XHP222 multipurpose grease or equivalent.

#### 2.10.33.Battery System



ALWAYS replace batteries with the same type and size identified in your New Fiver Parts Manual and charge the batteries using the recommended voltage. Over-charging a lead acid battery can produce explosive and hazardous gas. Any change in battery configuration may require modification to the charging system voltage levels and battery service procedures to prevent over-charging and equipment damage. Consult the batter manufacturer's recommendations before installing replacement components.

□ Check external condition of battery and battery cables periodically. If required, wash exterior with a dilute solution of ammonia or soda to neutralize acid, then flush off with clean water. Keep vent plugs tight to keep neutralizing solution out of cells. Tighten hold-down nuts to prevent batteries from shaking but not so tight as to strain battery case. See "Fig. PM-21: Battery Tray" on page 47.

- ☐ Check the battery cable ends on the battery posts. To ensure good contact, these must be tightened firmly.
- ☐ Check for post or cable end corrosion. If corrosion exists disconnect cables from the posts and clean both with soda solution and a wire brush. Install ends and tighten firmly, then coat with dielectric grease.
- Check battery for obvious damage such as, cracked case (shows loss of electrolyte), or damaged, cracked, or loose terminal posts.
- If obvious damage is noted, replace battery.
- If no obvious damage is noted, check electrolyte level.
- ☐ If electrolyte level is above top of plates in all cells, conduct specific gravity test. Refer to Section 9 of this manual for procedure.
- ☐ If electrolyte level is below specified level in one or more cells, add water to proper levels, then charge for 15 minutes at 15 to 25 amperes, with vent caps removed. Connect a 300 ampere load to battery for 15 seconds to remove electrolyte surface charge. Conduct specific gravity test. Refer to Section 9 of this manual for procedure.




Fig. PM-21: Battery Tray



#### 2.10.34. Wheelchair Ramp Inspection

Inspect & lubricate the wheelchair ramp mechanism every 6,000 miles (9,600 km).

#### 2.10.34.1.Mechanism

- Inspect and adjust chain tension as required. Refer to Section 20 of this manual for inspection and adjustment procedure.
- ☐ Inspect ramp pump electrical connectors for condition and security. See "Fig. PM-22: Wheelchair Ramp Inspection" on page 48.

- Inspect electrical harnesses and hydraulic hoses for condition and secure attachment.
- ☐ Inspect fluid level in reservoir. Top up as required.
- Inspect and tighten mounting hardware as required.
- ☐ Ensure stowed proximity switch is functioning and is positioned to activate at 15° from the STOWED position.




Fig. PM-22: Wheelchair Ramp Inspection

#### 2.10.34.2.Skid Plate

Locate the wheelchair ramp skid plate at the forward edge of the entrance door. See "Fig. PM-23: Ramp Skid Plate Inspection" on page 49. Inspect the skid plate for impact or abrasion damage. Abrasion of the outboard edge is acceptable providing the wear indicator hole on the plate is still evident. Use a 1/8" drill bit to clear the wear indicator hole if plugged with debris. Refer to Section 20 of this manual for skid plate replacement procedure.

#### 2.10.34.3.Lubrication

Refer to 2.35. "Fluid & Lubrication Guide" on page 97 in this section for lubricant specification. Clean existing lubricated surfaces of any dirt, grime, or dried lubricant and then apply fresh lubricant to the following areas:

- Drive chain rollers and side plates.
- ☐ Teflon sleeve bushings located on the tensioner blocks.
- ☐ Teflon sleeve bushings located on the LH and RH ramp pivots.
- ☐ Bronze bushing located on idler sprocket.
- Hydraulic cylinder pivot.
- ☐ Between the sliding surfaces of the mechanism (slots in the support plates and flats on the push shaft and clevis shaft).
- Hydraulic cylinder pivot points.

Operate the wheelchair ramp through several cycles to distribute the lubricant into the working surfaces.




Fig. PM-23: Ramp Skid Plate Inspection



#### 2.10.35.Driver's Heater/Defroster Inspection



Reposition Battery Disconnect switch to OFF before servicing heater/ defroster electrical components to avoid shorts.

☐ Inspect air filter. Clean or replace as required. See "Fig. PM-24: Defroster Inspection" on page 50.

- ☐ Inspect electrical plugs for clean contacts. Check wiring for proper routing and for any evidence of rubbing.
- □ Inspect condition of coolant hoses and ensure all hoses clamps are properly tightened.




Fig. PM-24: Defroster Inspection

#### 2.10.36.Floor Heaters

- Inspect the unit for damaged or loose components.
- ☐ Check coolant hose connections for leak.
- ☐ Clean or replace return air filters.

#### 2.10.37.HVAC Return Air Filter

Clean or replace filter as required every 6,000 miles (9,600 km). See "Fig. PM-25: HVAC Return Air Filter" on page 51.

1. Locate the HVAC return air grille on the ceiling of the vehicle.

- 2. Unlatch the return air grille and allow the grille to swing downward.
- Release the shock cord from the filter frame.
- 4. Remove the filter from the filter frame.
- 5. Remove accumulated debris by blowing compressed air in direction opposite to normal air flow.
- 6. Wash filter in warm soapy water, rinse, and allow to dry.
- 7. Installation is the reverse of removal.




Fig. PM-25: HVAC Return Air Filter



#### 2.10.38.Rear Axle Breather Tube



DO NOT attempt to shorten or otherwise relocate the breather tube. The volume inside the tube acts as an expansion reservoir and must be at least 5 ft. (1.5 m) in length.

☐ Check that the breather tube is securely attached to the elbow located on top of the differential housing and is attached to the breather membrane, located on the street-side suspension support. See "Fig. PM-26: Rear Axle Breather Inspection" on page 52.

☐ Clean any sludge or debris accumulation from the breather membrane outlet and ensure that the tube is clear. Replace the breather membrane (valve) if clogged, dirty, or oil soaked. Refer to 2.10.38.1. "Breather Valve Replacement" on page 52 in this section for procedure.

#### 2.10.38.1.Breather Valve Replacement

- Remove the breather tube from the valve by pushing the collar on the valve towards the valve body. Maintain pressure on the collar while pulling out the tube.
- Inspect the end of the breather tube before installing new breather valve. Tubing end must be cut square and free from any burrs or rough edges.
- 3. Push tube into breather valve until seated.




Fig. PM-26: Rear Axle Breather Inspection

## 2.10.39.Engine Compartment Line Routing Inspection

Perform a visual inspection on the condition and routing of all engine compartment lines every 6,000 miles (9,600 km) or whenever line or harness maintenance/ replacement has occurred. For the purpose of this inspection, engine compartment lines may be defined as all rigid steel lines and copper tubing, flexible lines, hoses, and tubing as well as electrical cables and harnesses. This inspection applies to all lines used in the fuel, air, hydraulic, lubricating, cooling, electrical, and HVAC systems. Open all engine compartment doors and inspection panels to allow complete inspection of the area. It may be necessary to raise the vehicle to properly inspect all lines.

#### 2.10.39.1.Line Condition Inspection

- Inspect all rigid lines for condition. Repair or replace the line if any of the following conditions are evident:
  - a. Abraded or fretted surfaces
  - b. Kinked or deformed tubing
  - c. Corrosive pitting
  - d. Loose mounting flanges or connectors
  - e. Fluid or air leakage
  - f. Excessive buildup of oily residue, dirt or road grime. Clean as required.
- Inspect all flexible lines and hoses for condition. Repair or replace the line if any of the following conditions are evident:
  - a. Cut, abraded, or frayed protective cover (includes textile, polyester, or steel braid as well as silicone firesleeving).
  - b. Crushed, kinked, distorted, or twisted hose.
  - c. Charred, heat damaged, cracked, hard, or stiff hose.

- d. Blistered, soft, or deteriorated hose.
- e. Loose mounting flanges or fittings/connectors
- f. Cracked or corroded fittings/connectors.
- g. Fluid or air leakage.
- h. Excessive buildup oily of oily residue, dirt or road grime. Clean as required.
- 3. Inspect exhaust bellows for correct alignment with exhaust tubes on either side of bellows. Examine the tubes and bellows from above and below, with a 90° angle between the viewing points. The exhaust tubes on either side of the bellows must be aligned parallel with each other and display no offset. Convolutions of bellows must be evenly spaced from one end of the bellows to the other. Replace bellows if it is torn or otherwise damaged. Refer to Section 4 of this manual for further information on this equipment.
- Inspect all power cables and wiring harnesses for condition. Repair or replace the cable, harness, and/or protective covering if any of the following conditions are evident:
  - a. Loose or corroded connections
  - Damaged or missing protective insulator boots on positive terminals of power cables.
  - Lack of dielectric grease on exposed power cable terminals. Clean terminals and reapply dielectric grease.
  - d. Crushed, cut, or heat-damaged wire covering (corrugated split-loom).
  - e. Blistered, soft, or deteriorated wire insulation.
  - f. Excessive buildup of oily residue, dirt or road grime. Clean as required.

# NEW ELVER

### 6,000 Miles (9,600 km) Preventive Maintenance

#### 2.10.39.2.Line Routing Inspection

- Inspect all rigid lines for proper routing. Provide additional or repositioned clamping, if the following conditions exist:
  - Line runs across another line, component, or vehicle structure without being properly clamped.
  - b. Line is improperly held by clamp. Select proper clamp size or tighten clamp as necessary. Clamp must fit snugly on line without causing restriction.
  - c. Ensure band clamps (typically used to attach rubber hose to metal tubing) are tight.
- 2. Inspect all flexible lines and hoses for proper routing.
  - a. Ensure lines are not routed in close proximity to hot zones such as the turbocharger, engine exhaust, auxiliary coolant heater etc. Provide additional clamps or reposition the existing clamps to obtain the required clearance (minimum 1"). Use brackets or spacers, if necessary, to obtain the required clearance. Provide protective shielding in situations where the optimum clearance cannot be achieved.



DO NOT clamp or cable tie fuel lines to electrical cables/harnesses. Maintain a minimum clearance of 1/2" between fuel lines and electrical cables/harnesses. DO NOT use cable ties on textile or steel braided lines.

b. Ensure lines do not run across another line, component, or vehicle structure without being properly clamped.

#### ™NOTE:

It is permissible to cable tie synflex air lines with synflex fuel lines.

- c. Ensure lines meet the minimum bend radius requirements. Provide a minimum bend radius of six times the diameter of the line. Reposition line or replace with a line of the proper length if necessary.
- d. Ensure flexible lines are routed and clamped so as to provide minimal slack without being taut. Provide additional slack in lines where there could be relative movement between the joined locations. Do not space clamps less than 12 inches apart.
- e. Provide cushioned loop clamps (P-clamps) or plastic split-block style clamps in locations where vibration or road shock may be transmitted to the line. Plastic split-block style clamps are typically used with large diameter lines only.
- f. Inspect condition of P-clamps to ensure they are tight and the rubber cushion is intact and in full contact with the line. Replace P-clamp if the rubber cushion is not of the full enclosure style.



3. Inspect all power cables and wire harnesses for proper routing.



DO NOT clamp or cable tie electrical cables/harnesses to fuel lines. Maintain a minimum clearance of 1/2" between fuel lines and electrical cables/harnesses.

a. Ensure cables/harnesses do not run across another line, component, or vehicle structure without being properly clamped. Ensure that grommets or rubber edging are used wherever the cable/harness passes through a bulkhead or panel.

#### ™NOTE:

It is permissible to cable tie electrical wire harnesses to synflex air lines but not to textile or steel braided lines.

 Ensure cables/harnesses are not clamped to another hose or line. Cables/harnesses should be clamped only to stationary structure or brackets.



Damage to the internal wire bundle can occur if the wire loom is clamped to an object subject to excessive vibration. The vibrations can transmit through the cushioned clamp and create relative movement between the internal wire bundle and the corrugated surface of the wire loom, resulting in damage to

the wire insulation over a period of time. Use an alternative clamping method that will isolate the vibration or relocate the wire harness and clamp at a different location.

- c. Ensure cables/harnesses are secured with P-clamps wherever practical. Harnesses should be clamped no more than 24 inches apart, where possible. Use cable ties to secure any portion of a harness bundle that cannot be secured within the P-clamps. Maintain relationship same between clamped and unclamped wire harness looms throughout the entire run of the wire bundle. Use cable ties at 12" intervals. Ensure cable ties are not overtightened or supporting too much weight so as to cut into the wire loom.
- d. Ensure that cable ties are not used within four inches of the connector. Provide strain relief or otherwise allow some flexion at the terminal connector. It is acceptable, however, to cable tie the terminal connector body itself when it is running parallel with another harness.
- e. The excessive length of a harness may require that it be looped. Ensure that the harness is looped in an appropriate area and that the minimum bend radius is observed. Provide a minimum bend radius of six times the diameter of the harness.
- f. Inspect condition of P-clamps to ensure they are tight and the rubber cushion is intact and in full contact with the cable/ harness.

## 2.11. 7,500 Miles (12,000 km) Preventive Maintenance

## 2.11.1. Air Filter Restriction Indicator Inspection

Inspect the air filter restriction indicator every 7,500 miles (12,000 km), 250 hours, or 3 months, whichever occurs first. Locate the restriction indicator in the engine compartment and refer to the scale on the indicator that is calibrated in inches of water. Replace the air filter element if the reading exceeds 18"  $H_2O$ .

The service life of an air filter element is affected by several factors including operating environment, hours of operation, and total time in service. The requirement for air filter element replacement is determined by monitoring the reading on the Filter Minder® air filter gauge. This gauge monitors air restriction downstream of the air cleaner assembly. See "Fig. PM-27: Air Filter Restriction Indicator" on page 56.

The air filter gauge is calibrated in inches of water on one side and millimeters of water on the opposite side. The gauge will register and retain the highest air restriction reading experienced during operation. Maximum air restriction readings will be obtained typically during full throttle, full load operation.

Air filter element replacement is required when the filter media has trapped approximately 80% of its load carrying capacity. This capacity equates to an air filter gauge reading of 18 to 20 inches of water. The air filter element is considered to have reached its maximum service life at this point and must be replaced. Refer to 2.11.2. "Air Filter Replacement" on page 57 in this section for replacement procedure.




Fig. PM-27: Air Filter Restriction Indicator

#### 2.11.2. Air Filter Replacement

The air filter housing assembly includes a primary and safety element. The primary element provides engine protection during operation and the safety element is designed to prevent contaminates from entering the induction system during servicing. The safety element is located within the filter housing, immediately downstream of the primary element. See "Fig. PM-28: Air Filter Elements" on page 57.

The replacement interval for the primary element is determined by the filter restriction indicator reading. Replace the primary element when the gauge reading is between 18 to 20 inches of water. The safety element should be replaced every third primary element change or whenever the surface of the safety element has become contaminated.

#### ™NOTE:

There is no need to remove and visually inspect the air filter element if the indicator reading is less than 18"  $H_2O$ . Replacing the air filter element at 18"  $H_2O$ . will maximize the service life of the filter and minimize any risk associated with excessive handling of the air filter.




Fig. PM-28: Air Filter Elements

#### 2.11.2.1.Removal

1. Open the air filter access door located on the rear curbside corner of the vehicle.



The air filter housing is mounted with the clean air outlet pointing downward and care must be used when performing an element replacement to avoid contaminating the induction system during servicing.

- Remove the air filter housing cover by releasing the four over-center latches located on both sides near the center of the body. Remove the cover by pulling straight out from the housing.
- 3. Using the plastic handle on the primary element gently lift up on the element to loosen the gasket seal, which will tilt the element to an approximate 5 degree angle. Carefully remove the primary element from housing.
- Carefully clean out all contaminates from the housing and sealing surfaces with a damp cloth before servicing the safety element.



The lower elbow located at the base of the vertical air intake pipe must be disconnected before removing the safety filter. Removal of the safety filter may dislodge dirt or other contaminants that could enter the air intake system.

 If the safety element has to be replaced use the plastic handle on the face of the safety element. Pull the element towards the center of the housing and carefully remove it from the housing to avoid contaminates from entering the induction system.

### ™NOTE:

If new elements are not going to be installed immediately, temporarily cover the outlet tube to prevent contaminants from entering the air intake system.

6. Carefully wipe out the safety seal surface in the housing with a damp cloth.

#### 2.11.2.2.Inspection

- Inspect the rubber seal on air filter housing access door (U-shaped cover with four over-center latches). Replace the access door if the seal is deteriorated or damaged. Refer to your New Flyer Parts Manual for part number of access door.
- Inspect the clamped connections at the inlet and outlet of the air filter housing. There should be no evidence of bulged or deformed hoses.



DO NOT exceed 40 in-lbs torque on the hose clamps. Over-tightening the clamps will deform the plastic air filter housing inlet/outlets.

- Use a bright light to inspect the interior of the air filter housing and check for any evidence of distortion or cracking on the inlet and outlet clamped connections. Replace air filter housing if cracked or damaged. Refer to Section 4 of this manual for replacement procedure.
- 4. Shine a bright light into the air intake tube leading away from the air filter housing and ensure no evidence of dust trails or other contaminants exist. Remove air intake piping and clean as necessary.

#### 2.11.2.3.Installation

1. Install the safety element using the handle facing up and outward. Insert the safety element tab into the positioning slot before pushing the element down into place.

#### ™NOTE:

The safety element handle must be towards the service cover opening and completely seated to allow for proper installation of the primary element.

2. Use the handle on the primary element to insert it into the housing at the same angle as it was removed. Insert the element until it makes contact with the inside of the housing. Pull down on the handle to complete the seal.

#### ™NOTE:

The element must be completely seated to allow for proper installation of service cover.



## NEVER use latches to force the element into place.

- Install service cover with the indexed rib at the top and attach all 4 latches. If the cover doesn't seat, remove and re-check the filter position.
- Clean and reinstall lower elbow to air intake pipe. Torque T-Bolt clamps at either end of elbow to 85 in-lbs.

#### 2.11.3. Charge Air Cooler & Piping

Inspect the charge air cooler & piping every 7,500 miles (12,000 km), 250 hours, or 3 months, whichever occurs first.

- □ Inspect the charge air cooler (CAC) for dirt and debris blocking the fins. Check for cracks, holes, or other damage. If damage is found, refer to Section 6 of this manual for replacement procedures.
- Inspect the charge air piping and hoses for leaks, holes, cracks, or loose connections.
   Tighten the hose clamps if necessary.



## 12,000 Miles (19,300 km) Preventive Maintenance NEW FLY

## 2.12. 12,000 Miles (19,300 km) Preventive Maintenance

#### 2.12.1. Electronic Accelerator

Perform the following maintenance every 12,000 miles (19,300 km) or 600 operating hours, whichever comes first:

- ☐ Check the area around the treadle to ensure that nothing will interfere with treadle operation (mats, discarded material and so forth). See "Fig. PM-29: Accelerator Inspection" on page 60.
- ☐ Check the entire treadle assembly for cleanliness.

- Check the nylon roller on the underside of the pedal and on the transfer lever for freedom of movement.
- Check all pivot points for freedom of movement, excessive wear and corrosion.
- Check all fasteners, fittings and retaining rings to verify that they are all properly installed.
- Actuate the treadle valve by pressing the pedal by hand. The action should be smooth without binding. When the pedal is released, it should return immediately without sticky or sluggish action.
- Excessive wear and corrosion requires the installation of new bushings.




Fig. PM-29: Accelerator Inspection

### FLYER 12,000 Miles (19,300 km) Preventive Maintenance

#### 2.12.2. Driver's Heater/Defroster

Inspect and test the defroster blower motor every 12,000 miles (19,300 km) or as determined by operating conditions. The inspection interval will need to be more frequent during the winter months when the heaters are exposed to slush, salt and grit that have been tracked into the vehicle.

Remove defroster access cover to allow detailed inspection of the blower motor and electrical connections.



DO NOT attempt to clean defroster assembly using pressure washing equipment or using shop air in excess of 60 psi

- Inspect for buildup of salt or dirt deposits in and around the blower motor. Clean surfaces as necessary to remove contamination.
- Inspect electrical connectors for loose or corroded connections.
- ☐ Test operation of blower motor at all operating speeds to ensure smooth and quiet operation.
- ☐ If blower motor operation is suspect, use a clamp-on Fluke ammeter, or equivalent, to test current draw at each speed setting. Refer to Section 10 of this manual for defroster motor specifications. Replace blower motors that do not meet the specified operating limits.

#### ™NOTE:

Disassembly, cleaning, and repair of the blower motor is considered uneconomical and it is recommended that the blower motor be replaced if found defective.

#### 2.12.3. Floor Heaters

Inspect and test the floor heater blower motors every 12,000 miles (19,300 km) or as determined by operating conditions. The inspection interval will need to be more frequent during the winter months when the heaters are exposed to slush, salt and grit that have been tracked into the vehicle.



Pressure washing vehicle flooring can easily force contamination into the heater assembly. Avoid pressure washing in and around the area where the floor heaters are located or, at least, protect the heaters from any high pressure washing solutions or air pressure exceeding 60 psi.

- Remove heater assembly access covers to allow detailed inspection of the blower motor and electrical connections.
- Inspect for buildup of salt or dirt deposits in and around the blower motor. Clean surfaces as necessary to remove contamination.
- Inspect electrical connectors for loose or corroded connections.
- Test operation of blower motor at all operating speeds to ensure smooth and quiet operation.
- ☐ If blower motor operation is suspect, use a clamp-on Fluke ammeter, or equivalent, to test current draw at each speed setting. Refer to Section 10 of this manual for heater motor specifications. Replace heater motors that do not meet the specified operating limits.

#### RNOTE:

Disassembly, cleaning, and repair of the blower motor is considered uneconomical and it is recommended that the blower motor be replaced if found defective.

## 2.13. 15,000 Miles (24,000 km) Preventive Maintenance

#### 2.13.1. Cooling System Pressure Test



DO NOT attempt to open the pressure cap on the surge tank until the system has cooled down and the pressure relief valve has been operated. Opening the pressure cap with pressurized hot coolant can result in scalding injury and loss of coolant.

Perform a cooling system pressure test every 15,000 miles (24,000 km) as follows:

- Pressure test the cooling system at 15 to 20 psi (103 to 138 kPa) using a commercially available pressure tester. Maintain pressure for one minute while observing gauge reading. If pressure reading drops check for source of leak and repair as necessary.
- Pressure test the pressure cap at 12 to 15 psi (83 to 103 kPa) and ensure that it maintains pressure. Increase pressure until the pressure relief actuates. Pressure relief should occur at approximately 18 psi. Also inspect the vacuum relief valve on the underside of the cap to ensure that it functions.

#### 2.13.2. Coolant Filter Replacement



DO NOT attempt to change the coolant filter until the system has cooled down and the pressure relief valve has been operated. Servicing the coolant filter with pressurized hot coolant can result in scalding injury.

#### ™NOTE:

If it is necessary for any reason to drain the cooling system before an element change, the treated water should be saved and reused. If the treated water is discarded, a new filter element must be installed since the protective agents in the used filter will have been partially consumed in treating the discarded water.

- Close the coolant filter inlet and outlet valves. See "Fig. PM-30: Coolant Filter" on page 62.
- Remove the spin-on filter element using a filter wrench.
- 3. Lubricate seal on new filter element with clean engine oil.
- Ensure filter base is clean and install filter element.
- Tighten filter in accordance with instructions provided on filter.
- 6. Open the coolant filter inlet and outlet valves
- 7. Start engine and check for coolant leaks.
- 8. Check coolant level and top up if necessary.




Fig. PM-30: Coolant Filter

### **EW FLYER** 18,000 Miles (29,000 km) Preventive Maintenance

## 2.14. 18,000 Miles (29,000 km) Preventive Maintenance

#### 2.14.1. Engine Mounts

Every 18,000 miles (29,000 km) inspect the front and rear engine rubber mounts for the following conditions:

- □ Cracks
- Material separation
- Loose or damaged fasteners

Replace mounts which show any of these signs of damage. Replace damaged fasteners. Retorque loose fasteners. Refer to Section 4 of this manual for correct torque specifications.

#### 2.14.2. Power Steering Filter

Replace the power steering filter, located in the hydraulic reservoir, every 18,000 miles (29,000 km) or every six months, whichever occurs first.

Dispose of used filter, any spilled hydraulic fluid and used shop rags in an environmentally responsible manner. Start engine and check filter installation for leaks before operating vehicle. Refer to Section 3 of this manual for further information on the reservoir and filter. See "Fig. PM-31: Hydraulic Filter Replacement" on page 63.




Fig. PM-31: Hydraulic Filter Replacement



#### NEW FLYER

## 2.15. 24,000 Miles (38,600 km) Preventive Maintenance

#### 2.15.1. Brake Treadle Assembly & Brake Valve

Perform maintenance on the brake treadle assembly and brake valve every 24,000 miles (38,600 km), 900 operating hours or three months, whichever occurs first,

- □ Remove any accumulated contamination, such as dirt and gravel, from the heel of the treadle, the plunger, the plunger boot and the mounting plate. See "Fig. PM-32: Brake Valve Inspection" on page 65.
- ☐ Clean and inspect the treadle roller, the roller pin, and the hinge pin. Replace any worn, corroded, or damaged parts. Lubricate with Barium grease. Refer to 2.35. "Fluid & Lubrication Guide" on page 97 in this section for lubrication specifications.

- Inspect the plunger boot for cracks, holes or deterioration and replace boot if damaged.
- ☐ Inspect the plunger for wear or corrosion. Replace plunger if required.
- Check that the brake treadle mounting plate is securely fastened. Inspect pivot pin holes and plunger bore in mounting plate for wear or corrosion. Replace mounting plate if required.
- Apply a thin layer of Barium grease between the plunger and the mounting plate bore. Do not use excessive amounts of lubricant.
- ☐ Perform operation and leakage tests on the brake valve. Refer to Section 8 of this manual for test procedures.

## **SEW FLYER** 30,000 Miles (48,000 km) Preventive Maintenance




Fig. PM-32: Brake Valve Inspection

## 2.16. 30,000 Miles (48,000 km) Preventive Maintenance

#### 2.16.1. Fuel Tank

Open the drain at the bottom of the Fuel Tank every 30,000 miles (48,000 km) to drain off any water and/or sediment.

#### 2.16.2. Engine Drive Belts

Inspect alternator, water pump, and HVAC belts every 30,000 miles (48,000 km), 1000 hours, or one year, whichever occurs

first. Inspect belts for wear, cracks, fraying, glazing, or other damage. Small transverse cracks running across the ribs are acceptable unless intersected by a longitudinal crack running along the length of the belt. Replace the belt if chunks of material are missing or belt is frayed.

#### ™NOTE:

When replacing with a new belt, ensure that the belt is properly aligned and tensioned. Confirm proper operation of the automatic belt tensioner.



#### NEW FLYER

## 2.17. 36,000 Miles (58,000 km) Preventive Maintenance

#### 2.17.1. Disc Brake Caliper Inspection

Perform a disc brake caliper inspection every 36,000 miles (58,000 km) or every year, whichever occurs first. A more frequent inspection may be necessary depending on the operating conditions. Perform the following inspections:

- Inspect the six brake caliper mounting bolts that attach the brake caliper to the axle to ensure the bolts are tight. Refer to Section 1 and 2 of this manual for mounting bolt torque specifications.
- ☐ Caliper Running Clearance refer to "Brake Pad Clearance Inspection" in Section 1 and 2 of this manual for inspection procedure.
- ☐ Guide Pin Covers check that the protective covers are properly installed on the caliper guide pins and are in good condition. Replace covers if damaged or missing.
- Adjuster Cap check that the protective cap is properly installed on the adjuster and is in good condition. Replace adjuster cap if damaged or missing
- Brake Disc refer to "Brake Disc Inspection" in Section 1 and 2 of this manual for inspection procedure.

☐ Brake Adjuster - refer to "Automatic Adjustment Inspection" in Section 1 and 2 of this manual for inspection procedure

#### ™NOTE:

The brake adjuster should always be inspected and tested whenever brake pads have been replaced

- ☐ Caliper Guide Pin refer to "Caliper Guide Pin Inspection" in Section 1 and 2 of this manual for inspection procedure.
- ☐ Tappet & Boot Assembly refer to "Tappet Rubber Boot Inspection" in Section 1 and 2 of this manual for inspection procedure.
- Guide Pin Inner Boot refer to "Upper Guide Rubber Boot Inspection" in Section 1 and 2 of this manual for inspection procedure.

#### 2.17.2. Power Steering Fluid

Replace the fluid in the hydraulic reservoir every 36,000 miles (58,000 km) or yearly, whichever occurs first. More frequent change intervals may be required if operating under less than ideal conditions. Severe operating conditions involving extremes of moisture, dust and temperature fluctuations may require a more frequent hydraulic fluid change interval. Refer to 2.35. "Fluid & Lubrication Guide" on page 97 in this section for fluid specifications.

### **NEW FLYER** 36,000 Miles (58,000 km) Preventive Maintenance

#### 2.17.3. Rear Axle Oil Change

Change the rear axle oil every 36,000 miles (58,000 km), or every year, whichever occurs first. Use this oil change interval only if operating with mineral oil in a hot temperature region. Refer to 2.2. "Rear Axle Operating Conditions" on page 2 in this section for a definition of a hot temperature region. Refer to 2.35. "Fluid & Lubrication Guide" on page 97 in this section for fluid specification.

#### 2.17.3.1.Drain



Differential fluid can reach operating temperatures in excess of 212°F (100°C). Allow adequate time for differential to cool before draining fluid.

- Ensure vehicle is parked on a level surface or raised to a working height that maintains a level attitude.
- 2. Place a suitably sized container beneath the differential gear housing.

#### ™NOTE:

Differential gear housing oil fill quantity is approximately 4.0 U.S. gallons (15 liters)

- 3. Remove the fill plug from the front of the differential housing. See "Fig. PM-33: Rear Axle Drain & Fill Locations" on page 67.
- Remove the drain plug from the bottom of the differential housing and allow the differential to drain completely.

#### 2.17.3.2.Fill

 Inspect the magnetic drain plug for any significant accumulation of metal particles and wipe clean.

#### ™NOTE:

Fine "fuzz-like" metal particles are considered normal but any solid slivers of significant size or chips of metal will require further investigation to determine cause.

- 2. Clean and inspect the threads of the drain plug before applying Loctite-567 thread sealant. Install and torque the drain plug to 52 ft-lb. (70 Nm).
- 3. Add slightly less than 4.0 U.S. gallons (15 liters) and allow fluid level to stabilize.
- 4. Continue to add fluid slowly until the fluid is level with the bottom of the fill plug.
- 5. Install the fill plug and torque to 52 ft-lb. (70 Nm).




Fig. PM-33: Rear Axle Drain & Fill Locations



## 2.18. 48,000 Miles (77,200 km) Preventive Maintenance

#### 2.18.1. Front End Alignment

Perform minor alignment. Refer to Section 3 of this manual for procedure.

#### 2.18.2. Front & Rear Brake Chambers

#### 2.18.2.1.Front Brake Chambers

Perform the following inspection every 48,000 miles (77,200 km):

- Visually inspect the exterior surfaces of the brake chamber for signs of damage. Replace the brake chamber if damaged. Refer to Section 1 of this manual for replacement procedure.
- 2. Apply system pressure (minimum 100 psi) to the brake chamber and check for leaks around the circumference of the clamp band and air inlet fittings, using soapy water or leak detection solution.
  - a. If bubbles appear around clamp band, release air pressure and torque clamp band nuts to 30 to 35 ft-lbs (41 to 47 Nm). Recheck for leaks. If leaks continue, replace the brake chamber.
  - b. If bubbles appear at air inlet fittings, tighten fittings until leaks cease, but do not exceed 25 to 30 ft-lb. (34 to 41 Nm) torque for 3/8 18 NPTF fittings or 13 to 15 ft-lb. (18 to 20 Nm) for M16 x 1.5 -6H fittings. If leaks continue, release air pressure and remove air lines from inlet ports. Repair or replace hose and fittings as required Reinstall air lines to the brake chamber and recheck for leaks.
- Check to ensure the mounting stud nuts are torqued to 133 to 155 ft-lb. (180 to 210 Nm).

#### 2.18.2.2.Rear Brake Chambers

Perform the following inspection every 48,000 miles (77,200 km):

- Visually inspect the exterior surfaces of the spring brake chamber for signs of damage. Replace the brake chamber if damaged. Refer to Section 2 of this manual for replacement procedure.
- 2. Apply system pressure (minimum 100 psi) to the spring brake chamber and check for leaks at the head/flange case interface, air inlet fittings, at vent elbows in non-pressure housing, and center seal using soapy water or leak detection solution.
  - a. If bubbles appear at the head/flange case interface, a leak is present and the spring brake chamber must be replaced.
  - b. Check for leaks from the vent elbow located in the non-pressure housing. If more than one vent elbow is present, plug all but one elbow and check for leaks at the unplugged elbow. If leaks are detected, there is an internal leak and the spring brake chamber needs to be replaced.
  - c. For center seal leaks, check for continuous discharge from the service side quick release valve. If a leak is present, the brake chamber must be replaced.
  - d. If bubbles appear at air inlet fittings, tighten fittings until leaks cease, but do not exceed 25 to 30 ft-lb. (34 to 41 Nm) torque for 3/8 18 NPTF fittings or 13 to 15 ft-lb. (18 to 20 Nm) for M16 x 1.5 -6H fittings. If leaks continue, exhaust all air from spring side of the chamber. Remove air lines from inlet ports. Repair or replace hose and fittings as required. Reinstall air lines to brake chamber and check for leaks.



### NEW FLYER 54,000 Miles (87,000 km) Preventive Maintenance

- With spring brake still fully pressurized, apply system pressure (minimum 100 psi) to the service brake chamber and check for leaks around the circumference of the clamp band and air inlet fittings, using soapy water or leak detection solution.
  - a. If bubbles appear around clamp band, release air pressure and torque clamp band nuts to 30 to 35 ft-lb. (41 to 47 Nm). Recheck for leaks. If leaks continue, replace the brake chamber.
  - b. If bubbles appear at air inlet fittings, tighten fittings until leaks cease, but do not exceed 25 to 30 ft-lb. (34 to 41 Nm) torque for 3/8 18 NPTF fittings or 13 to 15 ft-lb. (18 to 20 Nm) for M16 x 1.5 -6H fittings. If leaks continue, exhaust all air from service side of the chamber. Remove air lines from inlet ports. Repair or replace hose and fittings as required. Reinstall air lines to the brake chamber, and recheck for leaks
- Check to ensure the mounting stud nuts are torqued to 133 to 155 ft-lb. (180 to 210 Nm).



DO NOT use an impact wrench to tighten the release bolt in the following step.

- 5. Check to ensure that the release bolt is seated against the head insert and torqued to 50 to 60 ft-lb. (68 to 81 Nm). Fully seating the release bolt ensures that the parking brake will have full stroke capability and seals the release bolt threads, preventing contaminants from entering the brake chamber.
- 6. Check the external breather tube to ensure there is no damage or cracks in the rubber elbows and ensure the tube is securely engaged a minimum of ½ inch (13 mm) into the rubber elbows and glued together with a high quality rubber cement. Replace with breather tube repair kit if required.

## 2.19. 54,000 Miles (87,000 km) Preventive Maintenance

#### 2.19.1. Rear Axle Oil Change

Change the rear axle oil every 54,000 miles (87,000 km), or every year, whichever occurs first. Use this oil change interval only if operating with mineral oil in a moderate temperature region. Refer to 2.2. "Rear Axle Operating Conditions" on page 2 in this section for a definition of a moderate temperature region. Refer to 2.17.3. "Rear Axle Oil Change" on page 67 in this section for oil change drain and fill procedure. Refer to 2.35. "Fluid & Lubrication Guide" on page 97 in this section for fluid specification.



## 60,000 Miles (96,000 km) Preventive Maintenance N ≡ W

## 2.20. 60,000 Miles (96,000 km) Preventive Maintenance

#### 2.20.1. Fuel Tank

Every 60,000 miles (96,000 km) or twelve months, whichever comes first, tighten all fuel tank mountings and brackets. At the same time, check the seal in the fuel tank cap, the breather hole in the cap, and the condition of the flexible fuel lines. Repair or replace the parts as necessary.

#### 2.20.2. Air Compressor Discharge Lines

Inspect the air compressor discharge lines for carbon buildup every 60,000 miles (96,000 km), 2,000 operating hours or two years. If the total deposit in a cross-section of the line exceeds 1/16", clean the line, and inspect and clean the air compressor cylinder head and valve assembly. Refer to Section 8 of this manual for procedure.

#### 2.20.3. Crankcase Breather Element

Replace the crankcase breather element every 60,000 miles (96,000 km) or 2,000 hours, whichever occurs first.

#### 2.20.3.1.Removal

- 1. Set the Battery Disconnect switch to the OFF position.
- 2. Steam clean the crankcase breather cover area and dry with compressed air.

 Remove the eleven bolts that attach the crankcase breather cover to the crankcase breather base. See "Fig. PM-34: Crankcase Breather" on page 70.

### ™NOTE:

The six bolts that attach the breather base to the valve cover do not need to be removed.

- 4. Remove the breather cover.
- 5. Remove the breather element from the breather base and discard.




Fig. PM-34: Crankcase Breather



## **NEW FLYER** 60,000 Miles (96,000 km) Preventive Maintenance




Fig. PM-35: Breather Cover Torque Sequence

#### 2.20.3.2.Inspection & Cleaning

- 1. Inspect the breather cover and base for cracks or other damage.
- Clean any debris or sludge buildup from inside the breather cover and base. Be careful not to allow debris or cleaning fluid to enter the crankcase when cleaning the breather base.

#### 2.20.3.3.Installation

- 1. Lubricate the O-ring on the new breather element with engine oil.
- 2. Install the new breather element onto the breather base.
- Install the breather cover using eleven bolts. Torque bolts to 44 in-lb. (5 Nm) in the sequence shown. See "Fig. PM-35: Breather Cover Torque Sequence" on page 71.



## 75,000 Miles (120,700 km) Preventive Maintenance NEW FLYER

## 2.21. 75,000 Miles (120,700 km) Preventive Maintenance

### 2.21.1. Transmission Filters



Fluid and filter change frequency is determined by the severity of transmission service. More frequent changes may be necessary if the operating conditions create high levels of contamination or overheating. Perform an oil analysis to determine proper change interval if there is any question as to the severity of the transmission duty cycle. Refer to Allison Service Manual and Allison Service Tip #1099 for more information on oil analysis and recommended change intervals.

#### ™NOTE:

Refer to Allison Service Manual and Allison Service Tips #1099 for more information on fluid and filter change intervals and fluid contamination.

#### ™NOTE:

The transmission in this vehicle is equipped with Allison Prognostics. This feature allows customers to maximize the life of transmission fluid and filters through an interactive display on the Shift Selector. Refer to Section 5 of this manual for more information on Allison Prognostics.

Change both filters every 75,000 miles (120,000 km), 3,000 hours, or 36 months and top up fluid. Refer to 2.23. "150,000 Miles (241,400 km) Preventive Maintenance" on page 73 in this section for procedure.

## 2.22. 96,000 Miles (154,500 km) Preventive Maintenance

#### 2.22.1. Front End Alignment

Perform major alignment. Refer to Section 3 of this manual for procedure.



## NEW FLYER 150,000 Miles (241,400 km) Preventive Maintenance

## 2.23. 150,000 Miles (241,400 km) Preventive Maintenance

#### 2.23.1. Transmission Fluid



Fluid and filter change frequency is determined by the severity of transmission service. More frequent changes may be necessary if the operating conditions create high levels of contamination or overheating. Perform an oil analysis to determine proper change interval if there is any question as to the severity of the transmission duty cycle. Refer to Allison Service Manual and Allison Service Tip #1099 for more information on oil analysis and recommended change intervals.

#### ™NOTE:

Refer to Allison Service Manual and Allison Service Tips #1099 for more information on fluid and filter change intervals and fluid contamination.

#### ™NOTE:

The transmission in this vehicle is equipped with Allison Prognostics. This feature allows customers to maximize the life of transmission fluid and filters through an interactive display on the Shift Selector. Refer to Section 5 of this manual for more information on Allison Prognostics.

Change both filters every 75,000 miles (120,000 km), 3,000 hrs., or 36 months and top up fluid. Change the fluid every

150,000 miles (240,000 km), 6,000 hrs., or 48 months. See "Fig. PM-36: Transmission Oil Filters" on page 74.

#### RNOTE:

The transmission should be at the operating temperature of 160 to 200°F (71 to 93°C) when the oil is drained. This will ensure quicker and better drainage. Check oil for contamination. Refer to Section 5 of this manual if contamination exists.

- Remove the drain plug from the control module and allow the oil to drain. Check the condition of the oil per Section 5 of this manual.
- To remove filters, remove twelve bolts, two filter covers, two O-rings, two square cut seals and two filters.
- To install filters, prelube and install the two O-rings, two square cut seals followed by the filters (lube O-ring on cover and in filter cartridge only) onto the filter covers.
- Index each filter/cover assembly to the holes in the channel plate/sump. Push cover assembly to seat seals (do not use bolts to draw cover to sump: this can damage cover/seal/sump).
- 5. Install six bolts into each cover and tighten to 42 to 50 ft-lb. (57 to 68 Nm).
- Inspect the drain plug(s) O-ring and replace if necessary. Reinstall the 0.750 -16 UNF - 2A drain plug(s) and tighten to 18 to 24 ft-lb. (25 to 32 Nm).
- Fill transmission with new oil. Refer to Section 5 of this manual for required quantities.



## 200,000 Miles (321,000 km) Preventive Maintenance NEW FLYER




Fig. PM-36: Transmission Oil Filters

## 2.24. 200,000 Miles (321,000 km) Preventive Maintenance

#### 2.24.1. Muffler Particulate Filter

Every 200,000 miles or 6,500 operating hours remove the muffler particulate filter and send it to an authorized Cummins

repair location for cleaning or replacement. Specialized cleaning equipment is required to perform this maintenance. Refer to Section 4 of this manual for further information on this equipment and the removal procedure for the muffler and the particulate filter.



## NEW FLYER 200,000 Miles (321,000 km) Preventive Maintenance

#### 2.24.2. Diesel Exhaust Fluid Filter

Replace the diesel exhaust fluid filter every 200,000 miles (321,000 km) or 6,500 operating hours, whichever occurs first.

#### 2.24.2.1. Removal

 Set the Master Run switch to the STOP-ENGINE position and allow at least 5 minutes for the purge cycle to complete before servicing the filter.

### ™NOTE:

The purge cycle occurs automatically following vehicle shut down and will pump all fluid from the lines back into the tank. The dosing module, located on the Selective Catalyst Reduction (SCR) device will emit an audible pumping sound throughout the purge cycle.

- Set the Battery Disconnect switch to the OFF position once the purge cycle is completed.
- Locate the filter housing on the bottom of the SCR Supply Module, Inspect the area around the seal and vent of the filter cap for signs of leakage. See "Fig. PM-37: Diesel Exhaust Fluid (DEF) Filter" on page 76.

#### ™NOTE:

Diesel exhaust fluid leaks leave a white deposit. If deposits are found, inspect components for defects. Refer to 2.24.2.2. "Cleaning & Inspection" on page 75 in this section for inspection requirements.

4. Unscrew the diesel exhaust fluid filter cap.

#### ™NOTE:

There may be residual diesel exhaust fluid in the filter housing. Place a container below the diesel exhaust fluid filter cap to catch any spillage. Remove and discard the equalizing element and filter element.

#### ™NOTE:

Examine the filter elements for evidence of contamination prior to discarding the element. Refer to 2.24.2.2. "Cleaning & Inspection" on page 75 in this section for inspection procedure.

#### 2.24.2.2.Cleaning & Inspection

- 1. Inspect the diesel exhaust filter for debris or contamination using visual and aromatic indicators. If debris is evident, also check:
- ☐ Diesel exhaust fluid tank pick up screen. Refer to Cummins Service Manual.
- ☐ The dosing unit inlet connector Refer to Cummins Service Manual.

#### ™NOTE:

Refer to "Contamination/Incorrect Fluid" in Section 4 of this manual for flushing procedures. Also refer to Cummins Service Manual for additional information on contaminated diesel exhaust fluid.

- Clean the filter cap with warm water and a clean cloth.
- Inspect the filter cap for cracks or holes that could create a diesel exhaust fluid leak path.
- Check the condition of the threads on the filter cap. Replace the filter cap if thread damage is evident.
- Inspect the threads of the filter housing on the SCR Supply Module. This is especially important if the filter cap was damaged. Replace the entire SCR Supply Module if thread damage is evident.



## 200,000 Miles (321,000 km) Preventive Maintenance NEW FLYER

#### 2.24.2.3.Installation

#### ™NOTE:

Lubrication of the diesel exhaust fluid filter o-rings is not required.

- Slide the diesel exhaust fluid filter equalizing element into the diesel exhaust fluid filter cartridge.
- 2. Insert the filter assembly into the housing of the SCR module.
- 3. Install the filter cap and torque to 177 in-lb. (2.0 Nm).



NEVER operate the vehicle with the filter cap removed.

4. Start the vehicle and check for leaks.

#### ™NOTE:

The aftertreatment diesel exhaust fluid dosing system will not prime until the correct SCR temperatures are reached. To verify that there are no diesel exhaust fluid leaks, initiate a stationary regeneration to get the SCR system up to temperature.




Fig. PM-37: Diesel Exhaust Fluid (DEF) Filter



## NEW FLYER 200,000 Miles (321,000 km) Preventive Maintenance

#### 2.24.3. DEF Tank Inlet Filter

#### ™NOTE:

The DEF tank filter replacement interval will be dependent on operating and environmental conditions. Manually filling the tank through the filler cap offers potential for entry of contaminants. Adjust to a more frequent replacement interval if suction filter appears dirty or has an accumulation of DEF crystals.

Replace the DEF tank inlet filter every 200,000 miles (321,000 km) or 6,500 operating hours, whichever occurs first, as follows:

#### ™NOTE:

The multi-function head unit assembly (MFHU) must be removed from the DEF tank in order to replace the inlet filter.

- 1. Set the Battery Disconnect switch to the OFF position.
- 2. Disconnect the electrical connectors, coolant lines, and DEF fluid lines from the multi-function head unit assembly of the DEF tank. See "Fig. PM-38: DEF Tank Inlet Filter" on page 78.
- Mark the position of the MFHU relative to the DEF tank.
- Remove the two T25 Torx screws securing the retaining ring to the tank and remove the retaining ring.



DO NOT pull on wiring harnesses or fittings when trying to remove filter head from tank.  Use a flat head screwdriver to gently pry under the head unit while simultaneously pulling on the top of the unit. Continue prying and pulling until the mounting base is free from the tank.



DO NOT pull directly upward on MFHU when removing it from the tank as this might damage the head unit and seal bore. ALWAYS angle the unit out of the tank to prevent damage.

- Pull the MFHU out of the tank until the inlet filter approaches the opening in the tank. Angle the MFHU and fold the filter element upwards. Continue to carefully remove the MFHU until completely free of the tank bore.
- Remove the T15 Torx filter retention screw located near the bottom of the DEF suction tube. Discard the screw.
- Pull the filter off the suction tube and discard the filter.

#### ™NOTE:

Examine the filter and if extremely dirty or contaminated, it is recommended that the tank be cleaned internally.

- Position the suction tube housing of the new filter onto the bottom of the suction tube and press the filter flush against the bottom of the heater tube fin. Align the filter so that the retention screw can be installed into the housing.
- 10. Install a new retention screw.
- 11. Apply a thin layer of O-ring lubricant to the bore seal O-ring.



## 200,000 Miles (321,000 km) Preventive Maintenance NEW FLYER



DO NOT push the MFHU directly into the tank as this could damage the unit.

12. Fold the filter element upward and position the bottom of the MFHU inside the tank bore at an angle. Carefully work the unit through the bore until the bottom of the unit and filter are inside the tank.



DO NOT press directly on the fittings when installing the MFHU into the tank.

- 13. Position the MFHU as marked during removal and press the on the top of the blue mounting base until completely seated in the tank bore.
- 14. Replace the retaining ring on the head unit and install the two T25 Torx screws. Torque the screws 20 to 30 in-lb.
- Reconnect the electrical connectors, coolant lines, and DEF fluid lines to the MFHU.
- Reset Battery Disconnect switch to ON position.
- 17. Start engine and check for coolant or DEF line leaks.




Fig. PM-38: DEF Tank Inlet Filter

### **Six Month Preventive Maintenance**

## 2.25. Six Month Preventive Maintenance

#### 2.25.1. D-2 Governor

Perform an operating and leakage test every six months or 1,500 hours, whichever occurs first. Refer to Section 8 of this manual for procedure.

#### 2.25.2. PR-2 Pressure Protection Valve

Perform an operating test and leakage check of the valve at this interval. Refer to Section 8 of this manual for procedure.

#### 2.25.3. ST-1 Safety Valve

Every six months or 1,500 operating hours perform operating and leakage test. Refer to Section 8 of this manual for test procedure

#### 2.25.4. SR-7 Spring Brake Modulating Valve

Perform an operating and leakage test every six months or 1,500 hours, whichever occurs first.



DO NOT attempt to disassemble and service the valve. The valve contains high spring forces that could result in personal injury if disassembled.

#### 2.25.4.1.Operating Test

- Block vehicle and hold by means other than vehicle brakes.
- 2. Charge air system to governor cut-out pressure.
- 3. Place parking brake control valve in the APPLIED position. Observe that the spring brake actuators apply promptly.

- Remove the plug from the unused delivery port and install a test pressure gauge known to be accurate.
- 5. Place the parking brake control valve in the RELEASE position. Observe that the spring brake actuators release fully.
- With the parking control valve in the RELEASE position, note the gauge pressure reading. Spring brake actuator holdoff pressure should be 107 psi. If the pressure reading is incorrect, the valve must be replaced.
- Place the parking brake control valve in the APPLIED position: The gauge reading should drop to zero promptly. A slow release of pressure, more than three seconds, would indicate faulty operation. Replace the valve.
- Maintain the parking brake control valve in the APPLIED position and gradually apply the brake treadle. The reading on the test pressure gauge, installed in the delivery port should increase.
- 9. Place the parking brake control valve in the RELEASE position.
- 10. Drain the rear brake reservoir to zero psi.
- 11.Apply the brake treadle several times and note that the pressure reading on the gauge decreases each time the brake treadle is applied. After several applications, pressure on the gauge will drop to the point where release of the spring brake actuators will no longer occur.

#### 2.25.4.2.Leakage Test

With the air system fully charged and the parking brake control valve in the RELEASE position, coat all the ports, including the exhaust port, with a soap solution. A 1" bubble in three seconds (175 SCCM) is permitted.

If the Spring Brake Modulating Valve does not function as described in the operating test, or leakage is excessive, it is recommended that the valve be replaced.



#### 2.25.5. SC-1 Single Check Valve

Every six months or 1,500 operating hours perform operating and leakage test. Refer to Section 8 of this manual for test procedure.

#### 2.25.6. DC-4 Double Check Valve

Every six months or 1,500 operating hours perform operating and leakage test. Refer to Section 8 of this manual for test procedure.

#### 2.25.7. RV-1 Pressure Reducing Valve

Inspect and test the pressure reducing valve every six months or 1500 operating hours, whichever occurs first. Refer to Section 8 of this manual for procedure.

#### 2.25.8. RV-3 Pressure Reducing Valve

Inspect and test the pressure reducing valve every six months or 1500 operating hours, whichever occurs first. Refer to Section 8 of this manual for procedure.

#### 2.25.9. R-14 Brake Relay Valve

Perform an operating and leakage test every six months or 1,500 operating hours. Refer to Section 8 of this manual for procedure.

#### 2.25.10.Brake Foot Valve

Every six months or 1,500 operating hours perform operating and leakage test. Refer to Section 8 of this manual for test procedure. Check for physical damage such as broken air lines and missing parts.

#### 2.25.11.Oil/Water Separator

Inspect the Consep oil/water separator as follows:

- Inspect connections for air leaks during the compressor loading cycle. Apply a soap solution around the pipe fittings, hose connections, and at the manual drain port located on the bottom of the drain valve.
- With the compressor charging, apply the brakes and release. After each brake application and release an audible "click" will be heard at the drain valve and a slight puff of air will be expelled.

- If the valve does not operate, check electrical wiring and connector for loose, dirty, or corroded pins. Check for correct voltage at the connector (with brakes applied). Refer to Electrical Schematic "ES Climate Control CC" for further aid in troubleshooting the electrical circuit.
- If the valve does not operate properly, remove from vehicle and service. Refer to Section 8 of this manual for repair instructions.

#### 2.25.12.Steering Knuckle

Lubricate the upper and lower steering knuckle bearing every six months if operating under harsh winter conditions where the vehicle is exposed to salt spray or extremes of temperature. It is recommended that the bearings be greased before the start of the winter season, and then again immediately following the winter season. The lubrication interval may be extended to once every year or 36,000 miles (58,000 km), whichever occurs first if operating under less severe conditions. Lubricate the bearings as follows:



DO NOT over-pressurize the bearing cavity when greasing the bearing, as this could cause the sealing washer, located below the circlip, to bulge outward. Replace sealing washer if distorted.

 Remove the protective plastic cap from the grease fitting and purge-lubricate the bearing. Use only RenoLit LX-OTP-2 lubricant.

#### ™NOTE:

To aid purging of old grease, ensure steering knuckle and grease are at room temperature. Rotate the steering knuckle left and right while applying grease so that the old grease can escape.

- Clean any excess grease from the steering knuckle joint as well as the area above the sealing washer.
- Install protective plastic cap on grease fitting.



# **Six Month Preventive Maintenance**

### 2.25.13.Engine Compartment Access Door Inspection

Inspect, clean, and lubricate the scissor hinges on the engine compartment door every six months as follows:

- Operate the door through its opening range while observing the hinge for smooth operation. Ensure the hinge is not buckled or distorted. Replace the hinge if damaged.
- 2. Use compressed air to blow out any grit from the pivot points of the hinge.
- Wipe any displaced lubricant or grit with a clean cloth.
- 4. Use a brush to work Never-Seez into all the pivot points of the hinge.
- 5. Wipe excess lubricant with a clean cloth.

### 2.25.14. Fire Suppression System



The fire suppression system must be serviced by an authorized Amerex technician that is trained and certified on the Amerex Circuit Monitor and Control Panel Systems and in accordance with NFPA and any federal, state, and/or local code requirements.

□ Perform a six month inspection in accordance latest version of Amerex Installation, Operation, and Instruction Manual No. 19680 and Amerex Installation, and Maintenance Manual 13980.

# 2.25.15.Primary (Suction) Fuel Filter

### ™NOTE:

The frequency at which the fuel filter collar threads require lubrication is dependent on operating conditions. If operating in a harsh winter or salt corrosion environment, lubricate the collar threads every six months.

Lubricate the threads of the fuel collar every six months, or at the beginning and end of the winter season, as follows:

- 1. Set the Battery Disconnect switch to the OFF position.
- Remove the vent cap located on top of the clear cover.
- Place a suitable container beneath the drain valve and drain the fuel until it is below the level of the collar.
- Use a collar wrench to loosen and remove the collar.
- 5. Apply a thin coating of NEVER-SEEZ® anti-seize lubricant to the threads of the collar and fuel filter body.
- 6. Reinstall collar and hand-tighten only.
- Prime the unit by filling the clear cover with clean diesel fuel until it reaches the top of the filter.
- 8. Hand-tighten the vent cap.
- Start the engine and operate at fast idle for at least one minute to purge any air from the system.



## 2.25.16.Power Steering Miter Box

Locate the grease fitting on the bottom of the power steering miter box. Use a manual grease gun and apply only two pumps of grease to lubricate the miter box. Do not apply excessive pressure or quantity of grease that could result in damage to seals. Refer to 2.35. "Fluid & Lubrication Guide" on page 97 in this section for lubricant specification. See "Fig. PM-39: Power Steering Miter Box Lubrication" on page 82.




Fig. PM-39: Power Steering Miter Box Lubrication

# **Yearly Preventive Maintenance**

# 2.26. Yearly Preventive Maintenance

### 2.26.1. Door Sensitive Edge Inspection & Test

Inspect and test the door sensitive edge function every year or 100,000 door operating cycles, whichever occurs first.

- Visually inspect door sensitive edge for cuts, tears, or other damage. Replace sensitive edge if damaged.
- ☐ Inspect for properly connect tubing from sensitive edge to pressure wave switch.
- Inspect electrical connections on pressure wave switch.
- Perform a functional test on the sensitive edge system. Refer to Section 16 of this manual for test procedure.

#### 2.26.2. Fuel Hoses

Thoroughly inspect all fuel hoses annually for cover damage, and for damaged, worn, twisted, crimped, brittle, cracked or leaking lines. Replace hoses whose outer cover is worn through or whose metal reinforcements are damaged. Replace all hoses in or out of machinery every five years or during major overhaul.

### 2.26.3. Wheelchair Ramp Pump

### 2.26.3.1. Hydraulic Fluid

### ™NOTE:

The yearly fluid change interval is based on typical transit operating conditions but may need to be adjusted to suit actual operating frequency. Periodic oil samplings may also be taken to determine fluid cleanliness.

Change fluid as follows:

- Set Battery Disconnect switch to OFF position.
- Suction fluid from reservoir and dispose of fluid in accordance with local regulations.
- Disconnect hydraulic lines from ports "1" and "2" on manifold.

- Manually operate ramp through several operating cycles to expel as much fluid as possible from the actuating cylinder and lines.
- Inspect filters and screens. Refer to 2.26.3.2. "Screen & Filter Inspection" on page 84 in this section for replacement procedure. See "Fig. PM-40: Hydraulic Power Pack Assembly" on page 84.
- 6. Connect and tighten hydraulic lines to ports "1" and "2" on the manifold.
- Fill the reservoir. Refer to 2.35. "Fluid & Lubrication Guide" on page 97 in this section for fluid specifications.
- 8. Manually place the ramp in the stowed position.
- 9. Crack open or remove the STOW line at the aft end of the cylinder.
- 10.Set the Battery Disconnect switch to the ON position.



# DO NOT allow the reservoir to run dry while priming the pump

- 11.Use the ramp DEPLOY switch to "jog" the unit through short deploy strokes, Gradually increase the length of the deploy strokes until a steady stream of fluid flows from the line without air bubbles.
- 12.Tighten the STOW pressure line at the aft end of the cylinder and crack open or remove the DEPLOY line at the forward end of the cylinder.
- 13.Use the ramp STOW switch to "jog" the unit through short stow strokes, Gradually increase the length of the stow strokes until a steady stream of fluid flows from the line without air bubbles.
- 14. Tighten the DEPLOY line at the forward end of the cylinder.
- 15. Operate the ramp through several deploy/ stow cycles.
- 16. Top up reservoir to within 1" of filler cap.






Fig. PM-40: Hydraulic Power Pack Assembly

### 2.26.3.2. Screen & Filter Inspection

Inspect the inlet (suction) screen as follows:

- Separate the reservoir from the manifold by removing the four bolts and clamp plates.
- 2. Remove and discard the O-Ring.
- 3. Remove inlet filter from pump and clean or replace as necessary.
- Install new O-Ring and install reservoir onto manifold.
- 5. Install four bolts with clamp plates and tighten bolts.

Inspect the manifold filters as follows:

1. Disconnect hydraulic lines from manifold ports.

- 2. Remove elbow fittings from manifold.
- 3. Use dental pick or similar tool to remove filter from each port.
- Clean or replace filters as necessary.
- 5. Reinstall elbow fittings into manifold ports.
- Install and tighten hydraulic lines.Inspect the breather vent as follows:
- 1. Locate the breather vent on top of the pump manifold.
- Use a hex socket to remove the breather vent from the manifold.
- 3. Clean or replace the sintered bronze filter as necessary.
- 4. Reinstall breather vent into manifold.

# **Yearly Preventive Maintenance**

### 2.26.4. Instrument Panel & Side Console

Once yearly, inspect the interior of the instrument panel for loose wires. Inspect the interior of the side console for loose wires and chafing air lines. Refer to Section 19 of this manual for further information on these components.

### 2.26.5. Fire Extinguisher

Examine every 12 months to ensure extinguisher is operable. Recharge if below the specified weight or pressure is below operable range. Replace any damaged parts. Check hose for obstructions.

Record maintenance use and recharge dates on the fire extinguisher maintenance tag.

#### 2.26.6. QR-1 Quick Release Valve

Perform the following operation and leakage test at every year or 1,500 hours, whichever occurs first:

- Block the vehicle's wheels and fully charge the air system.
- 2. Apply the parking brake.
- Locate the QR-1 Quick Release Valve on the front axle.
- 4. Apply and release the service brakes several times and observe that the brakes promptly respond at both wheels.
- Make and hold a full brake application and apply a soap solution to the exhaust port. Leakage of a 1" bubble in 3 seconds is permissible.

- Maintain full brake application and apply a soap solution to the body and cover. No leakage is permitted between the body and cover.
- 7. Repair or replace valves that do not function properly or have excessive leakage.

### 2.26.7. Air Strainer

Replace the air strainer every year or 36,000 miles, whichever occurs first.

- Park the vehicle on level ground and chock the wheels.
- Drain the air tanks.
- Locate the air strainer on the front brake & kneeling valve panel.
- 4. Disconnect air line from air strainer.
- Unthread air strainer assembly from nipple connector.
- Remove fittings from air strainer and install in same position on new air strainer. Use Loctite 567 thread sealant on pipe threads.
- Install new air strainer assembly on nipple connector, using Loctite 567 thread sealant on pipe threads.
- 8. Connect and tighten air line.
- Charge the air system to operating pressure and check for leaks at the air strainer connections.

PM - 85

# **Yearly Preventive Maintenance**



#### 2.26.8. Radiator

Inspect the radiator on a yearly basis as follows:

- ☐ Inspect the main positive and negative power cables for wear or frayed insulation. Ensure the protective rubber boots are in place and in good condition.
- Check the main power cable connections for tightness and torque to 20 ft-lb. (27 Nm) if necessary.
- Inspect the condition of the inner and outer nylon bushings on the main power cable pass-through studs.
- Inspect main wiring harness and connections to TMC controller and all fans.
- Inspect fuses and fuse holders.
- Inspect support structure for any damage or loose mounting hardware.

### 2.26.9. Headlight Aim

Check headlight aim on a yearly basis. Refer to Section 9 of this manual for headlight aiming procedures.

### 2.26.10.Oil/Water Separator

### ™NOTE:

This rebuild service interval is determined by the type of service and may need to be adjusted to suit the particular operating environment. High compressor duty cycles and high temperatures can cause a buildup of carbon in the condenser, drain valve, and filter. This contamination must be removed for proper operation.

Rebuild the oil/water separator at this interval and perform a functional test. Refer to Section 8 of this manual for servicing procedures. Refer to your New Flyer Parts Manual for rebuild kit part number.

### 2.26.11. Primary (Suction) Fuel Filter

Inspect the fuel filter every year or 40,000 miles, whichever occurs first, as follows:

- Unplug the electrical connectors from the WIF sensor and heater. Inspect terminals for corrosion. Repair or replace connectors as required.
- Inspect fuel connections for leaks. Check condition and routing of fuel lines. Repair as required.

# **Two Year Preventive Maintenance**

# 2.27. Two Year Preventive Maintenance

### 2.27.1. Cooling System



ALWAYS follow the filling and deaeration procedure when flushing the cooling system. Refer to Section 6 of this manual for procedure.

Cooling system and radiator maintenance should be performed every two years, or 80,000 miles, whichever occurs first.

#### 2.27.1.1.Coolant

- Drain and refill the cooling system with recommended coolant. Refer to 2.35. "Fluid & Lubrication Guide" on page 97 in this section for recommended coolant.
- ☐ Clean and flush the cooling system on an "as needed" basis only. The cooling system must be cleaned and flushed if contaminants such as silicate gel, oil, grease, fuel, scale, rust, or solder bloom are found in the system. Refer to Cummins Operation and Maintenance Manual and Cummins Coolant Requirements and Maintenance Bulletin 3666132 for detailed cleaning and flushing procedures.

### 2.27.1.2. Radiator External Cleaning

Use the following procedure to remove any buildup of mud, salt, sand, road oils, brake lining dust, or tire rubber/carbon black from the exterior surface of the radiator:

### ™NOTE:

The interval at which the radiator is removed for a soak cleaning may be adjusted to suit the actual operating environment and radiator condition.

- Soak the radiator for 24 hours in a hot (150°F) non-caustic detergent solution with all fittings plugged.
- 2. Use low pressure spray equipment with cleaning solvent to clean the fin louvers.
- 3. Final rinse with clear water and air dry.
- Inspect cooling fins and straighten to the original geometry using needle nose pliers or a fin comb.

### 2.27.1.3. Radiator Internal Cleaning

# ™NOTE:

Refer to Cummins Operation and Maintenance Manual and Cummins Coolant Requirements and Maintenance Bulletin 3666132 for detailed cleaning and flushing procedures if performing a complete cooling system flush. Otherwise proceed with following instructions if cleaning is restricted to the radiator only.

- Flush the core with an aluminum compatible system flush solvent, following manufacturer's instructions.
- 2. Rinse with clean water and air dry.

# 2.27.2. Alternator Bearing Replacement

### ™NOTE:

The two year maintenance interval is based on vehicles operating on a 16-18 hour day, six days a week and may need to be adjusted depending on actual operating conditions and previous maintenance history. A more frequent maintenance interval may be required for vehicles operating under a severe duty cycle or operating in conditions where the alternator is exposed to prolonged periods of high engine compartment temperatures.

Replace the front and rear alternator bearing every two years. Refer to Section 9 of this manual for bearing replacement procedure.



## 2.27.3. Air Dryer

## ™NOTE:

The desiccant cartridge and valve box service interval is determined by the type of service and may need to be adjusted to suit the particular operating environment. High compressor duty cycles, excessive compressor oil bypass, and high temperatures can shorten the life of the desiccant cartridge.

Replace the desiccant cartridge and valve box at this interval and perform functional test. See "Fig. PM-41: Air Dryer Assembly" on page 88. Refer to Section 8 of this manual for procedures.

### ™NOTE:

The valve box is located at the bottom of the air dryer and contains the purge valve and muffler.

### 2.27.4. Fire Suppression System

The internal Nickel Metal Hydride (NiMH) backup battery, installed in the SafetyNet Driver Panel, will require periodic replacement. Refer to your Amerex Installation, Operation, and Instruction Manual 16601 for replacement instructions.




Fig. PM-41: Air Dryer Assembly

# **Two Year Preventive Maintenance**

## 2.27.5. Door System Inspection

Perform the following inspection/maintenance on the major door system components every two years or 250,000 door operating cycles, whichever occurs first:

### 2.27.5.1.Connecting Rods & Rod End Bearings

☐ Visually inspect the fore and aft connecting rods on the baseplate for evidence of bending or distortion. Replace damaged connecting rods.

- Check jam nuts on the rod ends for tightness.
- ☐ Check for excessive play in the rod ends. Replace worn rod ends.
- □ Lubricate rod ends with a few drops of SAE #20 oil. See "Fig. PM-42: Entrance Door Baseplate Lubrication" on page 89. See "Fig. PM-43: Exit Door Baseplate Lubrication" on page 90.




Fig. PM-42: Entrance Door Baseplate Lubrication






Fig. PM-43: Exit Door Baseplate Lubrication

# 2.27.5.2.Door Shaft Levers & Mounting Hardware

- Visually inspect the levers on the upper door shaft for worn splines, cracks or other damage. Replace damaged parts.
- ☐ Check lever clamp bolt (wedge & screw) for tightness.

### 2.27.5.3. Upper Door Shaft Pivot Bearings

The upper door shaft pivot bearings locate directly on the door baseplate. Check for smooth rotation of door shafts without binding, noise, or excessive radial or axial play. Replace worn or damaged bearings. These are sealed ball bearing assemblies and do not require lubrication.

# 2.27.5.4.Lower Door Shaft Pivot Bearing

The lower door shaft pivot bearing assemblies are bolted to the vehicle floor and support the door shaft. A spherical bearing rides inside a plain bushing within the lower end of the door shaft. Check for excessive radial play between pivot bearing and the door shaft bushing. Replace

pivot bearing and/or bushing if wear exceeds 0.060". DO NOT lubricate pivot bearing.

# 2.27.5.5.Upper Roller Guide, Brackets, & Bearings

The upper roller bracket assembly is bolted to the door panel and consists of a roller mounted on the shaft of the bracket. The roller tracks within the roller channel (slotted guide) of the baseplate.

- Manually open the door panel, ensuring that the roller operates smoothly within the roller channel of the baseplate.
- Inspect the roller for wear or flat spots. DO NOT lubricate the outer surface of the roller.
- Inspect the bearing shaft on the bracket for wear or scoring. Lubricate the bearing shaft with SAE #20 oil, but DO NOT lubricate the outer surface of the roller.
- ☐ Clean the roller channel in the baseplate but DO NOT lubricate channel.



## 2.27.5.6. Entrance Door Shaft & Arm Assembly

The upper end of the door shaft consists of a splined shaft with a connecting arm and rod end. The lower end of the door shaft consists of a hollow shaft with a connecting arm and hinged mounting bracket. See "Fig. PM-44: Entrance Door Shaft & Arm Assembly" on page 91.

- Check door shaft and arm assemblies for any evidence of bending, twisting, or other physical damage. Repair or replace damaged door shaft and arm assemblies as required.
- Inspect splines on upper end of door shaft for wear, cracks, or other damage. Replace damaged door shaft.
- ☐ Clean the rod end and mounting bracket areas on the upper and lower ends of the door shaft using a clean dry cloth. DO NOT lubricate the sealed spherical bearings on rod ends.
- ☐ Inspect upper and lower mounting brackets for any damage and ensure that they are securely mounted to the door panel.
- ☐ Inspect rod end and shoulder bolt for wear or damage. Replace rod end and/or shoulder bolt if worn or damaged.




Fig. PM-44: Entrance Door Shaft & Arm Assembly



### 2.27.5.7.Exit Door Shaft & Arm Assembly

- ☐ The upper and lower hinged mounting brackets attach the door shaft and arm assembly to the exterior side of the door panel. A lubrication fitting is provided on the hinged mounting bracket to allow lubrication of the flanged bronze bushing from the exterior of the vehicle. See "Fig. PM-45: Exit Door Shaft" on page 92. Check door shaft and arm assemblies for any evidence of bending, twisting, or other physical damage. Repair or replace damaged door shaft and arm assemblies as required.
- Inspect splines on upper end of door shaft for wear, cracks, or other damage. Replace damaged door shaft.
- ☐ Inspect hinged mounting bracket for excessive play.
- Inspect flanged bronze bushing and pin for wear or scoring. Replace flanged bushing and pivot pin if worn or damaged.
- ☐ Lubricate hinged mounting bracket at grease fitting, using a high pressure, low temperature (-40° F) grease.




Fig. PM-45: Exit Door Shaft

# **Two Year Preventive Maintenance**

#### 2.27.5.8.Door Panels

- ☐ Inspect door panels for structural damage. Repair or replace panel if required.
- Inspect exterior door panel pocket seals for cuts, tears, excessive wear, or other damage. Replace pocket seals if required.
- ☐ Inspect leading edge and door jamb seals for cuts, tears, excessive wear, or other damage. Replace if required.
- Apply a light film of silicone lubricant on the mating surfaces of the leading edge and door jamb seals and wipe clean with a dry cloth.

# 2.27.5.9.Door Panel Top & Bottom Seal Assemblies

- Inspect for damage to brush bristles or rubber seal strip. Replace brush if bristles are damaged.
- ☐ Adjust height of top brush to provide light contact only with the top edge of door panels so as to prevent binding.
- Adjust height of bottom brush to provide light contact only with the top surface of the flooring so as to prevent binding.

### 2.27.5.10.Door Operator Proximity Switches

- Check that the proximity switches function properly.
- ☐ Inspect electrical connections. Repair loose connections.
- ☐ Adjust proximity switch air gap if necessary. Refer to Section 16 of this manual for adjustment procedures.

### 2.27.5.11.Entrance Door Solenoid Valves

- ☐ Check for proper operation of the emergency release and dump valve solenoids.
- Inspect electrical connections.
- ☐ Inspect air lines to rotary dump valve and emergency release acutator cylinder. Ensure connections are tight.
- ☐ Inspect emergency release cable for proper operation.

#### 2.27.5.12.Driver's Door Controller

- ☐ Operate the door controller through all positions and check for proper function.
- □ Verify that the door controller moves freely without binding. Use a spring scale to measure torque required to rotate controller. Replace door controller if torque exceeds 15 in-lbs.



# 2.28. Three Year Preventive Maintenance

### 2.28.1. Under Body Inspection

Refer to Section 11 of this manual for procedure.

# 2.29. Four Year Preventive Maintenance

## 2.29.1. Air Dryer

### ™NOTE:

The air dryer rebuild interval is determined by the type of service and may need to be adjusted to suit the particular operating environment. High compressor duty cycles, excessive compressor oil bypass, and high temperatures can shorten the life of the air dryer.

Rebuild the air dryer at this interval and perform functional test. Refer to Section 8 in this manual for procedures and refer to your New Flyer Parts Manual for rebuild kit part number.

# 2.30. Five Year Preventive Maintenance

#### 2.30.1. Door Operator Proximity Switches

- ☐ Check that the switches function properly.
- ☐ Check for proper air gap setting between sensor and target. Refer to Section 16 of this manual for adjustment procedures.

### 2.30.2. Door Component Replacement

It is recommended that the following door components or assemblies be replaced every five years or 500,000 door operating cycles. The replacement interval may need to be adjusted depending on the actual operating conditions. Operating in a harsh environment where the door components are exposed to extremes in temperature,

salt spray, sand, grit, or other contaminants will shorten the life expectancy of the door system components.

- ☐ Connecting rods and rod end bearings
- Upper door shaft pivot bearings
- Door panel top seal assembly
- Door panel bottom seal assembly
- Door panel pocket seals
- ☐ Solenoid valves
- Sensitive edge system including door edge, transfer tube, pressure wave switch, and mechanical limit switches.

### 2.31. Six Year Preventive Maintenance

### 2.31.1. Fire Suppression System

Perform the following maintenance every six years:

- □ As per NFPA 17 guidelines, stored pressure dry chemical Agent Cylinders must be depressurized for inspecting the inside of the agent cylinder and the agent. Refer to latest version of Amerex Installation, Operation, and Maintenance Manual No. 13980 for additional information.
- ☐ Replace the electric linear actuator, located on the discharge valve, if it has been in service for six years.

### 2.31.2. Fire Extinguisher

Inspect the fire extinguisher every six years. Clean all parts to ensure they are operable and refill with new powder and repressurize. Refer to National Fire Protection Association (NFPA) Standard No.10 for additional information.

### 2.31.3. Booster Pump

Replace the pump motor bearings every six years. Refer to Section 10 of this manual for procedure.



### 2.32. Ten Year Preventive Maintenance

### 2.32.1. Door Component Replacement

It is recommended that the following door components or assemblies be replaced every ten years or 1,000,000 door operating cycles. The replacement interval may need to be adjusted depending on the actual operating conditions. Operating in a harsh environment where the door components are exposed to extremes in temperature, salt spray, sand, grit, or other contaminants will shorten the life expectancy of the door system components.

- □ Electric door operator
- ☐ Door shaft levers and mounting hardware
- Lower door shaft pivot bearings
- Upper roller guides, brackets, & bearings
- Door panel leading edge seals
- Door panel jamb seals
- Driver's door controller
- Door panels
- Shaft and arm assemblies
- ☐ Shaft and arm assembly hinged mounting brackets.

# 2.33. Twelve Year Preventive Maintenance

### 2.33.1. Fire Extinguisher

Hydrostatically test the fire extinguisher every twelve years. Refer to label on fire extinguisher for test pressure. Clean all parts to ensure they are operable and refill with new powder and repressurize. Record maintenance and recharge date on fire extinguisher inspection tag. Refer to National Fire Protection Association (NFPA) Standard No.10 for additional information.

### 2.33.2. Fire Suppression System



Hydrostatic testing may only be done by individuals certified to perform hydrostatic testing by those having jurisdiction in the particular area.

Perform a hydrostatic pressure test on the agent cylinder and all hose assemblies every twelve years. Perform test in accordance with CGA Pamphlet C-6, NFPA 17, and DOT requirements. Refer to latest version of Amerex Installation, Operation, and Maintenance Manual No. 13980 for test pressure and test adapters.



# 2.34. Fluid & Lubrication Points




Fig. PM-46: Fluid & Lubrication Points



# 2.35. Fluid & Lubrication Guide

The following Guide is a convenient reference for the lubrication points on your New Flyer vehicle. It provides component locations, lubrication procedures and intervals, and lubricant types. Further preventive

maintenance information on each component in this Guide can be found in this section of the manual under the component's specific maintenance interval. See "Fig. PM-46: Fluid & Lubrication Points" on page 96.

FLUID & LUBRICATION GUIDE				
Item	Component	Procedure	Interval	Lube Type
1	Windshield Washer Bottle		Fill bottle as required	Methylene Alcohol Windshield Washer Fluid
2	Entrance Door Baseplate	Lubricate connecting rod spherical bearings (4 bearings)	Every two years	SAE 20
		Lubricate upper bracket bearing shaft	Every two years	SAE 20
3	Exit Door Baseplate	Lubricate connecting rod spherical bearings (4 bearings)	Every two years	SAE 20
		Lubricate upper bracket bearing shaft	Every two years	SAE 20
		Lubricate door shaft hinged mounting bracket at grease fitting	Every two years	High pressure, low temperature (-40°F) grease
4	Power Steering Miter Box	Refer to 2.25.16. "Power Steering Miter Box" on page 82 in this section for procedure	Every six months	Calcium sulfonate complex grease such as Petro Canada Peerless LLC or equivalent
5	Steering Knuckle Bearings	Refer to 2.25.12. "Steering Knuckle" on page 80 in this section for procedure	Every 6 months or 30,000 miles (48,000 km)	Special-Purpose Grease. Refer to 2.35.2. "MAN Axle Approved Greases" on page 101 in this section for listing
6	Brake Treadle & Foot Valve Assembly	Lubricate brake valve plunger, roller & pin	Every 24,000 miles (38,600 km)	Barium Grease per BW-204-M (Bendix #246671)
7	Wheelchair Ramp Mechanism	Lubricate chains, teflon bearings, bronze bushings, & all sliding surfaces	Every six months	White Lithium Grease (Aerosol Spray)



FLUID & LUBRICATION GUIDE				
Item	Component	Procedure	Interval	Lube Type
8	Wheelchair Ramp Reservoir	Check fluid	Every 6,000 miles (9,600 km)	DEXRON® - III
		Change fluid	Yearly	DEXRON® - III
9	Rear Axle Carrier	Check for leaks under vehicle	Daily	Mineral-Based Extreme Pressure Gear Oil. Refer to
		Check oil level at carrier fill plug	Check at first 3,000 miles (4,800 km), thereafter every 6,000 miles (9,600 km)	2.35.1. "MAN Axle Approved Mineral Oils" on page 100 in this section for listing
		Change Oil	Drain & change upon receipt of vehicle, & thereafter change every 36,000 miles (58,000 km) for "hot region" operation. Refer to 2.2. "Rear Axle Operating Conditions" on page 2 in this section for definition. Change every 54,000 miles (87,000 km) for "moderate region" operation. Refer to 2.2. "Rear Axle Operating Conditions" on page 2 in this section for definition.	
10	Battery Slides	Check & keep clean	Every 6,000 miles (9,600 km)	Multi-Purpose Grease
11	Battery Terminals	Check & apply lubricant as required	Every 6,000 miles (9,600 km)	Dielectric grease such as TruckLite NYK-77
12	Diesel Exhaust Fluid Filter	Change filter	Every 200,000 miles (321,000 km)	API Certified Stabilized Urea Premix meeting ISO 22241-1 standard
13	Diesel Exhaust Fluid Tank	Check fluid & fill as required using pressure fill port	Daily	API Certified Stabilized Urea Premix meeting ISO 22241-1 standard



	F	LUID & LUBRIC	ATION GUIDE	
Item	Component	Procedure	Interval	Lube Type
14	Power Steering Reservoir	Check fluid level through sight glass	Daily	DEXRON®-III
		Change filter	Every 18,000 miles (29,000 km)	DEXRON®-III
		Change fluid	Every 36,000 miles (58,000 km)	DEXRON®-III
15	Engine	Check dipstick level	Daily	Chevron Delo 400 LE 15W-40 (API CJ-4)
		Drain & refill	Every 6,000 miles (9,600 km)	Chevron Delo 400 LE 15W-40 (API CJ-4)
16	Transmission	Check dipstick level	Daily	TranSynd™ Synthetic Transmission Fluid
		Drain & refill	Change both filters eve (120,000 km), 3,000 hr up fluid. Change the flu (240,000 km), 6,000 hr to 2.23. "150,000 Miles Preventive Maintenance section for procedure.	s., or 36 months & top iid every 150,000 miles s., or 48 months. Refer (241,400 km)
17	Driveshaft Slip Joint	Refer to 2.10.4. "Driveshaft" on page 21 in this section for procedure	Upon receipt of vehicle, & thereafter every 6,000 miles (9,600 km)	Extreme Pressure Grease meeting NLGI Grade 2 specification with operating temperature range of 325°F to -10°F (163°C to -23°C). Use CITGO Lithoplex RT-2 or equivalent
18	Driveshaft U-Joints	Refer to 2.10.4. "Driveshaft" on page 21 in this section for procedure	Upon receipt of vehicle, & thereafter every 6,000 miles (9,600 km)	Extreme Pressure Grease meeting NLGI Grade 2 specification with operating temperature range of 325°F to -10°F (163°C to -23°C). Use CITGO Lithoplex RT-2 or equivalent
19	Engine Oil Filters	Replace (full-flow, spin-on)	Every 6,000 miles (9,600 km)	Chevron Delo 400 LE 15W-40 (API CJ-4)



	FLUID & LUBRICATION GUIDE			
Item	Component	Procedure	Interval	Lube Type
20	Surge Tank	Check sight glass	Daily	Old World Industries/ Peak FleetCharge® with Bitrex
		Drain & fill cooling system. Flush only if required	Every two years or 80,000 miles (128,000 km)	Old World Industries/ Peak FleetCharge® with Bitrex
21	Steering Driveshafts	Purge lubricate at grease fittings. Refer to 2.10.6. "Steering Driveshafts" on page 24 in this section for procedure	Every 6,000 miles (9,600 km)	Extreme Pressure Grease meeting NLGI Grade 2 specification with operating temperature range of 325°F to -10°F (163°C to -23°C). Use CITGO Lithoplex RT-2 or equivalent
22	Rear Axle Wheel Bearing	Refer to Section 2 of this manual for lubrication procedure	Whenever rear axle bearing or seals are being serviced	Special-Purpose Grease. Refer to 2.35.2. "MAN Axle Approved Greases" on page 101 in this section for listing

## MOTE:

Moderate regions are defined as geographic locations where the average monthly temperature does not exceed 25°C (77°F) for more than two months of the year.

Hot regions are defined as geographic locations where the average monthly temperature exceeds 25°C (77°F) for more than two months of the year.

### 2.35.1. MAN Axle Approved Mineral Oils

Lubricants used in the rear axle must meet MAN specifications. Oil composition and additives are critical to maintaining the designed operating life of the axle components. The use of unapproved oils has been shown to accelerate the wear rate of internal components and shorten the overall lifespan of the axle. The use of unapproved oils will void the warranty coverage on the axle. The following table provides a list of approved oils that are available in North America.

MAN AXLE APPROVED MINERAL OILS		
Product Brand Name (Viscosity)	MAN Specification	
Mobilube HD-A (SAE 80W-90)	MAN 342 M1	
Castrol Axle EPX 90 (SAE 80W-90)	MAN 342 M1	
Shell Spirax MB 90 (SAE 80W-90)	MAN 342 M1	



MAN AXLE APPROVED MINERAL OILS	
Product Brand Name (Viscosity)	MAN Specification
Petro Canada TRAXON XL Synthetic Blend (SAE 80W-90	MAN 342 M1
Conoco Universal Gear Lubricant (SAE 85W-140)	MAN 342 M1
Conoco Universal Gear Lubricant (SAE 80W-90)	MAN 342 M2
Phillips 66 SMP Gear Oil (SAE 85W-140)	MAN 342 M1
Phillips 66 SMP Gear Oil (SAE 80W-90)	MAN 342 M2
Kendall NS-MP Hypoid Gear Lubricant (SAE 80W-90)	MAN 342 M2

## 2.35.2. MAN Axle Approved Greases

The lubricants used on MAN axles are special-purpose greases that meet the requirements of the specific application

and must not be substituted with alternate grease products. The following table provides a list of approved greases that are available in North America.

MAN AXLE APPROVED GREASES		
Application	Product Brand Name	MAN Specification
Front Axle Steering Knuckle	Fuchs Renolit LX-OTP 2	
Rear Axle Wheel Bearing	Fuchs Renolit LX-PEP 2	MAN 284 Li-H2
	Fuchs Renolit LX-NHU 2	MAN 284 Li-H2







# Front Axle & Suspension

1.	SAFETY	1-1
	1.1. Safety Procedures	1-1
	1.2. Hoisting & Related Safety Information	
	The moterning a motatod during minimum	-
2.	FRONT AXLE & SUSPENSION	1-2
	2.1. Description	1-2
	2.2. Operation	
	2.3. Removal	
	2.4. Installation	
	2.4. IIIStanation	1-3
3.	FRONT AXLE	1-6
•	3.1. Description	
	3.2. Front Axle Specifications	
	• • • • • • • • • • • • • • • • • • •	
	3.3. Maintenance	
	3.4. Tires	
	3.4.1. Tire Specifications	
	3.4.2. Maintenance & Replacement	
	3.5. Wheels	
	3.5.1. Inspection	
	3.5.1.1. Wheel Assemblies	
	3.5.1.3. Nuts	
	3.5.2. Installation	
	3.6. Wheel Bolts	
	3.6.1. Removal	
	3.6.2. Installation	
	3.7. Wheel Hub	1-10
	3.7.1. Description	1-10
	3.7.2. Inspection	1-11
	3.7.3. Wheel Flange Removal	
	3.7.3.1. Special Tool Assembly	
	3.7.4. Wheel Flange Installation	
	3.7.5. Brake Disc Removal & Installation	
	3.7.6. Hub Unit Removal	
	3.7.7. Hub Removal with Hydraulic Puller	
	3.7.7.1. Hydraulic Puller Tool Assembly	
	3.8. Center Link & Tie Rod Ends	
	J.U. Jeiilei Liiik & IIe Iiuu Liiu3	I-IJ

1 - ii

# Table of Contents



	3.8.1.	Inspection	1-19
	3.8.2.	Removal	
	3.8.3.	Installation	1-20
	3.9. Tie	Rod Arms & Steering Arm	1-21
	3.9.1.	Description	
	3.9.2.	Removal	
	3.9.3.	Installation	1-22
	3.10. Stee	ering Knuckle	
		Steering Knuckle Axial Play Check	
		King Pin Removal	
		King Pin Installation	
		. King Pin Bearing & Seal Removal	
		King Pin Bearing & Seal Installation	
4.	FRONT	SUSPENSION	1-34
		scription	
		nt Air Springs	
	4.2.1.	. •	
	4.2.2.	Front Air Springs Specifications	
	4.2.3.	Operation	
	4.2.4.	Removal	
	4.2.5.	Disassembly	
	4.2.6.	Cleaning & Inspection	
	4.2.7.	Leak Test Procedure	
	4.2.8.	Installation	
	4.2.9.	Functional Tests	1-36
	4.3. From	nt Radius Rods	1-37
	4.3.1.	Description	1-37
	4.3.2.	Upper Radius Rod Specifications	
	4.3.3.	Lower Radius Rod Specifications	
	4.3.4.	Operation	
	4.3.5.	Front Radius Rod Troubleshooting	
	4.3.6.	Maintenance	1-38
	4.3.7.	Removal	
	4.3.8.	Lower Radius Rod Bushing Replacement	
	4.3.9.	Installation	
		Functional Test	
	4.4. Fro	nt Shock Absorbers	1-41
	4.4.1.	Description	<b>1-4</b> 1
	4.4.2.	Front Shock Absorbers Specifications	1-41
	4.4.3.	Operation	
	4.4.4.	Front Shock Absorber Troubleshooting	
	4.4.5.	Removal	
	4.4.6.	Cleaning & Inspection	
	4.4.7.	Adjustment	
	4.4.8.	Installation	
	4.4.9.	Functional Test	1-44



	T BRAKE SYSTEM	
	ont Disc Brakes	
5.2. Fi		
5.2.1	•	
• • • • • • • • • • • • • • • • • • • •	•	
5.2.3	· ·	
5.2.4	·	
	5.2.4.1. Brake Pad Clearance Inspection	
	5.2.4.3. Brake Pad Wear Inspection	
	5.2.4.4. Brake Disc Inspection	
	5.2.4.5. Caliper Guide Pin Inspection	
	5.2.4.6. Tappet Rubber Boot Inspection	
	5.2.4.7. Upper Guide Rubber Boot Inspection	
	Brake Pads	
	5.2.5.1. Removal	
	5.2.5.2. Cleaning & Inspection	
	5.2.5.3. Installation	
	. Brake Caliper & Carrier Assembly	
	5.2.6.1. Removal	
	5.2.6.2. Installation	
5.2.7	Caliper Guide Pins	1-6
	5.2.7.1. Removal	
	5.2.7.2. Inspection	
	5.2.7.3. Installation	1-6
5.2.8	. Tappet & Rubber Boot	1-6
	5.2.8.1. Removal	1-6
	5.2.8.2. Inspection	1-6
	5.2.8.3. Installation	1-6
5.2.9	Brake Disc	1-70
	5.2.9.1. Removal	1-7
	5.2.9.2. Installation	1-7
	5.2.9.3. Machining	1-7
5.3. Fr	ont Brake Chambers	1-7
5.3.1	. Description	1-7
5.3.2	•	
5.3.3	·	
5.3.4	•	
5.3.5		
5.3.6		
	T ANTI-LOCK BRAKING SYSTEM (ABS) 8	
	ONENTS	
	escription	
	oeration	
- r	ont ABS Speed Sensor	

# Table of Contents



	6.3.1.	Removal	1-75
		Installation	
	6.4. Fro	nt ABS Pulse Generating Wheel	1-76
		nt ABS Modulator Valve	
	6.5.1.		
	6.5.2.	·	
		Removal	
		Installation	
	6.6. ABS	S Electronic Control Unit (ECU)	1-79
	6.6.1.	Description	1-79
	6.6.2.	ABS Troubleshooting	1-79
	6.6.3.	Blink Code Diagnostics & Troubleshooting	1-80
	6.	.6.3.1. Description	1-80
		.6.3.2. Diagnostic Mode	
		.6.3.3. Clear Mode	
	6.	.6.3.4. System Configuration Code	1-80
7.	FRONT	AXLE SPECIAL TOOLS	1-81
	7.1. Fro	nt Axle Special Tools Chart	1-81
8.	VENDO	OR SERVICE INFORMATION	1-88
		ritor Wabco Manual	1-88





# 1. SAFETY

# 1.1. Safety Procedures

This section of the service manual contains procedures which require the mechanics to strictly observe safety procedures in order to ensure personal and equipment safety.

Always ensure that the vehicle is appropriately hoisted and blocked for procedures which require elevating the vehicle. Be aware of the limitations of the blocking equipment, and always ensure that the jarring and shaking created by component removal and installation procedures does not overload the blocks, or cause the vehicle to become unstable.

Certain procedures may require the vehicle be operated in an elevated position in order to accurately troubleshoot and diagnose a problem. If the vehicle must be running while elevated, become familiar with the repair area prior to starting the engine. Take special care in noting areas which will become hot, electrically energized, and areas where moving and rotating components are located. Limit the work in these areas as personal and equipment safety is at risk.

For procedures which involve air lines, ensure the line is safely depressurized prior to disconnecting. Disconnecting pressurized lines will cause solid particles deposited in the line to be uncontrollably propelled, and will also cause the hose end to whip randomly as the air escapes.

# 1.2. Hoisting & Related Safety Information

Refer to the General Information Section of this manual for information on types of hoists, hoisting procedures, jackstands and related safety information. Refer to this information and read carefully before lifting, hoisting or jacking the vehicle.



# 2. FRONT AXLE & SUSPENSION

# 2.1. Description

This front axle and suspension include the following sub-components and systems:

- Axle Assembly
- Suspension Components
- □ Brake System
- ☐ ABS System

The axle assembly is held in alignment to the vehicle by two upper and lower radius rods. Air spring towers bolted to mounting

pads on each side of the axle transmit the weight of the vehicle to the axle. The wheel end assemblies are mounted on steering knuckles fitted with an upper double row needle bearing and a lower double row needle thrust bearing which pivot on king pins to allow vehicle steering. A steering arm attached to the left knuckle receives inputs from the steering system. An adjustable cross tube transmits steering effort to the right-hand knuckle and maintains wheel alignment. A steering damper assembly is used to absorb road shocks and stabilize the steering system. Adjustable stop bolts installed on each knuckle assembly limit right and left turning angles. See "Fig. 1-1: Front Axle & Suspension" on page 2.




Fig. 1-1: Front Axle & Suspension



# 2.2. Operation

As the vehicle travels, the axle moves vertically relative to the vehicle chassis. The air springs compress and extend as the wheels go over bumps and dips allowing this movement. The rate of movement is controlled by the shock absorbers. The radius rods maintain alignment of the assembly to the vehicle chassis. A leveling valve connected by an operating link to the axle controls the air pressure in both air springs to maintain ride height and prevent tilting of the vehicle when loading is uneven.

### 2.3. Removal

- 1. Drain system air pressure.
- Raise vehicle using wheel lift or center post lift system. Refer to the General Information Section of this manual for procedure.
- 3. Place safety stands under vehicle frame and carefully lower vehicle onto stands.
- Lower lift system slightly more to allow axle assembly to drop about 3" (76 mm).
- Disconnect drag link from steering arm using hydraulic ball joint press (Items 43, 64, 65, & 66 from special tool list). Turn steering wheel fully to the left to move drag link out of the way.
- Disconnect leveling valve linkage from the streetside mounting bracket (do not disturb adjustment) and pull down on leveling valve lever to deflate air springs.

- 7. Disconnect air lines at brake chambers.
- 8. Disconnect ABS brake sensor harnesses.
- Remove two M18 bolts from each pivot pin retaining lower radius rods to vehicle frame. See "Fig. 1-2: Lower Radius Rod Removal" on page 4.
- Remove two M14 bolts from each pivot pin retaining upper radius rods to vehicle frame.
- 11. Ensure axle is well supported, remove 1/2" nut from left and right axle air spring lower mounting pads.
- 12. Disconnect lower end of shock absorbers from mounting pad on axle.

### ™NOTE:

Make sure all Items disconnected from the axle are moved or tied out of the way to prevent interference with axle removal.



Make sure axle assembly is strapped or chained to lifting device to prevent tilting or falling when freed from the frame mounting points.

13. Carefully lower axle and wheel assembly to floor with lift system. Use appropriate lifting equipment to lift the axle onto an adequate work stand. See "Fig. 1-3: Axle Lowered from Vehicle" on page 4.






Fig. 1-2: Lower Radius Rod Removal




Fig. 1-3: Axle Lowered from Vehicle



## 2.4. Installation

## ™NOTE:

Refer to 4.5. "Front Suspension Torque Specifications" on page 45 in this section for all installation torque values.

- Carefully lift axle into position using appropriate lifting equipment.
- 2. Install upper radius rod retaining bolts and torque to specification.
- 3. Connect lower end of shock absorbers to axle and torque mounting hardware to specification.

- 4. Install 1/2" nut retaining air spring to mounting pad and torque to specification.
- 5. Install lower radius rods and torque bolt to specification.
- 6. Connect ABS sensor wiring.
- 7. Connect air lines to brake chambers.
- 8. Connect leveling valve linkage.
- 9. Connect drag link to steering arm. Torque nut to specification and install cotter pin.
- Lower vehicle and test drive to ensure correct operation.



# 3. FRONT AXLE

# 3.1. Description

The front axle and suspension installation consists of a MAN VOK-07-F low floor axle complete with wheel hub assembly, brake caliper & brake disc assembly, center link assembly, tie rod arms and a steering arm. The axle assembly also includes ABS sensor and pulse generating wheel. The brake chambers are mounted directly on the disc brake caliper assembly.

# 3.2. Front Axle Specifications

Manufacturer	MAN
Model	VOK-07-F
Capacity	15,873 lb. (7,200 kg)
Туре	Cast drop beam design

#### 3.3. Maintenance



The repair or reconditioning of front axle components is not allowed. The manufacturer recommends replacing damaged out of specification components. All major components are heat treated and tempered. The components cannot be bent, welded, heated or repaired in any way without reducing the strength or life of the component which can result in a vehicle accident and personal injury. Repair or reconditioning of front axle components will void the warranty.

The following operations on front axle components are prohibited:

- Welding of or to the steering arms, tie rod arms, knuckles, king pins, axle beams, tie rod assemblies, hubs, brake discs or brakes.
- ☐ Hot or cold bending of the knuckles, steering arms, tie rod arms, ball studs, axle beams or tie rod assemblies.

 Drilling out of the king pin bores in the axle beam.

Refer to the Preventive Maintenance Section of this manual for front axle maintenance procedures and intervals.

### **3.4.** Tires

### 3.4.1. Tire Specifications

Manufacturer	Michelin
Model	X INCITY Z
Size	305/70R22.5
Inflation Pressure	125 psi
Maximum Load (single tire)7,76	60 lbs. @ 125 psi

### 3.4.2. Maintenance & Replacement



ALWAYS use tire mounting equipment that is specifically designed for the application and will ensure proper tire mounting without incurring any damage. ALWAYS follow manufacturer's recommendations for use of tire mounting equipment.

### ™NOTE:

In order to maintain compliance with Environmental Protection Agency (EPA 2014-2016) and regulatory emission standards, ALWAYS replace tires with ones that meet or exceed the rolling resistance performance of the original tires.

### ™NOTE:

Consult your tire supplier to ensure that the replacement tire meets the required rolling resistance requirements.

Refer to and follow original tire manufacturer's maintenance procedures in conjunction with the scheduled maintenance identified in the Preventive Maintenance Section of this manual.



### 3.5. Wheels



Special care must be taken when removing, servicing and installing the wheel and tire assembly to ensure operator, mechanic and passenger safety standards are maintained for the service life of the vehicle.

### 3.5.1. Inspection

There are several factors that determine the serviceability of the wheel. These include, but are not limited to corrosion, bent rim, excess paint build up and cracks. Inspect all parts for damage. Ensure that studs, nuts, mounting surfaces of the hub, drum, and wheels are clean, and free of grease or corrosion.

### 3.5.1.1. Wheel Assemblies

Ensure that the wheel mounting surfaces do not have excessive paint thickness, and repair if required. Excessive paint thickness, debris, or excessive corrosion on the wheel mounting surfaces will gradually work its way out during operation and the wheel will become loose. This could result in cracked or broken wheels, damaged brake disc, broken studs, and wheel separation from the vehicle.

Inspect all wheels for cracks, elongated bolt holes, correct shape and form, and other defects that would render the wheel unsafe. Wheels with cracks are not considered serviceable. There are no rework limits for cracks on wheels. Any wheel with a crack is considered scrap, and shall not be reworked. Scrap all wheels which show:

- Cracking
- Deep corrosion defined by a corrosive pit being deeper than 1/2 of the material thickness.

П	Pittin	C

☐ Excessive wear on the mounting surfaces

Bent flanges

Elongated bolt holes

☐ Extended use or excessive wear on the disc face

Illegible stamping

Excessive bead blasting used to remove paint may have a negative effect on the wheel. Too much metal may be removed during repeated bead blasting. As this may lead to wheel cracking and early wheel failure the wheel must be scrapped. Never rework, weld, braze or otherwise heat any damaged wheel. Do not attempt to straighten bent or damaged flanges.

Wheels may be refinished and returned to service if no out of service conditions are present.

#### 3.5.1.2. Studs

Studs with thread damage from over tightening, being run loose, excessive corrosion or other secondary damage should be removed from service. Refer to 3.6. "Wheel Bolts" on page 9 in this section for stud replacement procedure.

#### 3.5.1.3. Nuts

Thread the nuts onto the studs by hand. Nuts must turn easily by hand. Two-piece flange-nuts may be damaged by extended use, excessive torque, or corrosion. Scrap any nut with cracks in the flange, damaged threads or any nut that does not swivel freely with moderate pressure applied to the flange while rotating the nut. Nuts which no longer rotate freely due to corrosion, wear, or paint build-up may be lubricated. Before reusing flange-nuts, apply (2) drops of 30 weight oil between the flange and the body of the hex nut. If a binding condition still exists it should be removed from service.



#### 3.5.2. Installation



This procedure assumes that the vehicle has already been safely jacked up and blocked.

1. Prior to wheel installation, inspect threads of wheel studs and stud nuts. Ensure stud mounting surfaces are clean. Inspect wheel rim center surface for damage.



Replace parts showing even minor damage.

- 2. Align rim stud holes with wheel studs. See "Fig. 1-4: Hub Piloted Wheels" on page 8.
- 3. Install wheel against wheel hub flange.
- 4. Tighten wheel nuts to 100 ft-lb. (136 Nm). Ensure wheel is flush around entire wheel flange mounting surface.
- 5. Lower vehicle to ground.
- 6. Using torque wrench, pretorque wheel nuts to 200 ft-lb. (272 Nm). See "Fig. 1-5: Wheel Nut Torquing Sequence" on page 8.
- 7. Using torque wrench, final torque wheel nuts in sequence to final specification.

### ™NOTE:

Refer to 4.5. "Front Suspension Torque Specifications" on page 45 in this section for final installation torque value. Torque on dry, unlubricated thread only.



BE SURE wheel and tire assembly are at ambient temperatures before checking wheel nut torque.

8. Check torque on all wheel nuts after 50 to 100 miles of operation.




Fig. 1-4: Hub Piloted Wheels




Fig. 1-5: Wheel Nut Torquing Sequence



# 3.6. Wheel Bolts

### 3.6.1. Removal

Use a hammer to remove the wheel bolt from the flange. See "Fig. 1-6: Wheel Bolt Removal" on page 9.




Fig. 1-6: Wheel Bolt Removal

### 3.6.2. Installation

- 1. Insert a new wheel bolt with the truncated end facing the wheel hub. See "Fig. 1-7: Wheel Bolt Installation" on page 9.
- 2. Screw the wheel bolt adapter (Item 15 from special tools list) onto the wheel bolt.
- 3. Install the wheel bolt using the wheel bolt adapter (Item 15 from special tools list) and the impact tool (Item 16 from special tools list).




Fig. 1-7: Wheel Bolt Installation



## 3.7. Wheel Hub

### 3.7.1. Description

The wheel hub assemblies used on this axle are unitized components. The bearings, hub seal and ABS pulse wheel make up the hub assembly. The bearings are grease lubricated and factory adjusted to

provide correct adjustment. The hub is retained to the spindle by a slotted, self locking nut. The wheel driving flange and brake disc are bolted to the end of the hub with 12 capscrews. Wheels are of the hub piloted design and are secured to the hub assembly with ten mounting studs. See "Fig. 1-8: Wheel End Assembly" on page 10.




Fig. 1-8: Wheel End Assembly



## 3.7.2. Inspection

Inspect the wheel hub bearings for excessive play as follows:

- 1. Raise the vehicle and support the front axle on jack stands.
- 2. Ensure the brakes are released and the wheels can rotate freely.
- Attach the base of a magnetic dial gauge to any part of the steering knuckle. See "Fig. 1-9: Wheel Bearing Inspection" on page 11.
- 4. Align the dial gauge pin perpendicular to the face of the brake rotor and as close as possible to the outer edge of the brake disc. Also ensure that the dial gauge pin is located at either the 6 o'clock or 12 o'clock position.

## ™NOTE:

It is important that the dial gauge pin be positioned at the correct distance from the center of the brake disc in order to obtain an accurate reading. The tip of the gauge should be resting approximately 8.25 to 8.5 inches (210 to 215 mm) from the center of the disc.

- 5. Zero the dial gauge.
- Grasp the wheel at the top and bottom and rock back and forth while observing the dial indicator reading.

#### ™NOTE:

If clearance issues resulted in the dial gauge being positioned somewhere other than the 12 o'clock or 6 o'clock position, then ensure the wheel is grasped at a location that corresponds to the dial gauge. As

- an example, if the dial gauge was located at the 2 o'clock position, then grasp the wheel at the 2 o'clock and 8 o'clock positions and rock back and forth.
- If total movement exceeds 0.010" (0.25 mm). Replace the wheel hub as an assembly.

# ™NOTE:

The wheel hub is a unitized assembly and has no replaceable components.




Fig. 1-9: Wheel Bearing Inspection



# 3.7.3. Wheel Flange Removal

- 1. Drain the air tanks.
- Raise the vehicle. Refer to the General Information Section of this manual for procedure.
- 3. Place jack stands under the vehicle at all jacking locations and lower the vehicle until the weight is taken by the jack stands.
- 4. Remove the wheels.
- Assemble flange bolt removal tool (Items 17, 18, 19, 20, 21, 22, 23, 24, 25 from special tools list) and place tool onto two flange mounting bolts. Refer to 3.7.3.1. "Special Tool Assembly" on page 13 for tool assembly instructions. See "Fig. 1-10: Flange Mounting Bolt Removal" on page 12.
- 6. Use the special tool to loosen all the flange mounting bolts.
- 7. Support the wheel flange and completely remove the mounting bolts.
- 8. Remove the flange from the brake disc.




Fig. 1-10: Flange Mounting Bolt Removal



# 3.7.3.1. Special Tool Assembly

The special tool for removing & installing the wheel flange bolts is comprised of nine individual pieces and must be assembled in accordance with following instructions. See "Fig. 1-11: Special Tool Assembly" on page 13.

- 1. Insert the torque multiplier into one end of the support square tube.
- 2. Attach the socket holding tube to the other end of the square support tube and secure with adapter and screw.
- 3. Attach socket onto the torque multiplier and secure with connecting pin.
- 4. Secure the connecting pin in place with O-ring.
- 5. Insert one Torx socket into torque multiplier socket.
- 6. Insert the remaining Torx socket into the socket holding tube.

## ™NOTE:

Check condition of bolts. DO NOT reuse any mounting bolts with signs of damage or deformity.




Fig. 1-11: Special Tool Assembly



# 3.7.4. Wheel Flange Installation

- Lubricate the contact face of the brake disc and the wheel flange with multipurpose grease.
- 2. Install wheel flange against brake disc and install 12 Torx-head bolts.

# ™NOTE:

Replace any mounting bolts with signs of damage or deformity.

3. Use the flange bolt tool (Items 17, 18, 19, 20, 21, 22, 23, 24, 25 from special tools list) to torque 12 Torx-head bolts in a cross-tightening pattern to 288 ft-lb. (390 Nm).

# ™NOTE:

The flange bolt tool is a torque multiplier with a ratio of 1:3.5. For a final torque of 288 ft-lb. (390 Nm), set the torque wrench to 82 ft-lb. (111 Nm).

4. Install the wheels and lower the vehicle.

## 3.7.5. Brake Disc Removal & Installation

Remove the brake disc. Refer to 5.2.9. "Brake Disc" on page 70 in this section for removal procedure.



#### 3.7.6. Hub Unit Removal

- Remove the Wheel Flange. Refer to 3.7.3. "Wheel Flange Removal" on page 12 in this section for procedure.
- Remove the brake carrier and caliper assembly. Refer to 5.2.6. "Brake Caliper & Carrier Assembly" on page 61 in this section for removal procedure.
- 3. Remove the brake disc. Refer to 5.2.9. "Brake Disc" on page 70 in this section for removal procedure.
- Install slotted nut socket (Item 30 from special tools list) onto slotted nut. See "Fig. 1-12: Wheel Hub Slotted Nut Socket" on page 15.
- Install counter holder flange, torque multiplier, counter holder and torque reaction arm (Items 31, 32, 33, & 34 from special tools list) on end of hub and over slotted nut socket. See "Fig. 1-13: Wheel Hub Nut Removal" on page 16.
- Anchor counter holder's torque reaction arm solidly and turn hex on torque multiplier to loosen slotted nut.
- Remove the special tools from the hub, then remove the slotted nut and thrust washer. Discard and do not reuse the slotted nut.
- 8. Thread the fitting sleeve (Item 42 from special tools list) onto end of spindle and carefully pull hub assembly off spindle.

#### ™NOTE:

If hub assembly does not slide off the spindle, then it will be necessary to remove the fitting sleeve and assemble mechanical removal tools in accordance with the following steps.

9. Bolt the puller removal flange (Item 37 from special tools list) onto the hub.

- 10.Install threaded bushing, puller cap, and spindle screw. (Items 36, 38, & 40 from special tools list) into the puller removal flange. See "Fig. 1-14: Wheel Hub Removal" on page 16.
- 11. Rotate the spindle screw to pull off hub unit assembly from the steering knuckle spindle

#### ™NOTE:

If difficulty is experienced removing the hub with the mechanical tools, then it may be necessary to remove the hub hydraulically. Refer to 3.7.7. "Hub Removal with Hydraulic Puller" on page 16 in this section for procedure.




Fig. 1-12: Wheel Hub Slotted Nut Socket






Fig. 1-13: Wheel Hub Nut Removal




Fig. 1-14: Wheel Hub Removal

# 3.7.7. Hub Removal with Hydraulic Puller

- Assemble the hydraulic puller tool. Refer to 3.7.7.1. "Hydraulic Puller Tool Assembly" on page 17 in this section for assembly instructions.
- 2. Mount the hydraulic puller on the wheel hub flange using mounting bolts.
- 3. Tighten the two nuts evenly on the threaded rods until the pressure piece seats against the steering knuckle spindle.
- Connect the hydraulic pump (Item 43 from special tools list) to the hollow piston cylinder
- 5. Remove the hub by applying hydraulic pressure.



# 3.7.7.1. Hydraulic Puller Tool Assembly

Assemble the individual components of the hydraulic puller tool (Items 43, 44, 45, 46, 47, 48, & 49 from special tools list) in accordance with the following instructions. See "Fig. 1-15: Hydraulic Puller Tool Assembly" on page 17.

- 1. Insert the pressure piece into the hollow piston cylinder.
- 2. Screw the two threaded rods into the extractor flange.
- 3. Insert the hollow piston cylinder into the extractor flange.
- 4. Install the traverse plate over the two threaded rods and secure with nuts.




Fig. 1-15: Hydraulic Puller Tool Assembly



## 3.7.8. Hub Unit Installation

- Lubricate steering knuckle spindle and hub bearings with Molykote-D paste. Apply paste on the machined surface of the spindle where the hub bearings are seated except 3/4" of inner bearing seat.
- Thread the fitting sleeve (Item 42 from special tools list) onto end of spindle. See "Fig. 1-16: Hub Fitting Sleeve Installation" on page 18.
- Install hub assembly onto guide sleeve and push hub until it is fully seated.

## ™NOTE:

If the hub assembly cannot be fully seated by hand, then use the hub installation tools and the following procedure:

- 4. Bolt puller flange (Item 31 from special tools list) onto end of hub.
- Install puller assembly (Items 36, 39, 40 & 41 from special tools list) onto the puller flange. See "Fig. 1-17: Wheel Hub Installation" on page 18.
- 6. Thread end of puller screw into the end of the fitting sleeve and turn handle on puller to push hub assembly onto spindle.
- Remove the assembly of special tools including the fitting sleeve from the steering knuckle spindle.
- 8. Install thrust washer and new slotted nut and hand tighten.
- 9. Install slotted nut socket (Item 30 from special tools list) onto slotted nut.
- Install counter holder flange (Items 31 from special tools list) on end of hub and over slotted nut socket.
- 11.Insert the torque wrench and ratchet (Items 35 & 7 from special tools list) into the slotted nut socket.
- 12. Torque the slotted nut to 546 ft-lb. (740 Nm).
- 13. Remove special tools.
- 14.Install brake disc. Refer to 5.2.9. "Brake Disc" on page 70 in this section for procedure.
- 15.Install wheel flange. Refer to 3.7.4. "Wheel Flange Installation" on page 14 in this section for procedure.




Fig. 1-16: Hub Fitting Sleeve Installation




Fig. 1-17: Wheel Hub Installation



## 3.8. Center Link & Tie Rod Ends

## 3.8.1. Inspection

- Visually inspect the center link, clamp and tie rod ends, paying particular attention to the rolled seam of the ball joint. All components must be free of corrosion and physical damage.
- Inspect the rubber boot on the ball joint for evidence of damage. The rubber boot must be securely retained by the clamping rings and should not rotate by hand.
- 3. Compress the rubber boot by hand and check that there are no cracks and that no grease emerges.
- Check the ball joint for axial play by applying vertical force (up and down) to the ball joint. The maximum allowable axial play is 0.079 in. (2.0 mm). Replace center link ball joint if necessary.
- Check the ball joint for radial play by applying horizontal force (side to side). The maximum allowable radial play is 0.010 in. (0.25 mm).

# ™NOTE:

The radial play is considered within tolerance if the axial play is within the maximum allowable tolerance.

- 6. There must not be any play between the threads on the ball joint and the threads of the center link tube adjusting sleeve.
- Twist the center link by hand and ensure that the ball joints rotate freely at either end.

#### 3.8.2. Removal

 Remove and discard self-locking nuts from center link tie rod ends.

- Assemble the ball joint press (Items 64 & 65) and position over the ball joint. Align the press so the piston is centered on the ball joint and tight. See "Fig. 1-18: Tie Rod End Removal" on page 19.
- Secure the ball joint press to the vehicle using the safety chain. (Item 66 from special tools list).
- 4. Connect the hydraulic pump (Item 43 from special tools list) and separate center link tie rod ends from tie rod arms.
- 5. Loosen center link tie rod end clamp bolt.
- 6. Thread tie rod end out of center link.




Fig. 1-18: Tie Rod End Removal



#### 3.8.3. Installation

## ™NOTE:

Refer to 4.5. "Front Suspension Torque Specifications" on page 45 in this section for all installation torque values.

- Thread adjusting sleeve into center link until the end of the hex head on the sleeve is 0.708 ± 0.275 in. (18 ± 7 mm) from the end of the center link. Refer to dimension "A". See "Fig. 1-19: Tie Rod End Adjustment" on page 20.
- Hold adjusting sleeve to prevent rotation and thread in tie rod end until center line of ball joint is 2.0 in. (52 ± 7 mm) from end of adjusting sleeve. Refer to dimension "B".
- 3. Check that the exposed thread length on the tie rod end (dimension "D") equals the exposed thread length on the adjusting sleeve (dimension "C").
- 4. Apply NEVER-SEEZ®, install center link tie rod ends into tie rod arms.
- 5. Install new self-locking nut (M24 x 1.5) and torque to specification.

## ™NOTE:

Install an 8 mm Allen wrench in end of ball stud to prevent it from rotating while tightening self locking nut.

Ensure center link tie rod end clamp is correctly oriented on center link. Ends of clamp must be centered over slot in center link and positioned to allow clamp bolt to pass through machined recess in end of link. See "Fig. 1-20: Center Link Tie-Rod End" on page 21.

- 7. Tighten center link tie rod end clamp bolt (M14 x 1.5) to specification.
- 8. Check toe-in and adjust as required. Refer to Section 3 of this manual for procedure.




Fig. 1-19: Tie Rod End Adjustment






Fig. 1-20: Center Link Tie-Rod End

# 3.9. Tie Rod Arms & Steering Arm

## 3.9.1. Description

The LH and RH tie rod arms are bolted onto the steering knuckle and serve to connect the steering center link with the steering knuckles. The steering arm is bolted to the streetside steering knuckle and serves to connect the drag link to the steering knuckle. See "Fig. 1-21: Tie Rod & Steering Arms" on page 22.

# ™NOTE:

The tie rod arms and steering arm are not repairable and cannot be straightened or welded. Replace the tie rod arm or steering arm with a new item if any wear or damage is evident.






Fig. 1-21: Tie Rod & Steering Arms

#### 3.9.2. Removal

- Assemble the ball joint press (Items 64 & 65) and position over the drag link ball joint. Align the Press so the piston is centered on the ball joint and tight.
- Secure the ball joint press to the vehicle using the safety chain. (Item 66 from special tools list.)
- 3. Connect the hydraulic pump (Item 43 from special tools list) and separate drag link from steering arm.
- 4. Use internal Torx socket (Item 67 from special tools list) and socket wrench assembly (Items 3, 4, 5, & 6 from special tools list) and remove two M22 bolts from steering arm and each tie rod arm.

#### 3.9.3. Installation

- Install steering arm using two new selflocking bolts.
- 2. Install each tie rod arm using two new self-locking bolts.
- 3. Use internal Torx socket (Item 67 from special tools list) and torque wrench assembly (Items 3, 4, 5, & 7 from special tools list) and torque bolts to specification.
- Connect drag link ball joint to steering arm and tighten to specification. Refer to Section 3 of this manual for installation procedure.



# 3.10. Steering Knuckle

## ™NOTE:

The following procedure requires the vehicle to be lifted with the wheels off the ground and the axle supported. The weight of the wheels places an axial load on the upper steering knuckle bearings opposite to what is experienced in normal operation. This will result in increased friction when the wheels are turned left and right during the axial play check and is considered normal under these circumstances. Do not use this "stiff to turn" condition as criteria for rejecting steering knuckle bearings.

## 3.10.1. Steering Knuckle Axial Play Check

- Raise and support front axle at the serviceable height using appropriate jack stands, that will allow the front wheels to be suspended off the service bay floor and permit the use of a wheel lifting bar.
- Install a dial gauge assembly with magnetic base. Place the magnetic base on the axle beam and the tip of the dial gauge on top of the steering knuckle.
- Ensure front wheels are facing forward, insert wheel lifting bar under wheel, raise and lower wheel, noting amount of axial (up and down) play. Assistance may be required to visually verify steering knuckle movement.
- 4. Determine if the amount of axial (up and down) steering knuckle play is in excess of the 0.008" (0.2 mm) and note as to left or right front wheel for reference when inserting the correct size of shim.
- 5. Repeat procedure for the remaining wheel.

## 3.10.2. King Pin Removal

- Set Battery Disconnect switch to OFF position.
- Drain all air tanks.
- Raise vehicle to working height. Refer to the General Information Section of this manual for procedure.
- Place jack stands under each jacking point on the vehicle frame. Lower the vehicle and allow the jack stands to take the weight of the vehicle.
- 5. Remove tire and wheel assembly.
- Remove brake chamber. Refer to 5.3. "Front Brake Chambers" on page 72 in this section for removal procedure.
- Remove disc brake pads. Refer to 5.2.5. "Brake Pads" on page 59 in this section for removal procedure.
- Remove the brake caliper and carrier assembly. Refer to 5.2.6. "Brake Caliper & Carrier Assembly" on page 61 in this section for removal procedure
- 9. Remove the wheel flange. Refer to 3.7.3. "Wheel Flange Removal" on page 12 in this section for removal procedure.
- 10. Remove the brake disc. Refer to 5.2.9. "Brake Disc" on page 70 in this section for removal procedure.

#### ™NOTE:

It is not necessary to remove the wheel hub from the steering knuckle. The steering knuckle can be serviced with the wheel hub in place.



11. Disconnect tie rod end from tie rod arm of steering knuckle being serviced. Refer to 3.8. "Center Link & Tie Rod Ends" on page 19 in this section for procedure.

## ™NOTE:

It is not necessary to separate the tie rod end if the tie rod arm has already been removed from the steering knuckle.

- 12. Remove the ABS speed sensor. Refer to 6.3. "Front ABS Speed Sensor" on page 75 in this section for procedure.
- 13. Using the thrust bearing sleeve positioning tool (Item 50 from special tools list) slide the dust guard on the thrust bearing down and away from the axle beam. See "Fig. 1-22: Axle Beam Dust Guard" on page 24.
- 14.Remove circlips (snap ring) from upper and lower king pin sealing washers. See "Fig. 1-23: King Pin Snap Ring Removal" on page 24.
- 15. Remove the sealing washers and O-rings.
- 16. Position king pin press (Items 51 & 52 from special tools list), with pressing ram at the bottom, over steering knuckle.
- 17.Insert mandrel (Item 55 from special tools list) into press ram and spacer tube (Item 57 from special tools list) into crossbeam on press.
- 18. Mount king pin press onto steering knuckle ensuring sleeve and mandrel are correctly aligned and press king pin up into spacer tube and out of knuckle. See "Fig. 1-24: King Pin Removal" on page 25.
- 19. Lift king pin out though bore in press crossbeam using magnetized centering mandrel. (Item 53 from special tools list). See "Fig. 1-25: King Pin Removal Tool" on page 26.
- 20. Retract press ram and remove king pin press and attachments.
- 21. Remove steering knuckle assembly and spacer shim.




Fig. 1-22: Axle Beam Dust Guard




Fig. 1-23: King Pin Snap Ring Removal






Fig. 1-24: King Pin Removal






Fig. 1-25: King Pin Removal Tool

## 3.10.3. King Pin Installation

- Determine required thickness of steering knuckle axial play control shim.
  - a. Measure space between lower surface of upper king pin boss on knuckle and thrust bearing face. Dimension "A". See "Fig. 1-26: Steering Knuckle Spacer Shim" on page 27.

- Measure distance between upper and lower machined faces adjacent to king pin bore on axle beam. Dimension "B".
- c. Subtract dimension "B" from dimension "A" to obtain the required shim thickness.

## ™NOTE:

The correct axial play is 0.0 to 0.008" (0.0 to 0.2 mm).

- 2. Retract the press ram and position press with pressing ram on top. Install spacer tube (Item 57 from special tools list) into press cross beam.
- 3. Position steering knuckle on axle beam and align with king pin bore in axle beam.
- Install correct shim between thrust bearing and axle beam.
- 5. Place magnetized end of short centering mandrel (Item 54 from special tools list) against lower end of king pin.
- Position steering knuckle on spacer tube and press king pin in until the stop is reached.

## ™NOTE:

The Kingpin will only be partially installed and the magnetized centering mandrel can be removed.

 Install pressing adapter (Item 56 from special tools list) on end of ram and complete the king pin installation. See "Fig. 1-28: King Pin Installation" on page 28.



8. Remove the hydraulic press and special tools then manually move the steering knuckle back and forth, until it contacts the axle and stops. Repeat several times.

# ™NOTE:

It must be possible to turn the steering knuckle easily and through the complete range of motion

- Using the thrust bearing sleeve positioning tool (Item 50 from special tools list) slide dust guard sleeve on thrust bearing up until it locks into position. See "Fig. 1-27: Thrust Bearing Sleeve Positioning Tool" on page 27.
- 10.Install upper and lower sealing washer with new O-ring into king pin bore and retain with circlip. See "Fig. 1-29: King Pin & Steering Knuckle Assembly" on page 29.
- 11.Lubricate both grease fittings. Refer to the Preventive Maintenance Section of this manual for grease specifications.
- 12.Install a protective plastic cap on the king pin grease fittings.




Fig. 1-26: Steering Knuckle Spacer Shim




Fig. 1-27: Thrust Bearing Sleeve Positioning Tool






Fig. 1-28: King Pin Installation






Fig. 1-29: King Pin & Steering Knuckle Assembly

## 3.10.4. King Pin Bearing & Seal Removal

- Position press ram at the top. Insert spacer tube (Item 57 from special tools list) into press cross beam. Place steering knuckle upside down (Iower needle bearing end of knuckle facing up) on spacer tube and secure steering knuckle with retaining strap. Insert long end of pressing mandrel (Item 61 from special tools list) into larger end of pressing adapter (Item 60 from special tools list). Position pressing adapter in king pin bearing bore of steering knuckle and short end of pressing mandrel onto end of press ram. See "Fig. 1-30: King Pin Needle & Thrust Bearing Removal" on page 30.
- 2. Press needle bearing and thrust bearing assembly out of steering knuckle.

- 3. Retract press ram and remove pressing adapter.
- 4. Remove sealing ring and install pressing adapter (Item 60 from special tools list) into center of steering knuckle (small end down) and on inner end of needle bearing. See "Fig. 1-31: King Pin Needle Bearing Removal" on page 31.
- Slide shorter end of pressing mandrel (Item 61 from special tools list) down through king pin bore of knuckle and into pressing adapter (Item 60 from special tools list).
- Position long end of mandrel against press ram and press needle bearing out of steering knuckle and into spacer tube (Item 57 from special tools list).






Fig. 1-30: King Pin Needle & Thrust Bearing Removal






Fig. 1-31: King Pin Needle Bearing Removal

#### 3.10.5. King Pin Bearing & Seal Installation

- Slide needle bearing assembly onto pressing adapter (Item 62 from special tools list). The packing sleeve will slide out of the bearing. Save the sleeve for reuse.
- Place pressing adapter and needle bearing into center of steering knuckle and over bearing boss in lower part of knuckle. Ensure smaller end of pressing adapter is towards bearing boss.
- Slide short end of pressing mandrel (Item 61 from special tools list) through bore of knuckle and into larger end of pressing adapter (Item 62 from special tools list). See "Fig. 1-32: King Pin Needle Bearing Installation" on page 32.
- 4. Slide pressing adapter (Item 60 from special tools list) over mandrel and into bore of

- steering knuckle to center mandrel in the bore and act as a guide.
- Position long end of mandrel against press ram and press needle bearing in until shoulder on pressing adapter (Item 62 from special tools list) seats on steering knuckle.
- 6. Retract the press ram and remove mandrel and pressing adapters.
- 7. Reinstall packing sleeve in bearing to prevent bearing needles from falling out when handling the steering knuckle.
- 8. Lift steering knuckle assembly off spacer tube (Item 57 from special tools list) and rotate 180°. Reinstall on spacer tube ensuring needle bearing and packing sleeve assembly is facing up.



- Insert pressing adapter (Item 63 from special tools list) into needle bearing and thrust bearing assembly. Do not remove packing sleeve. Ensure flange on pressing adapter seats against thrust bearing.
- 10. Place pressing adapter and needle bearing and thrust bearing assembly into center of steering knuckle and over bearing boss in lower part of knuckle. Ensure smaller end of pressing adapter is towards bearing boss.
- Remove packing sleeve from upper needle bearing assembly.
- 12.Insert short end of pressing mandrel (Item 61 from special tools list) through upper needle bearing assembly and into larger end of pressing adapter. (Item 63 from special tools list).
- 13. Slide pressing adapter (Item 62 from special tools list) over mandrel and into needle bearing to center mandrel in upper bearing and act as a guide.

- 14. Position long end of mandrel against press ram and press needle bearing and thrust bearing assembly in until shoulder on pressing adapter (Item 63 from special tools list) seats on steering knuckle. See "Fig. 1-33: King Pin Needle & Thrust Bearing Installation" on page 33.
- 15. Retract the press ram and remove mandrel and pressing adapters.
- 16. Install the double-lip seal into the steering knuckle upper bore. See "Fig. 1-34: Steering Knuckle Seal Installation" on page 33.

# ™NOTE:

Ensure that the lip on the larger diameter of the seal enters the machined groove in the steering knuckle. Earlier versions of this seal did not have this lip and the steering knuckle did not have the machined groove. Refer to your New Flyer Parts Manual to ensure correct seal is installed to match the steering knuckle configuration




Fig. 1-32: King Pin Needle Bearing Installation






Fig. 1-33: King Pin Needle & Thrust Bearing Installation




Fig. 1-34: Steering Knuckle Seal Installation



# 4. FRONT SUSPENSION

# 4.1. Description

The front axle suspension components include:

- Front Air Springs
- ☐ Front Radius Rods
- □ Front Shock Absorbers

# 4.2. Front Air Springs

## 4.2.1. Description

The air spring assembly consists of a rubber bellows mounted on a plate. The upper cover contains two threaded fittings. One fitting attaches the air spring to the chassis; the other is hollow and is used as an air inlet for suspension control. The upper and lower beads are crimped permanently during manufacture and cannot be separated.

## 4.2.2. Front Air Springs Specifications

Make	Firestone
Model	1T15LP-5

#### 4.2.3. Operation

The air spring assembly receives air pressure from the vehicle air system and responds to height adjustment inputs from the height control valve or kneeling control. Pressurized air enters the spring though a hollow mounting stud at the top of the spring. The spring action of the bellows allows for movement of the axle as the wheels go over bumps and depressions.

#### 4.2.4. Removal

- 1. Raise the vehicle using wheel lifts or center post lift. Refer to the General Information Section of this manual for procedure.
- 2. Use safety stands under frame to hold vehicle in position.

- 3. Lower wheel lift until there is a 3" (76 mm) space between axle and axle bumper.
- 4. If system is pressurized, disconnect height control valve rod then pull down valve lever to exhaust air from spring. (mark rod attachment position for reinstallation)
- Disconnect air line. Remove lower nut attaching air spring to mounting plate. See "Fig. 1-35: Front Air Spring Removal & Installation" on page 34.
- Remove nuts and washers securing upper end of air spring to chassis.
- 7. Slide spring out of chassis and remove.




Fig. 1-35: Front Air Spring Removal & Installation



## 4.2.5. Disassembly

The air spring is supplied as a complete assembly, piston bellows and bead plate therefore no disassembly is required.

## 4.2.6. Cleaning & Inspection

- 1. Clean air springs with soap and water.
- Check condition of mounting studs and threaded hole.
- 3. Examine piston for cracking or damage.
- 4. Examine the bellows assembly for cracks in the rubber or physical damage.

#### 4.2.7. Leak Test Procedure

Test the air springs assembly (positioned in safety cage) for leakage using the pres-

sure test fixture illustrated and the following procedure: See "Fig. 1-36: Leak Test Fixture" on page 35.

- 1. Thread male end of quick disconnect into air inlet hole of housing.
- Connect air line and raise air pressure initially to approximately 45 to 55 psi. Air springs should now be properly seated in housing. Check bead ring area for air leaks using a solution of soapy water.
- 3. If no air leakage is present, raise air pressure to a maximum 120 psi.
- 4. Disconnect air line, remove test fitting and remove air springs assembly from safety cage.




Fig. 1-36: Leak Test Fixture



## 4.2.8. Installation

# ™NOTE:

Refer to 4.5. "Front Suspension Torque Specifications" on page 45 in this section for all installation torque values.

- Raise the vehicle using wheel lifts or center post lift. Refer to the General Information Section of this manual for procedure.
- 2. Use safety stands under frame to hold vehicle in position.
- 3. Lower wheel lift until there is a 3" (76 mm) space between axle and axle bumper.

- 4. Align stud in bottom of air spring with holes in mounting plate. Install bolts and torque to specification.
- 5. Install nuts on upper air spring studs and torque to specification.
- 6. Lower vehicle.

#### 4.2.9. Functional Tests

- 1. Run engine to build up air pressure.
- 2. Check for air leaks.
- 3. Test drive vehicle to verify ride quality and silence of operation.



# 4.3. Front Radius Rods

# 4.3.1. Description

The upper radius rods are attached to the spring towers and to the chassis. The

lower radius rods are attached to the center of the axle beam and the lower front chassis cross member. See "Fig. 1-37: Upper & Lower Radius Rod Installation" on page 37.




Fig. 1-37: Upper & Lower Radius Rod Installation



## 4.3.2. Upper Radius Rod Specifications

ManufacturerMAN
ConstructionSteel body, rubber bushings
Tensile Strength70,000 psi
Cross Pin Angle0° offset
Mounting Bolt SizeM14

#### 4.3.3. Lower Radius Rod Specifications

Manufacturer	ZF Lemforder
Construction	Steel body, rubber bushings
Tensile Strength	70,000 psi
Cross Pin Angle	1° offset
Mounting Bolt Si	ze M18

#### 4.3.4. Operation

The four radius rods hold the axle in alignment to the chassis as it oscillates and moves up and down. Pivot points are rubber bushed to allow movement without transmitting noise or vibration. Shims installed between a radius rod and its mounting point are used to set front axle alignment.

#### 4.3.5. Front Radius Rod Troubleshooting

Drive the vehicle while listening for rattling or clunking sounds as the suspension reacts to surface irregularities. Also listen for clunking sounds when transitioning between acceleration and braking. If noise is evident inspect radius rod mounting hardware and condition of bushings.

#### 4.3.6. Maintenance

Refer to the Preventive Maintenance Section of this manual for scheduled inspection intervals.

#### 4.3.7. Removal



DO NOT attempt to remove more than one radius rod at a time. Removing two or more radius rods will cause the axle to become unstable.

 Raise the vehicle. Refer to the General Information Section of this manual for lifting procedures.

# ™NOTE:

Radius rod replacement should be done at vehicle ride height to ensure the radius rod bushing is in a neutral load position. The use of wheel lifts is recommended or alternatively supporting the axles with jack stands.

Remove the radius rod mounting bolts while taking note of the washer locations and quantity.

#### ™NOTE:

The hardened washers located between the radius rod cross-pin and the axle or vehicle structure serve as shims for alignment purposes. Always replace washers at each location with the same quantity as originally removed.

3. Remove the radius rod from the vehicle.





# 4.3.8. Lower Radius Rod Bushing Replacement

# ™NOTE:

The upper radius rod bushings are not replaceable. Replace the complete radius rod as an assembly if bushings are worn or damaged.

1. Place radius rod on a hydraulic press with snap-ring groove facing up.

## ™NOTE:

The bushing must be compressed before the snap-ring can be removed.

- 2. Select a pressing sleeve that will seat on the metal shell of the bushing. Do not press on the rubber portion of the bushing.
- 3. Slowly compress the bushing until pressure is relieved from the snap ring.
- 4. Use snap ring pliers to remove the snap ring. Discard snap ring.
- 5. Reverse the position of the radius rod and tap out the bushing.

## ™NOTE:

If the bushing is heavily corroded, it may be necessary to remove the bushing with the hydraulic press.

- Clean and inspect snap-ring groove for wear or damage.
- Use a wire brush or scraper to remove any rubber that has transferred to the bore of radius rod.
- 8. Apply lubricant, supplied in kit, to the bushing O.D. and the I.D. of the radius rod bore.
- Insert bushing into bore of radius rod so that the cross-pin angle is properly aligned. See "Fig. 1-38: Front Lower Radius Rod Bushing Replacement" on page 40.
- 10.Use a pressing sleeve and press on the metal shell of the bushing sufficiently to compress the bushing and allow insertion of the snap-ring into the groove.
- 11.Use snap-ring pliers to insert snap-ring into groove. Ensure snap-ring is fully seated.

#### ™NOTE:

The snap-ring should be positioned so that the opening of the snap-ring is facing downward and toward the radius rod tube at a 45° angle.






Fig. 1-38: Front Lower Radius Rod Bushing Replacement

## 4.3.9. Installation

# ™NOTE:

Refer to 4.5. "Front Suspension Torque Specifications" on page 45 in this section for all installation torque values.

 Install the radius rod in its original location and orientation using the same location and quantity of washers as originally removed. Ensure the bend in the radius rod tube is pointing downward.

# ™NOTE:

The mounting bolts should install freely without having to twist or forcibly align the mounting holes in the cross-pin. If difficulty

is experienced aligning the radius rod mounting holes with the vehicle structure or axle, remove the radius rod for closer examination and ensure the bushing and cross-pin were installed at the proper angle.

2. Apply Never-Seez® to fastener threads and torque bolts to specification.

## 4.3.10. Functional Test

Test drive vehicle and check for proper suspension action without noise or vibration.



## 4.4. Front Shock Absorbers

## 4.4.1. Description

The two front shock absorbers are a double-acting, telescoping type and consist of a piston, a piston rod, a working cylinder, a reservoir cylinder, a main valve assembly, a bypass valve assembly, and a compression (footvalve) valve assembly. The shock absorbers can be adjusted to compensate for loss of rebound damping force caused by wear of moving parts. These units are of welded construction and cannot be repaired.

#### 4.4.2. Front Shock Absorbers Specifications

Make	Koni
Model	90-2517
Mounting	Top pin, bottom pin
Collapsed Length	15.5"
Extended Length	24.5"
Stroke	9.0"

## 4.4.3. Operation

The function of the shock absorber is to absorb the energy caused by movement of the suspension. The shock absorber makes two movements, a bump stroke and a rebound stroke.

#### Bump Stroke

During the bump stroke, the piston and rod travel into the cylinder. Oil flows from below the piston through orifices and into the upper part of the cylinder, thus equalizing pressure in the cylinder. The piston rod entering the cylinder displaces oil which escapes through the compression valve. The restriction of oil flow through the compression valve produces the bump damping force of the shock absorber.

#### □ Rebound Stroke

When the piston and rod travel upwards, oil above the piston is trapped and forced

through orifices in the piston and rod. The bypass valve is forced open when the pressure generated by the oil overcomes the force of the bypass valve spring. The resistance to oil flow produces the rebound damping force. The void caused by the piston rod exiting the cylinder is filled with oil from the reservoir entering the cylinder through the compression valve.

## 4.4.4. Front Shock Absorber Troubleshooting

Perform the following operational test if vehicle ride deterioration is experienced or if shock absorber failure is suspected:

- 1. Drive the vehicle at moderate speeds for at least 15 minutes to bring shock absorbers up to normal operating temperature.
- Within a few minutes of driving the vehicle, touch each shock absorber carefully on its body below the dust cover or tube, after first touching a nearby part of the chassis to establish a reference ambient temperature of the metal.
- All shock absorbers should be warmer than the chassis. A shock absorber that is noticeably cooler than the other shock(s) on the same axle indicates a possible internal failure and warrants removal of the shock absorber for further inspection.
- Remove the suspected shock absorber and inspect for internal failure by shaking the shock. The rattling sound of internal parts indicates a failure.
- Inspect the shock absorber for loss of damping force. Refer to 4.4.6. "Cleaning & Inspection" on page 43 in this section for procedure. Replace shock absorber if defective.

## ™NOTE:

Only replace the shock absorber that is defective. Although it is not necessary to replace shock absorbers in sets, it is recommended that the other shock absorber(s) be given a thorough inspection.



#### 4.4.5. Removal



ALWAYS support the weight of the axle when replacing shock absorbers.

 Raise the vehicle. Refer to the General Information Section of this manual for lifting procedures. Follow all applicable safety requirements.

# ™NOTE:

The upper shock mount requires removal of the mounting plate in order to access the top mounting nut.

- 2. Remove the four nuts retaining the upper shock mounting plate to the chassis bracket. See "Fig. 1-39: Shock Absorber Installation" on page 42.
- 3. Remove the protective cap from the lower shock mounting nut and remove the nut.
- Remove the clamping plate, rubber bushing, and centering ring from the shock stud, noting the location and orientation of the parts.
- Compress the lower shock sufficiently to remove the shock stud from the lower mounting bracket. Remove the remaining rubber bushing from the shock stud.
- 6. Remove the shock absorber assembly from the vehicle and disassemble the upper mounting components as follows:
  - Remove the protective cap from the upper shock mounting nut and remove the nut.
  - b. Remove the clamping plate, rubber bushing, and centering ring from the shock stud, noting the location and orientation of the parts.
  - Remove the remaining mounting plate, rubber bushing and steel sleeve from the shock stud.




Fig. 1-39: Shock Absorber Installation



## 4.4.6. Cleaning & Inspection

- Discard rubber bushings and mounting hardware.
- 2. Check condition of threads on each end of the bayonet mounting studs.
- Check for leakage at the piston rod seal. Leakage can most easily be seen with the shock fully extended and will appear as a stream of fluid originating from the piston rod seal.

## MOTE:

DO NOT replace shock absorbers that exhibit misting. Misting is a normal condition that results from very small amounts of shock fluid evaporating at high operating temperatures through the upper rod seal. This vapor condenses when it reaches the cooler outside air and deposits a film on the outside of the shock body, which in time will attract road debris and dust to form a layer of grime. The evaporation of fluid through the rod seal area helps lubricate and prolong the life of the seal.

- 4. Inspect the exterior of the shock absorber tube for dents or other physical damage.
- 5. Inspect the piston rod for bending, scoring, nicks, or other surface imperfections.
- 6. Hold the shock in its installed position, push in and pull out on the piston rod, while holding the other end stationary to check for bump (compression) and rebound (extension) damping. The shock absorber should extend and compress smoothly in both directions, although more force will be required in extension than compression.

#### 4.4.7. Adjustment

## ™NOTE:

The shock absorbers fitted on this vehicle feature adjustable rebound damping. This adjustment can be used to compensate for

loss of damping force or additional vehicle weight. New shock absorbers are designed for optimal performance at the minimal damping setting and should be installed as received. Adjust shock absorbers that exhibit deteriorated damping characteristics using the following procedure. Ensure that both shock absorbers on a common axle are adjusted equally.

- 1. Remove shock absorbers from vehicle in accordance with preceding instructions.
- Clamp the lower end of the shock absorber in a vise, being careful not to damage the threaded end of the stud.
- Collapse the shock absorber while slowly rotating it counterclockwise. As it nears the fully collapsed position, the cams on the internal adjusting nut should engage the recesses of the footvalve and a slightly increased resistance to rotation should be felt.
- Maintain slight pressure on the shock absorber in the fully collapsed position while rotating it counterclockwise and recording the number of turns until the internal stop is reached.
- Readjust the shock absorber by rotating it clockwise while maintaining slight pressure on the shock absorber in the fully collapsed position. Return the shock absorber to its original setting and rotate an additional 1/2 to 1 full turn to provide increased damping.
- Pull the piston rod straight out approximately 1/2", without rotating the shaft, until the internal adjusting nut disengages the footvalve.

#### ™NOTE:

The shock absorber has a range of adjustment of approximately 2 to 3 full turns between the internal stops. DO NOT force rotation of the shock absorber beyond this range.



#### 4.4.8. Installation

- Assemble the upper shock mounting components as follows:
  - a. Slide the steel sleeve and rubber bushing onto the shock stud. Ensure that the flat side of the rubber bushing seats against the shock body.
  - Place the mounting plate onto the rubber bushing ensuring that the mounting plate seats on the pilot diameter of the rubber bushing.
- 2. Assemble the remaining upper shock mounting components as follows:
  - a. Slide the centering ring and rubber bushing onto the shock stud ensuring that the pilot diameter of the rubber bushing seats within the concave side of the centering ring.
  - b. Install the clamping plate onto the rubber bushing ensuring that the concave side of the clamping plate seats against the flat side of the rubber bushing.
  - c. Install the M16 self-locking nut and torque to specification.
  - d. Install the protective cap over the lock nut.
- Align the four holes in the upper shock mount plate with the studs on the chassis mounting bracket.

- 4. Install four lock nuts and torque nuts to specification.
- Assemble the lower shock mounting components as follows:
  - Slide the rubber bushing onto the shock stud ensuring that the flat side of the rubber bushing seats against the shock body.
  - Compress the shock sufficiently to allow the shock stud to enter the lower mounting bracket.
- Assemble the remaining lower shock mounting components as follows:
  - a. Slide the centering ring and rubber bushing onto the shock stud ensuring that the pilot diameter of the rubber bushing seats within the concave side of the centering ring.
  - Install the clamping plate onto the rubber bushing ensuring that the concave side of the clamping plate seats against the flat side of the rubber bushing.
  - c. Install the M16 self-locking nut and torque to specification
  - d. Install protective cap over the lock nut.

#### 4.4.9. Functional Test

Road test the vehicle to confirm compliant suspension action and quiet operation. Also check for any evidence of rubbing during operation.



#### **Front Suspension Torque** 4.5. **Specifications**

See "Fig. 1-40: Front Suspension Torque Points" on page 47.

	FRONT SUSP	ENSION T	ORQUE SP	ECIFICATION	ONS
ITEM	DESCRIPTION	QTY. (per axle)	BOLT	NUT	TORQUE ft-lb. (Nm)
1	Upper Radius Rod to Frame	4	M14		105 ft-lb. (142 Nm) NEVER-SEEZ®
2	Lower Radius Rod to Frame	4	M18		230 ft-lb. (310 Nm) NEVER-SEEZ®
3	Upper Radius Rod to Axle	4	M14		105 ft-lb. (142 Nm) NEVER-SEEZ®
4	Lower Radius Rod to Axle	4	M18		230 ft-lb. (310 Nm) NEVER-SEEZ®
5	Lower Shock Mounting Nut	2		M16 x 1.5	56 ft-lb. (76 Nm) NEVER-SEEZ®
6	Upper Shock Mounting Nut	2		M16 x 1.5	56 ft-lb. (76 Nm) NEVER-SEEZ®
7	Upper Shock Mounting Plate to Frame	8		3/8" - 16	35 ft-lb. (47 Nm) NEVER-SEEZ®
8	Lower Air Spring to Mounting Plate	2		1/2" UNC Lock	25 to 35 ft-lb. (34 to 47 Nm) NEVER-SEEZ®
9	Upper Air Spring to Frame	2		3/4" UNF	45 ft-lb. (60 Nm) NEVER-SEEZ®
10	Upper Air Spring to Frame	2		1/2" UNC Lock	20 ft-lb. (27 Nm) NEVER-SEEZ®
11	Brake Chamber to Mounting Bracket	4		M16 x 1.5	Initial Torque: 25 ft-lb. (34 Nm) Final Torque: 135 ft-lb. (183 Nm) NEVER-SEEZ®
12	Tie Rod End Clamp Retaining Bolt	2		M14	125 ft-lb. (170 Nm) NEVER-SEEZ®
13	Wheel Nut	20		M22 x 1.5	450 to 500 ft-lb. (610 to 680 Nm)
14	Power Steering Gear Mounting Plate to Frame	4	3/4" UNC	3/4" UNC Prevailing Torque	157 to 173 ft-lb. (213 to 235 Nm) NEVER-SEEZ®



FRONT SUSPENSION TORQUE SPECIFICATIONS					
ITEM	DESCRIPTION	QTY. (per axle)	BOLT	NUT	TORQUE ft-lb. (Nm)
15	Power Steering Gear to Mounting Plate	5	M20 x 1.5"		350 ft-lb. (475 Nm) NEVER-SEEZ®
16	Drag Link to Pitman Arm & Steering Arm	2		Castle Nut	95 to 115 ft-lb. (129 to 156 Nm) NEVER-SEEZ®
17	Drag Link Tie Rod End Clamp Bolt	2		M12	59 to 70 ft-lb. (80 to 90 Nm) NEVER-SEEZ®
18	Steering Driveshaft Yoke Pinch Bolt	2	M10		50 ft-lb. (68 Nm)
19	Steering Miter Box to Frame Bolt	3	3/8" UNC		25 to 30 ft-lb. (34 to 40 Nm) Loctite-272
20	Tie Rod End Nut	2		M24	221 ft-lb. (300 Nm) NEVER-SEEZ®
21	Steering Arm	2	M22 x 1.5 Torx Socket Head		500 ft-lb. (680 Nm)
22	Tie Rod Arm	4	M22 x 1.5 Torx Socket Head		500 ft-lb. (680 Nm)

# ™NOTE:

All bolts and nylon locknuts are Grade 8 and yellow zinc dichromate coated. All fasteners are dry unless otherwise noted.






Fig. 1-40: Front Suspension Torque Points



# 5. FRONT BRAKE SYSTEM

# 5.1. Description

The front brake system includes:

- ☐ Front Disc Brakes
- □ Brake Chambers
- ☐ Anti-Lock Braking (ABS) System

Refer to 5.2. "Front Disc Brakes" on page 48 in this section for information on the disc brakes. Refer to 5.3. "Front Brake Chambers" on page 72 in this section for information on the brake chambers. Refer to 6. "FRONT ANTI-LOCK BRAKING SYSTEM (ABS) & COMPONENTS" on page 75 in this section for information on the ABS System.

# 5.2. Front Disc Brakes

# 5.2.1. Description

The front disc brakes includes the brake caliper, brake carrier, disc pads, and brake disc, See "Fig. 1-41: Disc Brake Assembly" on page 49.

# 5.2.2. Front Disc Brakes Specifications & Wear Limits

Manufacturer Knorr-Bremse
ModelSN 7000
Type Air-actuated sliding caliper
Brake pad clearance
Brake pad thickness (min)0.08" (2.0 mm)
Brake disc thickness (min)
Brake disc lateral run-out (max)0.006" (0.15 mm)
Brake caliper guides (max play)






Fig. 1-41: Disc Brake Assembly



# 5.2.3. Operation

# ™NOTE:

When reviewing the following information on operation of the disc brake assembly See "Fig. 1-42: Disc Brake Cross Section" on page 51.

During brake application the push rod of the brake chamber extends and moves the actuator lever in the brake caliper. This input force is transferred by an eccentric roller bearing to the bridge section of the caliper. This force is then distributed by the bridge and two threaded tubes to the tappets. The tappets apply force directly to the inboard brake pad. Once the running clearance between the brake pads and brake disc have been overcome, the reaction forces are transmitted by the sliding caliper to the outboard brake pads on the brake disc generates the braking force.

When brake pressure is released, the return spring within the caliper forces the bridge section along with the threaded tubes and lever back to the starting position.

An automatic adjuster mechanism is used to ensure consistent running clearance between the brake pads and brake disc. The adjuster is mechanically connected to the lever and will operate each time the brakes are applied. The running clearance between the pads and brake disc increases as the brake pads wear. This increased clearance will allow the adjuster mechanism to rotate slightly. A drive chain transfers this movement to both threaded sleeves, which rotated inward equally. The rotational inward movement of the threaded sleeves and tappets effectively takes up the additional running clearance as the brake pads wear.






Fig. 1-42: Disc Brake Cross Section



# 5.2.4. Inspection

The following inspections may be performed with the brake caliper assembly installed on the axle, providing that the following preparatory steps have been taken.

- 1. Vehicle raised to working height and properly supported with jack stands.
- 2. Wheel and tire assembly removed.

# ™NOTE:

Refer to the Preventive Maintenance Section of this manual for the scheduled interval at which the following inspections are to be preformed.

### 5.2.4.1. Brake Pad Clearance Inspection



Excessive brake pad clearance can result in reduced braking efficiency. Inadequate clearance can result in excessive wear and overheating. Ensure recommended brake pad clearance is maintained.

1. Push the brake caliper fully inboard.

- Insert a pry bar between the backing plate on the inboard brake pad and the caliper and carefully pry brake pad away from the tappets.
- 3. Use feeler gauges (Item 11 from special tools list) to measure clearance between both tappets and brake pad simultaneously. Measure over the whole tappet surface of both tappets. Clearance should fall within the range of 0.024 to 0.043" (0.6 to 1.1 mm). There may be damage to the adjuster if the clearance deviates from this.

# ™NOTE:

Check the clearance at both tappets simultaneously, using (at least 220mm long) feeler gauges. If the gap difference between the two tappets is >0.25mm, then the caliper guide pin clearance must be checked. Refer to 5.2.4.5. "Caliper Guide Pin Inspection" on page 56 in this section for procedure.

 Check for properly functioning adjusters if clearance is outside of this range. Refer to 5.2.4.2. "Automatic Adjustment Inspection" on page 53 in this section for checking procedure.



# 5.2.4.2. Automatic Adjustment Inspection



The installed adjuster adapter must be used when turning the adjuster. The adjuster adapter is designed with a shear point so as to prevent excessive force from being applied to the internal adjustment mechanism and causing possible damage.

 Remove the protective cap from the adjuster by pulling on the tab. Do not use a screwdriver or similar tool to remove the cap, as damage to the sealing lip could occur.



NEVER turn adjuster without shear adapter being installed. If the shear torque of the shear adapter is exceeded, it is designed to fail. If shear adapter fails, try again using a new (unused) shear adapter. With a second failure of the shear adapter, the caliper must be exchanged since internal damage is present.

DO NOT use an open-ended wrench as this may damage the adapter.

- Rotate the adjuster adapter one half turn (approx. 3 clicks) counter-clockwise using a 10 mm wrench. See "Fig. 1-43: Checking Adjuster Movement" on page 53.
- 3. Position a 10 mm box end wrench on the adjuster adapter so that the wrench is positioned close to the vertical position.
- Actuate the brake treadle 5 times with approximately 30 psi (2 bar) brake application pressure and note the movement of the installed wrench.
- 5. The wrench should move in a clockwise direction in response to each brake application, until clearance is taken up.

# ™NOTE:

The angle of turn or movement of the wrench decreases or slows as the number of steps rises.

- Replace the brake caliper if the automatic adjuster does not operate properly. Improper operation is indicated by either:
  - a. No movement.
  - b. Movement on the first brake application only.
  - c. Moves CCW then CW on each brake application.
- Lubricate seal lip and reinstall protective cap. Position the tab so that it will be accessible for future removal and not be obscured by the brake chamber.




Fig. 1-43: Checking Adjuster Movement



# 5.2.4.3. Brake Pad Wear Inspection

# ™NOTE:

Brake pad wear can be assessed visually without removing the brake pads using the following procedure.

- 1. Locate the lower caliper guide pin.
- Inspect the amount of deformation on the bellows area of the rubber bushing. A fully extended bellows indicates a new brake pad condition. A retracted and bulged bellows indicates a worn brake pad condition. See "Fig. 1-44: Brake Pad Wear Inspection" on page 54.
- 3. If a worn condition is indicated, remove the brake pads and measure actual thickness of friction material. Refer to 5.2.5. "Brake

- Pads" on page 59 in this section for removal procedure. Replace brake pads if measured thickness is 0.118" (3.0 mm) or less.
- If brake pad thickness is within limits, inspect condition of friction surface. Minor material breakout at the edges is permitted but major material breakout is unacceptable. Replace brake pads as necessary.

# ™NOTE:

Replace all brake pads on same axle. DO NOT replace one side only.

 Measure brake disc thickness. Refer to 5.2.4.4. "Brake Disc Inspection" on page 55 in this section for procedure.




Fig. 1-44: Brake Pad Wear Inspection



#### 5.2.4.4. Brake Disc Inspection

 Use a measuring caliper (Item 13 from special tools list) to measure brake disc thickness at the thinnest point of the disc, Avoid measuring at the outer edge or a roughened surface. Replace brake disc if thickness is 1.457" (37 mm) or less.

# ™NOTE:

It is recommended to replace the brake disc at time of brake pad replacement if the brake disc measures 1.535" (39 mm) or less.

2. Measure brake disc runout as follows:

# ™NOTE:

Confirm that the wheel hub axial play is within limits prior to proceeding with this inspection.

- a. Mount dial indicator (Items 29 & 69 from special tools list) so that tip of indicator is perpendicular to brake disc surface at 1.40" (35 mm) down from the outer rim of the rotor. See "Fig. 1-45: Rotor Run-Out Measurement Point" on page 55.
- b. Rotate brake disc a complete turn.
- Total indicated run-out must not exceed 0.006" (0.15 mm).
- d. Machine or replace the brake disc if run-out limits are exceeded. Refer to 5.2.9. "Brake Disc" on page 70 in this section for machining procedure.

# ™NOTE:

Replace all brake pads on same axle. DO NOT replace one side only.

- Inspect the brake disc for cracks and scoring. See "Fig. 1-46: Brake Disc Condition" on page 56.
  - a. Minor web-like cracks on the braking surface are acceptable. Refer to area "A" shown on illustration.

- b. Cracks less than 0.059" (1.5 mm) deep or wide and running in a radial direction are acceptable providing the cracks do not extend over more than 75% of the width of the braking surface. Refer to area "B" shown on the illustration.
- Cracks extending into the cooling cavity or into the inner support web are unacceptable.
- d. Circumferential scoring of the braking surface not to exceed 0.059" (1.5 mm) per side is acceptable. Refer to area "C" shown on illustration.

# ™NOTE:

Uneven or scored brake disc surfaces may be cleaned up by machining providing the minimum thickness limit is met. Replace brake disc if crack or scoring limits are exceeded. Replace both brake discs on same axle. DO NOT replace one side only.




Fig. 1-45: Rotor Run-Out Measurement Point






Fig. 1-46: Brake Disc Condition

# 5.2.4.5. Caliper Guide Pin Inspection

# ™NOTE:

Worn caliper guide pins will result in excessive movement in the caliper assembly relative to the brake carrier. Use the following procedure to determine if excessive wear is present:

 Remove worn brake pads and temporarily replace with a set of new pads during this procedure. Refer to 5.2.5. "Brake Pads" on page 59 in this section for removal procedure.

# ™NOTE:

Perform brake pad inspection on the removed pad. Refer to 5.2.4.3. "Brake Pad Wear Inspection" on page 54 in this section for procedure. Replace pads as necessary or reinstall existing pads.

2. Rewind the tappets back using a wrench and shear adapter. Clean dirt inside and out from guide pin bushing.

- 3. Push the caliper inward fully the pull the caliper outward fully. Movement of the caliper on the guide pins should be smooth throughout the full range of movement (approximately 1.0" (25 mm)). Replace the caliper guide pins if the full range of movement cannot be achieved or if excessive force is required to move the caliper.
- 4. Check for excessive play in the caliper guide pins as follows:
  - a. Pull the caliper fully outward.
  - Mount a dial indicator (Items 29 & 69 from special tools list) on the short bearing side of the carrier with the indicator tip resting on the brake caliper.
     Zero the dial gauge. See "Fig. 1-47: Measuring Guide Pin Play" on page 56.
  - c. Apply pressure to the brake caliper in an upward direction and read the dial gauge. Replace guide pins if reading exceeds 0.079" (2.0 mm). Refer to 5.2.7. "Caliper Guide Pins" on page 63 in this section for replacement procedure.




Fig. 1-47: Measuring Guide Pin Play



# 5.2.4.6. Tappet Rubber Boot Inspection



DO NOT adjust the tappets beyond 1.18" (30 mm) as measured from the surface of the caliper to the tappet thrust face. Turning any further will result in irreparable damage to the adjuster adapter. Penetration of dirt and moisture into the interior of the brake will lead to corrosion and impair the function of the clamping mechanism and the adjusting mechanism.

- Remove the brake pads. Refer to 5.2.5. "Brake Pads" on page 59 in this section for removal procedure
- Rotate the adjuster clockwise until the tappets extend approximately 1.18" (30) from the caliper surface. This will allow full extension of the tappet rubber boot for a proper visual inspection. See "Fig. 1-48: Tappet & Rubber Boot Inspection" on page 57.
- Inspect the rubber boot for proper seating, wear, cuts, or deterioration. Replace rubber boots as necessary. Refer to 5.2.8. "Tappet & Rubber Boot" on page 67 in this section for replacement procedure.

4. Inspect the tappet thrust surface for scoring, corrosion, or other damage. Replace tappets as necessary. Refer to 5.2.8. "Tappet & Rubber Boot" on page 67 in this section for replacement procedure.




Fig. 1-48: Tappet & Rubber Boot Inspection



# 5.2.4.7. Upper Guide Rubber Boot Inspection

- 1. Remove the brake pads. Refer to 5.2.5. "Brake Pads" on page 59 in this section for removal procedure.
- Push the caliper fully inward to expose the inner rubber boot on the upper guide pin.
   See "Fig. 1-49: Upper Guide Pin Inner Boot Inspection" on page 58.
- 3. Inspect the rubber boot for cracks, tears, wear, or deterioration. Replace as necessary. Refer to 5.2.7. "Caliper Guide Pins" on page 63 in this section for replacement procedure.




Fig. 1-49: Upper Guide Pin Inner Boot Inspection



#### 5.2.5. Brake Pads

#### 5.2.5.1. Removal

- Raise the vehicle to working height. Refer to the General Information Section of this manual for procedure.
- Place jack stands at each of the vehicle jacking points. Lower the vehicle until the weight is taken by the jack stands.
- 3. Remove wheel and tire assembly.
- 4. Remove the brake pad retainer as follows:
  - a. Remove the spring clip and washer from the retainer pin.
  - b. Push down on the retainer and slide out the retainer pin.
  - c. Remove the brake pad retainer.
- 5. Increase brake pad clearance as follows:
  - a. Remove the protective cover from the adjuster by using the pull tab. Do not use a screwdriver to pry off the cap, otherwise the seal could be damaged. See "Fig. 1-50: Brake Pad Removal" on page 59.



NEVER attempt to turn the adjuster without using the adjuster adapter. The adapter is designed to shear if excessive force is require to turn the adjuster, thereby preventing damage to internal components. If the adapter is replaced and shears a second time, replace the caliper assembly as internal damage is evident.

- b. Use the adjuster adapter and turn the adjuster counter-clockwise until the brake pads are free.
- 6. Remove the brake pads from the caliper.




Fig. 1-50: Brake Pad Removal

# 5.2.5.2. Cleaning & Inspection



DO NOT use compressed air to clean brake components as brake dust represents a health hazard.

- 1. Clean any corrosion or deposits from the brake pad guides using a scraper.
- Clean away any loose dirt using a damp cloth.
- 3. Inspect the brake pad retainer and replace if deformed or otherwise damaged.
- Inspect the rubber boot on the tappet and replace if worn or damaged. Refer to 5.2.8. "Tappet & Rubber Boot" on page 67 in this section for replacement procedure.



#### 5.2.5.3. Installation



DO NOT grease the brake pad guides as this will cause abraded material from brake pad to accumulate and prevent smooth movement of the brake pads in the guide.

- Push the brake caliper inward against the stop and insert the inboard brake pad. See See "Fig. 1-51: Brake Pad Installation" on page 60.
- 2. Pull the brake caliper outward against the stop and insert the outboard brake pad.
- 3. Install the brake pad retainer as follows:
  - a. Insert the inboard end of the pad retainer into the groove and apply sufficient downward pressure to allow insertion of the retaining pin. See "Fig. 1-52: Brake Pad Retainer Installation" on page 60.
  - b. Insert new retaining pin and secure with new washer and spring clip.
- 4. Adjust the brake pad clearance as follows:
  - Use the adjuster adapter and turn the adjuster clockwise until the pads touch the brake disc surface.
  - b. Turn the adjuster back three notches as confirmed by audible clicks.
  - c. Actuate the brakes 10 times with minimum 30 psi (2 bar) applied brake pressure. This action will automatically take up any clearance and provide the desired running clearance.
  - d. Verify the actual clearance by prying against the inboard brake pad backing plate and using a feeler gauge to measure clearance between the backing plate and tappet. Clearance should be 0.027 to 0.047" (0.7 to 1.2 mm).
- 5. Lower the vehicle and perform road test to verify satisfactory operation of the brakes.




Fig. 1-51: Brake Pad Installation




Fig. 1-52: Brake Pad Retainer Installation



# 5.2.6. Brake Caliper & Carrier Assembly

# ™NOTE:

The following procedure describes removal of the brake caliper and carrier as an assembly from the steering knuckle.

#### 5.2.6.1. Removal

- Raise the vehicle to working height. Refer to the General Information Section of this manual for procedure.
- 2. Place jack stands at each of the vehicle jacking points. Lower the vehicle until the weight is taken by the jack stands.
- 3. Remove wheel and tire assembly.
- 4. Remove the brake chamber. Refer to 5.3. "Front Brake Chambers" on page 72 in this section for removal procedure.
- 5. Remove the brake pads. Refer to 5.2.5. "Brake Pads" on page 59 in this section for removal procedure.



BE SURE to secure the brake caliper to prevent it from falling, prior to removing the mounting bolts. Serious personal injury could result if the brake caliper is allowed to fall.

# ™NOTE:

The tie rod arm must be removed to access the lower caliper mounting bolts. Use internal Torx socket (Item 67 from special tools list) and socket wrench assembly (Items 3, 4, 5, & 6 from special tools list) and remove two M22 bolts from tie rod arm.

- 6. Install the caliper support fixture (Item 1 from special tools list). See "Fig. 1-53: Brake Caliper Removal" on page 61.
- Remove the six M18 external torx head bolts that retain the entire caliper and carrier assembly to the steering knuckle and remove the entire caliper and carrier assembly from vehicle. Discard the six mounting bolts.




Fig. 1-53: Brake Caliper Removal



#### 5.2.6.2. Installation

- 1. Install the caliper support fixture (Item 1 from special tools list).
- Install caliper & carrier assembly onto steering knuckle and install six new M18 external torx head mounting bolts. Tighten the six bolts in an alternating pattern to an initial torque of 184 ft-lbs. (250 Nm), then final torque to 288 ft-lbs. (390 Nm).
- 3. Remove the supporting fixture (Item 1 from special tools list).

# ™NOTE:

Reinstall tie rod arm using two new self locking bolts. Use internal Torx socket

- (Item 67 from special tools list) and torque wrench assembly (Items 3, 4, 5, & 7 from special tools list) and torque bolts to specification.
- 4. Install brake pads. Refer to 5.2.5. "Brake Pads" on page 59 in this section for installation procedure.
- 5. Install brake chamber. Refer to 5.3. "Front Brake Chambers" on page 72 in this section for installation procedure.
- 6. Install tire and wheel assembly
- Lower the vehicle and road test the vehicle to verify satisfactory operation of the brakes.



# 5.2.7. Caliper Guide Pins

# ™NOTE:

The following procedure provides removal/ installation instructions for the brake caliper guide pins and bushings.

#### 5.2.7.1. Removal

- Remove the brake chamber. Refer to 5.3. "Front Brake Chambers" on page 72 in this section for removal procedure.
- Remove the brake pads. Refer to 5.2.5. "Brake Pads" on page 59 in this section for removal procedure.
- Remove the protective cover from the upper guide pin by using a small chisel to punch through the center of the cover. Lever out the cover.
- 4. Pry out the protective cap on the lower guide pin using pliers or similar tool.
- 5. Install support fixture (Item 1 from special tools list) onto brake caliper.
- Remove the two M16 socket head bolts that retain the caliper assembly to the brake carrier and lift the caliper assembly off the brake carrier. Discard the two mounting bolts.
- Fasten the caliper assembly onto mounting fixture with adapter plate (Items 80 & 79 from special tools list). Use two M12 x 110 mm long mounting bolts with M12 nuts to secure caliper to mounting fixture.

# MOTE:

For reference purposes, the guide pin in the upper position (as installed on the axle)

- is configured with a brass bushing and a rubber boot on the inner end. The guide pin in the lower position (as installed on the axle) is configured with a rubber bushing and does not use a rubber boot on the inner end of the guide pin.
- Remove the retaining ring from the rubber boot on the upper guide pin. See "Fig. 1-54: Brake Caliper Guide Pin Removal" on page 64.
- Pull both guide pins out of the caliper housing.
- 10.Use a screwdriver or similar tool to push out the inner rubber boot from the guide pin bore.
- 11. Remove the brass bushing from the upper guide pin bore as follows:
  - a. Assemble and install the installer punch, press-in sleeves, spindle, and collar nut (Items 72, 77, 75, 71, & 70 from special tools list). See "Fig. 1-55: Brass Bushing Removal" on page 64.
  - Pull the brass bushing out of the caliper.
- 12. Remove the bushing from lower guide pin bore as follows:
  - a. Assemble and install the installer punch, press-in sleeves, spindle, and collar nut (Items 72, 77, 75, 71, & 70 from special tools list). See "Fig. 1-56: Rubber Bushing Removal" on page 64.
  - b. Pull the bushing out of the caliper.






Fig. 1-54: Brake Caliper Guide Pin Removal




Fig. 1-55: Brass Bushing Removal




Fig. 1-56: Rubber Bushing Removal

# 5.2.7.2. Inspection

- 1. Inspect the guide pin bores for corrosion and clean as necessary.
- 2. Inspect the outside diameter of the guide pins for wear, scoring, or other damage. Replace guide pins as required.
- Inspect the inner rubber boot for cracks, tears, or deterioration. Replace as required.
- Thoroughly clean and inspect the brake carrier. Carefully inspect the guide area where the brake pads seat for any damage or excessive wear. Replace carrier as required.



#### 5.2.7.3. Installation

- Install the bushing in the lower guide pin bore as follows:
  - a. Insert bushing into press-in sleeve (Item 78 from special tools list).
  - b. Position installation tool with rubber bushing on the brake caliper and mount with spindle and collar nut tools (Items 70, 71, 72, 75, & 77 from special tools list). See "Fig. 1-57: Rubber Bushing Installation" on page 66.
  - Press the bushing into the caliper bore until the stop on the press-in sleeve is contacted.
- 2. Install the brass guide bushing in the upper guide pin bore as follows:
  - a. Assemble and install the centering sleeve, brass bushing, installer punch, spindle, and collar nut (Items 76, 72, 70, & 71 from special tools list). Ensure that the open side of the centering sleeve is facing away from the caliper. See "Fig. 1-58: Brass Bushing Installation" on page 66.
  - Press the brass bushing into the caliper bore until the stop on the press-in sleeve is contacted.
  - c. Insert the indenting tool (Item 74 from special tools list) into brass bushing from the outside until the stop is contacted. See "Fig. 1-59: Indenting Tool Installation" on page 66.
  - Screw the indenting bolt into the indenting tool until the stop is reached.
  - e. Unscrew the indenting bolt and remove the indenting tool.
- 3. Install the inner rubber boot as follows:
  - a. Insert the folds of the rubber boot into the press-in sleeve (Item 75 from special tools list). See "Fig. 1-60: Inner Boot Installation" on page 66.

- Position the press-in sleeve and installer sleeve (Items 73 & 75 from special tools list) on the brake caliper with spindle and collar nut (Items 71 & 70 from special tools list).
- Press the bellows into the seat using no more than 70 in-lb. (8 Nm) torque on the collar nut.
- Use grease supplied with the repair kit and lubricate the rubber bushing, brass bushing, and both guide pins. Install the guide pins into the caliper.
- Insert the lip of the inner boot into the groove on the guide pin and secure with retaining ring.
- Remove the caliper from the mounting fixture and install supporting fixture (Item 1 from special tools list) onto caliper.
- Lift the brake caliper into position on the brake carrier.
- Install two new M16 socket head caliper mounting bolts, ensuring that the inner boot and retaining ring are properly seated. Torque bolts to 133 ft-lb. (180 Nm) then tighten an additional 90°.
- Install a new protective cover into the caliper at the upper guide pin location. Use a soft-faced hammer to drive the cover flush with the surrounding surface.
- 10. Use centering sleeve (Item 76 from special tools list) to install protective cap into caliper at the lower guide pin location. Drive cap into place until centering sleeve stop is contacted. See "Fig. 1-61: Protective Cover & Cap Installation" on page 67.
- 11.Install the brake pads. Refer to 5.2.5. "Brake Pads" on page 59 in this section for removal procedure.
- 12.Install the brake chamber. Refer to 5.3. "Front Brake Chambers" on page 72 in this section for removal procedure.






Fig. 1-57: Rubber Bushing Installation




Fig. 1-59: Indenting Tool Installation




Fig. 1-58: Brass Bushing Installation




Fig. 1-60: Inner Boot Installation






Fig. 1-61: Protective Cover & Cap Installation

# 5.2.8. Tappet & Rubber Boot

# ™NOTE:

The following procedure provides removal/ installation instructions for the brake caliper tappets, rubber boots, and inner seals with the caliper installed on the vehicle.

#### 5.2.8.1. Removal

 Remove the brake pads. Refer to 5.2.5. "Brake Pads" on page 59 in this section for removal procedure.



DO NOT adjust the tappets beyond 1.18" (30 mm) as measured from the surface of the caliper to the tappet thrust face. Synchronization between the two threaded tubes can be lost if If the tappets are extended beyond this distance.

- Rotate the adjuster clockwise until the tappets extend approximately 1.18" (30) from the caliper surface. This will allow full extension of the tappet rubber boot for insertion of the removal tools. See "Fig. 1-62: Unscrewing Tappets" on page 68.
- Use a sharp knife to cut the rubber boot on the tappet. Insert the press-off fork tool (Item 81 from special tools list) between the tappet and the end of the threaded tube with the flat side of the forks against the threaded tube. See "Fig. 1-63: Removing Tappets" on page 68.
- Use a hammer and tap on the fork tool to dislodge the tappet from the threaded sleeve.
- 5. Use a screwdriver to pry the tappet boot out of the seal seat.
- Turn the adjuster counter-clockwise until the threaded sleeves are fully retracted within the caliper bore.



DO NOT damage the seal seat when removing the inner seal, otherwise the caliper will need to be replaced.

- Carefully pry the inner seal out of the seal seat. See "Fig. 1-64: Removing Inner Seal" on page 68.
- 8. Remove the bushing from the end of the threaded sleeve.






Fig. 1-62: Unscrewing Tappets




Fig. 1-63: Removing Tappets




Fig. 1-64: Removing Inner Seal

# 5.2.8.2. Inspection

- Rotate the adjuster clockwise until the end of the threaded sleeve extends 1.18" (30 mm) from the caliper surface. See "Fig. 1-65: Inspecting Threaded Tubes" on page 69.
- Inspect the threads on the threaded tubes for damage. The caliper will need to be replaced if thread damage is evident.
- Inspect the bore of the caliper for scoring, corrosion, or other damage in the area of the inner seal seat. Replace caliper if seal seat area damaged.






Fig. 1-65: Inspecting Threaded Tubes

#### 5.2.8.3. Installation

# ™NOTE:

This procedure can be performed with the caliper mounted to the axle or on a work bench. The special tools used contain two different length bolts depending on the method used. For installation on a work bench, use the longer bolt. For on-vehicle installation, use the shorter bolt.

- Rotate the adjuster counter-clockwise until the threaded tubes are fully retracted within the caliper bore.
- Thread the long forcing bolt into the installer sleeve (Item 82 from special tools list). See "Fig. 1-66: Installing Inner Seal" on page 70.

- 3. Place the new inner seal onto the press-in bushing (Item 83 from special tools list).
- 4. Place the assembled press-in bushing and inner seal into the installer sleeve. Use the forcing bolt to press the inner seal against the stop in the brake caliper.
- Rotate the adjuster clockwise until the end of the threaded sleeve extends 0.59" (15 mm) from the caliper surface.

#### MOTE:

The inner seal must not turn.

- Apply grease, supplied in the repair kit, onto the end of the threaded sleeves and install new bushings.
- Turn the adjuster counter-clockwise until the threaded sleeves are fully retracted within the caliper bore.
- 8. Place the tappet and rubber boot onto the bushing.

# ™NOTE:

Ensure the seal seat is clean and free from grease before installing the rubber boot into the seal seat.

- Hold the installer sleeve (Item 82 from special tools list) against the rubber boot and use the long forcing bolt to press the rubber boot against the stop in the seat. See "Fig. 1-67: Installing Tappet & Rubber Boot" on page 70.
- 10. Reverse the position of the installer sleeve so that the open end is facing away from the tappet and boot assembly and the head of the forcing bolt is facing the tappet. See "Fig. 1-68: Seating Tappet Against Stop" on page 70.
- 11. Use the forcing bolt to press the tappet up against the stop on the threaded sleeve.
- 12.Install the brake pads. Refer to 5.2.5. "Brake Pads" on page 59 in this section for installation procedure.






Fig. 1-66: Installing Inner Seal




Fig. 1-67: Installing Tappet & Rubber Boot




Fig. 1-68: Seating Tappet Against Stop

#### 5.2.9. Brake Disc

# 5.2.9.1. Removal

- 1. Remove the Wheel Flange. Refer to 3.7.3. "Wheel Flange Removal" on page 12 in this section for procedure.
- Remove the brake pads. Refer to 5.2.5. "Brake Pads" on page 59 in this section for removal procedure.
- 3. Remove the brake caliper and brake carrier as an assembly. Refer to 5.2.6. "Brake Caliper & Carrier Assembly" on page 61 in this section for removal procedure.
- 4. Thread the alignment pins (Item 14 from special tools list) through the brake disc into opposite facing tapped holes in the hub-unit. See "Fig. 1-69: Brake Disc Removal" on page 71.
- Use the lifting hook (Item 12 from special tools list) and remove the brake disc from the wheel hub by pulling it over the alignment pins.






Fig. 1-69: Brake Disc Removal

#### 5.2.9.2. Installation

- Inspect the threaded holes in the wheel hub unit and remove any accumulated grease or debris.
- 2. Clean the contact surface between the wheel hub unit and the brake disc.



DO NOT apply grease to the tapped holes of the wheel hub. Lubricated threads will affect desired torque value. Clean any grease from the threads.

- Apply a thin layer of Molykote D high-performance lubricant around the front edge contact surface of the hub unit. Ensure grease is applied to the complete circumference and edge of the hub unit.
- Use the lifting hook (Item 12 from special tools list) and install the brake disc onto the

hub unit, using the alignment pins to guide the brake disc into position.

 Install the Wheel Flange. Refer to 3.7.4.
 "Wheel Flange Installation" on page 14 in this section for procedure.

# 5.2.9.3. Machining



DO NOT machine the brake disc to less than 1.575" (40 mm) thickness. Allowance must be made for additional wear while in service and under no circumstances should the minimum disc brake thickness be reduced below 1.457" (37 mm) while in service.

# ™NOTE:

The brake disc must be machined while installed on the vehicle.

- ALWAYS machine equal amounts of material from both sides of the disc.
- ALWAYS machine the minimum amount of material required in restoring disc to serviceable limits.
- ALWAYS machine in several passes, being careful not to take off too much material in one pass.
- ☐ ALWAYS machine both brake discs on an axle. Do not machine one disc only.
- ☐ ALWAYS replace brake pads in sets whenever brake discs have been machined to ensure proper seating-in of the brake pads and to maintain braking efficiency.
- Remove the brake pads. Refer to 5.2.5. "Brake Pads" on page 59 in this section for removal procedure.
- Use commercially available brake machining equipment designed to be mounted to brake assembly with the brake disc installed on the axle. Follow manufacturer's instructions for setting up equipment and machining brake disc.
- 3. Measure machined surface of brake disc. The minimum thickness of the brake disc must not be less than 1.575" (40 mm).



# 5.3. Front Brake Chambers

#### 5.3.1. Description

The brake chamber is a diaphragm type actuator which converts the energy of air pressure into mechanical force. The diaphragm is held between a pressure plate and non-pressure plate by a clamp ring.

# ™NOTE:

The brake chamber assembly is a non-serviceable unit and must be replaced as an assembly. DO NOT attempt to disassemble the brake chamber.

#### 5.3.2. Front Brake Chambers Specifications

Manufacturer	MGM Brakes
Model	CS24L
Туре	Diaphragm
Maximum Operating Pressure	
Air Volume at Full Stroke (100	
Maximum Stroke	2.5" (64 mm)

# 5.3.3. Operation

Controlled air pressure enters the brake chamber through the inlet port to act on the diaphragm and move the push plate and rod assembly forward. The brake chamber is bolted to the disc brake caliper and is used to actuate the disc brake mechanism.

This forward motion of the push rod acts on an eccentric lever within the caliper assembly and applies the vehicle brakes. The greater the air pressure admitted to the brake chamber, the greater the force applied by push rod. Push rod force is determined by multiplying the delivered air pressure by the effective diaphragm area.

When air pressure is released from the brake chamber, the push rod return spring returns the diaphragm, push plate and rod assembly to their released positions, thereby releasing the brakes.



#### 5.3.4. Maintenance

Refer to the Preventive Maintenance Section of this manual for scheduled maintenance and inspection intervals and procedures.

#### 5.3.5. Removal

- 1. Set Battery Disconnect switch to the OFF position.
- 2. Chock the wheels.

- 3. Drain all air tanks.
- Disconnect the air line from the brake chamber.
- Remove the two lock nuts securing the brake chamber to the brake caliper assembly and remove the brake chamber from the vehicle. See "Fig. 1-70: Front Brake Chamber Removal & Installation" on page 73.
- 6. Place a protective cover over the brake caliper to prevent entry of contaminants.




Fig. 1-70: Front Brake Chamber Removal & Installation



#### 5.3.6. Installation



Disc brake chambers must be inspected for seal condition and height measurement before a used brake chamber can be reinstalled.

- If installing a new brake chamber, ensure that the protective cover is removed from the push rod. If installing a used brake chamber, perform the following inspection:
  - a. Measure the height of the seal on the brake chamber. The seal must be in good condition and protrude at least 0.118" (3.0 mm) from the brake chamber mounting surface.
  - b. If the seal measures less than 0.118" (3.0 mm) then the brake chamber must be replaced as an assembly.



Cover the brake chamber opening on the brake caliper when cleaning the mounting surfaces so as to prevent entry of any contaminants.

Clean the brake chamber and caliper mounting surfaces. Ensure that any protective covers are removed from the brake caliper.

- Apply Renolit Unitemp 2 grease to the spherical cup located in the brake caliper and to the end of the brake chamber push rod. Do not apply an excessive amount of grease.
- 4. Carefully install brake chamber on brake caliper assembly.
- Install new M16 lock nuts and torque to specification. Refer to 4.5. "Front Suspension Torque Specifications" on page 45 in this section for torque specification.

# ™NOTE:

Ensure that the brake hose bracket is positioned between the lock nuts and the brake caliper.

- Ensure brake chamber rubber vent tubes do not interfere with the brake caliper. Rotate tubes as necessary, ensuring tubes face either downward or rearward for drainage.
- Connect air line to brake chamber and torque air line fitting to 25 to 30 ft-lb. (34 to 40 Nm).
- 8. Start vehicle and charge air system to normal operating pressure.
- 9. Check for air leaks.
- Actuate brakes several times and check for proper operation.



# 6. FRONT ANTI-LOCK BRAKING SYSTEM (ABS) & COMPONENTS



To prevent serious personal injury, put blocks under the front tires to stop the vehicle from moving. Apply the parking brakes.

DO NOT work under a vehicle supported only by jacks. Jacks can slip or fall over and cause serious personal injury.

To prevent serious eye injury, always wear safe eye protection when performing maintenance or service.

# 6.1. Description

The major components of the ABS System include:

- □ ABS Speed Sensor
- □ ABS Pulse Generating Wheel
- ABS Modulator Valves
- ☐ ABS Electronic Control Unit (ECU)

# 6.2. Operation

ABS is an electronic braking system that monitors and controls wheel speed during braking. The system works with standard air brake systems. ABS monitors wheel

speeds at all times and controls braking during wheel lock situations. By reducing wheel lock, the system improves vehicle stability and control. In the event of a malfunction in the system, the braking in the affected wheel will return to normal braking.

The system consists of a tooth wheel-mounted on the hub of each monitored wheel. A sensor is installed with its sensing end against each tooth wheel. The sensor continually provides wheel speed information to the Electronic Control Unit (ECU), located above the lighting panel on the streetside of the vehicle, which in turn supplies signals to the ABS modulator valves. The modulator valves control air pressure to each wheel during ABS operation. The valves modulate air pressure to the brake chamber during ABS operation to control braking and prevent wheel lock up.

# 6.3. Front ABS Speed Sensor

#### 6.3.1. Removal

- 1. Raise the tire off the ground. Put safety stands under the axle.
- 2. Pull speed sensor out of sleeve using a twisting motion if necessary. Do not pull on cable. See "Fig. 1-71: Front Speed Sensor Removal & Installation" on page 76.
- Disconnect sensor cable from chassis harness.
- 4. Pull sleeve out of bearing bore.






Fig. 1-71: Front Speed Sensor Removal & Installation

#### 6.3.2. Installation

- Grease speed sensor retaining sleeve with high-temperature grease and push in to stop in bearing bore on axle.
- 2. Grease speed sensor. Push sensor into sleeve.

# ™NOTE:

Push, DO NOT knock in the sensor. The gap between the speed sensor and the pulse generating wheel is self-adjusting.

3. Ensure that the electrical connector to the speed sensor is correctly routed, and not bent.

4. Use ty-wraps and cable tie tool (Item 59 from special tools list) to secure ABS wiring harness to vehicle structure.

# 6.4. Front ABS Pulse Generating Wheel

#### ™NOTE:

The ABS pulse generating wheel is an integral part of the wheel hub assembly and is not repairable. Replace the complete wheel hub assembly if the ABS pulse generating wheel is damaged.





# 6.5. Front ABS Modulator Valve

# 6.5.1. Description

ABS modulator valves are used to control brake application on the front axle. The valves are bracket-mounted to the vehicle structure and located between the brake foot valve and brake chambers. The modulator valve is electrically controlled with a solenoid valve and includes an inlet, outlet and exhaust port.

# 6.5.2. Operation

During normal brake application the modulator valves are inactive and do not affect the brake application. If the ABS ECU detects an ABS event (impending wheel lock-up) it will energize the solenoids in the modulator valves to control the brake application pressure to the service brake chambers.

To decrease brake application pressure, the ECU will energize the inlet and outlet solenoids of the modulator valve that will close the supply port and open the delivery and exhaust ports. To hold brake application pressure at a given value, the ECU will energize the inlet solenoid and de-energize the outlet solenoid of the modulator valve that will close the supply and exhaust ports.

This modulation of brake application pressure will continue until the impending wheel lock-up condition is alleviated.



#### 6.5.3. Removal

- 1. Set the Battery Disconnect switch to the OFF position.
- 2. Disconnect the wiring from the ABS valve.
- Disconnect the air lines from ports 1 and 2 of the ABS valve. See "Fig. 1-72: Front Modulator Valve Removal & Installation" on page 78.
- 4. Remove the two mounting bolts and nuts.
- 5. Remove the ABS valve.

# ™NOTE:

ABS valves are not serviceable.

#### 6.5.4. Installation

- Install the ABS valve with two mounting bolts and nuts.
- Connect the line to the brake chamber to port 2 of the ABS valve. Connect the air supply line to port 1 of the ABS valve.
- Connect the harness connector to the ABS valve.
- 4. Set the Battery Disconnect switch to the ON position.




Fig. 1-72: Front Modulator Valve Removal & Installation



# 6.6. ABS Electronic Control Unit (ECU)

# 6.6.1. Description

The ABS System ECU is located on the streetside of the vehicle behind the front advertising panel. See "Fig. 1-73: ABS ECU" on page 79.




Fig. 1-73: ABS ECU

# 6.6.2. ABS Troubleshooting

Troubleshooting can be performed on the ABS system using any of the following methods:

- □ Blink Code troubleshooting
- ☐ Meritor Wabco TOOLBOX software
- ☐ Pro-Link® Plus diagnostic tool

Refer to 6.6.3. "Blink Code Diagnostics & Troubleshooting" on page 80 in this section for basic information on blink code troubleshooting concerning the use of the ABS Fail indicator and the ABS switch installed in this vehicle.

Meritor Wabco TOOLBOX software is a PC-based diagnostic tool which can be used to test the ABS system components and display active and stored faults. The user's manual for this software is available for download on meritorwabco.com/toolbox. The software, available from Meritor Wabco, is loaded onto the PC and the PC is connected to one of the vehicle's diagnostic connectors.

The Pro-Link® Plus is a hand-held diagnostic device which can be used in place of blink code troubleshooting. The Pro-Link is fitted with the required cartridge and is connected to one of the vehicle's diagnostic connectors.

Refer to "Multiplexing System Layout" included with your Vehicle Systems Drawing Manual for the locations of the vehicle's diagnostic connectors.

Refer to 8. "VENDOR SERVICE INFOR-MATION" on page 88 in this section for further information on the use of the TOOLBOX software and the Pro-Link diagnostic tool. Also refer to this manual for detailed blink code troubleshooting charts and procedures.



# 6.6.3. Blink Code Diagnostics & Troubleshooting

# 6.6.3.1. Description

The ABS Fail indicator on the instrument panel indicates system status and displays blink code diagnostics. The indicator lamp works as follows:

- When the Master Run switch is set to the DAY-RUN position, the indicator illuminates momentarily for a check and then extinguishes. This indicates the system is O.K.
- ☐ The indicator will flash if the normal ABS function is being modified due to road conditions while the vehicle is in operation.
- ☐ The indicator will remain illuminated after the vehicle is started if an existing fault is present.
- ☐ After the system is serviced, the indicator will remain illuminated until the vehicle is driven at speeds above 4 mph (6 kp/h).

The Blink Code system requires use and interpretation of a series of blink codes. A blink code is a series of flashes emitted by the ABS Fail indicator which describes a system fault or condition. Each blink code contains two digits or sets of flashes: a 1 1/2 second pause occurs between

each set of flashes in the digit. A four second pause separates the individual codes displayed. Blink code diagnostics are activated by the ABS switch in the front destination sign compartment.

# 6.6.3.2. Diagnostic Mode

Enter diagnostic mode by activating the ABS switch for one second, and then releasing it.

#### 6.6.3.3. Clear Mode

Enter clear mode to erase faults from the ECU. This is done by activating the ABS switch for three seconds and then releasing it. If the system displays eight quick flashes followed by a system configuration code, the clear was successful. If this does not occur, faults are still active and must be repaired before they can be cleared.

### 6.6.3.4. System Configuration Code

This is a one digit code consisting of two flashes repeated every four seconds by the ABS switch during clear mode to indicate that all ABS faults have been cleared from ECU memory.



# 7. FRONT AXLE SPECIAL TOOLS

# 7.1. Front Axle Special Tools Chart

The following special tools are referenced in the axle servicing text in this section.

Refer to your New Flyer Parts Manual for purchase part numbers. See "Fig. 1-74: Special Tools-1" on page 85. See "Fig. 1-75: Special Tools-2" on page 86. See "Fig. 1-76: Special Tools-3" on page 87.

SPECIAL TOOLS	DESCRIPTION
1	Supporting Fixture
2	Socket, E24
3	Retaining Bolt, M8
4	Adapter, Wrench
5	Socket Wrench, Size 22 Splined
6	Wrench Handle, Socket
7	Handle, Torque Wrench
8	Handle, Screwdriver Torque
9	Shaft, Removable Screwdriver
10	Bit, Removable Screwdriver
11	Gauge, Feeler
12	Lifting Hook
13	Callipers, Measuring
14	Pin, Centering
15	Adapter
16	Impact Tool
17	Torque Multiplier - 1:3.5
18	Socket
19	Socket - Wheel Flange Bolt
20	Support
21	Holding Tube, Socket
22	Pin, Connecting 36 mm
23	O-Ring, 42mm



SPECIAL TOOLS	DESCRIPTION
24	Screw, Cap Cylinder
25	Adapter, Tool Assembly
26	Handle, Slip On
27	Washer
28	Gauge, Dial Stand
29	Gauge, Dial
30	Slotted Nut Spanner Socket
31	Counter Holder Flange
32	Power Wrench
33	Counter Holder
34	Reaction Arm
35	Ratchet
36	Bushing, Threaded M115
37	Removal Flange, Hub Unit
38	Puller Cap, Threaded
39	Cover, Fitting
40	Spindle
41	Nut, Spindle
42	Fitting Sleeve
43	Pump, Hydraulic
44	Piston Cylinder, Hollow, 200 kN
45	Flange Extractor
46	Pressure Piece, Hub Unit Bearing, 200 kN
47	Rod, Threaded, M20 x 270
48	Nut, Collar
49	Plate, Traverse
50	Positioning Tool, Thrust Bearing Sleeve



SPECIAL TOOLS	DESCRIPTION
51	Fixture, Hydraulic Press
52	Press Hydraulic 750 kN
53	Punch, Aligning
54	Mandrel, Short W/Magnet
55	Mandrel, Pressing
56	Mandrel, King Pin Press In
57	Spacer Tube
58	Mandrel, King Pin Cap Installation
59	Tool, Cable Tie Tying
60	Pressing Adapter
61	Mandrel, Guide & Press
62	Pressing Adapter
63	Pressing Adapter
64	Joint Press
65	Flat Cylinder
66	Chain, Safety
67	Torque Adapter, TX100
68	Socket Wrench, Size 36 Splined
69	Mounting Fixture, Dial Gauge
70	Nut, Collar Trapezoidal Thd.
71	Spindle, Trapezoidal Thd.
72	Punch, Installer
73	Sleeve, Installer
74	Tool, Indenting
75	Sleeve, Press-In
76	Sleeve, Centering
77	Sleeve, Press-In



SPECIAL TOOLS	DESCRIPTION
78	Sleeve, Press-In
79	Plate, Adapter
80	Mounting Fixture
81	Fork, Press-Off
82	Sleeve Installer
83	Bushing Installer






Fig. 1-74: Special Tools-1






Fig. 1-75: Special Tools-2






Fig. 1-76: Special Tools-3



# 8. VENDOR SERVICE INFORMATION

The following supplier manuals contain additional reference information.

## 8.1. Meritor Wabco Manual

☐ Maintenance Manual 112 Anti-Lock Braking System (ABS) for Trucks, Tractors, and Buses for E Version ECUs



# Rear Axle & Suspension

1.	SAFETY	2-1
	1.1. Safety Procedures	2-1
	1.2. Hoisting & Related Safety Information	
	g w carety	
2.	REAR AXLE & SUSPENSION	2-2
	2.1. Description	2-2
	2.2. Operation	
	2.3. Removal	
	2.4. Installation	
	2.5. Disassembly	
	2.6. Assembly	
	2.0. Assembly	2-0
3.	REAR AXLE	2-7
	3.1. Description	2-7
	3.2. Rear Axle Specifications	
	3.3. Operation	
	3.4. Maintenance	
	3.5. Tires	
	3.5.1. Tire Specifications	
	3.5.2. Maintenance & Replacement	
	3.6. Wheels	
	3.6.1. Inspection	
	3.6.1.1. Wheel Assemblies	
	3.6.1.2. Studs	2-9
	3.6.1.3. Nuts	
	3.6.2. Installation	
	3.7. Wheel Bolts	
	3.7.1. Removal	
	3.7.2. Installation	
	3.8. Axle Shaft	
	3.8.1. Removal	
	3.8.2. Installation	
	3.9. Rear Wheel Hub	
	3.9.1. Description	
	3.9.2. Inspection	
	3.9.3.1. Uncaging the Brake Chamber	
	3.9.3.2. Unlocking Slotted Nut	
	ullet	

## Table of Contents



	3.9.3.3. Centering Device Assembly	2-10
	3.9.3.4. Inserting Centering Device	2-16
	3.9.3.5. Loosening Slotted Nut	2-16
	3.9.3.6. Slotted Nut Removal	2-16
	3.9.3.7. Wheel Hub Removal	2-19
	3.9.4. Disassembly	2-20
	3.9.4.1. Retaining Ring Removal	2-20
	3.9.4.2. Outer Tapered Roller Bearing Removal	2-21
	3.9.4.3. Outer Bearing Outer Race Removal	2-22
	3.9.4.4. Inner Tapered Roller Bearing Removal	2-23
	3.9.4.5. Inner Bearing Outer Race Removal	2-24
	3.9.5. Assembly	2-25
	3.9.5.1. Inner Bearing Outer Race Installation	2-25
	3.9.5.2. Greasing Hub Unit Wheel Bearings	2-25
	3.9.5.3. Inner Tapered Roller Bearing Installation	2-26
	3.9.5.4. Outer Bearing Outer Race Installation	2-27
	3.9.5.5. Outer Tapered Roller Bearing Installation	2-28
	3.9.5.6. Retaining Ring Installation	2-28
	3.9.6. Installation	2-29
	3.9.6.1. Mounting Wheel Hub	2-29
	3.9.6.2. Screwing on Slotted Nut	2-29
	3.9.6.3. Caging Brake Chamber	2-29
	3.9.6.4. Inserting Centering Device	2-29
	3.9.6.5. Tightening Slotted Nut	2-29
	3.9.6.6. Locking Slotted Nut	2-30
	3.9.6.7. Uncaging Brake Chamber	2-30
3.1	10 Dinian Caal Danlacoment	2-31
	10. Pinion Seal Replacement	2-01
	3.10.1. Removal	
	3.10.1. Removal	2-32
	3.10.1. Removal	2-32 2-32
	3.10.1. Removal	2-32 2-32 2-33
	3.10.1. Removal	2-32 2-32 2-33 2-33
	3.10.1. Removal	2-32 2-32 2-33 2-34
	3.10.1. Removal	2-32 2-32 2-33 2-34 2-34
	3.10.1. Removal	2-32 2-32 2-33 2-34 2-34
	3.10.1. Removal	2-32 2-32 2-33 2-34 2-35 2-35
	3.10.1. Removal	2-32 2-33 2-33 2-34 2-35 2-35
	3.10.1. Removal	2-32 2-33 2-34 2-34 2-35 2-35 2-35
	3.10.1. Removal  3.10.1.1.Unlocking Slotted Nut 3.10.1.2.Removing Slotted Nut 3.10.1.3.Removing Input Flange 3.10.1.4.Removing Radial Shaft Seal 3.10.1.5.Removing Input Flange Shield 3.10.2. Installation 3.10.2.1.Installing Input Flange Shield 3.10.2.2.Installing Radial Shaft Seal 3.10.2.3.Installing Input Flange	2-32 2-33 2-34 2-34 2-35 2-35 2-36 2-36
	3.10.1. Removal	2-32 2-33 2-34 2-34 2-35 2-35 2-36 2-36
	3.10.1. Removal 3.10.1.1.Unlocking Slotted Nut 3.10.1.2.Removing Slotted Nut 3.10.1.3.Removing Input Flange 3.10.1.4.Removing Radial Shaft Seal 3.10.1.5.Removing Input Flange Shield 3.10.2. Installation 3.10.2.1.Installing Input Flange Shield 3.10.2.2.Installing Radial Shaft Seal 3.10.2.3.Installing Radial Shaft Seal 3.10.2.3.Installing Input Flange 3.10.2.4.Tightening Slotted Nut 3.10.2.5.Locking Slotted Nut	2-32 2-33 2-34 2-34 2-35 2-35 2-36 2-36
	3.10.1. Removal 3.10.1.1.Unlocking Slotted Nut 3.10.1.2.Removing Slotted Nut 3.10.1.3.Removing Input Flange 3.10.1.4.Removing Radial Shaft Seal 3.10.1.5.Removing Input Flange Shield 3.10.2. Installation 3.10.2.1.Installing Input Flange Shield 3.10.2.2.Installing Radial Shaft Seal 3.10.2.3.Installing Radial Shaft Seal 3.10.2.3.Installing Input Flange 3.10.2.4.Tightening Slotted Nut 3.10.2.5.Locking Slotted Nut 3.10.2.5.Locking Slotted Nut	2-32 2-32 2-33 2-34 2-35 2-35 2-36 2-36 2-36 2-37
	3.10.1. Removal	2-322-332-342-352-352-362-362-362-372-37
	3.10.1. Removal 3.10.1.1.Unlocking Slotted Nut 3.10.1.2.Removing Slotted Nut 3.10.1.3.Removing Input Flange 3.10.1.4.Removing Radial Shaft Seal 3.10.1.5.Removing Input Flange Shield 3.10.2. Installation 3.10.2.1.Installing Input Flange Shield 3.10.2.2.Installing Radial Shaft Seal 3.10.2.3.Installing Radial Shaft Seal 3.10.2.4.Tightening Slotted Nut 3.10.2.5.Locking Slotted Nut 3.10.2.5.Locking Slotted Nut 3.11.1.Removal 3.11.1.Removing Breather Connection 3.11.1.2.Attaching Lifting Device	2-322-332-342-352-352-362-362-362-372-372-38
	3.10.1. Removal 3.10.1.1. Unlocking Slotted Nut 3.10.1.2. Removing Slotted Nut 3.10.1.3. Removing Input Flange. 3.10.1.4. Removing Radial Shaft Seal 3.10.1.5. Removing Input Flange Shield. 3.10.2. Installation 3.10.2.1. Installing Input Flange Shield. 3.10.2.2. Installing Radial Shaft Seal 3.10.2.3. Installing Input Flange. 3.10.2.4. Tightening Slotted Nut 3.10.2.5. Locking Slotted Nut.  11. Differential Carrier 3.11.1. Removal 3.11.1.1. Removing Breather Connection 3.11.1.2. Attaching Lifting Device 3.11.1.3. Removing Differential Carrier	2-322-332-342-352-352-362-362-372-372-382-38
	3.10.1. Removal 3.10.1.1.Unlocking Slotted Nut 3.10.1.2.Removing Slotted Nut 3.10.1.3.Removing Input Flange. 3.10.1.4.Removing Radial Shaft Seal 3.10.1.5.Removing Input Flange Shield. 3.10.2. Installation 3.10.2.1.Installing Input Flange Shield. 3.10.2.2.Installing Radial Shaft Seal 3.10.2.3.Installing Radial Shaft Seal 3.10.2.4.Tightening Slotted Nut 3.10.2.5.Locking Slotted Nut 3.10.1.1.Removal 3.11.1.Removal 3.11.1.Removing Breather Connection 3.11.1.Removing Differential Carrier 3.11.1.Removing Differential Carrier 3.11.1.Removing Differential Carrier	2-322-332-342-352-352-362-362-372-372-382-382-39
	3.10.1. Removal 3.10.1.1.Unlocking Slotted Nut 3.10.1.2.Removing Slotted Nut 3.10.1.3.Removing Input Flange. 3.10.1.4.Removing Radial Shaft Seal. 3.10.1.5.Removing Input Flange Shield. 3.10.2. Installation. 3.10.2.1.Installing Input Flange Shield. 3.10.2.2.Installing Radial Shaft Seal. 3.10.2.3.Installing Input Flange. 3.10.2.4.Tightening Slotted Nut. 3.10.2.5.Locking Slotted Nut. 3.10.1.1.Removal 3.11.1.Removal 3.11.1.Removing Breather Connection. 3.11.1.2.Attaching Lifting Device 3.11.1.3.Removing Differential Carrier 3.11.2. Installation. 3.11.2.1.Installing Differential Carrier	2-322-332-342-352-352-362-362-372-372-382-382-392-39
3.1	3.10.1. Removal 3.10.1.1.Unlocking Slotted Nut 3.10.1.2.Removing Slotted Nut 3.10.1.3.Removing Input Flange 3.10.1.4.Removing Radial Shaft Seal 3.10.1.5.Removing Input Flange Shield 3.10.2. Installation 3.10.2.1.Installing Input Flange Shield 3.10.2.2.Installing Radial Shaft Seal 3.10.2.3.Installing Input Flange 3.10.2.4.Tightening Slotted Nut 3.10.2.5.Locking Slotted Nut 3.10.2.5.Locking Slotted Nut 3.11.1.Removal 3.11.1.Removal 3.11.1.Removing Breather Connection 3.11.1.2.Attaching Lifting Device 3.11.1.3.Removing Differential Carrier 3.11.2. Installation 3.11.2.1.Installing Differential Carrier 3.11.2.Installing Differential Carrier	2-322-332-342-352-352-362-362-372-372-382-392-39
3.1	3.10.1. Removal 3.10.1.1.Unlocking Slotted Nut 3.10.1.2.Removing Slotted Nut 3.10.1.3.Removing Input Flange 3.10.1.4.Removing Radial Shaft Seal 3.10.1.5.Removing Input Flange Shield. 3.10.2. Installation 3.10.2.1.Installing Input Flange Shield. 3.10.2.3.Installing Radial Shaft Seal 3.10.2.3.Installing Radial Shaft Seal 3.10.2.3.Installing Input Flange. 3.10.2.4.Tightening Slotted Nut 3.10.2.5.Locking Slotted Nut.  11. Differential Carrier 3.11.1. Removal 3.11.1.1.Removing Breather Connection 3.11.1.2.Attaching Lifting Device 3.11.1.3.Removing Differential Carrier 3.11.2. Installation 3.11.2.Installing Differential Carrier 3.11.2.Installing Differential Carrier 3.11.2.Installing Breather Connection.	2-322-332-342-352-352-362-362-372-382-382-392-392-39
3.1	3.10.1. Removal	2-322-332-342-352-352-362-362-372-372-382-392-392-392-412-41
3.1	3.10.1. Removal 3.10.1.1.Unlocking Slotted Nut 3.10.1.2.Removing Slotted Nut 3.10.1.3.Removing Input Flange 3.10.1.4.Removing Radial Shaft Seal 3.10.1.5.Removing Input Flange Shield 3.10.2. Installation 3.10.2.1.Installing Input Flange Shield 3.10.2.2.Installing Radial Shaft Seal 3.10.2.3.Installing Radial Shaft Seal 3.10.2.3.Installing Input Flange 3.10.2.4.Tightening Slotted Nut 3.10.2.5.Locking Slotted Nut 4.1. Differential Carrier 3.11.1. Removal 3.11.1.Removing Breather Connection 3.11.1.3.Removing Differential Carrier 3.11.2. Installation 3.11.2.1.Installing Differential Carrier 3.11.2. Installing Differential Carrier 3.11.2. Installing Differential Carrier 3.11.2.1.Removal 3.12.1.Removal 3.12.1.Removal	2-322-332-342-352-352-362-362-372-372-382-382-392-392-392-412-41
3.1	3.10.1. Removal	2-322-332-342-352-352-362-362-372-372-382-392-392-392-412-41





3.12.1.3.Removing Differential from Housing	2-43
3.12.2. Installation	2-44
3.12.2.1.Installing Differential Into Housing	2-44
3.12.2.2.Installing Bearing Caps & Adjusters	
3.12.3. Disassembly	2-45
3.12.3.1.Removing Tapered Roller Bearings (Hydraulic Method)	2-46
3.12.3.2.Removing Tapered Roller Bearings (Mechanical Method)	2-48
3.12.3.3.Special Tool Assembly	2-49
3.12.3.4.Removing Crown Gear & Differential Cover	
3.12.3.5.Removing Differential Pinion & Side Gears	
3.12.4. Assembly	
3.12.4.1.Gear Pairing Numbers	
3.12.4.2.Installing Differential Pinion Gears	
3.12.4.3.Installing Crown Gear	
3.12.4.4.Installing Differential Side Gear (Lock Side)	
3.12.4.5.Installing Differential Housing Cover	
3.12.4.6.Tightening Crown Gear Mounting Bolts	
3.12.4.7.Installing Tapered Roller Bearings	
3.12.5. Adjustments	
3.12.5.1.Backlash Adjustment	
3.12.5.2.Bearing Preload Adjustment	
3.12.5.3.Crown Gear Contact Pattern	
3.12.5.4.Contact on Tooth Tip	
3.12.5.5.Contact on Tooth Root	
3.13. Drive Pinion Gear Housing	
3.13.1. Description	
3.13.2. Removal	
3.13.2.1.Removing Roller Bearing	
3.13.3. Installation	
3.13.3.1.Installing Roller Bearing	
3.13.3.2.Installing Shims	
3.13.3.3.Installing Drive Pinion Gear Housing	
3.13.3.4.Checking & Adjusting Friction Coefficient	
3.13.3.5.Determining Drive Pinion Gear Installation Depth	
3.13.4. Disassembly	
3.13.4.1.Removing Drive Pinion Gear Housing	
3.13.4.2.Removing Bearing Inner Race	
3.13.4.3.Removing Inner Tapered Roller Bearing	
3.13.4.5.Removing Juler Bearing Outer Race	
3.13.5. Assembly	
3.13.5.1.Installing Outer Bearing Outer Race	
3.13.5.2.Installing Outer Bearing Outer Race	
3.13.5.3.Installing Inner Tapered Roller Bearing & Bearing Inner Race	
3.13.5.4.Installing Drive Pinion Gear Housing	
3.13.5.5.Installing Outer Tapered Roller Bearing	
REAR SUSPENSION	2-79
4.1. Description	
4.2. Rear Air Springs	
4.2.1. Description	
2000.puo.	

4.

## Table of Contents



	4.2.2.	Rear Air Springs Specifications	2-79
	4.2.3.	Operation	2-79
	4.2.4.	Removal	2-79
	4.2.5.	Disassembly	2-80
	4.2.6.	Cleaning & Inspection	2-80
	4.2.7.	Leak Test Procedure	
	4.2.8.	Installation	
	4.2.9.	Functional Tests	
	4.3. Rea	ar Radius Rods	
	4.3.1.	Description	
	4.3.2.	Rear Upper Radius Rod Specifications	
	4.3.2.	Rear Lower Radius Rod Specifications	
	4.3.4.	Operation	
	4.3.4. 4.3.5.	Rear Radius Rod Troubleshooting	
	4.3.5. 4.3.6.	Maintenance	
	4.3.6. 4.3.7.		
	_	Removal  Bushing Replacement	
	4.3.8.	<b>5</b> 1	
	4.3.9.	Installation	
		Functional Test	
		ar Shock Absorbers	
	4.4.1.	Description	
	4.4.2.	Rear Shock Absorbers Specifications	
	4.4.3.	Operation	
	4.4.4.	Removal	
	4.4.5.	Disassembly	
	4.4.6.	Cleaning & Inspection	
	4.4.7.	Assembly	
	4.4.8.	Adjustment	2-89
	4.4.9.	Installation	2-90
	4.4.10.	. Functional Test	2-90
	4.5. Rea	ar Suspension Torque Specifications	2-91
5.	REAR E	BRAKE SYSTEM	2-93
	5.1. Des	scription	2-03
		ar Disc Brakes	
	5.2.1.	Description	
	5.2.2.	Rear Disc Brakes Specifications & Wear Limits	
	5.2.3.	Operation	
	5.2.4.	Inspection	
		2.4.1. Brake Pad Clearance Inspection	
		2.4.2. Automatic Adjustment Inspection	
		2.4.3. Brake Pad Wear Inspection	
		2.4.5. Caliper Guide Pin Inspection	
		2.4.6. Tappet Rubber Boot Inspection	
		2.4.7. Upper Guide Rubber Boot Inspection	
	5.2.5.	·	
		2.5.1. Removal	
	· · ·		



	• '	2-104
	5.2.5.3. Installation	
	5.2.6. Brake Caliper & Carrier Assembly	2-106
	5.2.6.1. Removal	2-106
	5.2.6.2. Installation	2-107
	5.2.7. Caliper Guide Pins	2-108
	5.2.7.1. Removal	
	5.2.7.2. Inspection	
	5.2.7.3. Installation	
	5.2.8. Tappet & Rubber Boot	
	5.2.8.1. Removal	
	5.2.8.2. Inspection	
	5.2.8.3. Installation	
	5.2.9. Brake Disc	
	5.2.9.1. Removal	
	5.2.9.2. Installation.	
	5.2.9.3. Machining	
	5.3. Rear Brake Chambers	
	5.3.1. Description	
	5.3.2. Rear Brake Chambers Specifications	
	5.3.3. Operation	
	5.3.3.1. Service Brakes	
	5.3.3.2. Spring Brake (Parking/Emergency Brake)	
	5.3.4. Maintenance	2-119
	5.3.5. Removal	2-119
	5.3.6. Installation	2-120
h	REAR AXI E ANTI-I OCK BRAKING SYSTE	Μ (ABS) &
6.	COMPONENTS	2-121
б.	COMPONENTS 6.1. Description	2-121 2-121
ნ.	COMPONENTS	2-121 2-121
6.	COMPONENTS 6.1. Description 6.2. Operation	2-121 2-121 2-121
6.	6.1. Description	2-121 2-121 2-121 2-122
6.	6.1. Description	2-121 
6.	COMPONENTS	2-1212-1212-1212-1222-1222-122
6.	COMPONENTS	2-121 2-121 2-121 2-122 2-122 2-123
6.	COMPONENTS	2-121 2-121 2-121 2-122 2-122 2-123 2-123
6.	COMPONENTS	2-121 2-121 2-121 2-122 2-122 2-123 2-123 2-123
6.	COMPONENTS	2-1212-1212-1212-1222-1222-1232-1232-1232-1232-123
6.	COMPONENTS  6.1. Description	2-1212-1212-1212-1222-1222-1232-1232-1232-1232-1232-123
6.	COMPONENTS  6.1. Description	2-121 2-121 2-121 2-122 2-122 2-123 2-123 2-124 2-124 2-124
6.	COMPONENTS	2-121 2-121 2-121 2-122 2-122 2-123 2-123 2-123 2-124 2-124 2-125
6.	COMPONENTS  6.1. Description  6.2. Operation  6.3. Rear ABS Speed Sensor & Sensor Holder  6.3.1. Description  6.3.2. Removal  6.3.3. Installation  6.3.3.1. Default Gap Setting  6.3.3.2. Positioning ABS Sensor Holder  6.3.3.3. Centering Device Assembly & Installation  6.3.3.4. ABS Sensor Holder Installation  6.3.3.5. Checking & Setting ABS Sensor Gap  6.3.3.6. Routing ABS Sensor Electrical Harness  6.4. Rear ABS Pulse Generating Wheel & Radial Sensor Senso	2-121 2-121 2-121 2-122 2-122 2-123 2-123 2-123 2-123 2-124 2-124 2-125 Seal 2-126
6.	COMPONENTS  6.1. Description  6.2. Operation  6.3. Rear ABS Speed Sensor & Sensor Holder  6.3.1. Description  6.3.2. Removal  6.3.3. Installation  6.3.3.1. Default Gap Setting  6.3.3.2. Positioning ABS Sensor Holder  6.3.3.3. Centering Device Assembly & Installation  6.3.3.4. ABS Sensor Holder Installation  6.3.3.5. Checking & Setting ABS Sensor Gap  6.3.3.6. Routing ABS Sensor Electrical Harness  6.4. Rear ABS Pulse Generating Wheel & Radial \$  6.4.1. Description	2-121 2-121 2-121 2-122 2-122 2-123 2-123 2-123 2-124 2-124 2-125 Seal 2-126
6.	COMPONENTS  6.1. Description  6.2. Operation  6.3. Rear ABS Speed Sensor & Sensor Holder  6.3.1. Description  6.3.2. Removal  6.3.3. Installation  6.3.3.1. Default Gap Setting  6.3.3.2. Positioning ABS Sensor Holder  6.3.3.3. Centering Device Assembly & Installation  6.3.3.4. ABS Sensor Holder Installation  6.3.3.5. Checking & Setting ABS Sensor Gap  6.3.3.6. Routing ABS Sensor Electrical Harness  6.4. Rear ABS Pulse Generating Wheel & Radial \$ 6.4.1. Description  6.4.2. Removal & Installation	2-121 2-121 2-121 2-122 2-122 2-123 2-123 2-123 2-123 2-124 2-124 2-125 Seal 2-126 2-126
6.	COMPONENTS  6.1. Description  6.2. Operation  6.3. Rear ABS Speed Sensor & Sensor Holder  6.3.1. Description  6.3.2. Removal  6.3.3. Installation  6.3.3.1. Default Gap Setting  6.3.3.2. Positioning ABS Sensor Holder  6.3.3.3. Centering Device Assembly & Installation  6.3.3.4. ABS Sensor Holder Installation  6.3.3.5. Checking & Setting ABS Sensor Gap  6.3.3.6. Routing ABS Sensor Electrical Harness  6.4. Rear ABS Pulse Generating Wheel & Radial \$  6.4.1. Description	2-121 2-121 2-121 2-122 2-122 2-123 2-123 2-123 2-123 2-124 2-124 2-125 Seal 2-126 2-126
6.	COMPONENTS  6.1. Description  6.2. Operation  6.3. Rear ABS Speed Sensor & Sensor Holder  6.3.1. Description  6.3.2. Removal  6.3.3. Installation  6.3.3.1. Default Gap Setting  6.3.3.2. Positioning ABS Sensor Holder  6.3.3.3. Centering Device Assembly & Installation  6.3.3.4. ABS Sensor Holder Installation  6.3.3.5. Checking & Setting ABS Sensor Gap  6.3.3.6. Routing ABS Sensor Electrical Harness  6.4. Rear ABS Pulse Generating Wheel & Radial \$ 6.4.1. Description  6.4.2. Removal & Installation  6.5. Rear ABS Modulator Valve	2-121 2-121 2-121 2-122 2-122 2-123 2-123 2-123 2-123 2-124 2-124 2-125 Seal 2-126 2-126 2-126
6.	COMPONENTS  6.1. Description  6.2. Operation  6.3. Rear ABS Speed Sensor & Sensor Holder  6.3.1. Description  6.3.2. Removal  6.3.3. Installation  6.3.3.1. Default Gap Setting  6.3.3.2. Positioning ABS Sensor Holder  6.3.3.3. Centering Device Assembly & Installation  6.3.3.4. ABS Sensor Holder Installation  6.3.3.5. Checking & Setting ABS Sensor Gap  6.3.3.6. Routing ABS Sensor Electrical Harness  6.4. Rear ABS Pulse Generating Wheel & Radial \$ 6.4.1. Description  6.4.2. Removal & Installation  6.5. Rear ABS Modulator Valve  6.5.1. Description	2-121 2-121 2-121 2-122 2-122 2-123 2-123 2-123 2-124 2-124 2-124 2-126 2-126 2-126 2-126 2-126 2-126
6.	COMPONENTS  6.1. Description  6.2. Operation  6.3. Rear ABS Speed Sensor & Sensor Holder  6.3.1. Description  6.3.2. Removal  6.3.3. Installation  6.3.3.1. Default Gap Setting  6.3.3.2. Positioning ABS Sensor Holder  6.3.3.3. Centering Device Assembly & Installation  6.3.3.4. ABS Sensor Holder Installation  6.3.3.5. Checking & Setting ABS Sensor Gap  6.3.3.6. Routing ABS Sensor Electrical Harness  6.4. Rear ABS Pulse Generating Wheel & Radial \$ 6.4.1. Description  6.4.2. Removal & Installation  6.5. Rear ABS Modulator Valve  6.5.1. Description  6.5.2. Operation	2-121 2-121 2-121 2-122 2-122 2-123 2-123 2-123 2-124 2-124 2-125 Seal 2-126 2-126 2-126 2-126 2-126
6.	COMPONENTS  6.1. Description  6.2. Operation  6.3. Rear ABS Speed Sensor & Sensor Holder  6.3.1. Description  6.3.2. Removal  6.3.3. Installation  6.3.3.1. Default Gap Setting  6.3.3.2. Positioning ABS Sensor Holder  6.3.3.3. Centering Device Assembly & Installation  6.3.3.4. ABS Sensor Holder Installation  6.3.3.5. Checking & Setting ABS Sensor Gap  6.3.3.6. Routing ABS Sensor Electrical Harness  6.4. Rear ABS Pulse Generating Wheel & Radial \$ 6.4.1. Description  6.4.2. Removal & Installation  6.5. Rear ABS Modulator Valve  6.5.1. Description	2-121 2-121 2-121 2-122 2-122 2-123 2-123 2-123 2-124 2-124 2-125 Seal 2-126 2-126 2-126 2-126 2-126 2-126 2-126

## Table of Contents



	6.6. ABS Electronic Control Unit (ECU)	2-128
	6.6.1. Description	2-128
	6.6.2. ABS Troubleshooting	
	6.6.3. Blink Code Diagnostics & Troubleshooting	2-129
	6.6.3.1. Description	
	6.6.3.2. Diagnostic Mode	
	6.6.3.3. Clear Mode	
	6.6.3.4. System Configuration Code	2-129
7.	REAR AXLE SPECIAL TOOLS	2-130
	7.1. Rear Axle Special Tools Chart	2-130
8.	DRIVESHAFT	2-139
	8.1. Description	2-139
	8.2. Driveshaft Specifications	
	8.3. Operation	
	8.4. Maintenance	
	8.5. Removal	
	8.6. Disassembly	
	8.7. Assembly	
	•	
	8.8. Installation	2-144
9.	VENDOR SERVICE INFORMATION	2-145
	9.1 Meritor Wahoo Manual	2-145



## 1. SAFETY

## 1.1. Safety Procedures

This section of the service manual contains procedures which require the mechanics to strictly observe safety procedures in order to ensure personal and equipment safety.

Always ensure that the vehicle is appropriately hoisted and blocked for procedures which require elevating the vehicle. Be aware of the limitations of the blocking equipment, and always ensure that the jarring and shaking created by component removal and installation procedures does not overload the blocks, or cause the vehicle to become unstable.

Certain procedures may require the vehicle be operated in an elevated position in order to accurately troubleshoot and diagnose a problem. If the vehicle must be running while elevated, become familiar with the repair area prior to starting the engine. Take special care in noting areas which will become hot, electrically energized, and areas where moving and rotating components are located. Limit the work in these areas as personal and equipment safety is at risk.

For procedures which involve air lines, ensure the line is safely depressurized prior to disconnecting. Disconnecting pressurized lines will cause solid particles deposited in the line to be uncontrollably propelled, and will also cause the hose end to whip randomly as the air escapes.

# 1.2. Hoisting & Related Safety Information

Refer to the General Information Section of this manual for information on types of hoists, hoisting procedures, jack stands and related safety information. Refer to this information and read carefully before lifting, hoisting or jacking the vehicle.



# 2. REAR AXLE & SUSPENSION

## 2.1. Description

This rear axle and suspension system incudes the following sub-components and systems:

- ☐ Axle Assembly
- ☐ Axle Suspension Beam
- Suspension Components
- ☐ Brake System
- □ ABS System

#### □ Driveshaft

The rear axle is mounted to a suspension beam assembly. See "Fig. 2-1: Rear Axle & Suspension Assembly" on page 2. The axle/suspension beam assembly is held in alignment to the chassis by four radius rods. The upper radius rods are attached to the upper part of the differential housing and the vehicle chassis. The lower radius rods are attached to the inner front of the suspension beam and the chassis. Four air spring assemblies are attached to pads provided at the front and rear of the suspension beam. Four double acting shock absorbers, two in front of and two behind the axle, are mounted to the suspension beam and the chassis.




Fig. 2-1: Rear Axle & Suspension Assembly



## 2.2. Operation

As the vehicle travels, the axle and suspension beam assembly move vertically relative to the vehicle chassis. The air springs compress and extend as the wheels go over bumps and dips allowing this movement. The rate of movement is controlled by the shock absorbers. The radius rods maintain alignment of the assembly to the vehicle chassis. Leveling valves connected by operating links to the left and right front of the suspension beam control the air pressure in each pair of air springs to maintain ride height and prevent tilting of the vehicle when loading is uneven.

#### 2.3. Removal

#### ™NOTE:

The following procedure describes the removal of the axle and suspension beam as a unit with wheels and tires installed.

- 1. Drain system air pressure.
- 2. Raise vehicle using wheel lifts or center post lift. Refer to the General Information Section of this manual for procedure.
- 3. Place safety stands under vehicle frame.
- Lower rear wheel lift slightly to allow axle assembly to drop approximately 3" (76 mm).
- Scribe reference marks on the driveshaft and differential flange for alignment purposes during installation. Disconnect the driveshaft and secure it out of the way. Refer to 8. "DRIVESHAFT" on page 139 in

this section for information on this component.

- 6. Unplug ABS sensor harnesses.
- Remove membrane breather from vehicle structure mounting bracket.
- Disconnect leveling valve links from suspension beam brackets (do not disturb adjustment). Refer to Section 8 of this manual for disconnect procedure. Pull valve lever down to drain air from air springs.
- Disconnect upper and lower radius rods at their chassis mounting points and leave opposite end attached to axle and suspension beam.
- 10. Disconnect the shock absorbers from the axle suspension beam and leave upper shock mounts attached to vehicle structure.
- 11. Remove the center nut from the bottom of each air spring and leave air spring upper mounts attached to vehicle structure.
- 12.Tag and disconnect brake chamber air lines.
- 13. Check for and disconnect any other lines or harnesses routed to the axle or axle components.
- 14. Carefully lower axle, suspension beam and wheel assembly to floor with wheel lift.

#### ™NOTE:

Make sure assembly is strapped or chained to lifting device to prevent it from tilting or falling.



## 2.4. Installation

#### MOTE:

Refer to the Special Tools Chart in Section 1 of this manual for the disc brake servicing tools.

- Raise vehicle and support on safety stands.
- Place axle, suspension beam and wheel assembly on wheel lift, secure with straps or chains to prevent tilting or falling and elevate into position.
- 3. Install upper and lower radius rods to chassis with bolts and nuts, do not tighten.
- 4. Align lower air spring mounting hole with suspension beam mounting pad, install and torque nut to specification.
- 5. Install lower end of shock absorbers to suspension beam with rubber isolators, cupped washers and nuts.
- Torque shock absorber nuts to specification.

- 7. Torque upper and lower radius rod bolts to specification.
- 8. Attach brake chamber air lines to correct locations.
- 9. Connect ABS sensor harness connectors.
- 10. Mount membrane breather to vehicle structure mounting bracket.
- 11. Check for and connect any other lines or harnesses removed during the disassembly process.
- 12. Align scribe marks on driveshaft and differential flange. Install driveshaft and torque bolts to  $69 \pm 6$  ft-lb. ( $94 \pm 8$  Nm). Refer to 8. "DRIVESHAFT" on page 139 in this section for procedure.
- 13. Connect leveling valve links to original positions on suspension beam brackets.
- 14. Raise vehicle to free up safety stands. Remove stands and lower vehicle.



## 2.5. Disassembly

- 1. Support axle and suspension beam on jack stands or suitable work stand.
- Remove wheel and tire assemblies from axle.
- Remove nuts, spacers and jacking pad assembly from the four U-bolts retaining axle tube to suspension beam. See "Fig. 2-2: Axle to Suspension Beam Mounting Detail" on page 5.

## ™NOTE:

Sealant has been applied to the U-bolts, stiffener plates and spacer tubes during the installation process. It may be necessary to pry mounting hardware pieces to release and fully remove them.

- 4. Remove the U-bolts.
- 5. Use hoisting equipment with a minimum capacity of 10,000 lb. (4,550 kg) to lift the axle assembly onto an axle stand equipped to prevent the axle from rotating when set in place. If necessary, tie the axle to the stand with chains or straps.




Fig. 2-2: Axle to Suspension Beam Mounting Detail



## 2.6. Assembly

### ™NOTE:

Refer to 4.5. "Rear Suspension Torque Specifications" on page 91 in this section for all assembly and installation torque values.

- Use appropriate hoisting equipment and carefully lower the axle onto the suspension beam. Align axle mounting pad with dowel pin holes and U-bolt holes in the suspension beam.
- 2. Install U-bolts (two per side), spacers, and stiffener plates.

- Coat threads with NEVER-SEEZ®, install lock nuts and torque initially to 50 ft-lb. (68 Nm).
- 4. Working in a circular pattern from inner to outer bolts, torque bolts to specification.
- Apply Sikaflex 221 to the edges of the spacer tubes and the stiffener plates to ensure a seal between the top and bottom plates. Also seal the U-Bolt to the top plate holes in the suspension beam.
- 6. Install tire and wheel assemblies on axle.



## 3. REAR AXLE

## 3.1. Description

The rear axle assembly consists of a MAN HY-1350-F low floor hypoid axle complete with wheel hub assembly, brake caliper &

brake disc assembly, The axle assembly also includes ABS sensor and pulse generating wheel. The brake chambers are mounted directly on the disc brake caliper assembly. See "Fig. 2-3: Rear Axle Assembly" on page 7.




Fig. 2-3: Rear Axle Assembly



## 3.2. Rear Axle Specifications

Make MAN
Model HY-1350-F
Gear Ratio4.56
Capacity28,660 lb. (13,000 kg)
Wheel Studs M22 x 1.5 @ 13.189" (335mm) bolt circle
Flange
Input Offset Horizontal - 2.75" (70 mm) Vertical - 1.18" (30 mm)
Mounting Pad Angle4.25°
Differential Oil Capacity
15.3 guart (14.5 l)

#### 3.3. Operation

Drive power is transmitted through a driveshaft to the flange connection on the input end of the pinion shaft. The pinion shaft transfers power 90° to the axle shafts via the pinion gear and crown wheel. The crown wheel drives the pinion carrier, pinion gear set and side gears.

The flanged end of the axle shaft is bolted to the wheel hub and drives the wheel hub.

#### 3.4. Maintenance

Refer to the Preventive Maintenance Section of this manual for scheduled maintenance requirements.

## 3.5. Tires

#### 3.5.1. Tire Specifications

Manufacturer	Michelin
Model	X CTRAZ
Size	305/70R22.5
Inflation Pressure	125 psi
Maximum Load (dual tires)7,121	lbs. @ 125 psi

#### 3.5.2. Maintenance & Replacement



ALWAYS use tire mounting equipment that is specifically designed for the application and will ensure proper tire mounting without incurring any damage. ALWAYS follow manufacturer's recommendations for use of tire mounting equipment.

### RNOTE:

In order to maintain compliance with Environmental Protection Agency (EPA 2014-2016) and regulatory emission standards, ALWAYS replace tires with ones that meet or exceed the rolling resistance performance of the original tires.

### ™NOTE:

Consult your tire supplier to ensure that the replacement tire meets the required rolling resistance requirements.

Refer to and follow original tire manufacturer's maintenance procedures in conjunction with the scheduled maintenance identified in the Preventive Maintenance Section of this manual.



#### 3.6. Wheels



Special care must be taken when removing, servicing and installing the wheel and tire assembly to ensure operator, mechanic and passenger safety standards are maintained for the service life of the vehicle.

#### 3.6.1. Inspection

There are several factors that determine the serviceability of the wheel. These include, but are not limited to corrosion, bent rim, excess paint build up and cracks. Inspect all parts for damage. Ensure that studs, nuts, mounting surfaces of the hub, drum, and wheels are clean, and free of grease or corrosion.

#### 3.6.1.1. Wheel Assemblies

Ensure that the wheel mounting surfaces do not have excessive paint thickness, and repair if required. Excessive paint thickness, debris, or excessive corrosion on the wheel mounting surfaces will gradually work its way out during operation and the wheel will become loose. This could result in cracked or broken wheels, damaged brake disc, broken studs, and wheel separation from the vehicle.

Inspect all wheels for cracks, elongated bolt holes, correct shape and form, and other defects that would render the wheel unsafe. Wheels with cracks are not considered serviceable. There are no rework limits for cracks on wheels. Any wheel with a crack is considered scrap, and shall not be reworked. Scrap all wheels which show:

- □ Cracking
- Deep corrosion defined by a corrosive pit being deeper than 1/2 of the material thickness.

☐ Excessive wear on the mounting surfaces

Bent flanges

Elongated bolt holes

☐ Extended use or excessive wear on the disc face

Illegible stamping

Excessive bead blasting used to remove paint may have a negative effect on the wheel. Too much metal may be removed during repeated bead blasting. As this may lead to wheel cracking and early wheel failure the wheel must be scrapped. Never rework, weld, braze or otherwise heat any damaged wheel. Do not attempt to straighten bent or damaged flanges.

Wheels may be refinished and returned to service if no out of service conditions are present.

#### 3.6.1.2. Studs

Studs with thread damage from over tightening, being run loose, excessive corrosion or other secondary damage should be removed from service.

#### 3.6.1.3. Nuts

Thread the nuts onto the studs by hand. Nuts must turn easily by hand. Two-piece flange-nuts may be damaged by extended use, excessive torque, or corrosion. Scrap any nut with cracks in the flange, damaged threads or any nut that does not swivel freely with moderate pressure applied to the flange while rotating the nut. Nuts which no longer rotate freely due to corrosion, wear, or paint build-up may be lubricated. Before reusing flange-nuts, apply (2) drops of 30 weight oil between the flange and the body of the hex nut. If a binding condition still exists it should be removed from service.



#### 3.6.2. Installation



This procedure assumes that the vehicle has already been safely jacked up and blocked.



Replace any wheel mounting parts showing any damage.

- Prior to wheel installation, inspect threads of wheel studs and stud nuts for signs of gouging. Ensure stud mounting surfaces are clean. Inspect wheel rim center surface for damage.
- Align mounting holes of inner wheel with wheel studs and install inner wheel against wheel hub. Install outer wheel against inner wheel. See "Fig. 2-4: Hub Piloted Wheels - Rear" on page 10.
- 3. Pretorque wheel nuts 100 ft-lb. (136 Nm). Ensure both wheels are mounted flush around entire hub mounting surface.
- 4. Lower vehicle to ground.
- 5. Using torque wrench, pretorque wheel nuts in sequence to 200 ft-lb. (272 Nm). See "Fig. 2-5: Wheel Nut Torquing Sequence" on page 10.
- 6. Using torque wrench, final torque wheel nuts in sequence to final specification.

## ™NOTE:

Refer to 4.5. "Rear Suspension Torque Specifications" on page 91 in this section for final installation torque value. Torque on dry, unlubricated thread only.



BE SURE wheel and tire assembly are at ambient temperatures before checking wheel nut torque.

7. Check torque on all wheel nuts after 50 to 100 miles of operation.




Fig. 2-4: Hub Piloted Wheels - Rear




Fig. 2-5: Wheel Nut Torquing Sequence



## 3.7. Wheel Bolts

#### 3.7.1. Removal

Use a hammer to remove the wheel bolt from the flange. See "Fig. 2-6: Wheel Bolt Removal" on page 11.




Fig. 2-6: Wheel Bolt Removal

#### 3.7.2. Installation

- 1. Insert a new wheel bolt with the truncated end facing the wheel hub. See "Fig. 2-7: Wheel Bolt Installation" on page 11.
- Screw the Wheel Bolt Adapter (Item 1 from the special tools list) onto the wheel bolt.
- Install the wheel bolt using the Wheel Bolt Adapter (Item 1 from the special tools list) and the Impact Tool (Item 2 from the special tools list).




Fig. 2-7: Wheel Bolt Installation



### 3.8. Axle Shaft



Due to the danger of injury when working with heavy components, always use assistance when moving or lifting the axle shaft.

#### 3.8.1. Removal

#### ™NOTE:

The brake chamber release bolt must be screwed in to remove the axle shaft mounting bolts. If the axle shaft is being removed while the axle is installed in the vehicle, the parking brake must be applied.

- Secure the brakes by tightening the brake chamber release bolt to 50 to 60 ft-lb. (68 to 81 Nm). See "Fig. 2-8: Screwing in Release Bolt" on page 12.
- 2. Remove and discard the mounting bolts. See "Fig. 2-9: Axle Shaft Removal & Installation" on page 13.
- 3. Remove the axle shaft and clean the hub and shaft mating surfaces.

## ™NOTE:

The axle shafts are of unequal length. Ensure that each axle is identified as to its location.




Fig. 2-8: Screwing in Release Bolt






Fig. 2-9: Axle Shaft Removal & Installation



#### 3.8.2. Installation



Due to the danger of injury when working with heavy components, always use assistance when moving or lifting the axle shaft.



Final tightening torque of all fasteners must be performed manually using a torque wrench.

1. Apply a thin coating of ThreeBond white sealing agent on the axle shaft and wheel hub mating surfaces.



The streetside and curbside axle shafts are not interchangeable. Ensure the axle shafts are installed in the correct location as marked during removal.

2. Insert the axle shaft into the axle support, rotating slightly if necessary to insert the shaft into the differential gears.



DO NOT use impact tools to cage or uncage the brake chamber.

- 3. Install new mounting bolts and torque to 266 ft-lb. (360 Nm).
- 4. Release and cage the spring brake by rotating the brake chamber release bolt counter-clockwise approximately 22 to 23 turns. The force to compress the spring must not exceed 74 ft-lb. (100 Nm) during the caging process. The brake chamber is considered fully caged when the head of the release bolt extends approximately 1.30" beyond the surface of the brake chamber.



Check to ensure that the brake system is functioning properly any time the brake chamber release bolt has been tightened.



## 3.9. Rear Wheel Hub

#### 3.9.1. Description

The wheel hub consists of inner and outer tapered roller bearings, inner grease seal with integral ABS pulse wheel, and outer grease seal. The wheel hub is secured to the axle spindle with a locking slotted nut. The wheel bearing clearance is preset and non-adjustable. The wheel bearings require lubrication only if being replaced.

#### 3.9.2. Inspection

Inspect the wheel hub bearings for excessive play as follows:

- 1. Raise the vehicle and support the rear axle on jack stands.
- 2. Ensure the brakes are released and the wheels can rotate freely.
- Attach the base of a magnetic dial gauge to any rigid part of the vehicle structure or axle housing. See "Fig. 2-10: Wheel Bearing Inspection" on page 15.
- 4. Align the dial gauge pin perpendicular to the face of the brake rotor and as close as possible to the outer edge of the brake disc. Also ensure that the dial gauge pin is located at either the 6 o'clock or 12 o'clock position.

#### ™NOTE:

It is important that the dial gauge pin be positioned at the correct distance from the center of the brake disc in order to obtain an accurate reading. The tip of the gauge should be resting approximately 8.25 to 8.5 inches (210 to 215 mm) from the center of the disc.

5. Zero the dial gauge.

Grasp the wheel at the top and bottom and rock back and forth while observing the dial indicator reading.

## ™NOTE:

If clearance issues resulted in the dial gauge being positioned somewhere other than the 12 o'clock or 6 o'clock position, then ensure the wheel is grasped at a location that corresponds. As an example, if the dial gauge was located at the 2 o'clock position, then grasp the wheel at the 2 o'clock and 8 o'clock positions and rock back and forth.

If total movement exceeds 0.010 inch (0.25 mm) remove and inspect the wheel bearings for wear. Replace worn components as necessary.




Fig. 2-10: Wheel Bearing Inspection



#### 3.9.3. Removal



Due to the danger of injury when working with heavy components, always use assistance when moving or lifting the wheel hub.

See "Fig. 2-11: Wheel Hub Assembly" on page 17.

#### 3.9.3.1. Uncaging the Brake Chamber



DO NOT use impact tools to cage or uncage the brake chamber.

Uncage the brake chamber by rotating the release bolt clockwise until fully seated. Torque the release bolt 50 to 62 ft-lb. (68 to 81 Nm).

### 3.9.3.2. Unlocking Slotted Nut

Unlock the slotted nut by using a punch on the deformed collar of the slotted nut. See "Fig. 2-12: Unlocking Slotted Nut" on page 18.

## 3.9.3.3. Centering Device Assembly

Assemble the centering device using Items 3, 4, 5, 6 and 7 from special tools list. See "Fig. 2-13: Assembling Centering Device" on page 18.

#### 3.9.3.4. Inserting Centering Device

- Insert the centering device into the axle stub until it stops. See "Fig. 2-14: Inserting Centering Device" on page 18.
- 2. Clamp the centering device in place by tightening the screw spindle.

#### 3.9.3.5. Loosening Slotted Nut

- Install the Slotted Nut Socket (Item 8 from special tools list) over the centering device and onto the slotted nut. See "Fig. 2-15: Slotted Nut" on page 18.
- Install the Torque Multiplier (Item 9 from special tools list) on the slotted nut socket and secure it in place with Spindle Screw and Washer (Items 7 & 6 from special tools list).
- Position Counter-Holder (Item 12 from special tools list) so that the head of the tool slips over the studs on the torque multiplier body and the base of the counterholder is braced against the floor to counteract the rotational movement of the torque multiplier.
- Operate the torque multiplier in a counterclockwise direction to loosen the slotted nut. See "Fig. 2-16: Loosening Slotted Nut" on page 19.
- 5. Remove the special tools.

#### 3.9.3.6. Slotted Nut Removal

- 1. Loosen the wheel hub mounting bolts.
- Remove the slotted nut and the thrust washer. See "Fig. 2-17: Removing Slotted Nut" on page 19.
- 3. Discard the slotted nut.







Fig. 2-11: Wheel Hub Assembly





AXLE STUB
CENTERING DEVICE

\$119407a.svg

Fig. 2-12: Unlocking Slotted Nut

Fig. 2-14: Inserting Centering Device




Fig. 2-13: Assembling Centering Device




Fig. 2-15: Slotted Nut






Fig. 2-16: Loosening Slotted Nut




Fig. 2-17: Removing Slotted Nut

#### 3.9.3.7. Wheel Hub Removal



The wheel hub is heavy. Use a lifting device or assistance if necessary when removing the wheel hub.

1. Remove the wheel hub mounting bolts.

### ™NOTE:

Check condition of bolts. Do not re-use any mounting bolts with signs of damage or deformity.

- Install threaded Guide Sleeve (Item 13 from special tools list) onto the axle stub and lubricate guide sleeve surface. See "Fig. 2-18: Removing Wheel Hub" on page 20.
- Pull wheel hub off axle stub and guide sleeve. Use a smooth continuous motion during removal to avoid binding the wheel hub bearings on the guide sleeve. Place wheel hub on a clean work surface.
- 4. Unscrew Guide Sleeve (Item 13 from special tools list) from axle stub.
- Clean the wheel hub sealing and contact surfaces. Check for damage. Remove and discard the O-ring.






Fig. 2-18: Removing Wheel Hub




Fig. 2-19: Removing Retaining Ring

## 3.9.4. Disassembly

### 3.9.4.1. Retaining Ring Removal

Remove the retaining ring for the wheel hub bearing. See "Fig. 2-19: Removing Retaining Ring" on page 20.



# 3.9.4.2. Outer Tapered Roller Bearing Removal NOTE:

The Press-Out Device (Item 17 from special tools list) must not be wedged tight in the wheel hub bearing bore when expanded. Damage to the wheel hub will result.

- Place the wheel hub on its outer bearing support with wood underneath. Insert the Press-Out Device (Item 17 from special tools list) into the wheel hub.
- Insert the Slip-On Handle (Item 14 from special tools list) with Press-Out Adapter (Item 16 from special tools list) into the press-out device. See "Fig. 2-20: Removing Outer Tapered Roller Bearing" on page 21.
- 3. Expand the press-out device by turning the slip-on handle until the stop is reached.
- 4. Press out the tapered roller bearing and the radial shaft seal.




Fig. 2-20: Removing Outer Tapered Roller Bearing



## 3.9.4.3. Outer Bearing Outer Race Removal

## ™NOTE:

The Press-Out Device (Item 17 from special tools list) must not be wedged tight when expanded in the wheel hub.

- Insert the Press-Out Device (Item 17 from special tools list) into the wheel hub. See "Fig. 2-21: Removing Outer Bearing Outer Race" on page 22.
- Insert the Slip-On Handle (Item 14 from special tools list) with the Press-Out Adapter (Item 16 from special tools list) into the press-out device
- 3. Expand the pressing device by turning the slip-on handle until the stop is reached.
- 4. Press out the bearing outer race.




Fig. 2-21: Removing Outer Bearing Outer Race



## 3.9.4.4. Inner Tapered Roller Bearing Removal

## ™NOTE:

The Press-Out Device (Item 17 from special tools list) must not be wedged tight when expanded in the wheel hub.

- Place the wheel hub on its inner bearing support with wood underneath. See "Fig. 2-22: Removing Inner Tapered Roller Bearing" on page 23.
- Insert the pressing device into the wheel hub.
- Insert the Slip-On Handle (Item 14 from special tools list) with Press-Out Adapter (Item 16 from special tools list) into the pressing device.
- 4. Expand the pressing device by turning the slip-on handle until the stop is reached.
- 5. Press out the tapered roller bearing and the radial shaft seal with ABS pulse wheel.
- Remove the radial shaft seal with ABS pulse wheel from the tapered roller bearing.

## ™NOTE:

The radial shaft seal with ABS pulse wheel is a press fit on the shoulder of the bearing inner ring and will need to be pressed off. Use an appropriate support fixture for the ABS pulse wheel and select a pressing fixture that will fit the inner ring of the bearing.




Fig. 2-22: Removing Inner Tapered Roller Bearing



## 3.9.4.5. Inner Bearing Outer Race Removal

## ™NOTE:

The Press-Out Device (Item 17 from special tools list) must not be wedged tight when expanded in the wheel hub.

- Place the wheel hub on its inner bearing support with wood underneath. See "Fig. 2-23: Removing Inner Bearing Outer Race" on page 24.
- Insert the press-out device into the wheel hub.
- 3. Insert the Slip-On Handle (Item 14 from special tools list) with Press-Out Adapter (Item 16 from special tools list) into the pressing device.
- 4. Expand the pressing device by turning the slip-on handle until the stop is reached.
- 5. Press out the bearing outer race.




Fig. 2-23: Removing Inner Bearing Outer Race



### 3.9.5. Assembly

### 3.9.5.1. Inner Bearing Outer Race Installation

- Place wheel hub on its outer bearing support with a piece of wood supporting from underneath. See "Fig. 2-24: Installing Inner Bearing Outer Race" on page 25.
- Assemble the Press-In Plate (Item 18 from special tools list) with the Slip-On Handle (Item 14 from special tools list) and the Washer (Item 15 from special tools list).
- 3. Press in the bearing outer race as far as the stop with the cone facing outwards.




Fig. 2-24: Installing Inner Bearing Outer Race

### 3.9.5.2. Greasing Hub Unit Wheel Bearings



An excessive quantity of grease leads to excess pressure and leakage in the wheel bearing. DO NOT exceed a grease quantity of 4.2 oz. (120 g).

- Apply high-temperature grease on the tapered roller bearings. See "Fig. 2-25: Greasing Hub Unit Wheel Bearings" on page 25. Refer to "Fluid & Lubrication Guide" in the Preventive Maintenance Section of this manual for a list of approved greases.
- Fill the cavity between the tapered roller bearings with the specified high-temperature grease.




Fig. 2-25: Greasing Hub Unit Wheel Bearings



# 3.9.5.3. Inner Tapered Roller Bearing Installation

- 1. Insert the tapered roller bearing into the wheel hub. See "Fig. 2-26: Installing Inner Tapered Roller Bearing" on page 26.
- 2. Assemble the Pressing Bush (Item 19 from special tools list) with the Slip-On Handle (Item 14 from special tools list) and the Washer (Item 15 from special tools list).
- 3. Lightly apply gear oil on the contact surfaces of the new radial shaft seal with ABS pulse wheel.
- Press the radial shaft seal with ABS pulse wheel into the wheel hub so that it seats flush.




Fig. 2-26: Installing Inner Tapered Roller Bearing



### 3.9.5.4. Outer Bearing Outer Race Installation

- 1. Place wheel hub on its inner bearing support.
- 2. Assemble the Press-In Plate (Item 18 from special tools list) with the Slip-On Handle (Item 14 from special tools list) and the Washer (Item 15 from special tools list).
- 3. Press in the bearing outer race as far as the stop with the cone facing outwards. See "Fig. 2-27: Installing Outer Bearing Outer Race" on page 27.




Fig. 2-27: Installing Outer Bearing Outer Race



# 3.9.5.5. Outer Tapered Roller Bearing Installation

- Insert the tapered roller bearing into the wheel hub. See "Fig. 2-28: Installing Outer Tapered Roller Bearing" on page 28.
- 2. Assemble the Pressing Bush (Item 20 from special tools list) with the Slip-On Handle (Item 14 from special tools list) and the Washer (Item 15 from special tools list).
- 3. Lightly apply gear oil on the contact surfaces of the new radial shaft seal.
- Press the radial shaft seal into the wheel hub with the sealing lip outwards, so that it is flush.

### 3.9.5.6. Retaining Ring Installation

Install the wheel bearing retaining ring in its groove. Be sure the retaining ring is properly installed into the groove of each bearing to provide proper connection.




Fig. 2-28: Installing Outer Tapered Roller Bearing



### 3.9.6. Installation



Due to the danger of injury when working with heavy components, always use assistance when moving or lifting the wheel hub.

### 3.9.6.1. Mounting Wheel Hub

- Apply a light coat of Molykote-D paste in the wheel hub bearing seat area and on the axle stub. Apply paste on the machined surface of the stub where the hub bearings are seated except 3/4" of inner bearing seat.
- Insert a new O-ring on the inside of the wheel hub.
- 3. Install the threaded Guide Sleeve (Item 13 from special tools list) onto the axle stub.
- 4. Install the wheel hub over the guide sleeve and align it to the brake disc.

### ™NOTE:

Replace any mounting bolts with signs of damage or deformity.

- 5. Install mounting bolts.
- Remove the Guide Sleeve (Item 13 from special tools list).

### 3.9.6.2. Screwing on Slotted Nut

- Torque mounting bolts to 207 ft-lb. (280 Nm).
- 2. Install the thrust washer.
- 3. Install a new slotted nut.

### 3.9.6.3. Caging Brake Chamber

 Allow the wheel hub to rotate by releasing the parking brake.

### ™NOTE:

If the parking brake is not functional, proceed to the following step.



# DO NOT use impact tools to cage or uncage the brake chamber.

2. Release and cage the spring brake by rotating the brake chamber release bolt counter-clockwise approximately 22 to 23 turns. The force to compress the spring must not exceed 74 ft-lb. (100 Nm) during the caging process. The brake chamber is considered fully caged when the head of the release bolt extends approximately 1.30" beyond the surface of the brake chamber.

### 3.9.6.4. Inserting Centering Device

- 1. Insert the centering device into the axle stub until the stop is reached.
- 2. Clamp the centering device.

### 3.9.6.5. Tightening Slotted Nut

- Fit the Slotted Nut Socket (Item 8 from special tools list) over the centering device and onto the slotted nut.
- 2. Place the Torque Multiplier (Item 9 from special tools list) on the slotted nut socket and secure it in place with Spindle Screw and Washer (Items 7 & 6 from special tools list).
- 3. Mount the Counter-Holder (Item 12 from special tools list) on the torque multiplier.



The torque multiplier has a 1:8 ratio. Set the torque wrench to 111 ft-lb. (150 Nm) for a final torque of 885 ft-lb. (1200 Nm).

- Rotate the Torque Multiplier to tighten the slotted nut. Torque the slotted Nut to 885 ft-lb. (1200 Nm) while turning the wheel hub constantly.
- 5. Remove the Special tools.



### 3.9.6.6. Locking Slotted Nut

Lock the slotted nut by using a rounded punch and deforming the collar of the slotted nut into the groove. See "Fig. 2-29: Locking Slotted Nut" on page 30.

### 3.9.6.7. Uncaging Brake Chamber



# DO NOT use impact tools to cage or uncage the brake chamber.

Uncage the brake chamber by rotating the release bolt clockwise until fully seated. Torque the release bolt 50 to 62 ft-lb. (68 to 81 Nm).




Fig. 2-29: Locking Slotted Nut



### 3.10. Pinion Seal Replacement

The following procedure describes replacement of the pinion shaft radial seal with the axle installed on the vehicle. See "Fig. 2-30: Pinion Seal Replacement" on page 31.

Refer to 8. "DRIVESHAFT" on page 139 in this section of the manual for removal and installation procedures.




Fig. 2-30: Pinion Seal Replacement



### 3.10.1. Removal

### 3.10.1.1.Unlocking Slotted Nut



Be sure the dimpled metal is completely bent out from the groove in the pinion shaft. Failure to do so may result in damage to the pinion shaft threads.

- Unlock the slotted nut using a chisel or punch to bend the dimpled metal out of the slot. See "Fig. 2-31: Unlocking Slotted Nut" on page 32.
- 2. Assemble special tools as follows:
  - a. Position Intermediate Flange (Item 43 from Special Tools List) on input flange and secure with mounting bolts. See "Fig. 2-32: Mounting Input Flange Tool" on page 32.
  - b. Place the Slotted Nut Wrench (Item 26 from Special Tools List) onto the slotted nut.
  - c. Install the Torque Multiplier (Item 9 from Special Tools List) onto the Intermediate Flange (Item 43 from Special Tools List) and secure using mounting nuts.




Fig. 2-31: Unlocking Slotted Nut




Fig. 2-32: Mounting Input Flange Tool



### 3.10.1.2.Removing Slotted Nut

- Loosen the slotted nut using the torque multiplier. The slotted nut must be turned counter-clockwise to loosen. See "Fig. 2-33: Removing Slotted Nut" on page 33.
- 2. Remove the special tools.
- 3. Remove and discard the slotted nut.




Fig. 2-33: Removing Slotted Nut

### 3.10.1.3. Removing Input Flange

- Place the 3-Arm Puller (Item 29 from Special Tools List) and Adapter Piece (Item 35 from Special Tools List) on the input flange.
- 2. Thread the 3-Arm Puller spindle against the Adapter Piece to remove the input flange. See "Fig. 2-34: Pulling Off Input Flange" on page 33.




Fig. 2-34: Pulling Off Input Flange



### 3.10.1.4.Removing Radial Shaft Seal

- Insert the hooks of the 3-Arm Puller (Item 32 from Special Tools List) behind the sealing lips of the radial shaft seal.
- Place the Spindle Adapter (Item 67 from Special Tools List) on the pinion shaft and thread in the spindle until it contacts the spindle adapter. See "Fig. 2-35: Removing Radial Shaft Seal" on page 34.
- 3. Pull out the radial shaft seal from the drive pinion gear housing and discard.

### 3.10.1.5.Removing Input Flange Shield

### ™NOTE:

Removal of the flange shield is required only if the protective shield is has been damaged.

- Fit the Separator (Item 75 from Special Tools List) under the shield. See "Fig. 2-36: Removing Input Flange Shield" on page 34.
- 2. Place the Separator and input flange on a press and support with suitable blocks.
- 3. Assemble the Pressing Plate (Item 74 from Special Tools List) with Detachable Handle (Item 33 from Special Tools List) and place onto the input flange.
- 4. Place a suitable support beneath the press to prevent the input flange from falling.
- Press out the input shaft from the protective shield.




Fig. 2-35: Removing Radial Shaft Seal




Fig. 2-36: Removing Input Flange Shield



### 3.10.2. Installation

### 3.10.2.1.Installing Input Flange Shield

- Assemble Pressing Plate (Item 71 from Special Tools List) with Detachable Handle (Item 33 from Special Tools List) and Thrust Washer (Item 15 from Special Tools List).
- 2. Press the new shield onto the input flange as far as possible. See "Fig. 2-37: Installing Input Flange Shield" on page 35.




Fig. 2-37: Installing Input Flange Shield

### 3.10.2.2.Installing Radial Shaft Seal

- Assemble the Pressing Adapter (Item 34 from Special Tools List) with the Detachable Handle (Item 33 from Special Tools List) and Thrust Washer (Item 15 from Special Tools List).
- 2. Press the open side of the new radial shaft seal into the drive pinion gear housing as far as possible. See "Fig. 2-38: Installing Radial Shaft Seal" on page 35.




Fig. 2-38: Installing Radial Shaft Seal



### 3.10.2.3.Installing Input Flange

- 1. Apply a thin coat of gear oil to the seal contact surface of the input flange.
- 2. Install the input flange onto the splines of the pinion shaft and press in by hand.
- 3. Install new slotted nut and hand tighten.
- 4. Position Intermediate Flange (Item 43 from Special Tools List) on input flange and secure with mounting bolts.
- Place the Slotted Nut Wrench (Item 26 from Special Tools List) onto the slotted nut.
- 6. Install the Torque Multiplier (Item 9 from Special Tools List) onto the Intermediate Flange (Item 43 from Special Tools List) and secure using mounting nuts.

### 3.10.2.4. Tightening Slotted Nut



The torque multiplier has a 1:8 ratio. Set the torque wrench to 88 ft-lb. (119 Nm) to achieve an output torque of 701 ft-lb. (950 Nm).

- 1. Torque the slotted nut to 701 ft-lb. (950 Nm).
- 2. Remove the special tools.

### 3.10.2.5.Locking Slotted Nut

Drive the collar of the slotted nut into the groove. See "Fig. 2-39: Locking Slotted Nut" on page 36.




Fig. 2-39: Locking Slotted Nut



### 3.11. Differential Carrier

### 3.11.1. Removal

The following procedure describes replacement of the differential carrier

assembly as a unit. The differential carrier assembly consists of the differential, axle gear housing, & drive pinion gear housing. See "Fig. 2-40: Differential Carrier Removal" on page 37.




Fig. 2-40: Differential Carrier Removal



### 3.11.1.1.Removing Breather Connection

- Unscrew the union nut and breather hose from the breather connection.
- 2. Assemble the Extractor (Item 42 from Special Tools List) with the Threaded Adapter (Item 41 from Special Tools List) and the Tapered Adapter (Item 40 from Special Tools List). See "Fig. 2-41: Removing Axle Breather Connection" on page 38.
- 3. Thread the puller attachment onto the breather connection and use the slide hammer action to extract the breather.




Fig. 2-41: Removing Axle Breather Connection

### 3.11.1.2. Attaching Lifting Device

- Mount the Lifting Device (Item 36 from Special Tools List) on the Assembly Crown (Item 37 from Special Tools List). See "Fig. 2-42: Differential Carrier Lifting Device" on page 38.
- Install the assembled Lifting Device and Assembly Crown with Lift Adapter (Item 76 from Special Tools List) onto a hydraulic lifting device.
- 3. Use the hydraulic lifting device to align the lifting equipment with the input flange.
- 4. Attach the lifting device to the input flange.
- 5. Thread the Support Screw (Item 38 from Special Tools List) into the lifting device.
- Note the location of the support screw and remove the corresponding bolt from the axle gear housing.
- 7. Prevent the axle gear housing from rotating during removal by threading the support screw into the axle gear housing bolt hole.




Fig. 2-42: Differential Carrier Lifting Device



### 3.11.1.3. Removing Differential Carrier

1. Mark the position of the mounting bolts.

### ™NOTE:

Six of the M16 mounting bolts are 50 mm long and the other six are 60 mm long. Ensure that the bolts are reinstalled in the correct location.

- Remove two opposing mounting bolts and replace with Alignment Pins (Item 78 from Special Tools List). See "Fig. 2-43: Differential Carrier Removal" on page 39.
- 3. Remove the remaining mounting bolts.
- Use the lifting device to carefully slide the the differential carrier out from the axle housing.
- 5. Clean the differential carrier and axle housing mating surfaces.
- 6. Move the differential carrier to a clean work area and remove the lifting equipment.




Fig. 2-43: Differential Carrier Removal

### 3.11.2. Installation

### 3.11.2.1.Installing Differential Carrier

- Prior to installing the differential carrier assembly into the axle housing, remove the oil filter, located in the upper area of the axle housing. See "Fig. 2-44: Axle Housing Oil Filter" on page 40.
- Install a new oil filter with new bolts and washers. DO NOT attempt to clean the oil filter. Torque M8 mounting bolts to 16 ft-lbs. (22 Nm) using Torque Wrench and Ratchet Adapter (Items 87 & 11 from Special Tools List).

### ™NOTE:

If new self-locking bolts are not readily available, it is permissible to clean the thread locking compound from the original bolts and reapply medium strength thread locking compound.

- Mount the Lifting Device and Assembly Crown (Items 36 & 37 from Special Tools List) to the differential and secure it in place with the Support Screw (Item 38 from Special Tools List).
- Use the hydraulic lift and adapter to position the lifting equipment and differential carrier assembly in line with the axle housing.
- Apply a thin coating of Loctite-518 Gasket Eliminator face-sealing agent on the differential carrier and axle housing mating faces.



- Install two Alignment Pins (Item 78 from Special Tools List) into two opposing threaded holes on the axle housing mounting flange.
- Use the lifting device and hydraulic lift to move the differential carrier toward the axle housing and slide over the alignment pins.
- 8. Use new mounting bolts and install in locations noted during removal. Hand-tighten only at this time.

### ™NOTE:

Six of the M16 mounting bolts are 50 mm long and the other six are 60 mm long. Ensure that the bolts are installed in the correct location.

- 9. Remove the alignment pins and install the two mounting bolts.
- 10. Use Torque Wrench with Square Drive (Items 96 and 39 from Special Tools List) and torque bolts to 273 ft-lb. (370 Nm).
- 11. Remove the support screw from the lifting device and install the last remaining bolt in its place and torque to 273 ft-lb. (370 Nm).
- 12. Remove the lifting equipment from the input flange.




Fig. 2-44: Axle Housing Oil Filter

### 3.11.2.2.Installing Breather Connection

- Assemble the Extractor, (Item 42 from Special Tools List) with the Threaded Adapter (Item 41 from Special Tools List) and the Tapered Adapter (Item 40 from Special Tools List).
- Thread the puller attachment onto the breather connection and use the slide hammer action to drive the breather into the axle housing.
- 3. Install the breather tube union nut onto the breather connection and tighten.



### 3.12. Differential

### 3.12.1. Removal

The following procedure describes separating the differential from the differential carrier assembly. See "Fig. 2-47: Differential Carrier Assembly" on page 42.

### 3.12.1.1.Placing Differential Carrier in Stand

- Install the Universal Support (Item 48 from Special Tools List) on the Engine Stand (Item 79 from Special Tools List) and tighten the mounting bolts. See "Fig. 2-45: Universal Support" on page 41.
- Use a hoist with Lifting Device (Item 47 from Special Tools List) and Attachment Plates (Item 49 from Special Tools List) to position the differential carrier assembly above the engine stand with support fixture. See "Fig. 2-46: Positioning Differential Carrier in Stand" on page 41.
- 2. Adjust the width of the two support arms to support the differential carrier and align the four sliders with the hole pattern in the carrier mounting flange.
- 3. Tighten all mounting bolts and ensure spring clips are fully engaged.
- Remove lifting equipment from differential carrier.




Fig. 2-45: Universal Support




Fig. 2-46: Positioning Differential Carrier in Stand






Fig. 2-47: Differential Carrier Assembly



### 3.12.1.2.Removing Bearing Caps & Adjusters

- Remove the split locking pins for the bearing adjusters on both sides. See "Fig. 2-48: Removing Bearing Caps" on page 43.
- Mark the installation position of the bearing caps.
- Remove the bearing cap bolts and bearing caps.
- 4. Remove the bearing caps.
- 5. Remove the threaded bearing adjusters.

# 1. Bearing Cap Bolt 2. Bearing Cap 3. Bearing Cap 4. Bearing Cap Bolt 5. Split Locking Pin 3. Bearing Cap 5. s126213a.jpg

Fig. 2-48: Removing Bearing Caps

### 3.12.1.3. Removing Differential from Housing

- Use a hoist with Lifting Device (Item 47 from Special Tools List) and Attachment Plates (Item 49 from Special Tools List) to lift the differential out of the axle gear housing. See "Fig. 2-49: Removing Differential Assembly" on page 43.
- Move the differential to a work bench and remove the lifting equipment from the differential.
- 3. Remove the outer races from the tapered roller bearings.




Fig. 2-49: Removing Differential Assembly



### 3.12.2. Installation

The following procedure describes installing the differential into the differential carrier assembly.

### 3.12.2.1.Installing Differential Into Housing

- 1. Apply a thin film of gear oil on both tapered roller bearings.
- 2. Place the bearing outer races on the tapered roller bearings.
- Insert the Lifting Device (Item 47 from Special Tools List) and Attachment Plates (Item 49 from Special Tools List) into differential.
- 4. Hoist differential into position above differential carrier housing.
- Carefully lower differential onto the housing.
- Remove the lifting equipment from differential.

### 3.12.2.2.Installing Bearing Caps & Adjusters

- Refer to the markings made during removal and position the bearing caps in their original location. See "Fig. 2-50: Bearing Cap Installation" on page 44.
- 2. Install new mounting bolts and torque to first stage of tightening 44 ft-lbs. (60 Nm).
- 3. Apply a thin layer of gear oil on the threaded adjusters retainers and then thread them in until lightly seated against the bearings. See "Fig. 2-51: Bearing Adjusters" on page 44.
- 4. Use the Slotted Nut Wrench (Item 46 from the Special Tools List) to alternately thread in the bearing adjusters while simultaneously rotating the crown gear by hand until the tapered roller bearings have a slight preload.
- Refer to 3.12.5. "Adjustments" on page 58 in this section for information on setting backlash and bearing preload.




Fig. 2-50: Bearing Cap Installation




Fig. 2-51: Bearing Adjusters



### 3.12.3. Disassembly

The following procedure describes disassembly of the differential tapered roller

bearings, crown gear, housing cover, side gears, and pinion gears. See "Fig. 2-52: Differential Assembly" on page 45.




Fig. 2-52: Differential Assembly



# 3.12.3.1.Removing Tapered Roller Bearings (Hydraulic Method)

### ™NOTE:

The tapered roller bearings can be removed either hydraulically or by mechanical means with bearing gripping tools. Both methods are presented here.

- 1. Assemble the hydraulic puller as follows:
  - a. Install the Threaded Adapter (Item 80 from Special Tools List) onto the Bearing Gripper (Item 93 from Special Tools List). See "Fig. 2-53: Hydraulic Bearing Puller Tool Assembly" on page 46.
  - Install the Cylinder Support (Item 81 from Special Tools List) onto the Threaded Adapter (Item 80 from Special Tools List).
  - c. Insert the Hollow Piston Cylinder (Item 101 from Special Tools List) into the Cylinder Support (Item 81 from Special Tools List).
  - d. Install Cap (Item 82 from Special Tools LIst) onto Cylinder Support (Item 81 from Special Tools List).
- 2. Support and place the differential with the teeth of the crown gear facing up.
- Install Differential Thrust Piece (Item 50 from Special Tools List) into differential. See "Fig. 2-54: Attaching Hydraulic Puller" on page 47.
- Insert Hydraulic Puller Thrust Piece (Item 106 from Special Tools List) into hollow piston cylinder.
- 5. Place the puller onto the tapered roller bearing and press down the outer ring to tension the gripping segments of the tool beneath the bearing.
- Screw the Threaded Sleeve (Item 83 from Special Tools List) into the hollow cylinder cap until the threaded sleeve contacts the stop inside the hollow piston cylinder.
- Connect the Hydraulic Pump (Item 102 from Special Tools List) to the connector on the hollow piston cylinder. See "Fig. 2-55: Attaching Hydraulic Pump" on page 47.

- 8. Operate the hydraulic pump and pull off the tapered roller bearing from differential bearing journal.
- 9. Remove the tooling and thrust piece from the differential.
- Turn over the differential and repeat bearing removal process for the other side.




Fig. 2-53: Hydraulic Bearing Puller Tool Assembly






Fig. 2-54: Attaching Hydraulic Puller




Fig. 2-55: Attaching Hydraulic Pump



# 3.12.3.2.Removing Tapered Roller Bearings (Mechanical Method)

- Insert the Differential Thrust Piece (Item 50 from Special Tools List) into differential. See "Fig. 2-56: Attaching Mechanical Puller" on page 48.
- Place the Bearing Gripper (Item 93 from Special Tools List) on the tapered roller bearing and press down the outer ring to tension the gripping segments of the tool beneath the bearing.
- Assemble the Puller Spindle with Reducer and Puller Sleeve (Items 53, 54 & 52 from Special Tools List) and then mount on the bearing gripper. See "Fig. 2-56: Attaching Mechanical Puller" on page 48.
- 4. Pull off the tapered roller bearing.

### ™NOTE:

The maximum travel of the spindle when pulling of the bearing is 1.25" (30 mm). Back off the small spindle and tighten the large spindle by the same amount to reset spindle travel. Repeat pulling procedure.

- Remove the thrust piece from the differential
- Turn over the differential and repeat bearing removal process for the other side.




Fig. 2-56: Attaching Mechanical Puller



### 3.12.3.3. Special Tool Assembly

A special tool is required to tighten the bolts that secure the crown gear to the differential housing and this tool may also be used for removal purposes. However, it is acceptable to use an air wrench for removal of the bolts. Assemble the special tool as follows:

- a. Attach Support (Item 86 from Special Tools List) with Socket Head Screw (Item 66 from Special Tools List) and Adapter (Item 104 from Special Tools List) to the Brace (Item 57 from Special Tools List). See "Fig. 2-57: Special Tool Assembly" on page 49.
- b. Insert the Torque Multiplier (Item 56 from Special Tools List) into the brace.
- c. Place the Socket (Item 85 from Special Tools LIst) on the torque multiplier and secure the socket with the Connecting Pin and the Rubber Ring (Items 64 & 103 from Special Tools List).




Fig. 2-57: Special Tool Assembly



## 3.12.3.4.Removing Crown Gear & Differential Cover



Due to the danger of injury when working with heavy components, the use of a suitable lifting device is required.

- Clamp Assembly Device (Item 55 from Special Tools List) in a vise.
- Select a Thrust Piece that will match the differential and install on Assembly Device (Item 55 from Special Tools List).
- Attach Hooks and Lifting Strap (Items 84 and 62 from Special Tools LIst) to differential and hoist into position onto assembly device. See "Fig. 2-58: Positioning Differential on Assembly Device" on page 50.
- 4. Remove lifting equipment from differential.
- 5. Select and install a Counter Brace that will match the differential lock and prevent it from rotating.
- Install the special bolt removal/tightening tool on each of the crown gear mounting bolts and loosen each bolt. See "Fig. 2-59: Crown Gear Bolt Loosening" on page 51.
- 7. Remove counter brace from assembly device.
- Attach Hooks and Lifting Strap (Items 84 and 62 from Special Tools LIst) to differential and lift differential from assembly device.
- Position differential on work bench with crown gear teeth facing down. Remove lifting equipment.
- 10.Mark the crown gear in relation to differential housing and cover of differential housing. See "Fig. 2-60: Marking Crown Gear" on page 51.

11.Remove three crown gear bolts offset by 120° and temporarily replace with 3 bolts (M18 x 1.5 x 90 mm). Thread the replacement bolts in enough to fully engage the threads in the crown gear.

### MOTE:

The three longer bolts are installed to prevent the crown gear from dropping during removal.

- 12. Remove remaining crown gear bolts.
- 13. Drive the crown gear off the differential housing by alternately striking each of the three securing bolts with a hammer.
- 14. Support the crown gear and remove the three securing bolts.
- 15. Separate cover from differential housing.




Fig. 2-58: Positioning Differential on Assembly Device






Fig. 2-59: Crown Gear Bolt Loosening




Fig. 2-60: Marking Crown Gear


# 3.12.3.5.Removing Differential Pinion & Side Gears



Due to the danger of injury when working with heavy components, always use assistance when moving or lifting the differential housing.

- Remove the differential side gear and thrust washer from the differential housing. See "Fig. 2-61: Differential Side Gear" on page 52.
- 2. Pull the differential pins (two pieces) out of the differential housing, then pull out the single piece pin. See "Fig. 2-62: Differential Pinion Gears" on page 52.
- 3. Remove the differential pinion gears with spherical washers from the differential housing.
- 4. Remove the remaining differential side gear with thrust washer from the differential housing.
- 5. Check all the parts of the differential for wear and replace as a set if necessary.





5. Differential Pin (2-1. Spherical Washer Piece) 2. Pinion Gear 6. Differential Housing Side Gear 7. Differential Pin Thrust Washer s132224a.jpg

Fig. 2-61: Differential Side Gear

Fig. 2-62: Differential Pinion Gears



### 3.12.4. Assembly



Components can be damaged due to incorrectly tightened fasteners. ALWAYS follow recommended torque procedures.

The following guidelines apply during assembly:

- ☐ If impact wrenches are used, these may only be used for pre-tightening to a maximum of 50% of the final torque value. Final tightening must always be performed manually using a torque wrench.
- Always replace crown gear and pinion drive gear as a set. The pairing numbers are stamped on the parts as well as an installation dimension. Always replace axle shaft side gears and differential pinions as a set.

### 3.12.4.1. Gear Pairing Numbers

### ™NOTE:

The reference dimension and pairing numbers for the crown gear and drive pinion are indicated on the drive pinion and the crown gear.

- Pay attention to the pairing numbers and when fitting a new gear set (crown gear/ drive pinion). See "Fig. 2-63: Gear Pairing Numbers" on page 53.
- 2. Install the gear set in an drive axle housing corresponding to the ratio.




Fig. 2-63: Gear Pairing Numbers

### 3.12.4.2.Installing Differential Pinion Gears

- Before assembly, thinly apply gear oil on all contact surfaces, thrust washers and tooth contact faces.
- 2. Insert the axle side gear with thrust washer into the differential housing.
- Insert the differential pinion gears with spherical washers into the differential housing.
- 4. Insert the single-piece differential pin through the differential pinion gears and into the differential housing.

### ™NOTE:

Insert the differential pins in the differential housing so that the tangs on the end of the two-piece pins engage the slot in the single-piece pin, thereby preventing the differential pins from rotating.

 Insert the two-piece differential pins through the differential pinion gears and into the corresponding slot of the singlepiece pin.



### 3.12.4.3.Installing Crown Gear



Due to the danger of injury when working with heavy components, always use assistance when moving or lifting the differential housing.

- Support the crown gear on wooden blocks with the gear teeth facing down. See "Fig. 2-64: Installing Crown Gear" on page 54.
- 2. Install Centering Pins (Item 68 from Special Tools List) into crown gear.
- 3. Lower the differential housing over the centering pins, ensuring that the marks on the housing and crown gear are aligned.
- Install three mounting bolts spaced 120° from each other.
- 5. Tighten the three mounting bolts evenly until the differential housing is fully seated against the crown gear.
- 6. Remove centering pins.




Fig. 2-64: Installing Crown Gear



# 3.12.4.4.Installing Differential Side Gear (Lock Side)

- 1. Apply a thin coating of gear oil to the contact surfaces and gear teeth.
- 2. Install axle side gear onto differential pinion gears. See "Fig. 2-66: Installing Differential Housing Cover" on page 55.
- 3. Install thrust washer onto side gear.
- 4. Rotate the side gear and ensure the pinion gears and opposite side gear rotate freely.

# 1. Thrust Washer 2. Side Gear 3. Differential Housing 4. Pinion Gears \$132226a.jpg

Fig. 2-65: Installing Differential Side Gear

### 3.12.4.5.Installing Differential Housing Cover

- Install the differential housing cover on differential housing, ensuring that markings are aligned. See "Fig. 2-66: Installing Differential Housing Cover" on page 55.
- 2. Install new mounting bolts and handtighten only at this time.




Fig. 2-66: Installing Differential Housing Cover



### 3.12.4.6. Tightening Crown Gear Mounting Bolts



Due to the danger of injury when working with heavy components, the use of a suitable lifting device is required.

- Attach Hooks (Item 84 from Special Tools List) and Lifting Strap (Item 62 from Special Tools List) to differential.
- 2. Place the differential on the spigot of the differential Assembly Device (Item 55 from Special Tools List).
- 3. Remove lifting equipment from differential.
- 4. Install counter brace onto assembly device and engage the teeth of the lock provision.
- Tighten all mounting bolts evenly and in diagonal sequence using Torque Wrench and Square Drive (Items 60 and 39 from Special Tools List). Torque bolts to first tightening sequence of 210 ft-lbs. (285 Nm).
- Install special tightening tool onto mounting bolts. See "Fig. 2-67: Installing Special Tool" on page 56.
- Set the torque wrench to 122 ft-lbs. (165 Nm).

### ™NOTE:

The special tightening tool incorporates a torque multiplier with a 3.5:1 ratio. Therefore, the torque wrench must be set to 122 ft-lbs. (165 Nm) to achieve the desired output torque of 420 ft-lbs. (570 Nm).

- 8. Final tighten mounting bolts evenly and in diagonal sequence using special tightening tool, torque wrench, and square drive. Torque bolts to 420 ft-lbs. (570 Nm).
- Remove counter brace from assembly device.




Fig. 2-67: Installing Special Tool



### 3.12.4.7.Installing Tapered Roller Bearings



Due to the danger of injury when working with heavy and hot components, the use of a suitable lifting device and the wearing of protective gloves is required.

- Lift the differential off the assembly device using Hooks and Lifting Strap (Items 84 & 62 from Special Tools List).
- 2. Move differential to work bench and support with crown gear teeth facing down.
- 3. Remove lifting equipment.
- Heat the tapered roller bearing to 250°F (120°C).
- Use protective gloves and install tapered roller bearing onto differential bearing journal, ensuring bearing is fully seated. See "Fig. 2-68: Installing Tapered Roller Bearing on Lock Side" on page 57.
- 6. Turn the differential over so that the teeth of the crown gear are facing up.
- 7. Heat the tapered roller bearing to 250°F (120°C).
- 8. Use protective gloves and install tapered roller bearing onto differential bearing journal, ensuring bearing is fully seated. See "Fig. 2-69: Installing Tapered Roller Bearing on Differential Side" on page 57.




Fig. 2-68: Installing Tapered Roller Bearing on Lock Side




Fig. 2-69: Installing Tapered Roller Bearing on Differential Side



### 3.12.5. Adjustments

The following adjustments must be made prior to installing the differential carrier into the axle housing:

- Backlash establishes the relative movement between the crown gear and pinion gear.
- ☐ Bearing Preload provides a predetermined load on the tapered roller bearings
- Contact Pattern provides a visual indication that the pinion installation depth and backlash are correctly set.

### 3.12.5.1.Backlash Adjustment

- Mark the circumference of the crown gear at three locations, equally spaced 120° apart.
- 2. Place the Dial Gauge Holder with Dial Gauge (Items 45 & 44 from Special Tools List) on the drive axle housing. See "Fig. 2-70: Backlash Adjustment" on page 58.
- 3. Position the dial gauge tip at right angles on the outer area of the tooth flank and zero the dial gauge.
- 4. Secure the input flange so as to prevent any movement of the pinion gear.
- Check the backlash by rotating the crown gear back and forth and observing the dial gauge reading. Perform this procedure at three locations, each offset by 120°.
- Adjust backlash to 0.010 to 0.014 in. (0.25 to 0.35 mm) by turning the two threaded bearing adjusters alternately, using the Slotted Nut Wrench (Item 46 from Special Tools List).
- 7. Remove the dial gauge and holder.
- Tighten the threaded bearing adjuster on the differential side to 15 ft-lb. (20 Nm) using Torque Wrench (Item 59 from Special Tools List), Ratchet Insert (Item 95 from Special Tools List) and Slotted Nut Wrench (Item 46 from Special Tools List).

### ™NOTE:

Lightly tap on both bearing caps while tightening the threaded adjusters in order to ensure bearings are properly seated.

9. Rotate the crown gear two or three turns and ensure no binding exists.




Fig. 2-70: Backlash Adjustment



### 3.12.5.2.Bearing Preload Adjustment

### ™NOTE:

Bearing caps have been previously tightened during assembly to the first stage torque setting of 44 ft-lbs. (60 Nm).

- Torque bearing cap mounting bolts to final torque setting of 391 ft-lbs. (530 Nm) using Torque Wrench and Square Drive (Items 96 & 39 from Special Tools List).
- Loosen the threaded bearing adjuster on the differential housing cover side using Slotted Nut Wrench (Item 46 from Special Tools List).
- Place Dial Gauge Holder with Dial Gauge (Items 45 & 44 from Special Tools List) on the crown gear. See "Fig. 2-71: Setting Bearing Preload Adjustment" on page 59.
- 4. Position the dial gauge tip at a right angle to the side of the bearing cap and zero the dial gauge.
- Torque the threaded bearing adjuster on the differential cover housing side to 89 ftlb. (120 Nm) using Torque Wrench (Item 60 from Special Tools List), Square Drive (Item 39 from Special Tools List) and Slotted Nut Wrench (Item 46 from Special Tools List).
- 6. Observe the reading on the dial gauge and if necessary retighten the threaded bearing adjuster until a bearing preload of 0.006 to 0.010 in. (0.15 to 0.25 mm) is achieved.
- 7. Recheck backlash and adjust to 0.008 to 0.012 in. (0.20 to 0.30 mm) if required.
- 8. Remove the dial gauge bracket and dial gauge.
- Secure both threaded bearing adjusters with new split pins. See "Fig. 2-72: Locking Threaded Bearing Adjusters" on page 60.




Fig. 2-71: Setting Bearing Preload Adjustment






Fig. 2-72: Locking Threaded Bearing Adjusters

### 3.12.5.3.Crown Gear Contact Pattern

- 1. Apply marking paste on both sides of three crown gear teeth spaced 120° apart.
- 2. Rotate the crown gear back and forth by hand several turns ensuring contact through the marking paste.
- Check the contact pattern. See "Fig. 2-73: Contact Pattern on Crown Gear" on page 60.
- 4. An ideal contact pattern would be centered on the tooth, however, the contact pattern is acceptable providing that no portion of the pattern extends to any edge of the gear tooth including the tip, root, heel, or toe.




Fig. 2-73: Contact Pattern on Crown Gear



#### 3.12.5.4. Contact on Tooth Tip

# ™NOTE:

Contact at the tip of the gear tooth indicates inadequate gear mesh.

- 1. If there is contact at the tooth tip, increase the installation depth of the drive pinion by using thinner shims. See "Fig. 2-74: Contact on Tooth Tip" on page 61.
- Recheck backlash and adjust as necessary. Refer to 3.12.5.1. "Backlash Adjustment" on page 58 in this section for procedure.




Fig. 2-74: Contact on Tooth Tip

#### 3.12.5.5.Contact on Tooth Root

#### ™NOTE:

Contact in the root of the gear tooth, indicates excessive gear mesh.

- 1. If there is contact on the tooth root, reduce the installation depth of the drive pinion by using thicker shims. See "Fig. 2-75: Contact on Tooth Root" on page 61.
- Recheck backlash and adjust as necessary. Refer to 3.12.5.1. "Backlash Adjustment" on page 58 in this section for procedure.




Fig. 2-75: Contact on Tooth Root



# 3.13. Drive Pinion Gear Housing

# 3.13.1. Description

The Drive Pinion Gear Housing is a cassette design which allows the pinion drive gear and housing to be removed from the Axle Gear Housing as an assembly. The mating faces on these housings provides a location adjust pinion installation depth with the use of shims. See "Fig. 2-76: Drive Pinion Gear Installation" on page 62.



Components can be damaged due to incorrectly tightened fasteners. If impact wrenches are used, these may only be used for pre-tightening to a

maximum of 50% of the specified final torque value. Final tightening must always be performed manually using a torque wrench.

## ™NOTE:

Replacement of the crown/pinion gear set or drive pinion gear housing or axle gear housing will require recalculation of the pinion installation depth with resultant shimming adjustments.

# ™NOTE:

Replacement of the roller bearing in the axle gear housing or replacement of tapered roller bearing in the drive pinion gear housing will require that the friction coefficient be rechecked and adjusted with shims as required.




Fig. 2-76: Drive Pinion Gear Installation



#### 3.13.2. Removal

- Position the axle gear housing in the Universal Holder (Item 48 from Special Tools List) with the pinion input flange facing up. See "Fig. 2-77: Drive Pinion Gear Housing Removal" on page 63.
- 2. Mark the position of the drive pinion gear housing in relation to the axle gear housing.
- 3. Remove the mounting bolts.



Due to the danger of injury when working with heavy components, the use of a suitable support equipment is required. DO NOT attempt to support the weight of the pinion gear housing by hand.

- Rotate the axle gear housing 180° so that the input flange is facing down. See "Fig. 2-78: Pressing Out Drive Pinion Gear Housing" on page 64.
- 5. Place a suitable support beneath the drive pinion gear housing so that it does not fall to the floor when pressed out.
- 6. Press out the drive pinion gear housing from the axle gear housing. Press directly on the end of the pinion gear shaft and not on the roller bearing.
- 7. Remove and discard the O-ring from the drive pinion gear housing.
- 8. Remove shims.
- 9. Clean mating surfaces of drive pinion gear housing and axle gear housing.




Fig. 2-77: Drive Pinion Gear Housing Removal






Fig. 2-78: Pressing Out Drive Pinion Gear Housing

# 3.13.2.1.Removing Roller Bearing

- 1. Rotate the axle gear housing 180° so that the input end is facing up.
- Assemble the Slide Hammer (Item 2 from Special Tools List) with Threaded Adapter (Item 69 from Special Tools List) and Expandable Puller (Item 70 from Special Tools List). See "Fig. 2-79: Removing Roller Bearing" on page 64.
- 3. Position the puller under the roller bearing and expand the tool.
- 4. Use the slide hammer function of the tool to extract the roller bearing from the axle gear housing.




Fig. 2-79: Removing Roller Bearing



#### 3.13.3. Installation

# 3.13.3.1.Installing Roller Bearing

- Assemble Pressing Adapter (Item 88 from Special Tools List), Detachable Handle (Item 33 from Special Tools List) and Thrust Washer (Item 15 from Special Tools List).
- 2. Press roller bearing into axle gear housing until stop is reached. Ensure roller bearing groove is facing up. See "Fig. 2-80: Installing Roller Bearing" on page 65.

# 3.13.3.2.Installing Shims

- 1. Thread Centering Pins (Item 78 from Special Tools List) into axle gear housing.
- 2. Install shims so that the lug on the shim aligns with the lug marking on the axle gear housing. See "Fig. 2-81: Installing Shims" on page 65.




Fig. 2-80: Installing Roller Bearing




Fig. 2-81: Installing Shims



#### 3.13.3.3.Installing Drive Pinion Gear Housing



Due to the danger of injury when working with heavy components, the use of a suitable lifting device is required.

- Thread Eyebolts (Item 89 from Special Tools List) into input flange and use Lifting Chain (Item 90 from Special Tools List) to hoist the drive pinion gear into position.
- 2. Install new O-ring in groove of drive pinion gear housing.
- Carefully lower the pinion gear housing over the Centering Pins (Item 78 from Special Tools List), ensuring that marks on the drive pinion gear housing and axle gear housing are aligned. See "Fig. 2-82: Installing Drive Pinion Gear Housing" on page 66.

#### ™NOTE:

Ensure that the shims are properly positioned with respect to the axle gear housing. The lug on the shim should align with a corresponding lug on the axle gear housing. Likewise, the notch in the drive pinion gear housing should align with the lug on the shim.

- 4. Remove the centering pins and lifting equipment.
- Install new mounting bolts and torque to 280 ft-lbs. (380 Nm) using Torque Wrench and Square Drive (Items 96 & 105 from Special Tools List).




Fig. 2-82: Installing Drive Pinion Gear Housing



# 3.13.3.4.Checking & Adjusting Friction Coefficient

# ™NOTE:

Replacement of the roller bearing in the axle gear housing or replacement of tapered roller bearing in the drive pinion gear housing will require that the friction coefficient be rechecked and adjusted with shims as required.

The following procedure describes the method used to determine whether pinion bearing preload is set correctly. Proper pinion bearing preload can be determined by measuring the force required to rotate the pinion gear. This is referred to as friction coefficient and should be between 6 to 12 ft-lb. (8 to 16 Nm).

#### ™NOTE:

In order to obtain an accurate friction coefficient reading, the drive pinion gear housing should be assembled without the radial shaft seal. Also, for test purposes, the drive pinion gear housing should be installed in the axle gear housing without shims or O-ring.

- Install input flange on drive pinion gear without radial shaft seal. See "Fig. 2-83: Installing Input Flange Without Seal" on page 68.
- 2. Install slotted nut and hand-tighten only at this time.



Due to the danger of injury when working with heavy components, the use of a suitable lifting device is required.

3. Thread Eyebolts (Item 89 from Special Tools List) into input flange and use Lifting

- Chain (Item 90 from Special Tools List) to hoist the drive pinion gear into position.
- Carefully lower the pinion gear housing over the Centering Pins (Item 78 from Special Tools List), ensuring that marks on the drive pinion gear housing and axle gear housing are aligned.
- Remove centering pins and lifting equipment.
- Install mounting bolts and torque to 280 ft-lb. (380 Nm) using Torque Wrench and Square Drive (Items 96 & 105 from Special Tools List).
- 7. Tighten slotted nut. Refer to 3.10.2.4. "Tightening Slotted Nut" on page 36 in this section for tightening procedure.
- Place the Friction Tester (Item 77 from Special Tools List) with the Slotted Nut Wrench (Item 26 from Special Tools List) on the slotted nut. See "Fig. 2-84: Mounting Friction Tester" on page 68.
- 9. Zero the friction tester.
- 10.Overcome the initial drive pinion gear release torque and read the friction coefficient while rotating the tester in a smooth continuous motion.
- 11.If the friction coefficient is not within the range of 6 to 12 ft-lb. (8 to 16 Nm), then disassemble the drive pinion gear housing and replace the shim with one of the correct size.

#### ™NOTE:

Thicker shim = lower friction coefficient.
Thinner shim = higher friction coefficient.
Shims are available in 0.002" (0.01 mm) increments and range in thickness from 0.137" to 0.208" (3.50 to 5.30 mm). Refer to your New Flyer Parts Manual for ordering information.

12. Recheck friction coefficient.






Fig. 2-83: Installing Input Flange Without Seal




Fig. 2-84: Mounting Friction Tester

# 3.13.3.5.Determining Drive Pinion Gear Installation Depth

- Position the axle gear housing in the Universal Holder (Item 48 from Special Tools List) with the input flange facing down.
- Attach the Auxiliary Bridge (Item 73 from Special Tools List) to the Depth Gauge (Item 72 from Special Tools List)
- 3. Place the depth gauge with auxiliary bridge across the bearing mounting brackets. See "Fig. 2-85: Pinion Depth" on page 69.
- Record measurement from bearing bracket to end of pinion gear as Dimension "A".
- Record the dimension stamped on the end face of the pinion gear as Dimension "C".
   See "Fig. 2-86: Dimension "C" on page 69.
- Subtract Dimension "A" from Dimension "C" and record the result as Dimension "S".

#### ™NOTE:

Dimension "S" is the required shim thickness.

 If Dimension "S" is not equal to zero, then the drive pinion gear will need to be separated from the axle gear housing and the shim thickness adjusted to match Dimension "S".

#### ™NOTE:

Shims are available in thicknesses of:

0.004" (0.10 mm)

0.006" (0.15 mm)

0.008" (0.20 mm)

0.014" (0.35 mm)

0.020" (0.50 mm)

8. Recheck Dimension "A" and ensure it equals Dimension "C", stamped on the end of the gear.






Fig. 2-85: Pinion Depth

# F27012ffaA08

Fig. 2-86: Dimension "C"

# 3.13.4. Disassembly

# 3.13.4.1.Removing Drive Pinion Gear Housing

- Position drive pinion gear housing on a hydraulic press and place a suitable support beneath the pinion gear to prevent it from dropping. Press out the drive pinion gear. See "Fig. 2-87: Removing Drive Pinion Gear" on page 69.
- 2. Remove the outer tapered roller bearing from the drive pinion gear housing. See "Fig. 2-88: Drive Pinion Gear Assembly" on page 70.
- 3. Remove the shim and spacer from the drive pinion gear.




Fig. 2-87: Removing Drive Pinion Gear






Fig. 2-88: Drive Pinion Gear Assembly



# 3.13.4.2.Removing Bearing Inner Race

- Remove the circlip from the roller bearing inner race using internal circlip pliers. See "Fig. 2-89: Removing Bearing Circlip" on page 71.
- Use a chisel to tap the end of the bearing inner race sufficiently to allow enough clearance for the insertion of the Separator tool.
- Place Separator (Item 30 from Special Tools List) on bearing inner race, ensuring the tool fully grips beneath the bearing race.
- Attach Puller (Item 31 from Special Tools List) to Separator. See "Fig. 2-90: Removing Drive Pinion Inner Bearing Race" on page 71.
- Hold the drive pinion gear from turning and place Box-End Ratchet and Ratchet Handle (Items 91 & 92 from Special Tools List) on spindle of puller. Pull off the bearing inner race from drive pinion gear.




Fig. 2-89: Removing Bearing Circlip




Fig. 2-90: Removing Drive Pinion Inner Bearing Race



# 3.13.4.3.Removing Inner Tapered Roller Bearing

- 1. Assemble the hydraulic puller as follows:
  - a. Install the Threaded Adapter (Item 80 from Special Tools List) onto the Bearing Gripper (Item 93 from Special Tools List). See "Fig. 2-91: Hydraulic Bearing Puller Tool Assembly" on page 72.
  - Install the Cylinder Support (Item 81 from Special Tools List) onto the Threaded Adapter (Item 80 from Special Tools List).
  - c. Insert the Hollow Piston Cylinder (Item 101 from Special Tools List) into the Cylinder Support (Item 81 from Special Tools List).
  - d. Install Cap (Item 82 from Special Tools LIst) onto Cylinder Support (Item 81 from Special Tools List).
- 2. Insert Thrust Piece (Item 106 from Special Tools List) into hollow piston cylinder.
- 3. Place the puller onto the tapered roller bearing and press down the outer ring of tool to tension the gripping segments of the tool beneath the bearing. See "Fig. 2-92: Attaching Hydraulic Puller" on page 73.
- 4. Screw the Threaded Sleeve (Item 83 from Special Tools List) into the hollow cylinder cap until the threaded sleeve contacts the stop inside the hollow piston cylinder.
- Connect the Hydraulic Pump (Item 102 from Special Tools List) to the connector on the hollow piston cylinder. See "Fig. 2-93: Attaching Hydraulic Pump" on page 73.
- 6. Operate the hydraulic pump and pull off the tapered roller bearing from drive pinion gear.





Fig. 2-91: Hydraulic Bearing Puller Tool Assembly





5 1. Hydraulic Pump 4. Threaded Sleeve 2. Hollow Piston Cylinder 5. Drive Pinion Gear 3. Cap s132245a.jpg

Fig. 2-92: Attaching Hydraulic Puller

Fig. 2-93: Attaching Hydraulic Pump



# 3.13.4.4.Removing Outer Bearing Outer Race

- Position the drive pinion gear housing on support blocks with the input end facing down. See "Fig. 2-94: Removing Outer Bearing Outer Race" on page 74.
- Assemble the Detachable Handle and Pressing Device Adapter (Items 33 & 16 from Special Tools List).
- Use the detachable handle and adapter disc to retract the claws on the Pressing Device (Item 17 from Special Tools List) sufficiently to enter drive pinion gear housing.
- Position the expandable pressing device so that the claws of the tool are located slightly above the outer bearing outer race.



DO NOT expand the pressing device to the extent that it will bind inside the drive pinion gear housing and possibly cause damage to the housing and/or tool.

- Use the handle and adapter to rotate the expandable pressing device until the claws of the tool lightly contact the bore of the pinion gear housing and rest on the surface of the outer bearing outer race.
- 6. Press the outer bearing outer race out of the drive pinion gear housing.




Fig. 2-94: Removing Outer Bearing Outer Race



# 3.13.4.5.Removing Inner Bearing Outer Race

- Reposition the drive pinion gear housing on support blocks with the input end facing up. See "Fig. 2-95: Removing Inner Bearing Outer Race" on page 75.
- 2. Assemble the Detachable Handle and Pressure Device Adapter (Items 33 & 16 from Special Tools List).
- Use the detachable handle and adapter to retract the claws on the Pressing Device (Item 17 from Special Tools List) sufficiently to enter drive pinion gear housing.
- 4. Position the expandable pressing device so that the claws of the tool are located slightly above the inner bearing outer race. Ensure that the claws of the tool do not engage the step in the bore.



DO NOT expand the pressing device to the extent that it will bind inside the drive pinion gear housing and possibly cause damage to the housing and/or tool.

- Use the handle and adapter to rotate the expandable pressing device until the claws of the tool lightly contact the bore of the pinion gear housing and rest on the surface of the inner bearing outer race.
- 6. Press the inner bearing outer race out of the drive pinion gear housing.




Fig. 2-95: Removing Inner Bearing Outer Race



#### 3.13.5. Assembly

#### 3.13.5.1.Installing Outer Bearing Outer Race

- Assemble the Outer Pressing Plate with the Detachable Handle and Thrust Washer (Items 18, 33 & 15 from Special Tools List). See "Fig. 2-96: Installing Outer Bearing Outer Race" on page 76.
- Press the outer bearing outer race into the drive pinion gear housing until it has seated.




Fig. 2-96: Installing Outer Bearing Outer Race

#### 3.13.5.2.Installing Inner Bearing Outer Race

- 1. Turn over the drive pinion gear housing.
- Assemble the Inner Pressing Adapter with the Detachable Handle and Thrust Washer (Items 94, 33 & 15 from Special Tools List). See "Fig. 2-97: Installing Inner Bearing Outer Race" on page 76.
- Press the inner bearing outer race into the drive pinion gear housing until it has seated.




Fig. 2-97: Installing Inner Bearing Outer Race



# 3.13.5.3.Installing Inner Tapered Roller Bearing & Bearing Inner Race



Wear protective gloves when handling hot parts.

- 1. Heat the tapered roller bearing to 250°F (120°C).
- Install the tapered roller bearing on the drive pinion gear, ensuring it is fully seated. See "Fig. 2-98: Mounting Inner Tapered Roller Bearing & Inner Race" on page 77.
- 3. Heat the bearing inner race to 250°F (120°C).
- 4. Install the bearing inner race until fully seated with the collar facing the drive pinion gear. See "Fig. 2-99: Installing Bearing Inner Race Circlip" on page 78.
- 5. Install new circlip in groove on drive pinion gear shaft to retain bearing inner race.




Fig. 2-98: Mounting Inner Tapered Roller Bearing & Inner Race






Fig. 2-99: Installing Bearing Inner Race Circlip

## 3.13.5.4.Installing Drive Pinion Gear Housing

- Install the drive pinion gear housing onto the drive pinion gear. See "Fig. 2-100: Installing Drive Pinion Gear Housing" on page 78.
- 2. Install the spacer and shim onto drive pinion gear.

# ™NOTE:

Shim thickness is determined by the friction coefficient. Refer to 3.13.3.4. "Checking & Adjusting Friction Coefficient" on page 67 for checking procedure. If friction coefficient has not been determined, use a 0.157" (4.0 mm) thick shim as an initial starting point.

#### 3.13.5.5.Installing Outer Tapered Roller Bearing



Wear protective gloves when handling hot parts.

- Heat the tapered roller bearing to 250°F (120°C).
- 2. Install the tapered roller bearing on the drive pinion gear, ensuring it is fully seated. See "Fig. 2-101: Installing Outer Tapered Roller Bearing" on page 78.




Fig. 2-100: Installing Drive Pinion Gear Housing




Fig. 2-101: Installing Outer Tapered Roller Bearing



# 4. REAR SUSPENSION

# 4.1. Description

The rear axle suspension components include:

- Rear Air Springs
- Rear Radius Rods
- □ Rear Shock Absorbers

# 4.2. Rear Air Springs

# 4.2.1. Description

The air spring assembly consists of a rubber bellows mounted on a plate. The upper cover contains two threaded fittings. One fitting attaches the air spring to the chassis; the other is hollow and is used as an air inlet for suspension control. The upper and lower beads are crimped permanently during manufacture and cannot be separated.

## 4.2.2. Rear Air Springs Specifications

Make	. Firestone
Model	1T15LP-5

#### 4.2.3. Operation

The air spring assembly receives air pressure from the vehicle air system and responds to height adjustment inputs from the height control valve or kneeling control. Pressurized air enters the spring though a hollow mounting stud at the top of the spring. The spring action of the bellows allows for movement of the axle as the wheels go over bumps and depressions.

#### 4.2.4. Removal

- Raise the vehicle using wheel lifts or center post lift. Refer to the General Information Section of this manual for procedure.
- 2. Use safety stands under frame to hold vehicle in position.

- 3. Lower wheel lift until there is a 3" (76 mm) space between axle and axle bumper.
- 4. If system is pressurized, disconnect height control valve rod then pull down valve lever to exhaust air from spring. (mark rod attachment position for reinstallation)
- Disconnect air line. Remove lower nut attaching air spring to mounting plate. See "Fig. 2-102: Rear Air Spring Removal & Installation" on page 79.
- 6. Remove nuts and washers securing upper end of air spring to chassis.
- 7. Slide spring out of chassis and remove.




Fig. 2-102: Rear Air Spring Removal & Installation



#### 4.2.5. Disassembly

The air spring is supplied as a complete assembly, piston bellows and bead plate therefore no disassembly is required.

#### 4.2.6. Cleaning & Inspection

- 1. Clean air springs with soap and water.
- Check condition of mounting studs and threaded hole.
- 3. Examine piston for cracking or damage.
- 4. Examine the bellows assembly for cracks in the rubber or physical damage.

#### 4.2.7. Leak Test Procedure

Test the air springs assembly (positioned in safety cage) for leakage using the pres-

sure test fixture illustrated and the following procedure: See "Fig. 2-103: Leak Test Fixture" on page 80.

- 1. Thread male end of quick disconnect into air inlet hole of housing.
- Connect air line and raise air pressure initially to approximately 45 to 55 psi. Air springs should now be properly seated in housing. Check bead ring area for air leaks using a solution of soapy water.
- If no air leakage is present, raise air pressure to a maximum 120 psi.
- 4. Disconnect air line, remove test fitting and remove air springs assembly from safety cage.




Fig. 2-103: Leak Test Fixture





#### 4.2.8. Installation

# ™NOTE:

Refer to 4.5. "Rear Suspension Torque Specifications" on page 91 in this section for all installation torque values.

- Raise the vehicle using wheel lifts or center post lift. Refer to the General Information Section of this manual for procedure.
- 2. Use safety stands under frame to hold vehicle in position.
- 3. Lower wheel lift until there is a 3" (76 mm) space between axle and axle bumper.

- 4. Align stud in bottom of air spring with holes in mounting plate. Install bolts and torque to specification.
- 5. Install nuts on upper air spring studs and torque to specification.
- 6. Lower vehicle.

#### 4.2.9. Functional Tests

- 1. Run engine to build up air pressure.
- 2. Check for air leaks.
- 3. Test drive vehicle to verify ride quality and silence of operation.



# 4.3. Rear Radius Rods

# 4.3.1. Description

The upper and lower rear radius rods consist of hollow steel tubes with crimped rod ends. The rod ends are fitted with rubber bushings and cross pins. The aft end of the upper radius rod attaches to a bracket on the axle housing and the aft end of the lower radius rod attaches to a bracket on the suspension beam. The forward end of the upper and lower radius rods attach to the vehicle structure.

# 4.3.2. Rear Upper Radius Rod Specifications

ManufacturerZF Lemforder
Construction Tubular steel body, rubber bushings with cross-pin
Tensile Strength70,000 psi
Front Cross-Pin Angle8.7° from horizontal centerline
Rear Cross-Pin Angle11.8° from horizontal centerline

## 4.3.3. Rear Lower Radius Rod Specifications

ManufacturerZF Lemforder
ConstructionTubular steel body, rubber bushings with cross-pin
Tensile Strength70,000 psi
Front Cross-Pin Angle7.6° from horizontal centerline
Rear Cross-Pin Angle7.3° from horizontal centerline

#### 4.3.4. Operation

The upper and lower radius rods locate the rear axle to the vehicle structure and allow for vertical movement of the axle. The rubber bushings in the rod ends absorb thrust loads and are designed to flex during suspension movement. The cross-pins are used as attachment points to the axle and vehicle structure and can be shimmed to adjust alignment thrust angles.

# 4.3.5. Rear Radius Rod Troubleshooting

Drive the vehicle while listening for rattling or clunking sounds as the suspension reacts to surface irregularities. Also listen for clunking sounds when transitioning between acceleration and braking. If noise is evident inspect radius rod mounting hardware and condition of bushings.



#### 4.3.6. Maintenance

Refer to the Preventive Maintenance Section of this manual for scheduled inspection intervals.

#### 4.3.7. Removal



DO NOT attempt to remove more than one radius rod at a time. Removing two or more radius rods will cause the axle to become unstable.

 Raise the vehicle. Refer to the General Information Section of this manual for lifting procedures.

#### ™NOTE:

Radius rod replacement should be done at vehicle ride height to ensure the radius rod bushing is in a neutral load position. The use of wheel lifts is recommended or alternatively supporting the axles with jack stands.

 Remove the radius rod mounting bolts while taking note of the spacer and washer locations and quantity. See "Fig. 2-104: Upper Radius Rod Removal & Installation" on page 83. See "Fig. 2-105: Lower Radius Rod Removal & Installation" on page 84.

#### MOTE:

The hardened washers located between the radius rod cross-pin and the axle or vehicle structure serve as shims for alignment purposes. ALWAYS replace washers at each location with the same quantity as originally removed. 3. Remove the radius rod from the vehicle.

# ™NOTE:

The cross-pin angles are different between forward and aft bushings and the radius rod tube is stamped with "FRONT" and a directional arrow to ensure the radius rod is installed correctly. If the marking is not legible, use a paint marker to indicate "FRONT" with a directional arrow.




Fig. 2-104: Upper Radius Rod Removal & Installation






Fig. 2-105: Lower Radius Rod Removal & Installation

#### 4.3.8. Bushing Replacement

#### ™NOTE:

The following procedure applies to both the upper radius rods and lower radius rods.

1. Place radius rod on a hydraulic press with snap-ring groove facing up.

# ™NOTE:

The bushing must be compressed before the snap-ring can be removed.

- 2. Select a pressing sleeve that will seat on the metal shell of the bushing. Do not press on the rubber portion of the bushing.
- 3. Slowly compress the bushing until pressure is relieved from the snap ring.
- 4. Use snap ring pliers to remove the snap ring. Discard snap ring.
- 5. Reverse the position of the radius rod and tap out the bushing.

# ™NOTE:

If the bushing is heavily corroded, it may be necessary to remove the bushing with the hydraulic press.

- 6. Clean and inspect snap-ring groove for wear or damage.
- Use a wire brush or scraper to remove any rubber that has transferred to the bore of radius rod.
- 8. Apply lubricant, supplied in kit, to the bushing O.D. and the I.D. of the radius rod bore.
- Insert bushing into bore of radius rod so that the cross-pin angle is properly aligned. See "Fig. 2-106: Rear Radius Rod Bushing Replacement" on page 85.
- 10.Use a pressing sleeve and press on the metal shell of the bushing sufficiently to compress the bushing and allow insertion of the snap-ring into the groove.
- Use snap-ring pliers to insert snap-ring into groove. Ensure snap-ring is fully seated.

# ™NOTE:

The snap-ring should be positioned so that the opening of the snap-ring is facing downward and toward the radius rod tube at a 45° angle.






Fig. 2-106: Rear Radius Rod Bushing Replacement



#### 4.3.9. Installation

## ™NOTE:

Refer to 4.5. "Rear Suspension Torque Specifications" on page 91 in this section for all installation torque values.

# ™NOTE:

The upper and lower radius rods have directional stamps marked "FRONT" on the tubular section of the rod to indicate which end is to be installed towards the front of the vehicle. If the stamp is illegible, locate the cross-pin with the greater angle at the axle end. See "Fig. 2-106: Rear Radius Rod Bushing Replacement" on page 85.

 Install the radius rod in its original location and orientation using the same location and quantity of washers as originally removed. The spacer should be located between the head of the bolt and the radius rod cross-pin. The lower radius rod uses a spacer with the front set of bolts only.

#### ™NOTE:

The mounting bolts should install freely without having to twist or forcibly align the mounting holes in the cross-pin. If difficulty is experienced aligning the radius rod mounting holes with the vehicle structure or axle, remove the radius rod for closer examination and ensure the bushing and cross-pin were installed at the proper angle.

Apply Never-Seez® to fastener threads and torque bolts to specification.

#### 4.3.10. Functional Test

Test drive vehicle and check for proper suspension action without noise or vibration.



#### 4.4. Rear Shock Absorbers

# 4.4.1. Description

The shock absorbers are cylindrical components which dampen suspension movement in varying road conditions. Each shock absorber consists of a cylinder, piston, rod and valves. The rod is fitted with a tubular protective shield.

#### 4.4.2. Rear Shock Absorbers Specifications

Make	Koni
Model	90-2518
Туре	Bayonet Mount
Maximum Length (boo	dy only) 3.34" (587 to 593 mm)
Minimum Length (bod 13.42 to 1	ly only) 3.66" (341 to 347 mm)
Stroke	9.68" (246 mm)
Thread Size	M16 x 1.5"

#### 4.4.3. Operation

The function of the shock absorber is to absorb the energy caused by movement of

the suspension. The shock absorber makes two movements, a bump and rebound stroke.

#### □ Bump Stroke

During the bump stroke, the piston and rod travel into the cylinder. Oil flows from below the piston through orifices and into the upper part of the cylinder, thus equalizing pressure in the cylinder. The piston rod entering the cylinder displaces oil which escapes through the compression valve. The restriction of oil flow through the compression valve produces the bump damping force of the shock absorber.

#### □ Rebound Stroke

When the piston and rod travel upwards, the oil above the piston is trapped and forced through orifices in the piston and rod. The bypass valve is forced open when the pressure generated by the oil overcomes the force of the bypass valve spring. The resistance to oil flow produces the rebound damping force. The void caused by the piston rod exiting the cylinder is filled with oil from the reservoir entering the cylinder through the compression valve.



#### 4.4.4. Removal



ALWAYS support the weight of the axle when replacing shock absorbers.

 Raise the vehicle. Refer to the General Information Section of this manual for lifting procedures. Follow all applicable safety requirements.

# ™NOTE:

The upper shock mount requires removal of the mounting plate in order to access the top mounting nut.

 Remove the four bolts retaining the upper shock mounting plate to the chassis bracket. See "Fig. 2-107: Shock Absorber Removal & Installation" on page 88.

#### RNOTE:

The two inboard mounting bolts that retain the air line support bracket are slightly longer to accommodate the thickness of the bracket. Note the location of these bolts for reassembly.

- 3. Remove the protective cap from the lower shock mounting nut and remove the nut.
- Remove the clamping plate, rubber bushing, and centering ring from the shock stud, noting the location and orientation of the parts.
- Compress the lower shock sufficiently to remove the shock stud from the lower mounting bracket. Remove the remaining shock mount plate and rubber bushing from the shock stud.
- 6. Remove the shock absorber assembly from the vehicle and disassemble the upper mounting components as follows:
  - a. Remove the protective cap from the upper shock mounting nut and remove the nut.
  - b. Remove the clamping plate, rubber bushing, and centering ring from the shock stud, noting the location and orientation of the parts.
  - Remove the remaining mounting plate, rubber bushing and steel sleeve from the shock stud.




Fig. 2-107: Shock Absorber Removal & Installation



#### 4.4.5. Disassembly

The shock absorber is a sealed unit. Disassembly is not possible.

#### 4.4.6. Cleaning & Inspection

- Inspect rubber mounting bushings for wear of deterioration.
- Check condition of threads on each end of the bayonnet mounting studs.
- 3. Check for leakage at the piston rod seal.
- 4. Inspect the exterior of the shock absorber for physical damage.
- Hold the shock in it's installed position, push in and pull out on the piston rod, while holding the other end stationary to check for bump and rebound damping.

#### 4.4.7. Assembly

The shock absorber is a sealed unit. No assembly is required.

#### 4.4.8. Adjustment

# ™NOTE:

The shock absorbers fitted on this vehicle feature adjustable rebound damping. This adjustment can be used to compensate for loss of damping force or additional vehicle weight. New shock absorbers are designed for optimal performance at the minimal damping setting and should be installed as received. Adjust shock absorbers that exhibit deteriorated damping characteristics using the following procedure. Ensure that both shock absorbers on a common axle are adjusted equally.

- 1. Remove shock absorbers from vehicle in accordance with preceding instructions.
- Clamp the lower end of the shock absorber in a vise, being careful not to damage the threaded end of the stud.
- Collapse the shock absorber while slowly rotating it counterclockwise. As it nears the fully collapsed position, the cams on the internal adjusting nut should engage the recesses of the footvalve and a slightly increased resistance to rotation should be felt.
- Maintain slight pressure on the shock absorber in the fully collapsed position while rotating it counterclockwise and recording the number of turns until the internal stop is reached.
- Readjust the shock absorber by rotating it clockwise while maintaining slight pressure on the shock absorber in the fully collapsed position. Return the shock absorber to its original setting and rotate an additional 1/2 to 1 full turn to provide increased damping.
- Pull the piston rod straight out approximately 1/2", without rotating the shaft, until the internal adjusting nut disengages the footvalve.

#### ™NOTE:

The shock absorber has a range of adjustment of approximately 2 to 3 full turns between the internal stops. DO NOT force rotation of the shock absorber beyond this range.



#### 4.4.9. Installation

- Assemble the upper shock mounting components as follows:
  - a. Slide the steel sleeve and rubber bushing onto the shock stud. Ensure that the flat side of the rubber bushing seats against the shock body.
  - b. Place the mounting plate onto the rubber bushing ensuring that the mounting plate seats on the pilot diameter of the rubber bushing.
- 2. Assemble the remaining upper shock mounting components as follows:
  - a. Slide the centering ring and rubber bushing onto the shock stud ensuring that the pilot diameter of the rubber bushing seats within the concave side of the centering ring.
  - b. Install the clamping plate onto the rubber bushing ensuring that the concave side of the clamping plate seats against the flat side of the rubber bushing.
  - c. Install the M16 self-locking nut and torque to specification.
  - d. Install the protective cap over the lock nut.
- Align the four holes in the upper shock mount plate with the welded nuts on the chassis mounting bracket.
- 4. Position the air line support bracket over the two holes on the inboard side of the mount plate.
- 5. Install four bolts and washers and torque bolts to specification.

# ™NOTE:

The two inboard mounting bolts that retain the air line support bracket are slightly longer to accommodate the thickness of the bracket. Ensure that the two longer bolts are installed at the bracket location.

- Assemble the lower shock mounting components as follows:
  - a. Slide the rubber bushing and shock mount plate onto the shock stud ensuring that the flat side of the rubber bushing seats against the shock body.
  - Compress the shock sufficiently to allow the shock stud to enter the lower mounting bracket.
- 7. Assemble the remaining lower shock mounting components as follows:
  - a. Slide the centering ring and rubber bushing onto the shock stud ensuring that the pilot diameter of the rubber bushing seats within the concave side of the centering ring.
  - b. Install the clamping plate onto the rubber bushing ensuring that the concave side of the clamping plate seats against the flat side of the rubber bushing.
  - c. Install the M16 self-locking nut and torque to specification
  - d. Install protective cap over the lock nut.

#### 4.4.10. Functional Test

Road test the vehicle to confirm compliant suspension action and quiet operation. Also check for any evidence of rubbing during operation.



# 4.5. Rear Suspension Torque Specifications

See "Fig. 2-108: Rear Suspension Torque Points" on page 92.

REAR SUSPENSION TORQUE SPECIFICATIONS					
ITEM	DESCRIPTION	QTY. (per axle)	BOLT	NUT	TORQUE ft-lb. (Nm)
1	Upper Radius Rod to Frame	4	3/4" UNC		300 ft-lb. (407 Nm) NEVER-SEEZ®
2	Upper Radius Rod to Axle Housing	4	M18 x 1.5		300 ft-lb. (407 Nm) NEVER-SEEZ®
3	Lower Radius Rod to Frame	4	3/4" UNC		300 ft-lb. (407 Nm) NEVER-SEEZ®
4	Lower Radius Rod to Axle Housing	4		3/4" UNC Locking	230 ft-lb. (312 Nm) NEVER-SEEZ®
5	Axle to Suspension Beam Nut	8		7/8" UNF Locking	380 ft-lb. (515 Nm) in increments of 100 ft-lb. (135 Nm) NEVER-SEEZ®
6	Air Spring to Suspension Beam	4		1/2" UNC Locking	20 ft-lb. (27 Nm) NEVER-SEEZ®
7	Air Spring to Frame	4		1/2" UNC Locking	19 ft-lb. (26 Nm) NEVER-SEEZ®
8	Air Spring to Frame	4		3/4" UNF Locking	30 ft-lb. (41 Nm) NEVER-SEEZ®
9	Lower Shock to Suspension Beam	4		M16 x 1.5 Locking	56 ft-lb. (76 Nm) NEVER-SEEZ®
10	Upper Shock to Mounting Bracket	4		M16 x 1.5 Locking	56 ft-lb. (76 Nm) NEVER-SEEZ®
11	Upper Shock Mounting Plate	8	3/8" UNC		23 ft-lb. (31 Nm) NEVER-SEEZ®
12	Wheel Nuts	20		M22 x 1.5	450 to 500 ft-lb. (610 to 680 Nm)
13	Brake Chambers	4		M16 x 1.5	Initial Torque: 25 ft-lb. (34 Nm) Final Torque: 135 ft-lb. (183 Nm) NEVER-SEEZ®

# ™NOTE:

All bolts and nylon locknuts are Grade 8 and yellow zinc dichromate coated. All fasteners are dry unless otherwise noted.






Fig. 2-108: Rear Suspension Torque Points



# 5. REAR BRAKE SYSTEM

# 5.1. Description

The rear brake system includes:

- □ Rear Disc Brakes
- □ Brake Chambers
- ☐ Anti-Lock Braking (ABS) System

Refer to 5.2. "Rear Disc Brakes" on page 93 in this section for information on the disc brakes. Refer to 5.3. "Rear Brake Chambers" on page 118 in this section for information on the brake chambers. Refer to 6. "REAR AXLE ANTI-LOCK BRAKING SYSTEM (ABS) & COMPONENTS" on page 121 in this section for information on the ABS System.

#### 5.2. Rear Disc Brakes

## 5.2.1. Description

The rear disc brake system includes the brake caliper, brake carrier, disc pads, brake disc, and brake chamber. See "Fig.

2-109: Disc Brake Assembly" on page 94. Refer to 5.3. "Rear Brake Chambers" on page 118 in this section for information on the brake chambers and Refer to 3.6. "Wheels" on page 9 in this section for brake disc removal and installation procedures.

# 5.2.2. Rear Disc Brakes Specifications & Wear Limits

Manufacturer	Knorr-Bremse
Model	SN 7000
Туре	. Air-actuated sliding caliper
Brake pad clear	ance 24 to 0.043" (0.6 to 1.1 mm)
Brake pad thickr	ness (min) 0.08" (2.0 mm)
Brake disc thick	ness (min) 1.457" (37 mm)
Brake disc latera	al run-out (max) 0.006" (0.15 mm)
Brake caliper gu	ides (max play) 0.079" (2.0 mm)






Fig. 2-109: Disc Brake Assembly



#### 5.2.3. Operation

#### ™NOTE:

When reviewing the following information on operation of the disc brake assembly See "Fig. 2-110: Disc Brake Cross Section" on page 96.

During brake application the push rod of the brake chamber extends and moves the actuator lever in the brake caliper. This input force is transferred by an eccentric roller bearing to the bridge section of the caliper. This force is then distributed by the bridge and two threaded tubes to the tappets. The tappets apply force directly to the inboard brake pad. Once the running clearance between the brake pads and brake disc have been overcome, the reaction forces are transmitted by the sliding caliper to the outboard brake pads on the brake disc generates the braking force.

When brake pressure is released, the return spring within the caliper forces the bridge section along with the threaded tubes and lever back to the starting position

An automatic adjuster mechanism is used to ensure consistent running clearance between the brake pads and brake disc. The adjuster is mechanically connected to the lever and will operate each time the brakes are applied. The running clearance between the pads and brake disc increases as the brake pads wear. This increased clearance will allow the adjuster mechanism to rotate slightly. A drive chain transfers this movement to both threaded sleeves, which rotated inward equally. The rotational inward movement of the threaded sleeves and tappets effectively takes up the additional running clearance as the brake pads wear.






Fig. 2-110: Disc Brake Cross Section



### 5.2.4. Inspection

The following inspections may be performed with the brake caliper assembly installed on the axle, providing that the following preparatory steps have been taken.

- 1. Vehicle raised to working height and properly supported with jack stands.
- 2. Wheel and tire assembly removed.

# ™NOTE:

Refer to the Preventive Maintenance Section of this manual for the scheduled interval at which the following inspections are to be preformed.

#### 5.2.4.1. Brake Pad Clearance Inspection



Excessive brake pad clearance can result in reduced braking efficiency. Inadequate clearance can result in excessive wear and overheating. Ensure recommended brake pad clearance is maintained.

1. Push the brake caliper fully inboard.

- Insert a pry bar between the backing plate on the inboard brake pad and the caliper and carefully pry brake pad away from the tappets.
- 3. Use feeler gauges (Item 11 from special tools list) to measure clearance between both tappets and brake pad simultaneously. Measure over whole tappet surface of both tappets. Clearance should fall within the range of 0.024 to 0.043" (0.6 to 1.1 mm). There may be damage to the adjuster if the clearance deviates from this.

#### MOTE:

Check the clearance at both tappets simultaneously, using (at least 220mm long) feeler gauges. If the gap difference between the two tappets is >0.25mm, then the caliper guide pin clearance must be checked. Refer to 5.2.4.5. "Caliper Guide Pin Inspection" on page 101 in this section for procedure.

 Check for properly functioning adjusters if clearance is outside of this range. Refer to 5.2.4.2. "Automatic Adjustment Inspection" on page 98 in this section for checking procedure.



### 5.2.4.2. Automatic Adjustment Inspection



The installed adjuster adapter must be used when turning the adjuster. The adjuster adapter is designed with a shear point so as to prevent excessive force from being applied to the internal adjustment mechanism and causing possible damage.

 Remove the protective cap from the adjuster by pulling on the tab. Do not use a screwdriver or similar tool to remove the cap, as damage to the sealing lip could occur.



NEVER turn adjuster without shear adapter being installed. If the shear torque of the shear adapter is exceeded, it is designed to fail. If shear adapter fails, try again using a new (unused) shear adapter. With a second failure of the shear adapter, the caliper must be exchanged since internal damage is present.

DO NOT use an open-ended wrench as this may damage the adapter.

- Rotate the adjuster adapter one half turn (approx. 3 clicks) counter-clockwise using a 10 mm wrench. See "Fig. 2-111: Checking Adjuster Movement" on page 98.
- 3. Position a 10 mm box end wrench on the adjuster adapter so that the wrench is positioned close to the vertical position.
- Actuate the brake treadle 5 times with approximately 30 psi (2 bar) brake application pressure and note the movement of the installed wrench.
- 5. The wrench should move in a clockwise direction in response to each brake application, until clearance is taken up.

# ™NOTE:

The angle of turn or movement of the wrench decreases or slows as the number of steps rises.

- Replace the brake caliper if the automatic adjuster does not operate properly. Improper operation is indicated by either:
  - No movement.
  - b. Movement on the first brake application only.
  - c. Moves CCW then CW on each brake application.
- Lubricate seal lip and reinstall protective cap. Position the tab so that it will be accessible for future removal and not be obscured by the brake chamber.




Fig. 2-111: Checking Adjuster Movement



### 5.2.4.3. Brake Pad Wear Inspection

# ™NOTE:

Brake pad wear can be assessed visually without removing the brake pads using the following procedure.

- 1. Locate the lower caliper guide pin.
- Inspect the amount of deformation on the bellows area of the rubber bushing. A fully extended bellows indicates a new brake pad condition. A retracted and bulged bellows indicates a worn brake pad condition. See "Fig. 2-112: Brake Pad Wear Inspection" on page 99.
- If a worn condition is indicated, remove the brake pads and measure actual thickness of friction material. Refer to 5.2.5. "Brake

- Pads" on page 104 in this section for removal procedure. Replace brake pads if measured thickness is 0.08" (2.0 mm) or less.
- If brake pad thickness is within limits, inspect condition of friction surface. Minor material breakout at the edges is permitted but major material breakout is unacceptable. Replace brake pads as necessary.

# ™NOTE:

Replace all brake pads on same axle. DO NOT replace one side only.

 Measure brake disc thickness. Refer to 5.2.4.4. "Brake Disc Inspection" on page 100 in this section for procedure.




Fig. 2-112: Brake Pad Wear Inspection



#### 5.2.4.4. Brake Disc Inspection

 Measure brake disc thickness at the thinnest point of the disc, Avoid measuring at the outer edge or a roughened surface. Replace brake disc if thickness is 1.457" (37 mm) or less.

# ™NOTE:

It is recommended to replace the brake disc at time of brake pad replacement if the brake disc measures 1.535" (39 mm) or less.

2. Measure brake disc runout as follows:

### ™NOTE:

Confirm that the wheel hub axial play is within limits prior to proceeding with this inspection.

- Mount dial indicator so that tip of indicator is perpendicular to brake disc surface at 1.40" (35 mm) down from the outer rim of the rotor. See "Fig. 2-113: Rotor Run-Out Measurement Point" on page 100.
- b. Rotate brake disc a complete turn.
- c. Total indicated run-out must not exceed 0.006" (0.15 mm).
- d. Machine or replace the brake disc if run-out limits are exceeded. Refer to 5.2.9. "Brake Disc" on page 115 in this section for machining procedure.

#### ™NOTE:

Replace all brake pads on same axle. DO NOT replace one side only.

- Inspect the brake disc for cracks and scoring. See "Fig. 2-114: Brake Disc Condition" on page 101.
  - a. Minor web-like cracks on the braking surface are acceptable. Refer to area "A" shown on illustration.
  - b. Cracks less than 0.059" (1.5 mm) deep or wide and running in a radial direction

- are acceptable providing the cracks do not extend over more than 75% of the width of the braking surface. Refer to area "B" on the illustration.
- Cracks extending into the cooling cavity or into the inner support web are unacceptable.
- d. Circumferential scoring of the braking surface not to exceed 0.059" (1.5 mm) per side is acceptable. Refer to area "C" on illustration.

# ™NOTE:

Uneven or scored brake disc surfaces may be cleaned up by machining providing the minimum thickness limit is met. Replace brake disc if crack or scoring limits are exceeded. Replace both brake discs on same axle. DO NOT replace one side only.




Fig. 2-113: Rotor Run-Out Measurement Point






Fig. 2-114: Brake Disc Condition

### 5.2.4.5. Caliper Guide Pin Inspection

# ™NOTE:

Worn caliper guide pins will result in excessive movement in the caliper assembly relative to the brake carrier. Use the following procedure to determine if excessive wear is present:

 Remove worn brake pads and temporarily replace with a set of new pads during this procedure. Refer to 5.2.5. "Brake Pads" on page 104 in this section for removal procedure.

### ™NOTE:

Perform brake pad inspection on the removed pad. Refer to 5.2.4.3. "Brake Pad Wear Inspection" on page 99 in this section for procedure. Replace pads as necessary or reinstall existing pads.

2. Rewind the tappets back using a wrench and shear adapter. Clean dirt inside and out from guide pin bushing.

- 3. Push the caliper inward fully the pull the caliper outward fully. Movement of the caliper on the guide pins should be smooth throughout the full range of movement (approximately 1.0" (25 mm)). Replace the caliper guide pins if the full range of movement cannot be achieved or if excessive force is required to move the caliper.
- 4. Check for excessive play in the caliper guide pins as follows:
  - a. Pull the caliper fully outward.
  - Mount a dial indicator on the short bearing side of the carrier with the indicator tip resting on the brake caliper. Zero the dial gauge. See "Fig. 2-115: Measuring Guide Pin Play" on page 101.
  - c. Apply pressure to the brake caliper in an upward direction and read the dial gauge. Replace guide pins if reading exceeds 0.079" (2.0 mm). Refer to 5.2.7. "Caliper Guide Pins" on page 108 in this section for replacement procedure.




Fig. 2-115: Measuring Guide Pin Play



### 5.2.4.6. Tappet Rubber Boot Inspection



DO NOT adjust the tappets beyond 1.18" (30 mm) as measured from the surface of the caliper to the tappet thrust face. Turning any further will result in irreparable damage to the adjuster adapter. Penetration of dirt and moisture into the interior of the brake will lead to corrosion and impair the function of the clamping mechanism and the adjusting mechanism.

- Remove the brake pads. Refer to 5.2.5. "Brake Pads" on page 104 in this section for removal procedure
- Rotate the adjuster clockwise until the tappets extend approximately 1.18" (30) from the caliper surface. This will allow full extension of the tappet rubber boot for a proper visual inspection. See "Fig. 2-116: Tappet & Rubber Boot Inspection" on page 102.
- Inspect the rubber boot for proper seating, wear, cuts, or deterioration. Replace rubber boots as necessary. Refer to 5.2.8. "Tappet & Rubber Boot" on page 112 in this section for replacement procedure.

4. Inspect the tappet thrust surface for scoring, corrosion, or other damage. Replace tappets as necessary. Refer to 5.2.8. "Tappet & Rubber Boot" on page 112 in this section for replacement procedure.




Fig. 2-116: Tappet & Rubber Boot Inspection



# 5.2.4.7. Upper Guide Rubber Boot Inspection

- 1. Remove the brake pads. Refer to 5.2.5. "Brake Pads" on page 104 in this section for removal procedure.
- Push the caliper fully inward to expose the inner rubber boot on the upper guide pin. See "Fig. 2-117: Upper Guide Pin Inner Boot Inspection" on page 103.
- Inspect the rubber boot for cracks, tears, wear, or deterioration. Replace as necessary. Refer to 5.2.7. "Caliper Guide Pins" on page 108 in this section for replacement procedure.




Fig. 2-117: Upper Guide Pin Inner Boot Inspection



#### 5.2.5. Brake Pads

#### 5.2.5.1. Removal

- Raise the vehicle to working height. Refer to the General Information Section of this manual for procedure.
- Place jack stands at each of the vehicle jacking points. Lower the vehicle until the weight is taken by the jack stands.
- 3. Remove wheel and tire assembly.
- 4. Remove the brake pad retainer as follows:
  - a. Remove the spring clip and washer from the retainer pin.
  - b. Push down on the retainer and slide out the retainer pin.
  - c. Remove the brake pad retainer.
- 5. Increase brake pad clearance as follows:
  - a. Remove the protective cover from the adjuster by using the pull tab. Do not use a screwdriver to pry off the cap, otherwise the seal could be damaged. See "Fig. 2-118: Brake Pad Removal" on page 104.



NEVER attempt to turn the adjuster without using the adjuster adapter. The adapter is designed to shear if excessive force is require to turn the adjuster, thereby preventing damage to internal components. If the adapter is replaced and shears a second time, replace the caliper assembly as internal damage is evident.

- b. Use the adjuster adapter and turn the adjuster counter-clockwise until the brake pads are free.
- 6. Remove the brake pads from the caliper.




Fig. 2-118: Brake Pad Removal

#### 5.2.5.2. Cleaning & Inspection



DO NOT use compressed air to clean brake components as brake dust represents a health hazard.

- Clean any corrosion or deposits from the brake pad guides using a scraper.
- Clean away any loose dirt using a damp cloth.
- 3. Inspect the brake pad retainer and replace if deformed or otherwise damaged.
- Inspect the rubber boot on the tappet and replace if worn or damaged. Refer to 5.2.8. "Tappet & Rubber Boot" on page 112 in this section for replacement procedure.



#### 5.2.5.3. Installation



DO NOT grease the brake pad guides as this will cause abraded material from brake pad to accumulate and prevent smooth movement of the brake pads in the guide.

- Push the brake caliper inward against the stop and insert the inboard brake pad. See See "Fig. 2-119: Brake Pad Installation" on page 105.
- 2. Pull the brake caliper outward against the stop and insert the outboard brake pad.
- 3. Install the brake pad retainer as follows:
  - a. Insert the inboard end of the pad retainer into the groove and apply sufficient downward pressure to allow insertion of the retaining pin. See "Fig. 2-120: Brake Pad Retainer Installation" on page 105.
  - b. Insert new retaining pin and secure with new washer and spring clip.
- 4. Adjust the brake pad clearance as follows:
  - Use the adjuster adapter and turn the adjuster clockwise until the pads touch the brake disc surface.
  - b. Turn the adjuster back three notches as confirmed by audible clicks.
  - c. Actuate the brakes 10 times with minimum 30 psi (2 bar) applied brake pressure. This action will automatically take up any clearance and provide the desired running clearance.
  - d. Verify the actual clearance by prying against the inboard brake pad backing plate and using a feeler gauge to measure clearance between the backing plate and tappet. Clearance should be 0.027 to 0.047" (0.7 to 1.2 mm).
- 5. Lower the vehicle and perform road test to verify satisfactory operation of the brakes.




Fig. 2-119: Brake Pad Installation




Fig. 2-120: Brake Pad Retainer Installation



# 5.2.6. Brake Caliper & Carrier Assembly

# ™NOTE:

The following procedure describes removal of the brake caliper and carrier as an assembly from the rear axle flange.

#### 5.2.6.1. Removal

- Raise the vehicle to working height. Refer to the General Information Section of this manual for procedure.
- Place jack stands at each of the vehicle jacking points. Lower the vehicle until the weight is taken by the jack stands.
- 3. Remove wheel and tire assembly.
- 4. Remove the brake chamber. Refer to 5.3. "Rear Brake Chambers" on page 118 in this section for removal procedure.
- 5. Remove the brake pads. Refer to 5.2.5. "Brake Pads" on page 104 in this section for removal procedure.



BE SURE to secure the brake caliper to prevent it from falling, prior to removing the mounting bolts. Serious personal injury could result if the brake caliper is allowed to fall.

- 6. Install the caliper support fixture (Item 1 from special tools list). See "Fig. 2-121: Brake Caliper Removal" on page 106.
- Remove the six hex head bolts that retain the entire caliper and carrier assembly to the rear axle flange and remove the entire caliper and carrier assembly from vehicle. Discard the six mounting bolts.




Fig. 2-121: Brake Caliper Removal





#### 5.2.6.2. Installation

## ™NOTE:

Refer to the Special Tools Chart in Section 1 of this manual for the disc brake servicing tools.

- Install the caliper support fixture (Item 1 from special tools list).
- Install caliper and carrier assembly onto rear axle flange and install six new M18 external hex head mounting bolts and tighten the six bolts in an alternating pattern to an initial torque of 184 ft-lb. (250 Nm).



Improper torque can result in stretched bolts. ALWAYS follow the recommended torque procedure.

- 3. Mark a line on the head of the bolt indicating the vertical position.
- 4. Final torque the bolt to 288 ft-lb. (390 Nm).

5. Remove the torque wrench and note the angular movement of the bolt head from vertical. The angle that the bolt head (or torque wrench) has travelled must be at least 10° but not exceed 130°.

### ™NOTE:

If the bolt does not travel the required angle from initial torque to final torque, then replace with a new bolt and repeat procedure.

- 6. Remove the supporting fixture (Item 1 from special tools list).
- Install brake pads. Refer to 5.2.5. "Brake Pads" on page 104 in this section for installation procedure.
- 8. Install brake chamber. Refer to 5.3. "Rear Brake Chambers" on page 118 in this section for installation procedure.
- 9. Install tire and wheel assembly
- 10. Lower the vehicle and road test the vehicle to verify satisfactory operation of the brakes.



### 5.2.7. Caliper Guide Pins

# ™NOTE:

The following procedure provides removal & installation instructions for the brake caliper guide pins and bushings.

#### 5.2.7.1. Removal

# ™NOTE:

Refer to the Special Tools Chart in Section 1 of this manual for the disc brake servicing tools.

- Remove the brake chamber. Refer to 5.3. "Rear Brake Chambers" on page 118 in this section for removal procedure.
- 2. Remove the brake pads. Refer to 5.2.5. "Brake Pads" on page 104 in this section for removal procedure.
- Remove the protective cover from the upper guide pin by using a small chisel to punch through the center of the cover. Lever out the cover.
- 4. Pry out the protective cap on the lower guide pin using pliers or similar tool.
- Install the caliper support fixture (Item 1 from special tools list). See "Fig. 2-122: Brake Caliper Removal" on page 109.



Support the caliper before removing the caliper mounting bolts.

- Remove the two M16 socket head bolts that retain the caliper assembly to the brake carrier and lift the caliper assembly off the brake carrier. Discard the two mounting bolts.
- Fasten the caliper assembly onto mounting fixture with adapter plate (Items 80 & 79 from special tools list). Use two M12 x 110 mm long mounting bolts with M12 nuts to secure caliper to mounting fixture.

#### ™NOTE:

For reference purposes, the guide pin in the upper position (as installed on the axle) is configured with a brass bushing and a rubber boot on the inner end. The guide

- pin in the lower position (as installed on the axle) is configured with a rubber bushing and does not use a rubber boot on the inner end of the guide pin.
- Remove the retaining ring from the rubber boot on the upper guide pin. See "Fig. 2-123: Brake Caliper Guide Pin Removal" on page 109.
- Pull both guide pins out of the caliper housing.
- 10.Use a screwdriver or similar tool to push out the inner rubber boot from the guide pin bore.
- 11. Remove the brass bushing from the upper guide pin bore as follows:
  - a. Assemble and install the installer punch, press-in sleeves, spindle, and collar nut (Items 72, 77, 75, 71, & 70 from special tools list). See "Fig. 2-124: Brass Bushing Removal" on page 109.
  - Pull the brass bushing out of the caliper.
- 12. Remove the bushing from the lower guide pin bore as follows:
  - a. Assemble and install the installer punch, press-in sleeves, spindle, and collar nut (Items 72, 77, 75, 71, & 70 from special tools list). See "Fig. 2-125: Rubber Bushing Removal" on page 109.
  - b. Pull the bushing out of the caliper.

# 5.2.7.2. Inspection

- 1. Inspect the guide pin bores for corrosion and clean as necessary.
- Inspect the outside diameter of the guide pins for wear, scoring, or other damage. Replace guide pins as required.
- Inspect the inner rubber boot for cracks, tears, or deterioration. Replace as required.
- Thoroughly clean and inspect the brake carrier. Carefully inspect the guide area where the brake pads seat for any damage or excessive wear. Replace carrier as required.




Fig. 2-122: Brake Caliper Removal




Fig. 2-124: Brass Bushing Removal




Fig. 2-123: Brake Caliper Guide Pin Removal




Fig. 2-125: Rubber Bushing Removal



#### 5.2.7.3. Installation

#### ™NOTE:

Refer to the Special Tools Chart in Section 1 of this manual for the disc brake servicing tools.

- Install the bushing in the lower guide pin bore as follows:
  - a. Insert bushing into press-in sleeve (Item 78 from specials tool list).
  - b. Position installation tool with rubber bushing on the brake caliper and mount with spindle and collar nut tools (Items 70, 71, 72, 75, & 77 from special tools list). See "Fig. 2-126: Rubber Bushing Installation" on page 111.
  - Press the bushing into the caliper bore until the stop on the press-in sleeve is contacted.
- Install the brass guide bushing in the upper guide pin bore as follows:
  - a. Assemble and install the centering sleeve, brass bushing, installer punch, spindle, and collar nut (Items 76, 72, 70, & 71 from specials tool list). Ensure that the open side of the centering sleeve is facing away from the caliper. See "Fig. 2-127: Brass Bushing Installation" on page 111.
  - Press the brass bushing into the caliper bore until the stop on the press-in sleeve is contacted.
  - c. Insert the indenting tool (Item 74 from special tools list) into brass bushing from the outside until the stop is contacted. See "Fig. 2-128: Indenting Tool Installation" on page 111.
  - d. Screw the indenting bolt into the indenting tool until the stop is reached.
  - e. Unscrew the indenting bolt and remove the indenting tool.
- 3. Install the inner rubber boot as follows:
  - a. Insert the folds of the rubber boot into the press-in sleeve (Item 75 from special tools list). See "Fig. 2-129: Inner Boot Installation" on page 111.

- Position the press-in sleeve and installer sleeve (Items 73 & 75 from special tools list) on the brake caliper with spindle and collar nut (Items 71 & 70 from special tools list).
- Press the bellows into the seat using no more than 70 in-lb. (8 Nm) torque on the collar nut.
- Use grease supplied with the repair kit and lubricate the rubber bushing, brass bushing, and both guide pins. Install the guide pins into the caliper.
- 5. Insert the lip of the inner boot into the groove on the guide pin and secure with retaining ring.
- Remove the caliper from the mounting fixture and install supporting fixture (Item 1 from special tools list) onto caliper.
- Lift the brake caliper into position on the brake carrier.
- Install new M16 socket head caliper mounting bolts, ensuring that the inner boot and retaining ring are properly seated. Torque bolts to 133 ft-lb. (180 Nm) then tighten an additional 90°.
- 9. Remove the supporting fixture.
- 10.Install a new protective cover into the caliper at the upper guide pin location. Use a soft-faced hammer to drive the cover flush with the surrounding surface.
- 11.Use centering sleeve (Item 76 from special tools list) to install protective cap into caliper at the lower guide pin location. Drive cap into place until centering sleeve stop is contacted. See "Fig. 2-130: Protective Cover & Cap Installation" on page 112.
- 12.Install brake pads. Refer to 5.2.5. "Brake Pads" on page 104 in this section for installation procedure.
- 13.Install brake chamber. Refer to 5.3. "Rear Brake Chambers" on page 118 in this section for installation procedure.
- 14. Install tire and wheel assembly
- 15. Lower the vehicle and road test the vehicle to verify satisfactory operation of the brakes.




Fig. 2-126: Rubber Bushing Installation




Fig. 2-128: Indenting Tool Installation




Fig. 2-127: Brass Bushing Installation




Fig. 2-129: Inner Boot Installation






Fig. 2-130: Protective Cover & Cap Installation

### 5.2.8. Tappet & Rubber Boot

# ™NOTE:

The following procedure provides removal/installation instructions for the brake caliper tappets, rubber boots, and inner seals.

#### 5.2.8.1. Removal

#### ™NOTE:

Refer to the Special Tools Chart in Section 1 of this manual for the disc brake servicing tools.

 Remove the brake pads. Refer to 5.2.5. "Brake Pads" on page 104 in this section for removal procedure.



DO NOT adjust the tappets beyond 1.18" (30 mm) as measured from the surface of the caliper to the tappet thrust face. Synchronization between the two threaded tubes can be lost if If the tappets are extended beyond this

#### distance.

- Rotate the adjuster clockwise until the tappets extend approximately 1.18" (30) from the caliper surface. This will allow full extension of the tappet rubber boot for insertion of the removal tools. See "Fig. 2-131: Unscrewing Tappets" on page 113.
- 3. Use a sharp knife to cut the rubber boot on the tappet. Insert the press-off fork tool (Item 81 from special tools list) between the tappet and the end of the threaded tube with the flat side of the forks against the threaded tube. See "Fig. 2-132: Removing Tappets" on page 113.
- Use a hammer and tap on the fork tool to dislodge the tappet from the threaded sleeve.
- 5. Use a screwdriver to pry the tappet boot out of the seal seat.
- Turn the adjuster counter-clockwise until the threaded sleeves are fully retracted within the caliper bore.



DO NOT damage the seal seat when removing the inner seal, otherwise the caliper will need to be replaced.

- Carefully pry the inner seal out of the seal seat. See "Fig. 2-133: Removing Inner Seal" on page 113.
- 8. Remove the bushing from the end of the threaded sleeve.

# 5.2.8.2. Inspection

- Rotate the adjuster clockwise until the end of the threaded sleeve extends 1.18" (30 mm) from the caliper surface. See "Fig. 2-134: Inspecting Threaded Tubes" on page 113.
- 2. Inspect the threads on the threaded tubes for damage. The caliper will need to be replaced if thread damage is evident.
- Inspect the bore of the caliper for scoring, corrosion, or other damage in the area of the inner seal seat. Replace caliper if seal seat area damaged.




Fig. 2-131: Unscrewing Tappets




Fig. 2-133: Removing Inner Seal




Fig. 2-132: Removing Tappets




Fig. 2-134: Inspecting Threaded Tubes



#### 5.2.8.3. Installation

# ™NOTE:

Refer to the Special Tools Chart in Section 1 of this manual for the disc brake servicing tools.

# ™NOTE:

This procedure can be performed with the caliper mounted to the axle or on a work bench. The special tools used contain two different length bolts depending on the method used. For installation on a work bench, use the longer bolt. For on-vehicle installation, use the shorter bolt.

- Rotate the adjuster counter-clockwise until the threaded tubes are fully retracted within the caliper bore.
- Thread the long forcing bolt into the installer sleeve (Item 82 from special tools list). See "Fig. 2-135: Installing Inner Seal" on page 114.
- 3. Place the new inner seal onto the press-in bushing (Item 83 from special tools list).
- 4. Place the assembled press-in bushing and inner seal into the installer sleeve. Use the forcing bolt to press the inner seal against the stop in the brake caliper.
- Rotate the adjuster clockwise until the end of the threaded sleeve extends 0.59" (15 mm) from the caliper surface.

# ™NOTE:

The inner seal must not turn.

- Apply grease, supplied in the repair kit, onto the end of the threaded sleeves and install new bushings.
- 7. Turn the adjuster counter-clockwise until the threaded sleeves are fully retracted within the caliper bore.
- 8. Place the tappet and rubber boot onto the bushing.

# ™NOTE:

Ensure the seal seat is clean and free from grease before installing the rubber boot into the seal seat.

- Hold the installer sleeve (Item 82 from special tools list) against the rubber boot and use the long forcing bolt to press the rubber boot against the stop in the seat. See "Fig. 2-136: Installing Tappet & Rubber Boot" on page 115.
- 10. Reverse the position of the installer sleeve so that the open end is facing away from the tappet and boot assembly and the head of the forcing bolt is facing the tappet. See "Fig. 2-137: Seating Tappet Against Stop" on page 115.
- 11. Use the forcing bolt to press the tappet up against the stop on the threaded sleeve.




Fig. 2-135: Installing Inner Seal






Fig. 2-136: Installing Tappet & Rubber Boot




Fig. 2-137: Seating Tappet Against Stop

#### 5.2.9. Brake Disc

#### 5.2.9.1. Removal

- Remove the brake pads. Refer to 5.2.5. "Brake Pads" on page 104 in this section for procedure.
- Remove the brake caliper & carrier assembly. Refer to 5.2.6. "Brake Caliper & Carrier Assembly" on page 106 in this section for procedure.
- Remove axle shaft. Refer to 3.8. "Axle Shaft" on page 12 in this section for procedure.
- 4. Remove slotted nuts from wheel hub. Refer to 3.9. "Rear Wheel Hub" on page 15 in this section for procedure.
- Install threaded guide sleeve (Item 13 from special tools list) onto the axle stub and lubricate guide sleeve surface. See "Fig. 2-138: Removing Wheel Hub & Brake Disc" on page 116.
- 6. Pull wheel hub with brake disc off axle stub and over the guide sleeve. Use a smooth continuous motion during removal to avoid binding the wheel hub bearings on the guide sleeve. Place wheel hub and brake disc assembly on a clean work surface.
- 7. Unscrew guide sleeve (Item 13 from special tools list) from axle stub.
- 8. Remove the wheel hub mounting bolts. See "Fig. 2-139: Separating Wheel Hub from Brake Disc" on page 116.
- 9. Remove wheel hub and O-ring from the brake disc.






Fig. 2-138: Removing Wheel Hub & Brake Disc




Fig. 2-139: Separating Wheel Hub from Brake Disc

#### 5.2.9.2. Installation

- 1. Insert a new O-ring into the wheel hub.
- 2. Mount the wheel hub on the brake disc.
- Install and hand-tighten all the mounting bolts.

### ™NOTE:

Check condition of bolts. DO NOT reuse any mounting bolts with signs of damage or deformity.

### ™NOTE:

Secure the brake disc/wheel hub assembly from rotating while final tightening the mounting bolts.

- 4. Torque the mounting bolts to 207 ft-lb. (280 Nm).
- 5. Install the threaded Guide Sleeve (Item 13 from special tools list) onto the axle stub.
- Apply a light coat of Molykote-D paste in the wheel hub bearing seat area and on the axle stub and guide sleeve. Apply paste on the machined surface of the stub where the hub bearings are seated except 3/4" of inner bearing seat.
- 7. Install the wheel hub and brake disc over the guide sleeve and onto the axle stub.
- 8. Remove the guide sleeve (Item 13 from special tools list).
- Install and tighten wheel hub slotted nuts. Refer to 3.9. "Rear Wheel Hub" on page 15 in this section for procedure.
- 10.Install axle shaft. Refer to 3.8. "Axle Shaft" on page 12 in this section for procedure.
- 11. Install the brake caliper and carrier assembly. Refer to 5.2.6. "Brake Caliper & Carrier Assembly" on page 106 in this section for procedure.
- 12.Install the brake pads. Refer to 5.2.5. "Brake Pads" on page 104 in this section for procedure.





### 5.2.9.3. Machining



DO NOT machine the brake disc to less than 1.575" (40 mm) thickness. Allowance must be made for additional wear while in service and under no circumstances should the minimum disc brake thickness be reduced below 1.457" (37 mm) while in service.

# ™NOTE:

The brake disc must be machined while installed on the vehicle.

- ☐ ALWAYS machine equal amounts of material from both sides of the disc.
- ☐ ALWAYS machine the minimum amount of material required in restoring disc to serviceable limits.
- ALWAYS machine in several passes, being careful not to take off too much material in one pass.

- ☐ ALWAYS machine both brake discs on an axle. Do not machine one disc only.
- ☐ ALWAYS replace brake pads in sets whenever brake discs have been machined to ensure proper seating-in of the brake pads and to maintain braking efficiency.
- Remove the brake pads. Refer to 5.2.5. "Brake Pads" on page 104 in this section for removal procedure.
- Use commercially available brake machining equipment designed to be mounted to brake assembly with the brake disc installed on the axle. Follow manufacturer's instructions for setting up equipment and machining brake disc.
- 3. Measure machined surface of brake disc. The minimum thickness of the brake disc must not be less than 1.575" (40 mm).



### 5.3. Rear Brake Chambers

# 5.3.1. Description

The rear brake chamber is a combination piggy-back configuration. The service brake portion is a diaphragm style actuator and the spring brake portion is a piston style actuator.

# ™NOTE:

The brake chamber assembly is a non-serviceable unit and must be replaced as an assembly. DO NOT attempt to disassemble the brake chamber.

#### 5.3.2. Rear Brake Chambers Specifications

Manufacturer MGM Brakes
Model MJB2424ET
TypePiston/Diaphragm
Maximum Operating Pressure145 psi (10.0 Bar)
Service Brake Air Volume82 cu. in. (1344 cc)
Spring Brake Air Volume98.5 cu. in. (1614 cc)
Maximum Stroke 3.0" (76 mm)

#### 5.3.3. Operation

#### 5.3.3.1. Service Brakes

Controlled air pressure enters the service brake chamber through the inlet port to act on the diaphragm and move the push plate and rod assembly forward. The brake chamber is bolted to the disc brake caliper and is used to actuate the disc brake mechanism. This forward motion of the push rod acts on an eccentric lever within the caliper assembly and applies the vehi-

cle brakes. The greater the air pressure admitted to the brake chamber, the greater the force applied by push rod. Push rod force is determined by multiplying the delivered air pressure by the effective diaphragm area. When air pressure is released from the brake chamber, the push rod return spring returns the diaphragm, push plate and rod assembly to their released positions, thereby releasing the brakes.

# 5.3.3.2. Spring Brake (Parking/Emergency Brake)

The parking brake automatically actuates the foundation brakes when there is no air pressure in the spring brake chamber. During normal operation the spring brake chamber is pressurized with air which pushes upon the piston, compressing the power spring, thereby holding the parking brake in the disengaged (released) position.

Since the service brake and spring brake chambers are isolated from each another by a seal, the parking brake cannot interfere with the normal operation of the service brake. Application of the parking brake releases air pressure in the spring brake chamber, enabling the power spring to force the push rod toward the service brake chamber. This motion of the push rod exerts force against the service brake push rod, causing application of the foundation brakes via the brake caliper.

The spring brake chamber is equipped with an integral release bolt that allows manual release of the power spring in service situations where an air supply is not available. The power spring is considered to be caged when the manual release bolt has fully compressed the power spring.



#### 5.3.4. Maintenance

Refer to the Preventive Maintenance Section of this manual for scheduled maintenance and inspection intervals and procedures.

#### 5.3.5. Removal

- Set the Battery Disconnect switch to the OFF position.
- 2. Chock the wheels.
- 3. Drain all air tanks.
- Mark the location of each air line and disconnect air lines from brake chamber.



DO NOT use impact tools to cage or uncage the brake chamber.

5. Manually cage the spring brake by rotating the integral release bolt counter-clockwise approximately 22 to 23 turns until the spring is fully caged. The force to compress the spring must not exceed 74 ft-lb. (100 Nm) during the caging process. The brake chamber is considered fully caged when the head of the release bolt extends approximately 1.30" beyond the surface of the brake chamber.

#### R NOTE:

For easier turning of the release bolt, apply 95 to 125 psi shop air pressure to the air inlet port marked "Spring". After caging, completely exhaust air from the spring chamber.

- Remove the two lock nuts securing the brake chamber to the brake caliper assembly and remove the brake chamber from the vehicle. See "Fig. 2-140: Removing Brake Chamber" on page 119.
- 7. Place a protective cover over the brake caliper to prevent entry of contaminants.




Fig. 2-140: Removing Brake Chamber



#### 5.3.6. Installation



Disc brake chambers must be inspected for seal condition and height measurement before a used brake chamber can be reinstalled.

- If installing a new brake chamber, ensure that the protective cover is removed from the push rod. If installing a used brake chamber, perform the following inspection:
  - a. Measure the height of the seal on the brake chamber. The seal must be in good condition and protrude at least 0.118" (3.0 mm) from the brake chamber mounting surface.
  - b. If the seal measures less than 0.118" (3.0 mm) then the brake chamber must be replaced as an assembly.



Cover the brake chamber opening on the brake caliper when cleaning the mounting surfaces so as to prevent entry of any contaminants.

- Clean the brake chamber and caliper mounting surfaces. Ensure that any protective covers are removed from the brake caliper.
- Apply Renolit Unitemp 2 grease to the spherical cup located in the brake caliper and to the end of the brake chamber push rod. Do not apply an excessive amount of grease.



DO NOT attempt to loosen clamp band bolt in order to rotate and reposition the air inlet ports. DO NOT use clamping tools such as vise grips to hold the push rod. The spring brake actuator contains an internal boot to seal the caliper from contaminants and may be damaged if brake chamber is rotated or if clamping tools are used on the push rod.



Ensure brake chamber is properly positioned so that the breather tube is NOT facing directly downward toward the road surface.

- 4. Carefully install brake chamber on brake caliper assembly.
- Install new M16 lock nuts and torque to specification. Refer to 4.5. "Rear Suspension Torque Specifications" on page 91 in this section for torque specification.
- Connect air lines, as marked during removal, to brake chamber and torque air line fittings to 25 to 30 ft-lb. (34 to 40 Nm).
- Start vehicle and charge air system to normal operating pressure.



Ensure the vehicle wheels are chocked during the following procedure.

- 8. Release the parking brake.
- Use soapy water or leak detection solution to inspect for air leaks at the spring brake air inlet fittings.
- 10. With parking brake still released and spring brake fully pressurized, fully apply the brake treadle (minimum 100 psi at service brake chamber).
- Check for air leaks at the service brake air inlet fittings.
- 12. Release the brake treadle and exhaust air from the service brake chamber and with air pressure still applied to the spring brake chamber, tighten the release bolt clockwise until it is seated against the head insert. Torque release bolt to 50 to 60 ft-lb. (66 to 81 Nm).
- 13. Apply parking brake and confirm that the spring brakes apply.



# 6. REAR AXLE ANTI-LOCK BRAKING SYSTEM (ABS) & COMPONENTS



To prevent serious personal injury, put blocks under the front tires to stop the vehicle from moving. Apply the parking brakes.

DO NOT work under a vehicle supported only by jacks. Jacks can slip or fall over and cause serious personal injury.

To prevent serious eye injury, always wear safe eye protection when performing maintenance or service.

# 6.1. Description

The major components of the ABS System include:

- □ ABS Speed Sensor
- □ ABS Pulse Generating Wheel
- ABS Modulator Valves
- ☐ ABS Electronic Control Unit (ECU)

# 6.2. Operation

ABS is an electronic braking system that monitors and controls wheel speed during braking. The system works with standard air brake systems. ABS monitors wheel speeds at all times and controls braking during wheel lock situations. By reducing wheel lock, the system improves vehicle stability and control. In the event of a malfunction in the system, the braking in the affected wheel will return to normal braking.

The system consists of a tooth wheel-mounted on the hub of each monitored wheel. A sensor is installed with its sensing end against each tooth wheel. The sensor continually provides wheel speed information to the Electronic Control Unit (ECU), located above the lighting panel on the streetside of the vehicle, which in turn supplies signals to the ABS modulator valves. The modulator valves control air pressure to each wheel during ABS operation. The valves modulate air pressure to the brake chamber during ABS operation to control braking and prevent wheel lock up.



# 6.3. Rear ABS Speed Sensor & Sensor Holder

#### 6.3.1. Description

The rear axle ABS sensor is installed in the ABS sensor holder which is press fit onto the axle shaft journal. The ABS sensor and sensor holder are positioned in close proximity to the ABS pulse generating wheel on the wheel hub.

### 6.3.2. Removal

- Remove the wheel hub. Refer to 3.9. "Rear Wheel Hub" on page 15 in this section for removal procedure.
- Remove the brake disc. Refer to 5.2.9. "Brake Disc" on page 115 in this section for removal procedure.
- Mark the position of the ABS sensor harness hose clamp. See "Fig. 2-141: Removing ABS Sensor Harness Clamp" on page 122.
- 4. Open the hose clamp and remove it along with the sensor harness clamp.
- Remove the bolt that retains the ABS sensor to the sensor holder.
- 6. Remove the ABS sensor.
- Mark the installation position of the ABS sensor holder with respect to the axle housing.
- 8. Assemble the Impact Tool (Item 2 from special tools list) with the Seal Race Removal Hook (Item 23 from special tools list).
- Position the seal race removal hook on the ABS sensor holder. See "Fig. 2-142: Removing ABS Sensor Holder" on page 122.
- Work alternately at two positions on opposite sides to evenly pull the ABS sensor holder off the axle housing.




Fig. 2-141: Removing ABS Sensor Harness Clamp




Fig. 2-142: Removing ABS Sensor Holder



#### 6.3.3. Installation

# ™NOTE:

The following procedure describes the process necessary to install the ABS sensor holder to a specific distance on the axle housing journal to ensure the proper gap between the ABS sensor and pulse generating wheel.

#### 6.3.3.1. Default Gap Setting

- Unscrew the three pressure jacking screws in the Assembly Sleeve (Item 25 from special tools list).
- Place the open dished side of the ABS sensor holder against the assembly sleeve tool. See "Fig. 2-143: Installing ABS Sensor" on page 123.
- Screw in the three pressure screws until they make light contact with the ABS sensor holder.

# 6.3.3.2. Positioning ABS Sensor Holder

- 1. Install the ABS sensor holder onto the axle housing journal using the alignment marks made during the removal procedure.
- Position the Assembly Sleeve (Item 25 from special tools list) so that the window on the side of the tool aligns with the through-hole on the ABS sensor holder.
- 3. Install the slotted nut and hand-tighten.
- 4. Insert the ABS sensor into the sensor holder and secure with mounting bolt.

# 6.3.3.3. Centering Device Assembly & Installation

- Assemble the centering device tool using Items 3, 4, 5, 6 & 7 from special tools list. See "Fig. 2-144: Assembling Centering Device" on page 123.
- Align the measuring surface of the assembly sleeve tool with the ABS sensor.
- 3. Insert the centering device into the axle housing until the stop is reached.
- 4. Clamp the centering device by tightening the threaded spindle.




Fig. 2-143: Installing ABS Sensor




Fig. 2-144: Assembling Centering Device



#### 6.3.3.4. ABS Sensor Holder Installation

- Place the Slotted Nut Socket (Item 8 from special tools list) over the centering device and onto the slotted nut.
- Install the Torque Multiplier (Item 9 from special tools list) on the slotted nut socket and secure it in place with Spindle Screw and Washer (Items 7 & 6 from special tools list).
- Position Counter-Holder (Item 12 from special tools list) so that the head of the tool slips over the studs on the torque multiplier body and the base of the counterholder is braced against the floor to counteract the rotational movement of the torque multiplier. See "Fig. 2-145: Installing ABS Sensor Holder" on page 124.
- 4. Tighten the slotted nut until the assembly sleeve tool contacts the axle journal.
- 5. Remove the special tools.




Fig. 2-145: Installing ABS Sensor Holder

# 6.3.3.5. Checking & Setting ABS Sensor Gap

## ™NOTE:

The pressure screws in the assembly sleeve are only allowed to be screwed in slightly in order to set back the ABS sensor holder. Rotating the pressure screws by 90° increases the gap by 0.010 in.(0.25mm).

#### ™NOTE:

The ABS sensor to assembly sleeve tool gap must be 0.014 in. (0.35mm).

- Use the Feeler Gauge (Item 22 from special tools list) to check the gap between the ABS sensor and the measuring surface of the assembly sleeve tool. See "Fig. 2-146: Setting Gap Width" on page 124.
- Adjust the gap by rotating the pressure screws evenly until the specified gap is reached.
- 3. Remove the assembly sleeve tool.




Fig. 2-146: Setting Gap Width



# **Rear ABS Speed Sensor & Sensor Holder**

# 6.3.3.6. Routing ABS Sensor Electrical Harness



Route the ABS sensor electrical harness carefully. Avoid routes where the harness is subject to tension, kinks and wearing against nearby components.

- 1. Position the hose clamp according to the alignment marks made during the disassembly procedure.
- 2. Insert ABS sensor harness into the clamp.
- 3. Position the clamp so that it is parallel and in a straight line with ABS sensor.
- 4. Tighten the mounting bolt for the hose clamp.
- Check the ABS system for proper operation.

# Rear ABS Pulse Generating Wheel & Radial Seal

# 6.4. Rear ABS Pulse Generating Wheel & Radial Seal

#### 6.4.1. Description

The ABS pulse generating wheel and radial seal assembly is mounted on the inboard side of the wheel hub. The slotted disc portion of the assembly provides the reference signal for the wheel speed which is sensed by the ABS sensor. The ABS sensor is mounted in a holder that is fixed on the axle housing journal. The pulse generating wheel and radial seal assembly is serviced as a unit.

#### 6.4.2. Removal & Installation

Inspect the pulse generating wheel and radial seal assembly for evidence of wear or damage and replace as necessary. Refer to 3.9. "Rear Wheel Hub" on page 15 in this section for replacement procedure.

# ™NOTE:

Only the bearing retaining ring, and inner bearing need to be removed from the wheel hub assembly in order to replace the pulse generating wheel and radial seal assembly.

# 6.5. Rear ABS Modulator Valve

#### 6.5.1. Description

ABS modulator valves are used to control brake application on the rear axle. The valves are bracket-mounted to the vehicle structure and located between the brake relay valve and brake chambers. The modulator valve is electrically controlled with a solenoid valve and includes an inlet, outlet and exhaust port.

# 6.5.2. Operation

During normal brake application the modulator valves are inactive and do not affect the brake application. If the ABS ECU detects an ABS event (impending wheel lock-up) it will energize the solenoids in the modulator valves to control the brake application pressure to the service brake chambers.

To decrease brake application pressure, the ECU will energize the inlet and outlet solenoids of the modulator valve that will close the supply port and open the delivery and exhaust ports. To hold brake application pressure at a given value, the ECU will energize the inlet solenoid and de-energize the outlet solenoid of the modulator valve that will close the supply and exhaust ports.

This modulation of brake application pressure will continue until the impending wheel lock-up condition is alleviated.

#### 6.5.3. Removal

- 1. Set the Battery Disconnect switch to the OFF position.
- 2. Disconnect the wiring from the ABS valve.
- Disconnect the air lines from ports 1 and 2 of the ABS valve. See "Fig. 2-147: Rear Modulator Valve Removal & Installation" on page 127.
- Remove the two mounting bolts and nuts.
- 5. Remove the ABS valve.

#### ™NOTE:

ABS valves are not serviceable.






Fig. 2-147: Rear Modulator Valve Removal & Installation

#### 6.5.4. Installation

- 1. Install the ABS valve with two mounting bolts and nuts.
- 2. Connect the line to the brake chamber to port 2 of the ABS valve. Connect the air supply line to port 1 of the ABS valve.
- Connect the harness connector to the ABS valve.
- 4. Set the Battery Disconnect switch to the ON position.



# 6.6. ABS Electronic Control Unit (ECU)

### 6.6.1. Description

The ABS System ECU is located on the streetside of the vehicle behind the front advertising panel. See "Fig. 2-148: ABS ECU" on page 128.




Fig. 2-148: ABS ECU

### 6.6.2. ABS Troubleshooting

Troubleshooting can be performed on the ABS system using any of the following methods:

- Blink Code troubleshooting
- ☐ Meritor Wabco TOOLBOX software
- ☐ Pro-Link® Plus diagnostic tool

Refer to 6.6.3. "Blink Code Diagnostics & Troubleshooting" on page 129 in this section for basic information on blink code trouble-shooting concerning the use of the ABS Fail indicator and the ABS switch installed in this vehicle.

Meritor Wabco TOOLBOX software is a PC-based diagnostic tool which can be used to test the ABS system components and display active and stored faults. The user's manual for this software is available for download on meritorwabco.com/toolbox. The software, available from Meritor Wabco, is loaded onto the PC and the PC is connected to one of the vehicle's diagnostic connectors.

The Pro-Link® Plus is a hand-held diagnostic device which can be used in place of blink code troubleshooting. The Pro-Link is fitted with the required cartridge and is connected to one of the vehicle's diagnostic connectors.

Refer to "Multiplexing System Layout" included with your Vehicle Systems Drawing Manual for the locations of the vehicle's diagnostic connectors.

Refer to 9. "VENDOR SERVICE INFOR-MATION" on page 145 in this section for further information on the use of the TOOLBOX software and the Pro-Link diagnostic tool. Also refer to this manual for detailed blink code troubleshooting charts and procedures.

# **ABS Electronic Control Unit (ECU)**

# 6.6.3. Blink Code Diagnostics & Troubleshooting

### 6.6.3.1. Description

The ABS Fail indicator on the instrument panel indicates system status and displays blink code diagnostics. The indicator lamp works as follows:

- When the Master Run switch is set to the DAY-RUN position, the indicator illuminates momentarily for a check and then extinguishes. This indicates the system is O.K.
- ☐ The indicator will flash if the normal ABS function is being modified due to road conditions while the vehicle is in operation.
- ☐ The indicator will remain illuminated after the vehicle is started if an existing fault is present.
- ☐ After the system is serviced, the indicator will remain illuminated until the vehicle is driven at speeds above 4 mph (6 kp/h).

The Blink Code system requires use and interpretation of a series of blink codes. A blink code is a series of flashes emitted by the ABS Fail indicator which describes a system fault or condition. Each blink code contains two digits or sets of flashes: a 1 1/2 second pause occurs between

each set of flashes in the digit. A four second pause separates the individual codes displayed. Blink code diagnostics are activated by the ABS switch in the front destination sign compartment.

#### 6.6.3.2. Diagnostic Mode

Enter diagnostic mode by activating the ABS switch for one second, and then releasing it.

#### 6.6.3.3. Clear Mode

Enter clear mode to erase faults from the ECU. This is done by activating the ABS switch for three seconds and then releasing it. If the system displays eight quick flashes followed by a system configuration code, the clear was successful. If this does not occur, faults are still active and must be repaired before they can be cleared.

#### 6.6.3.4. System Configuration Code

This is a one digit code consisting of two flashes repeated every four seconds by the ABS switch during clear mode to indicate that all ABS faults have been cleared from ECU memory.



# 7. REAR AXLE SPECIAL TOOLS

# 7.1. Rear Axle Special Tools Chart

Refer to your New Flyer Parts Manual for purchase part numbers. See "Fig. 2-149:

Special Tools-1" on page 134. See "Fig. 2-150: Special Tools-2" on page 135. See "Fig. 2-151: Special Tools-3" on page 136. See "Fig. 2-152: Special Tools-4" on page 137. See "Fig. 2-153: Special Tools-5" on page 138.

SPECIAL TOOLS	DESCRIPTION
1	Adapter, Wheel Bolt
2	Slide Hammer
3	Tapered Collar
4	Segment, Clamping Jaw
5	Extension, Centering Tool
6	Washer
7	Spindle, Screw
8	Socket, Nut Slotted
9	Multiplier, Torque 1:8
10	Reaction Arm
11	Ratchet Insert
12	Counter Holder
13	Guide Sleeve
14	Slip-on Handle, Press-in & Press-out
15	Washer, Press-in
16	Adapter, Pressing Device
17	Press Out Device, Bearing
18	Press-in Plate
19	Pressing Bush, Inner Tapered Roller Bearing
20	Pressing Bush, Outer Tapered Roller Bearing
21	Supporting Fixture
22	Gauge, Feeler
23	Hook, Seal Race Removal



SPECIAL TOOLS	DESCRIPTION
24	Flange, 150mm - 180mm
25	Sleeve Assembly, ABS Sensor Holder
26	Slotted Nut Wrench
27	Threaded Pin, Adapter Flange
28	Cotter Pin
29	Puller, 3 Arm, Input Flange
30	Separator, Roller Bearing Inner Race
31	Puller, Bearing Separator
32	Puller, 3 Arm, Input Flange Seal
33	Detachable handle
34	Pressing Adapter, Input Flange Seal
35	Adapter Piece, 3-Arm Puller, Input Flange
36	Lifting Device, Differential Removal
37	Assembly Crown, Differential Removal
38	Support Screw, Differential Removal
39	Square Drive
40	Adapter, Axle Breather Connection
41	Threaded Adapter, Axle Breather Connection
42	Extractor, Axle Breather Connection
43	Intermediate Flange 150 mm
44	Gauge, Dial
45	Holder, Dial Gauge
46	Slotted Nut Wrench, Differential Threaded Adjusters
47	Lifting Device
48	Holder, Universal
49	Plate Attachments
50	Thrust Piece, Differential
51	Bearing Gripper



SPECIAL TOOLS	DESCRIPTION
52	Puller Sleeve
53	Spindle, Bearing Puller
54	Reducer, Rolex II
55	Assembling Device, Differential
56	Torque Multiplier - 1:3.5
57	Brace
58	Adapter Pin
59	Torque Wrench
60	Torque Wrench (80-400 Nm)
61	Feeler Gauge
62	Lifting Strap
63	Open-End Wrench
64	Pin, Connecting
65	Cable Tie Pliers
66	Screw, Socket Head
67	Spindle Adapter, Input Seal
68	Pin, Centering
69	Adapter
70	Expandable Puller
71	Pressing Plate, Input Flange Shield Installation
72	Depth Gauge, Electronic
73	Support Bar, Electronic Depth Gauge
74	Pressing Plate, Input Flange Shield Removal
75	Separator, Input Flange Shield
76	Lift Adapter
77	Tester, Friction
78	Alignment Pins
79	Engine Stand



SPECIAL TOOLS	DESCRIPTION
80	Threaded Adapter
81	Cylinder Support
82	Сар
83	Threaded Sleeve
84	Hook
85	Socket
86	Support
87	Torque Wrench
88	Pressing Adapter, Roller Bearing
89	Eyebolt
90	Lifting Chain
91	Box-End Ratchet
92	Ratchet Handle
93	Bearing Gripper
94	Pressing Adapter, Pinion Bearing Outer Race
95	Ratchet
96	Torque Wrench (160-800 Nm)
97	Handle, Screwdriver Torque
98	Shaft, Removable Screwdriver
99	Bit, Removable Screwdriver
100	Calipers, Measuring
101	Piston Cylinder, Hollow 200 kN
102	Pump, Hydraulic
103	O-Ring, 42 mm
104	Adapter, Tool Assembly
105	Adapter, Wrench
106	Thrust Piece, Hydraulic Puller






Fig. 2-149: Special Tools-1






Fig. 2-150: Special Tools-2

Rev. A - Jul 27 2015






Fig. 2-151: Special Tools-3






Fig. 2-152: Special Tools-4






Fig. 2-153: Special Tools-5



# 8. DRIVESHAFT

# 8.1. Description

The driveshaft assembly is a short-coupled design that consists of a telescopic intermediate shaft with full round yokes and universal joints at each end. The driveshaft is adapted to the drive axle with a crosstooth flange and is adapted to the transmission with a half-round yoke. The intermediate shaft is a two-piece splined assembly that compensates for axial movement between the rear axle and transmission. See "Fig. 2-154: Driveshaft Installation" on page 139.

The universal joint cross includes drilled passageways and grease fittings to allow lubrication of the needle bearings without disassembly. The machined trunnions on the ends of the cross engage the needle bearings inside the bearing caps. The bearing cap "wings" provide the flange for securing the bearing cap to the yoke. A lock plate and two bolts are provided for this purpose.




Fig. 2-154: Driveshaft Installation



# 8.2. Driveshaft Specifications

Manufacturer	Prop Shaft Supply
Model	1710 Series
Angular Misalignment Cap 22° m	
Balancing Requirement 0.32 in-oz/10 lbs of s RPM	
Extended Length (yoke ce	
Collapsed Length (yoke c	
Weight (approx)70	).274 lbs (31.9 Kg)

# 8.3. Operation

The driveshaft couples and transmits output torque from the transmission to the drive axle. The u-joints allow for operating angles in both the vertical and horizontal planes. The telescopic spline arrangement compensates for axial movement between the transmission and drive axle during suspension movement.

# 8.4. Maintenance

Refer to the Preventive Maintenance section of this manual for scheduled servicing procedures.

#### 8.5. Removal



DO NOT service the driveline with the engine running. Ensure the engine is shut down and the Battery Disconnect switch is in the OFF position.

- Place the vehicle on a level surface, and lift the vehicle. Refer to the General Information Section of this manual for procedure.
- 2. Remove the driveshaft guard.
- Support driveshaft and remove bolts and bearing straps retaining cross in transmission yoke. See "Fig. 2-155: Driveshaft Assembly" on page 141.
- Remove bolts retaining driveshaft flange to drive axle and remove driveshaft assembly from vehicle.






Fig. 2-155: Driveshaft Assembly



# 8.6. Disassembly



DO NOT disassemble the driveshaft unless driveshaft balancing equipment is available. Disassembly and replacement of components will likely disturb the original driveshaft balance and may result in vibration and premature wear. The driveshaft assembly must be balanced to specification before being installed on the vehicle.

 Bend the tabs of the lock plates away from the bolts.

- 2. Remove the bolts and lock plates retaining the bearing caps to the yokes.
- 3. Remove the bearing caps.

# ™NOTE:

If necessary, use a commercial bearing puller to remove the bearing caps from the yoke bores.

- 4. Work the trunnions free of the yoke bores, and remove the universal joint cross from the yoke.
- Score alignment marks on the male and female portions of the telescoping intermediate shaft.
- 6. Pull the shafts apart.



# 8.7. Assembly



ALWAYS replace fasteners with new OEM parts. DO NOT reuse bolts, bearing strap, or locking plates.

ENSURE that the driveshaft halves are installed "in phase". If the alignment marks are not evident, then assemble the shafts so the lugs (ears) of the slip yoke are in line with the lugs (ears) of the tube yoke. This will ensure that the yokes are "in phase".

DO NOT use a hammer to seat the bearing caps into the yoke bores. A steel hammer can cause the yoke or bearing cap to crack and break off. Serious personal injury and damage to the trunnion, yoke or bearing cap can result.

1. Lubricate the splines and slide the shaft pieces together, using the alignment marks as a guide for proper reassembly.

## ™NOTE:

The alignment marks ensure that the two shafts are "in-phase". If the alignment marks are not evident, then assemble the shafts so the lugs (ears) of the slip yoke are in line with the lugs (ears) of the tube yoke. This will ensure that the yokes are "in-phase".

- 2. Install a universal joint cross into the yoke.
- 3. Position the trunnion portion of the u-joint cross fully into the yoke bore

#### ™NOTE:

Positioning the trunnion as far as possible into the yoke bore makes it easier to center and align the bearing cap with the trunnion.

- Install the bearing caps through the yoke bores and onto the universal joint cross trunnions.
- Tap the bearing cap lightly with a leather or rubber mallet to seat the bearing cap into the yoke bores.
- Install bolts and lock plates, but fingertighten only at this time.
- 7. Slide the u-joint cross across to the opposite yoke bore so that the trunnion extends as far as possible into the bore.



DO NOT use a press or excessive force to install the bearing cap. DO NOT strike the "wing" portion of the bearing cap as this will tend to cock the bearing cap in the bore. If the bearing cap does not enter the bore easily with light tapping, then remove and investigate the cause of the misalignment.

- Center the bearing cap over the trunnion and lightly tap into place until the flange of the bearing cap is seated against the yoke.
- Install bolts and lock plates. Torque bolts on both bearing caps to 38 to 41 ft-lb. (51 to 56 Nm).
- 10. Bend up tabs of lock plates so that the tabs seat against the flat of the hex head bolt.
- 11.Balance the driveshaft in accordance with ISO 1940 G16 standard using equipment specifically designed for this purpose. Refer to 8.2. "Driveshaft Specifications" on page 140 in this section for balancing specifications.



### 8.8. Installation



ALWAYS replace fasteners with new OEM parts. DO NOT reuse bolts, bearing strap, or locking plates.

 Inspect the condition of the mating flange/ yokes on the transmission and drive axle to ensure they are clean and undamaged.



DO NOT lift and support the driveshaft by the center shaft. Support should only be provided to the inboard yokes.

- 2. Support the driveshaft and align the universal joint bearing caps in the transmission yoke.
- 3. Install the bearing straps and capscrews into the yoke.



DO NOT seat the bearing cups into the yoke saddle by tightening down the capscrews. Uneven load distribution, yoke bearing rotation, and damage to the straps and yoke nibs can result.

- 4. Using a torque wrench, alternately tighten the capscrews to 115 to 135 ft-lb. (155 to 183 Nm).
- 5. Align the flange on the driveshaft with the flange on the drive axle and install bolts.
- 6. Tighten each bolt uniformly until the face pads of the flanges are properly seated.
- 7. Tighten the bolts in an alternating crosswise pattern. Torque to 81  $\pm$  3 ft-lb. (110  $\pm$  4 Nm).
- 8. Remove the supporting equipment.
- 9. Install driveshaft guard.





# 9. VENDOR SERVICE INFORMATION

The following supplier manuals contain additional reference information.

# 9.1. Meritor Wabco Manual

☐ Maintenance Manual 112 Anti-Lock Braking System (ABS) for Trucks, Tractors, and Buses for E Version ECUs





# **Steering System**

1.	SAFET	ΓΥ	3-1
		fety Procedures	
2.	STEEF	RING SYSTEM	3-2
		scription	
		•	
		intenance	
		bricants & Quantities	
	2.4. Fro	ont End Alignment	
	2.4.1.		
		2.4.1.1. Alignment	
		Front Wheel Alignment Specifications	
	2.5. Wh	neel Alignment Adjustments	
	2.5.1.		
		2.5.1.1. Mechanical Steering Stop Adjustment	
		2.5.1.2. Automatic Plunger Adjustment	
	2.5.2.		
	2.5.3.	3	
	2.5.4.		
	2.5.5.	- · · · · · · · · · · · · · · · · · · ·	
	2.5.6. 2.5.7.	•	
	_	· · · · · · · · · · · · · · · · · · ·	
		de Height	
	2.6.1.		
	2.6.2.	,	
		eering Column	
	2.7.1.		
	2.7.2.		
	2.7.3.	The state of the s	
		2.7.3.1. Removal	
		2.7.3.2. Installation	
	2.7.4.	2.7.3.3. Functional Test	
		2.7.4.1. Functional Test	
	2.7.5.		
	2.7.6.	•	
	2.7.7.		
	2.7.8.		
	2.7.9.	·	
		eering Driveshafts	
	2.8.1.	•	
	۷.۰.۱.		

# Table of Contents



	2.8.2. Removal	
	2.8.2.1. Upper Vertical Shaft	
	2.8.2.2. Lower Horizontal Shaft	
	2.8.3. Installation	3-22
	2.8.3.1. Upper Vertical Shaft	
	2.8.3.2. Lower Horizontal Shaft	
	2.8.4. Functional Tests	3-22
2.9	. Steering Damper	3-23
	2.9.1. Description	3-23
	2.9.2. Operation	3-23
	2.9.3. Steering Damper Specifications	3-24
	2.9.4. Removal	3-24
	2.9.5. Installation	3-24
2.1	0. Drag Link	3-25
	2.10.1. Description	
	2.10.2. Drag Link Specifications	
	2.10.3. Operation	
	2.10.4. Inspection	
	2.10.5. Ball Joint End Lift Measurement	
	2.10.6. Removal	
	2.10.7. Ball Joint Replacement	
	2.10.8. Installation	
2.1	1. Steering Miter Box	
	2.11.1. Description	
	2.11.2. Steering Miter Box Specifications	
	2.11.3. Operation	
	2.11.4. Removal	
	2.11.5. Installation	
	2.11.6. Functional Tests	
2 1	2. Power Steering Gear	
۷. ۱	2.12.1. Description	
	2.12.1. Description 2.12.2. Power Steering Gear Specifications	
	2.12.3. Operation	
	2.12.4. Power Steering Gear Troubleshooting	
	2.12.5. Removal	
	2.12.6. Disassembly	
	2.12.7. Cleaning & Inspection	
	2.12.8. Auto Plunger Repair	
	2.12.9. Assembly	
	2.12.10.Installation	
	2.12.11.Bleeding Power Steering Hydraulic System	
	2.12.11.Bleeding Fower Steering Hydraulic System	
	2.12.12.1 ullullullar 16515	3-42
H	YDRAULIC SYSTEM	3-43
3.1		
	Power Steering Pump	
J.2	3.2.1. Description	
	3.2.2. Power Steering Pump Specifications	
	3.2.2. Fower steering rump specifications	3-43

3.









3.2.3.	Pump Operation	3-44
	Removal	
	Installation	
	Power Steering Pump Troubleshooting	
	servoir	
3.3.1.	Description	3-47
	Maintenance	
	Pressure Filling	







# 1. SAFETY

# 1.1. Safety Procedures

This section of the service manual contains procedures which require the mechanics to strictly observe safety procedures in order to ensure personal and equipment safety.

Refer to the General Information Section of this manual for information on types of hoists, hoisting procedures, jackstands and related safety information. Refer to this information and read carefully before lifting, hoisting or jacking the vehicle.

Always ensure that the vehicle is appropriately hoisted and blocked for procedures which require elevating the vehicle. Be aware of the limitations of the blocking equipment, and always ensure that the jarring and shaking created by component removal and installation procedures does not overload the blocks, or cause the vehicle to become unstable.

Certain procedures may require the vehicle be operated in an elevated position in order to accurately troubleshoot and diagnose a problem. If the vehicle must be running while elevated, become familiar with the repair area prior to starting the engine. Take special care in noting areas which will become hot, electrically energized, and areas where moving and rotating components are located. Limit the work in these areas as personal and equipment safety is at risk.

For procedures which involve air lines, ensure the line is safely depressurized prior to disconnecting. Disconnecting pressurized lines will cause solid particles deposited in the line to be uncontrollably propelled, and will also cause the hose end to whip randomly as the air escapes.



# 2. STEERING SYSTEM

# 2.1. Description

The power steering system controls the movement of the front axle steering components and the front wheels. The steering system is hydraulically power-assisted. The major components of the steering system include:

- ☐ Steering Column
- Steering Driveshafts

Steering Damper
-----------------

- □ Drag Link
- ☐ Steering Miter Box
- Power Steering Gear
- ☐ Hydraulic System

# ™NOTE:

Refer to 3. "HYDRAULIC SYSTEM" on page 43 in this section for more information on the hydraulic system components.



### 2.2. Maintenance

The steering system requires little maintenance. However, care should be taken to keep system components and fluid free of contaminants to ensure maximum operating performance and trouble-free service. The following operations may be accomplished without removing steering components from the vehicle:

 Check and if necessary, tighten all steering gear mounting bolts, pitman arm retaining nut, drag link to steering arm retaining nuts. Check witness marks and check for wear in steering linkage and other components before making adjustments to steering gear assembly. Refer to "Front Suspension Torque Specifications" in Section 1 of this manual for torque values.

# ™NOTE:

Reapply witness marks after torquing any fasteners.

- Check front end alignment as indicated in this section.
- Prevent internal bottoming of steering gear by carefully checking axle stops periodically. Axle stops should be set to specification. Refer to 2.5.1. "Steering Stops" on page 5 in this section for specification.
- Check lube level for steering gear and components to prevent malfunction due to inadequate lubrication.
- 5. Maintain correctly inflated tires.
- 6. Always use a "puller", never use a torch or hammer to remove steering arms.
- Always carefully examine all steering parts which have been subject to "impact" and replace any that are damaged.
- Correct cause of any play, rattle, or shimmy in any part of the linkage of steering mechanism.
- Encourage operators to report any malfunction or accident that could have damaged the steering mechanism.

- Do not attempt to weld any broken steering components. (Replace only with original equipment.)
- 11.Do not severely cold-straighten any steering system part.
- 12.Do not heat-straighten or bend any steering system part.
- 13. Always use new original equipment seals and O-rings during repairs and overhauls.
- 14. Replacement of single bearing assemblies, or balls, if one or more make a "set" is not recommended.
- 15. Excessive heat will develop if any power steering gear is held in an extreme right or left turn longer than a few seconds. (Heat developed can damage seals and/or pump.)
- 16.Use care to prevent even minor hydraulic leaks from continuing.
- 17. Prevent dirt or foreign particles from entering hydraulic steering systems. (Always clean off around filler caps, before removing, to check oil supply). When the slightest evidence of dirt, sludge, or water is discovered in the system, drain and refill with clean recommended steering fluid.
- 18. The steering fluid level in the pump reservoir should be checked and fluid added when required. Refer to the Preventive Maintenance Section of this manual for lubrication intervals and fluid specifications.
- 19. Change reservoir filters as required. Refer to the Preventive Maintenance Section of this manual for filter change intervals.
- 20. Air in the fluid system will cause spongy action and noisy operation. When any hose has been disconnected or when fluid has been lost for any reason, system must be bled after adding fluid. Refer to 2.12.11. "Bleeding Power Steering Hydraulic System" on page 42 in this section for system bleeding procedure.



### 2.3. Lubricants & Quantities

The fluid used in the power steering system is the medium by which hydraulic pressures are applied and relieved, under control, to effect steering assist. The fluid also lubricates moving parts and dissipates heat.

The hydraulic reservoir must be kept filled to the proper indicator level and free of air. When filling the reservoir, start the engine and turn the steering wheel from left to right and continue filling until proper level is maintained. Refer to 2.12.11. "Bleeding Power Steering Hydraulic System" on page 42 in this section for system bleeding procedure.

A filter is included with the hydraulic reservoir. Replace this filter when changing the hydraulic fluid. Refer to 3.3. "Reservoir" on page 47 in this section for procedure.

# 2.4. Front End Alignment

# MOTE:

If the steering system is out-of-adjustment, inspect the steering arm for damage. Use a magnetic particle or liquid penetrant inspection procedure to inspect the steering arm. Pay particular attention to the bend, the taper and the area near the ball stud.

#### 2.4.1. Introduction

Check the front wheel alignment when the following occur:

- 1. When the vehicle does not steer correctly.
- 2. To correct a tire wear condition.

### ™NOTE:

Refer to the Preventive Maintenance Section of this manual for alignment intervals.

#### 2.4.1.1. Alignment

Do the major front wheel alignment in the following sequence:

 Set the tire pressure to manufacture setting.

- 2. Inspect all the systems that affect the wheel alignment.
- Set the vehicle ride height. Refer to 2.6. "Ride Height" on page 14 in this section for adjustment procedure.
- Check and adjust the wheel bearings. Refer to Section 1 of this manual for adjustment procedure.
- Check and adjust the maximum turn angle. Refer to 2.5.1. "Steering Stops" on page 5 in this section for procedure.
- Check and adjust the pressure relief in the power steering system. Refer to 2.5.1. "Steering Stops" on page 5 in this section for procedure.
- Check the king pin angle (steering axis) inclination). Refer to 2.5.4. "King Pin Inclination" on page 10 in this section for procedure. Inspect king pin axial play. Refer to "Steering Knuckle" in Section 1 of this manual for procedure.
- Check the camber angle. Refer to 2.5.5. "Camber Angle" on page 11 in this section for procedure.
- Check the caster angle. Refer to 2.5.6. "Caster Angle" on page 12 in this section for procedure.
- 10. Check and adjust the toe-in. Refer to 2.5.7. "Toe-In Adjustment" on page 13 in this section for procedure.

# 2.4.2. Front Wheel Alignment Specifications

Front Axle Set Back	0.0 ± 0.1° Max.
Rear Axle Thrust Angle	0.0 ± 0.1° Max.
King Pin	7°
Camber	1.0°
Caster	$3 \pm 0.5^{\circ}$ positive
Toe-In	0.08"
LH-RH Max. Wheel Cut	0.38"
Power Steering Relief	Automatic

# **Wheel Alignment Adjustments**

# 2.5. Wheel Alignment Adjustments

# 2.5.1. Steering Stops

The travel of the steering system is limited by mechanical stops on the steering knuckle and a hydraulic relief setting within the power steering gear.

- ☐ The mechanical stops on the steering knuckle provide a safe minimum clearance between the tire and the chassis.
- ☐ The hydraulic power steering relief provides a means of relieving hydraulic pressure prior to contacting the mechanical steering stop and determines the maximum usable wheel cut or steering angle. Hydraulic relief is provided by automatic relief valve plungers located in the bearing cap and cylinder head.

#### 2.5.1.1. Mechanical Steering Stop Adjustment

The mechanical left-hand and right-hand steering stops are factory preset to obtain a minimum clearance of 0.38" between the tire and the chassis, suspension, or steering components. The maximum usable steering cut is determined by the power steering relief valve which is automatically set to relieve before the axle stop bolt contacts the axle boss. See "Fig. 3-1: Turn Angle & Tire to Frame Clearance" on page 5.

During the alignment process the mechanical steering stops may need to be reset.

To achieve the required maximum steering angles, first adjust the front axle left and right-hand stop bolts. Proceed as follows:

 Park vehicle on level surface and chock rear wheels.

- Raise the vehicle and place jack stands under the front axle. Tire must clear the ground and be free to turn fully left and right.
- 3. Loosen mechanical stops on axle and screw them in all the way.
- Turn wheels fully left until a gap of 0.38" exists between the tire and any vehicle component.
- 5. Adjust axle stop until it just contacts the axle. Torque the lock nut 50  $\pm$  5 ft-lb. (68  $\pm$  7 Nm).
- Repeat steps 4 and 5 with the wheels turned fully right.
- Reset the automatic plungers. Refer to 2.5.1.2. "Automatic Plunger Adjustment" on page 6 in this section for reset procedure.




Fig. 3-1: Turn Angle & Tire to Frame Clearance



### 2.5.1.2. Automatic Plunger Adjustment

The automatic plungers are preset at the factory and do not require adjustment unless the mechanical steering stop setting has changed. Reset the automatic plungers as follows:

- 1. Park the vehicle on level ground, set the parking brake, and chock the rear wheels.
- 2. Raise the front axle until the tires clear the ground. Refer to the General Information section of this manual for further information on the jacking procedure.
- Remove the plastic cap from both steering gear plungers.



Carefully insert the punch into the bore to ensure the bore is not damaged during bottoming of plungers. DO NOT use a screwdriver to perform this procedure. Ensure there are no sharp edges on the punch which could damage the bore. DO NOT use excessive force when seating the plunger.

4. Carefully insert a 1/4" punch into each plunger hole and drive in the plunger until it bottoms in the bore.

### ™NOTE:

There is restricted working space between the steering gear bearing cap and the wheel housing. Use a shortened punch and lever the punch into the bore with a pry bar, being careful not to use excessive force.

- Start the vehicle and slowly turn the wheels fully left with the tires still off the ground. Continue turning the wheel until the mechanical stop is reached. This will reset the automatic plunger.
- 6. Repeat the previous step, except turn the wheel fully right.
- 7. Return the wheels to the straight ahead position.
- 8. Shut off the engine and lower the vehicle.
- 9. Remove chocks from rear wheels.



#### 2.5.2. Front Axle Setback

Front axle setback must be checked and adjusted to ensure that the front axle is 90° to the vehicle centerline and tracks properly.

Setback Specification ......0.0 ± 0.1°

- Park vehicle on level surface and set parking brake.
- 2. Install computerized alignment equipment.

### ™NOTE:

The vehicle wheel alignment and setback angle were adjusted at the factory using computerized equipment. New Flyer recommends the use of similar equipment when performing alignments.

3. Check setback angle on computer screen. Ensure reading is within specification.

# ™NOTE:

An out-of-specification positive reading indicates shimming is required on the streetside upper radius rod. An out-of-specification negative reading indicates shimming is required on the curbside upper radius rod.

 Select shims as required to correct adjustment to specifications. Each shim consists of an M14 hardened washer that measures 0.10" thick.

#### ®NOTE:

DO NOT exceed three shims in any one location, as this will affect bolt thread engagement. ALWAYS place shim between the cross-pin of the upper/lower radius rod and the vehicle frame.

 Loosen radius rod to frame attaching bolts on the side requiring adjustment. See "Fig. 3-2: Front Setback Angle Adjustment" on page 7.

# ™NOTE:

Adjust the number of shims equally on the upper and lower radius rods so as not to disturb the caster angle.

- 6. Remove one bolt and use a pry bar to force radius rod away from mount.
- Install shim and bolt. Thread bolt part way into bolt hole.
- 8. Repeat procedure at other bolt.
- 9. Torque radius rod bolts to specification. Refer to Section 1 of this manual for front suspension torque specifications.
- Recheck setback angle to ensure it conforms to specification.
- 11. Check and adjust caster angle as necessary.




Fig. 3-2: Front Setback Angle Adjustment



### 2.5.3. Rear Axle Thrust Angle

Rear axle thrust angle must be checked and adjusted to ensure that the rear axle is 90° to the vehicle centerline and tracks properly.

Thrust Angle Specification ......0.0 ± 0.1°

- Park vehicle on level surface and set parking brake.
- 2. Install computerized alignment equipment.

# RNOTE:

The vehicle wheel alignment and thrust angle were adjusted at the factory using computerized equipment. New Flyer recommends the use of similar equipment when performing alignments.

3. Check thrust angle on computer screen. Ensure reading is within specification.

# ™NOTE:

An out-of-specification positive reading indicates shimming is required on the streetside upper/lower radius rod. An out-of-specification negative reading indicates shimming is required on the curbside upper/lower radius rod.

 Select shims as required to correct adjustment to specifications. The shims consist of a 3/4" hardened washer that measures 0.125" thick.

# ™NOTE:

DO NOT exceed three shims in any one location, as this will affect bolt thread engagement. ALWAYS place shim between the cross-pin of the upper/lower radius rod and the vehicle frame.

# **Wheel Alignment Adjustments**

 Loosen radius rod to frame attaching bolts on the side requiring adjustment. See "Fig. 3-3: Rear Thrust Angle Adjustment" on page 9.

# ™NOTE:

Adjust the number of shims equally on the upper and lower radius rods so as to not disturb pinion angle.

6. Remove one bolt and use a pry bar to force radius rod away from mount.

- 7. Install shim and bolt. Thread bolt part ways into bolt hole.
- 8. Repeat procedure at other bolt.
- 9. Torque radius rod bolts to specification. Refer to Section 2 of this manual for rear suspension torque specifications.
- 10. Recheck thrust angle to ensure it conforms to specification.




Fig. 3-3: Rear Thrust Angle Adjustment



# 2.5.4. King Pin Inclination

Specification ......7°

King pin (or steering axis) inclination is the angle measured between the center line of the king pin and the vertical position (as viewed from the front of the vehicle). The king pin inclination and the camber angle put the approximate center of the tire tread in contact with the road. This reduces steering effort and improves directional stability. See "Fig. 3-4: King Pin Inclination" on page 10.

Use an alignment machine to check king pin inclination angle. Follow machine manufacturer's procedures. The king pin inclination is not adjustable. If the inclination is not at the specified angle, check axle beam and knuckle for damage. Service as necessary.




Fig. 3-4: King Pin Inclination



# **Wheel Alignment Adjustments**

### 2.5.5. Camber Angle

Specification ...... 1.0° (not adjustable)



The camber angle is not adjustable. NFI does not recommend changing the camber angle or bending the axle beam. If the axle beam is bent to change the camber angle, the strength of the axle is reduced and the warranty is voided. The axle may be damaged if bent. An axle damaged by bending may cause a vehicle accident and personal injury.

Camber is the angle of the tire with respect to the ground. Camber is positive when the distance between the top of the wheels is greater than the distance at the ground. A small amount of positive camber is built into the knuckle because camber changes with load. This results in a zero camber angle when the vehicle is operated at the normal load. If camber is out-of-specification by more than 1-1/2°, tire wear will occur. See "Fig. 3-5: Camber Angle" on page 11.

The camber angle is not adjustable. The camber angle is machined into the axle beam. If camber angle is not at the specified angle, check the axle beam and the steering knuckle for damage. Service as necessary.

Use an alignment machine to check the camber angle. Follow machine manufacturer's procedures.




Fig. 3-5: Camber Angle



### 2.5.6. Caster Angle

Specification .......  $3 \pm 0.5^{\circ}$  (RH) ......  $3 \pm 0.5^{\circ}$  (LH)

The caster angle is the angle from the vertical position to the center line of the king pin when seen from the side of the vehicle. See "Fig. 3-6: Caster Angle" on page 12. If the top of the king pin axis is toward the rear of the vehicle, the caster is positive.

Positive caster creates a self-aligning movement to stabilize the vehicle when driving straight ahead. If caster is too much, steering effort will increase or may amplify a shimmy condition.

Left and right-hand caster can be set independently. Adjust caster angle as follows:

- Park vehicle on level surface and set parking brake.
- 2. Install computerized alignment equipment.

#### ™NOTE:

The vehicle wheel alignment angles were adjusted at the factory using computerized equipment. New Flyer recommends the use of similar equipment when performing alignments.

3. Check caster angle on computer screen. Ensure reading is within specification.

#### ™NOTE:

Excessive positive caster reading indicates shims need to be either removed from the upper radius rod or added to the lower radius rod. Insufficient positive caster reading indicates shims need to be either added to the upper radius rod or removed from the lower radius rod. In order to determine the location where shims should be added or removed, determine the existing front axle setback angle and assess which method will be most advantageous to keeping setback angle within specification.

3 - 12

 Select shims as required to correct adjustment to specifications. Each shim consists of an M14 hardened washer that measures 0.10" thick.

# ™NOTE:

DO NOT exceed three shims at any one location. Ensure that adequate bolt thread engagement remains with the addition of shims. ALWAYS place shim between cross-pin of the radius rod and the vehicle frame.

- 5. Loosen radius rod to frame attaching bolts on the radius rod requiring adjustment.
- 6. Remove one bolt and use a pry bar to force radius arm away from mount.
- Install shim and bolt. Thread bolt part ways into bolt hole.
- 8. Repeat procedure at other bolt.
- Torque radius rod bolts to specification. Refer to Section 1 of this manual for front suspension torque specifications.
- 10. Recheck caster angle to ensure it conforms to specification.




Fig. 3-6: Caster Angle



# **Wheel Alignment Adjustments**

### 2.5.7. Toe-In Adjustment

Specification	0.0 to 0.08"(total toe)
	0.0 to 0.04 (RH)
	0.0 to 0.04 (LH)

Toe is the relationship of the distance between the front of the front tires and the rear of the front tires. When the front distance is less than the rear distance, the wheels are "toed-in". Toe-in is designed into the vehicle to counteract the tendency of the tires to toe-out when the vehicle is driven. Incorrect toe-in will result in rapid tire wear.



Most tire wear is caused by incorrect toe settings. DO NOT change camber or caster settings to correct tire wear problems. If the axle assembly is bent to change caster or camber, the strength of the axle is reduced and the warranty is voided. An axle damaged by bending may cause a vehicle accident and personal injury.

 Use an alignment machine to check toe setting. Follow machine manufacturer's procedures.

#### ™NOTE:

DO NOT measure toe-in with the front axle in the raised position. The weight of the vehicle must be on the front axle when toe-in is measured.

- If the toe measurement is not at the specified distance, refer to the following procedure:
  - a. Loosen the tube clamp nut and bolt on each end of the Center Link.
  - Rotate adjusting sleeves on Center Link until the specified toe-in distance is obtained.
  - c. Tighten the nut and bolt on each end of the Center Link to 130 ft-lb. (176 Nm).



# 2.6. Ride Height

# 2.6.1. Description

Ride height is measured between the axle and the rubber stop mounted to the frame of the vehicle. See "Fig. 3-7: Ride Height Adjustment" on page 14. Specifications are as follows:

- ☐ Front Ride Height 4.0" (Dim A)
- ☐ Rear Ride Height 3.8" (Dim B)

# ™NOTE:

Fabricate square spacers of corrugated cardboard to assist in measurement.

Vehicle ride height is adjusted by changing the length of the leveling valve link arm or by changing the link arm anchoring hole position in the link arm anchor mounting bracket. There are two leveling valves at the rear of the vehicle and one at the front. Adjustments on the two rear link arms change the tilt of the vehicle as well as the ride height. Adjustments on the front link arm changes height only.




Fig. 3-7: Ride Height Adjustment



### 2.6.2. Measurement & Adjustment

# ™NOTE:

If ride height measurements indicate the vehicle is tilted, correct tilt through height adjustment on the rear axle only.

- Check for restricted air lines which impair leveling valve operation.
- Bring air suspension to normal operating pressure.
- 3. Measure ride height at specified points.
- 4. If ride height does not meet specifications adjust to specified height as follows:
  - a. Loosen the gear clamp on the leveling link.
  - Set the ride height of the vehicle by manually moving the leveling valve lever until the specified ride height is achieved.
  - c. Return leveling valve lever to the neutral position and tighten the gear clamp on the leveling link.
- 5. Replace leveling valve if it fails to maintain set vehicle ride height.

# 2.7. Steering Column

#### 2.7.1. Removal



NEVER remove the steering column upper retaining ring. This could lead to loss of components.

- Telescope the steering column out to its most outward position, and center the steering wheel.
- Tilt the column all the way down, and pull the upper cover off by grasping the cover at the bottom, closest to the dash. See "Fig. 3-8: Steering Column Installation" on page 16.
- Tilt the column all the way up, and pull the lower cover off by grasping cover at the bottom, closest to the dash.
- Pry out horn button and disconnect horn wire.
- 5. Remove steering wheel retaining nut if steering wheel is to be removed.
- 6. Use a puller to remove steering wheel.
- 7. Unbolt U-joint under floor board. Remove steering column clamps.
- 8. Disconnect wiring attached to column.
- Remove steering column from vehicle. See "Fig. 3-9: Steering Column Assembly" on page 17.






Fig. 3-8: Steering Column Installation




Fig. 3-9: Steering Column Assembly

#### 2.7.2. Installation

- Install steering driveshaft if previously removed. Refer to 2.8. "Steering Driveshafts" on page 22 in this section for installation procedure.
- With the help of an assistant, install the steering column and loosely install the upper and lower steering column clamps. Ensure the splines on the end of the steering column fully engage the driveshaft clamp.
- Measure the distance between the tilt pivot point on the steering column and the driver's platform flooring. Pull up on the steering column until the tilt pivot point is

- 19.79" from the floor. Torque the nuts on the upper and lower steering column clamps to 17 ft-lb. (23 Nm).
- 4. Torque driveshaft clamp bolts to 50 ft-lb. (68 Nm).
- 5. Center and install steering wheel and steering wheel nut. Torque nut  $60 \pm 5$  ft-lb.  $(82 \pm 7 \text{ Nm})$ .
- 6. Tilt the column all the way up and reinstall the lower cover.
- 7. Tilt the column all the way down and reinstall the upper cover.
- 8. Hook up and install horn button.



### 2.7.3. Knob Replacement

#### 2.7.3.1. Removal

Loosen the 5/16" nut, and then remove knob by turning it in a counter-clockwise direction.

#### 2.7.3.2. Installation

Thread the new knob on by turning it in the opposite direction. Retighten the 5/16" nut until it contacts the knob. Turn the nut 1/4 turn to tighten it.

### 2.7.3.3. Functional Test

- 1. Tilt and telescope the column to ensure the column still functions properly.
- Pull up and push down on the steering wheel to ensure the shaft and retaining rings are seated properly
- 3. Test the horn to ensure that it is still functioning properly.
- Turn the steering wheel from full left to full right lock to lock to ensure that the column rotates freely.

# ™NOTE:

Refer to 2.7.1. "Removal" on page 15 and Refer to 2.7.2. "Installation" on page 17 in this section to remove the steering column and replace it with a new one if there are any abnormalities felt as the steering wheel is turned. DO NOT attempt to drive the vehicle with a malfunctioning steering column.

### 2.7.4. Horn Ring Lubrication

# ™NOTE:

This procedure is used to apply dielectric grease to the horn contact ring

- Telescope the column out toward the driver.
- 2. Tilt the column all the way down and pull the upper cover off by grasping the cover at the bottom, closest to the dash.
- Tilt the column all the up and pull the lower cover off, similar to removing the upper cover.
- Start the engine so the hydraulic system is active and the steering wheel can move easily.
- Locate the contact ring
- Using a soft brush, apply the grease liberally (so that contact ring is completely covered) while turning the steering wheel slowly.
- 7. Reinstall the upper and lower covers in the reverse order that they were removed.

#### 2.7.4.1. Functional Test

Ensure horn is working by verifying its activation at all tilt and telescoping angles and positions.



#### 2.7.5. Rod & Pawl Replacement

- Telescope the steering column out to its most outward position.
- 2. Tilt the column all the way down, and pull the upper cover off by grasping the cover at the bottom, closest to the dash.
- Tilt the column all the way up, and pull the lower cover off by grasping cover at the bottom, closest to the dash.
- Remove the retaining ring and washer from end of pawl rod. See "Fig. 3-10: Rod & Pawl Removal" on page 19.
- Remove pawl from end of rod assembly. Use a plastic hammer to tap rod out of pawl if necessary. Remove spring from pawl.
- 6. Pull roll pin out of rod.
- 7. Tilt steering column all the way up and remove knob from end of actuating lever.

- Slide rod and pawl assembly off actuating lever and casting. Remove spring from pawl.
- Install spring on replacement rod and pawl and slide rod end into casting. Ensure triangular hole in pawl slides over actuating lever.
- 10.Install roll pin into hole on end of rod and pawl assembly. Ensure roll pin sticks out an equal distance on either side of shaft.
- 11. Install spring on pawl and slide pawl over roll pin end of shaft.
- 12. Install washer and snap ring.
- 13.Install knob on tilt lever and secure with lock nut.
- 14. Tilt the column all the way up and down to ensure the pawl releases completely and engages fully with the teeth on the yoke in the locked position.
- 15. Install upper and lower covers.




Fig. 3-10: Rod & Pawl Removal



#### 2.7.6. Actuating Lever Replacement

- Remove rod and pawl assembly Refer to 2.7.5. "Rod & Pawl Replacement" on page 19 in this section for procedure.
- 2. Remove the roll pin retaining actuating lever to casting.
- 3. Remove spring from actuating lever.
- 4. Install spring on replacement lever.
- 5. Position lever on casting and install roll pin through eye of spring and into casting
- 6. Install rod and pawl assembly.

#### 2.7.7. Trough Cover Replacement

- Remove steering column assembly from vehicle.
- Slide trough cover off tilt bolts and remove from steering column. See "Fig. 3-11: Trough Cover Replacement" on page 20.
- Install replacement trough cover on steering column and snap into place over tilt bolts.
- 4. Install steering column.




Fig. 3-11: Trough Cover Replacement



#### 2.7.8. Gap Hider Cover Replacement

This procedure must be done with the column mounted in the vehicle.

- Using a small flat headed screwdriver, remove the horn button and disconnect the horn wire.
- 2. Using the steering wheel nut socket, remove the steering wheel nut.
- Using a steering wheel puller, remove the steering wheel.

#### RNOTE:

Use the shaft protector provided in this kit to protect the setscrew from the steering wheel puller.

- 4. Remove the existing gap hider cover.
- Install the new gap hider/cover making sure that the flats on the cover match the flats on the shaft. Also ensure that the spring cut end of the last coil is NOT seated on the horn contact.
- Reinstall the steering wheel.
- 7. Reinstall the steering wheel nut, and torque to  $60 \pm 5$  ft-lb.  $(82 \pm 7 \text{ Nm})$ .
- Reconnect the horn wire, and reinstall the horn button.

#### ™NOTE:

Ensure that the horn wire is not trapped by any part of the assembly. The spring cut ends must be 180° away from both horn contacts. The housing and plate may have to be rotated to accomplish this.

- Telescope the steering column all the way to the inner stops, and out to its outer stops, ensuring that the horn does not activate.
- Ensure the horn works correctly when activated.

#### 2.7.9. Functional Test

### ™NOTE:

The following test must be done prior to test driving the vehicle. The following is to be completed with the steering column tilted all the way up, all the way down, and in its center position.

- Start the vehicle to activate the hydraulic steering system.
- Rotate the steering column from full left to full right.
- While rotating the wheel listen and feel for the following;
  - a. Ensure that the rotation does not lock at any point.
  - Feel for ease and or variation in rotation.
  - Listen for any unusual noises (snapping, cracking, or popping) as the steering wheel is being rotated.

## ™NOTE:

If any of the above are present the steering column must be replaced.

- 4. Telescope the column to ensure that the telescopic function was not damaged at any point during the removal. Ensure that the column telescopes up and down freely, while moving it in to its Inner stops and then out to its outer stops.
- During the test drive check the following;
  - a. Ease and or variation in rotation.
  - b. Ensure the wheel begins to return to the center after turning a corner.
  - c. Ensure the wheel does not lock.
  - d. Listen for any usual noises during steering wheel operation.

## ™NOTE:

If any problems are encountered during this procedure the steering column must be replaced.



## 2.8. Steering Driveshafts

## 2.8.1. Description

The steering system uses two sliding driveshaft assemblies to transmit steering inputs from the steering column to the power steering gear. The upper, vertically mounted, shaft is connected to the steering column by means of a universal joint with a splined clamp arrangement.

The lower end of the shaft is similarly attached to the input shaft of the miter box.

The lower, horizontally mounted, driveshaft is connected to the output shaft of the miter box with a splined clamp and universal joint arrangement. The aft end of the driveshaft is similarly attached to the power steering box. The sliding spline configuration allows the shafts to accommodate variations in operating lengths due to angular movements of the shafts.

#### 2.8.2. Removal

#### 2.8.2.1. Upper Vertical Shaft

- Loosen upper shaft clamp bolt and slide shaft down from steering column.
- 2. Loosen lower shaft clamp bolt and slide shaft up from miter box input shaft.

#### 2.8.2.2. Lower Horizontal Shaft

- 1. Loosen forward driveshaft clamp bolt and slide driveshaft off miter box output shaft.
- 2. Loosen aft driveshaft clamp bolt and slide driveshaft off of steering box shaft.

#### 2.8.3. Installation

#### 2.8.3.1. Upper Vertical Shaft

#### ™NOTE:

Ensure the arrows painted on each half of the driveshaft are in phase (pointing towards each other) when the driveshaft is installed. If a new driveshaft is being installed, DO NOT remove the plastic retaining straps until installation is complete.

- Install lower universal joint clamp over miter box input shaft. Tighten clamp bolt to 50 ft-lb. (68 Nm).
- 2. Install upper universal joint clamp over steering column shaft. Tighten clamp bolt to 50 ft-lb. (68 Nm).

#### 2.8.3.2. Lower Horizontal Shaft

- Install aft universal joint clamp over steering box shaft. Tighten clamp bolt 50 ft-lb. (68 Nm).
- Install forward universal joint clamp over miter box output shaft. Tighten clamp bolt 50 ft-lb. (68 Nm).

#### 2.8.4. Functional Tests

## ™NOTE:

Perform the following test prior to test driving the vehicle to ensure the steering system does not bind or lock up.

- 1. Lock the tilt steering in the center position.
- With the engine running and the wheels on the ground steer to a full left and full right turn.
- 3. Check for ease of rotation while steering and listen for any abnormal noises.
- Repeat the steering check with the column tilted and telescoped to the uppermost and lowermost positions.



Correct any problems before test driving the vehicle.

 Perform an inspection of the steering driveshafts and recheck the clamp torques. Apply witness marks to the properly torqued fasteners ensuring the marks cross the bolt-head, driveshaft clamp and the nut.



## 2.9. Steering Damper

## 2.9.1. Description

The steering damper is installed horizontally between the front axle curbside steering arm and the chassis.

## 2.9.2. Operation

The steering damper is intended to absorb any irregular steering inputs that may be caused by bad road conditions or emergency vehicle response maneuvers. The steering damper will assist in maintaining safe control of the vehicle. See "Fig. 3-12: Steering Damper Installation" on page 23.




Fig. 3-12: Steering Damper Installation



#### 2.9.3. Steering Damper Specifications

#### 2.9.4. Removal

- Set the Battery Disconnect switch to the OFF position.
- 2. Raise the vehicle and support it on safety stands. Refer to the General Information Section of this manual for procedure.
- Remove cotter pins from steering damper ball joints.
- 4. Remove castle nuts and washers.
- Use an appropriate tool to separate steering damper from mount assemblies. Exercise care to prevent damaging the ball joint.

#### 2.9.5. Installation

- If steering damper mounting brackets were removed, reinstall as follows:
  - a. Reinstall the bracket to the vehicle frame and torque fasteners to 35 ft-lb. (47 Nm) with Never Seize.
  - Beinstall the bracket to the axle and torque fasteners to 260 ft-lb. (352 Nm) with Loctite.

#### ™NOTE:

Ensure tapered surfaces are clear of all foreign materials.

- Install steering damper into steering damper mount assemblies with the bladder towards the front of the vehicle and the ball joints inserted from the bottom.
- Install castle nuts and washers and torque to 55 ft-lb. (75 Nm) and tighten until cotter pin can be inserted.

## RNOTE:

If unable to insert cotter pin, remove the washer and install without it.

- 4. Install cotter pins into steering damper ball joints to lock castle nuts in place.
- 5. Lower the vehicle.
- 6. Set the Battery Disconnect switch to the ON position.



## 2.10. Drag Link

## 2.10.1. Description

The drag link assembly consists of a tube and two maintenance-free ball joint ends. One end of the tube is threaded and the other end is crimped onto the ball joint end.

#### 2.10.2. Drag Link Specifications

of ball joint ends	ensions 33.03" (839mm)
Front ball joint (pitma socket pin taper	n arm) 1:8
Rear ball joint (axle s socket pin taper	teering arm) 1:10

## 2.10.3. Operation

The rotational output of the steering gear is transmitted axially through the Pitman arm and to the drag link. The drag link transmits this axial movement to the left steering knuckle, causing it to pivot on the king pin axis, and move the wheel.

#### 2.10.4. Inspection

- 1. Inspect condition of tube for damage. Replace tube if damage is evident. Do not attempt to straighten.
- Inspect condition of rubber boot on ball joint ends for splits, cuts, or other damage. Replace ball joint if damage would allow ingress of moisture or foreign matter.
- Inspect ball joint ends for wear. Refer to the following procedure:
  - Ensure that the steered wheels are in the straight-ahead position and are supporting the weight of the vehicle.
  - Rock the steering wheel firmly in both directions against the resistance of the tires. The force should be sufficient to load the steering mechanism and joints.

 Visually examine the ball joints for excessive movement.

## ™NOTE:

The ball joint is designed to have clearance between the socket seat and ball pin when unloaded. The ball joint will appear to move or "kick" when this clearance is taken up under load. DO NOT misinterpret this condition as excessive wear. Perform a ball joint end lift measurement to determine whether wear is within acceptable limits.

d. Perform a ball joint end lift measurement by applying a load through the axis of the pin and measuring its movement relative to the socket body. See "Fig. 3-13: Ball Joint End Lift Measurement" on page 25. Refer to following table for wear limits.

## ™NOTE:

Use a pry bar to apply the load against the ball joint in direction "B". Use a magnetic base dial indicator to measure the axial movement.




Fig. 3-13: Ball Joint End Lift Measurement



#### 2.10.5. Ball Joint End Lift Measurement

BALL JOINT END LIFT MEASUREMENT			
Designed New End Lift	Applied Check Load "B"	Max. Allowable Check Load	Max. Allowable End Lift "A"
0.85 mm (0.033") max	1000 N (225 lb-force)	2200 N (495 lb-force)	2.0 mm (0.079")



DO NOT exceed maximum checking load or damage to internal components of the ball joint could result.

#### 2.10.6. Removal

- Set the Battery Disconnect switch to the OFF position.
- 2. Raise the vehicle and support it on safety stands. Refer to the General Information Section of this manual for procedure.
- 3. Remove castle nuts. See "Fig. 3-14: Drag Link Installation" on page 27.

 Use an appropriate tool to separate drag link from the axle steering arm and Pitman arm. Exercise care to prevent damaging the rubber boot.

## ™NOTE:

The ball joint end that attaches to the axle steering arm is crimped onto the drag link and cannot be replaced individually.






Fig. 3-14: Drag Link Installation

## 2.10.7. Ball Joint Replacement

## ™NOTE:

Only the ball joint installed into the steering gear's pitman arm can be replaced. If the ball joint on the axle's steering arm needs to be replaced, the entire drag link must be replaced.

1. Loosen the end clamp.

- 2. Unthread the ball joint end from the drag link.
- Thread new ball joint into the drag link and ensure the center-to-center length is correct. See "Fig. 3-15: Drag Link Adjustment" on page 28.
- 4. Torque clamp to 59 to 70 ft-lb. (80 to 95 Nm).






Fig. 3-15: Drag Link Adjustment

#### 2.10.8. Installation

- 1. Adjust the ball joint end on the pitman arm end of the drag link so that it is in the same vertical plane as the crimped ball joint at the opposite end of the drag link.
- 2. Ensure center-to-center length is 33.03" (839mm).
- 3. Install drag link.

## ™NOTE:

The front and rear ball joint ends have different socket pin tapers. Ensure that ball joint end with the shallow taper (1:8) is installed in the Pitman arm.

- Use anti-seize compound on threads and torque castle nuts 95 to 115 ft-lb. (129 to 156 Nm).
- 5. Torque ball joint end clamp bolts 59 to 70 ft-lb. (80 to 95 Nm).



## 2.11. Steering Miter Box

## 2.11.1. Description

The steering miter box transfers inputs from the steering column to the lower (horizontal) steering driveshaft and to the steering gear box.

#### 2.11.2. Steering Miter Box Specifications

Manufacturer	.R.H. Sheppard Co.
Operating Angle	90°
Lubrication	Grease Fitting
Gear Ratio	1 to 1
Torque Rating	400 in-lb.

### 2.11.3. Operation

The upper end of the steering miter box is attached to the steering column U-joint assembly and receives steering inputs from the steering wheel. A set of bevel gears in the steering miter box changes drive direction 90° and outputs through the lower steering driveshaft to the steering gear.

#### 2.11.4. Removal

1. Raise vehicle and support on safety stands. Refer to the General Information Section of this manual for procedure.

- 2. Remove steering box access panel.
- Working from underneath vehicle, remove U-joint clamping bolt at each end of the miter box.
- 4. Slide U-joints off gearbox input and output shafts.
- 5. Remove three bolts retaining gearbox to mounting plate and remove gearbox.

#### 2.11.5. Installation

- Position steering miter box on mounting bracket and install three mounting bolts. Apply Loctite-242 and torque bolts 25 to 30 ft-lb. (34 to 40 Nm).
- Slide input and output shaft U-joints onto splined shafts of gearbox.
- Install retaining bolts and torque 50 ft-lb. (68 Nm).
- 4. Install grease fitting. Lubricate with NLG2 chassis lube.

#### 2.11.6. Functional Tests

- 1. Turn steering wheel to a full left and full right turn to check for free operation.
- 2. Test drive vehicle.



## 2.12. Power Steering Gear

## 2.12.1. Description

The power steering gear consists of a sector shaft, geared piston and torsion bar operated control valve installed in the steering gear housing. The assembly is bolted to the frame of the vehicle under the operator's platform.

# 2.12.2. Power Steering Gear Specifications

#### ™NOTE:

A number is cast into the steering gear housing and identifies the basic family to which the steering gear belongs. A serial number is also assigned to each steering gear. Stamped letters and numbers on an exposed machined surface of the housing opposite the mounting side, identifies the gear specification.

Manufacturer	R.H. Sheppard Co.
Input Torque	45 in-lb max @100 psi
Pressure Relief	1,850 psi (12,755 kPa)
Minimum Pump Flow	3.5 gpm (16.1 L/m)

#### 2.12.3. Operation

Steering wheel movement is transmitted to a 90° gear box and driveshaft to the power steering gear input shaft. In neutral the rotary valve is centered by a torsion bar and equal low pressure is applied to both ends of the steering gear piston. Hydraulic oil circulates at back pressure only and provides a cushion and cooling for the internal parts. Rotary valve actuation by the steering wheel working against the torsion bar causes higher pressure to build up on one end of the piston. This pressure differential causes the piston to move in the bore of the gear housing, transmitting a rotary motion to the output shaft and Pitman arm. The drag link transfers this movement to the front axle steering arm to steer the vehicle.

When steering rotation stops, the rotary valve returns to neutral. Automatic relief valve plungers unload the hydraulic pressure when wheels are in a full turn in either direction.



## 2.12.4. Power Steering Gear Troubleshooting

POWER STEERING GEAR TROUBLESHOOTING		
PROBLEM	CAUSE	
Oil leak at steering input shaft.	Worn or damaged seal.	
Oil leak at output shaft.	Worn or damaged sector shaft seal.	
Oil forced out of reservoir or foaming.	Relief plungers not adjusted correctly creating high oil temperature.	
Wheel full turn restricted.	Relief plungers not adjusted correctly.	
Wheels turn hard in one direction.	Foreign material in relief ball seat in piston of steering gear.	
Hard steering or no return to straight ahead from turns.	Steering gear mounting distorted.	
Darting or wandering.	Air trapped in steering gear. Loose or worn internal parts.	

#### 2.12.5. Removal

- 1. Open the side console access door.
- 2. Raise vehicle to a suitable working height. Refer to the General Information Section of this manual for lifting procedure.
- Open the three steering gearbox access doors.

#### ™NOTE:

The two hinged lower access doors may be removed at the hinged end to eliminate interference when working beneath the vehicle.

 Loosen the clamp bolt and disconnect steering driveshaft from steering gear input shaft.

## ™NOTE:

Mark relative position of U-joint with input shaft before removal.

5. Disconnect the pressure and return hoses and from steering gearbox and cap the hoses. See "Fig. 3-16: Steering Gearbox Removal & Installation" on page 32.

- Note the installed angle of the diagnostic fitting and remove from steering gearbox.
- Remove cotter pin and castle nut retaining pitman arm to drag link and disconnect drag link from pitman arm using a two-jaw puller.

#### ™NOTE:

It may be necessary to loosen the five mounting bolts to allow sufficient movement of the steering gearbox and disengagement of the drag link.



The steering gearbox weighs approximately 110 lbs. ALWAYS use appropriate lifting equipment and the assistance of another person when removing or installing the steering gearbox.

8. Position lifting equipment beneath the steering gearbox support plate and support the weight of the steering gearbox.



9. Remove fasteners that secure the support plate to the vehicle structure.

## ™NOTE:

Use a shallow 1 1/8" socket to access the bolt head at the aft end of the support plate.

10. Carefully lower the steering gearbox from the vehicle and move to a work bench.

## ™NOTE:

The pitman arm may need to be rotated and the steering gearbox angled upwards in order to clear the vehicle structure during the lowering and removal process.

11. Remove the five bolts and spacers that secure the support plate to the steering gearbox.




Fig. 3-16: Steering Gearbox Removal & Installation



#### 2.12.6. Disassembly

- 1. Remove Pitman arm as follows:
  - Use a small punch and ball peen hammer to bend out two locking tabs on Pitman arm retainer. Do not bend tabs located in slot on Pitman arm.
  - b. Coat face of retainer with grease.
  - c. Slide Pitman arm puller over Pitman arm and remove retainer. Retainer will act as a jack screw against puller to remove arm.



The Pitman arm will be extremely tight. NEVER strike directly on the arm or apply any source of heat to it. Damage to the arm or sector shaft may result, which could lead to a vehicle accident. NEVER weld the Pitman arm or sector shaft.

 Remove sector shaft rubber boot and snap ring cover. See "Fig. 3-17: Sector Shaft Boot & Cover Removal" on page 34.

## ™NOTE:

Use a small chisel or punch and tap lightly against the snap ring cover to remove.

- Remove and discard the input shaft dust boot.
- 4. Remove sector shaft snap ring.
- 5. Remove dust cover from opposite end of sector shaft. See "Fig. 3-18: Sector Shaft Dust Cover Removal" on page 34.
- Use a soft-faced hammer and tap on the opposite end of the sector shaft until bearing cap is driven out of gearbox housing.
- 7. Carefully slide sector shaft out of housing.
- 8. Remove O-ring and backup seal from bearing cap.

## ™NOTE:

Take care when removing the excluder seal. DO NOT damage the seal bore.

- Remove internal excluder seals from the gearbox housing (sector shaft bore) and from the sector shaft bearing cap. See "Fig. 3-19: Cover & Sector Shaft Seal Removal" on page 35.
- 10.Use a center punch to make reference marks on the steering gear housing and the bearing cap housing to aid in reassembly. See "Fig. 3-20: Bearing Cap & Housing Reference Marks" on page 35.



DO NOT attempt to turn the shaft out of the piston. The recirculating balls must be removed before the shaft can be removed. Shaft damage will occur if it is forced out of the piston.

11.Remove attaching bolts from bearing cap. Turn input shaft until the plunger clears the piston.



The ball guide retainer must be held in place when sliding the piston out of the housing. Recirculating balls can be lost if the retainer is not held in place.

 Carefully slide piston and bearing cap from housing bore until ball guide retainer is exposed.

#### ™NOTE:

It may be necessary to rotate the piston to locate the ball guide retainer.



DO NOT crack the ball guide retainer during this operation.



13.Insert a small sheet metal screw into ball guide retainer until two or three threads of screw are engaged. Use small pliers to remove retainer from piston. See "Fig. 3-21: Ball Guide Retainer Removal" on page 35.

#### ™NOTE:

DO NOT remove the piston at this time. Leave it in the housing with the ball guide exposed.

- 14. Remove the ball return guides. The steel balls are then free to roll out of the ball cavity in the piston.
- 15. Carefully rotate shaft in and out several times to free all balls from piston.
- 16. After removing all 24 balls, remove bearing cap and input shaft from piston.
- 17. Carefully slide piston out of housing.

#### ™NOTE:

DO NOT force the shaft. The shaft will slide freely from the piston if all 24 balls are removed.

- 18. Remove the teflon piston ring and energizing O-ring from the piston.
- 19. Remove the seal ring and tetra seal from the bearing cap and shaft assembly.



DO NOT disassemble the bearing cap and shaft assembly. There are no serviceable parts in this assembly. Only the input shaft seal is serviceable.

20. Remove cylinder head and discard seal ring and tetra seal.




Fig. 3-17: Sector Shaft Boot & Cover Removal




Fig. 3-18: Sector Shaft Dust Cover Removal




Fig. 3-19: Cover & Sector Shaft Seal Removal




Fig. 3-20: Bearing Cap & Housing Reference Marks




Fig. 3-21: Ball Guide Retainer Removal

#### 2.12.7. Cleaning & Inspection

- Clean parts with solvent and blow dry with low pressure air.
- Inspect piston and piston bore for burrs. Remove by polishing with a fine stone or crocus cloth.
- Inspect thrust washers and bearings on input shaft for excessive wear or damage, replace as required.
- Inspect output shaft for excessive wear or damage to splines, threads or bearing surfaces.



#### 2.12.8. Auto Plunger Repair

- Remove automatic relief valve plungers from both ends of unit as follows:
  - a. Place the bearing cap or cylinder head in a vise. Remove the plastic plug from the auto plunger hole. Using a 1/4" punch and hammer, drive the auto plunger assembly in until it bottoms in the bore. The spring pin, flange and plunger body should be accessible for repair at this point.



Failure to keep the 1/4" punch straight in the bore or hitting the plunger too hard can result in damage to the steering gear or auto plunger assembly.

b. Carefully insert the screw driver bit into the plunger bore to engage the slotted head of the plunger body. Using the 10mm open end wrench to hold the flange across the flat sides, carefully turn the flange to remove the flange from the plunger body.



DO NOT allow the screw driver bit to slip off the plunger body in the process, damage to the bore can result. Discard flange.

#### ™NOTE:

The auto plunger flange is held in place with patch lock and the threads are staked during factory assembly. It will require approximately 15 to 20 in-lb. of torque to remove the flange.

- c. Remove the plunger body from the spring pin and discard. It may be necessary to tap the plunger body to remove it from the spring pin. Use of a 1/8" pin punch is recommended.
- Install automatic relief plungers in bearing cap and rear cover as follows:

a. Coat the O-ring of the plunger assembly with a light coat of grease and install the plunger body through the spring pin.



Check the plunger bore for nicks or gouges before installing the plunger assembly. Take care not to introduce dirt or contaminants in the plunger bore when reassembling.

b. Use the screw driver bit and ratchet to hold the plunger body. Screw the flange onto the plunger body using a 10mm open end wrench until the flange contacts the spring pin.

#### RNOTE:

The plunger body has patch lock on the threads and will require approximately 15 to 20 in-lb. of torque to overcome the patch lock.



The flange must contact the spring pin. Steering gear damage or a leak can result.

c. With the flange against the spring pin, use the center punch to stake the threads of the plunger body. Take care not to bend the plunger when staking the threads.



Use extreme caution when staking the threads of the plunger body. Hitting the threads too hard will bend the plunger and cause steering failure.

d. Install plastic caps over plungers.

#### ™NOTE:

Refer to 2.12.10. "Installation" on page 41 in this section for correct setting of automatic relief valve plunger.



#### 2.12.9. Assembly

 Install new seal ring on end of piston by placing backup O-ring in piston groove and installing teflon seal over it.

### ™NOTE:

The teflon seal will stretch as it is fitted over the ring groove. Use a ring compressor to prevent damage to the piston ring. Allow the piston to sit with the seal rings in place so they will shrink to ease installation in the piston bore.



DO NOT press on the lip of the seal.

#### ™NOTE:

The sector shaft seal is a two-piece seal. It will be necessary to bend the seal for installation. Once the seal is installed you may have to work the seal into place with your fingers or a blunt seal pick to properly seat the seal. Press only on the body of the seal.

- Install sector shaft seal in housing and coat with oil. See "Fig. 3-22: Sector Shaft Seal Installation" on page 39. Ensure lip of seal is toward housing and blue side of seal faces outward.
- 3. Lightly coat piston and piston bore with oil.



Exercise care when inserting the piston into the housing. It is a close tolerance fit and may jam in the bore. DO NOT force the piston into the housing.

Partly insert piston into housing leaving ball guides exposed.

## ™NOTE:

Make sure you have completed the Auto Repair procedure.

 Lightly coat new seal ring and tetra seal with grease and install on bearing cap. See "Fig. 3-23: Seal Ring Installation" on page 39. See "Fig. 3-24: Tetra Seal Installation" on page 40.

#### ™NOTE:

Both halves of the ball guide must be held down during ball loading or the balls will come out of their track.

Partially insert bearing cap and input shaft assembly into piston, leaving 3" of shaft exposed.

#### ™NOTE:

When properly positioned in the piston, one thread of the valve shaft will be visible through each of the ball feed holes in the piston.

7. Support the bearing cap and shaft assembly with your hand. Install the recirculating balls, one at a time, into the ball guide feed hole closest to the end of the piston.



DO NOT allow the recirculating balls to drop into the rearward hose or feed balls through both holes. Steering gear lock up can result.

- Slowly turn the input shaft into the piston while feeding the balls into the ball feed hole. As you feed the balls you will feel the shaft being supported as the balls fill the threads.
- Continue to feed the balls until the balls are visible in the rearward hole of the ball guide cavity.

## ™NOTE:

Approximately 16 balls will have been installed when they become visible in the rearward hole of the ball guide cavity.

3 - 37



Install both halves of the ball guide into the ball guide cavity.



Completely insert the ball guides into the cavity, otherwise the guides will be pushed out of the piston during assembly.

11. Slowly turn bearing cap assembly inward with one hand while inserting steel balls into ball guide with other hand.

### ™NOTE:

Both halves of the ball guide must be held down during ball loading or the balls will come out of their track.



DO NOT back the actuating shaft out of the piston while inserting the steel balls into the ball guide. Doing so will cause the balls to bind on the shaft and damage it.

#### ™NOTE:

Twenty four balls must be installed for proper operation.

- 12.Lubricate new O-ring and install it on ball guide retainer. Insert retainer over ball guide and tap it into place with a rubber hammer.
- 13.Slide piston into housing until ball guide retainer is secured by housing. Locate rack gear of piston with opening in housing.
- Carefully work piston ring into cylinder bore.
- 15.Install four long mounting bolts onto bearing cap to attach bearing cap to housing. Torque 230 to 277 ft-lb. (312 to 376 Nm).

## ™NOTE:

If the bearing cap will not sit flush on the housing, ensure the seal ring or tetra ring is correctly in place. Correct as required.

- 16.Locate timing mark on piston rack. Turn actuating shaft to center timing mark in pinion bore of housing.
- 17. Coat end of sector shaft with grease and insert sector shaft into housing. Ensure timing mark on sector shaft lines up between two timing marks on piston rack. See "Fig. 3-25: Sector Shaft Timing Marks" on page 40.
- 18. Tap end of sector shaft to ensure rack and pinion are completely engaged.
- 19.Install a new sector shaft oil seal in the sector shaft cover. When properly fitted, the seal will ride between the roller bearing and cover. The black lip of the seal must face the bearing.

## ™NOTE:

The sector shaft seal is a two-piece seal. It will be necessary to bend the seal for installation. Once the seal is installed you may have to work the seal into place with your fingers or a blunt seal pick to properly seat the seal. Press only on the body of the seal.



#### DO NOT press on the lip of the seal.

- Install sector shaft cover and retaining snap ring.
- Install new dust cover. Lightly tap cover until seated.
- 22. Place new O-ring and tetra seal on cylinder head, grease lightly to hold in place.
- 23. Attach cylinder head to housing. Torque bolts 53 to 64 ft-lb. (72 to 87 Nm).
- 24. Pack excluder seal lip areas with grease. Slide excluder seal over sector shaft with lip facing out. Use a 2 1/4" (57 mm) seal driver to press excluder into cover.

#### ™NOTE:

When properly installed, the lip of the excluder will face outward and the seal will bottom in the excluder seal groove.



- 25.Install the frame side dust cover on housing. Thoroughly clean the housing with a suitable solvent and apply a bead of RTV on the edge of the disk to secure it to the housing. Allow adequate time for the RTV to set.
- 26. Pack lip area of sector shaft boot with grease and install boot over shaft.
- 27.Clean sector shaft splines before installing Pitman arm.
- 28.Install sector shaft boot.
- 29. Install Pitman arm on steering gear output shaft. Align timing mark on Pitman arm with timing mark on output shaft.
- 30.Inspect tab lock retainer for any damage. Replace retainer if any damage is found.
- 31. Apply anti-seize compound to threads of sector shaft, retainer and to both sides of friction washer. See "Fig. 3-26: Anti-Seize Compound Application" on page 40.

#### ™NOTE:

DO NOT apply anti-seize compound to the Pitman arm contact side of the tab lock washer.

- 32. Screw retainer into output shaft by hand. Align tabs of tab lock washer with notches in Pitman arm. See "Fig. 3-27: Locking Pitman Arm Tabs" on page 40.
- 33. Torque retainer to 500 ft-lb. (746 Nm). Continue tightening until two tabs on lock washer align with notches in retainer.



NEVER back off the retainer to align the tabs, tighten beyond specified torque if necessary to align tabs.

34.Lock tabs in place with a hammer and punch.




Fig. 3-22: Sector Shaft Seal Installation




Fig. 3-23: Seal Ring Installation






Fig. 3-24: Tetra Seal Installation




Fig. 3-26: Anti-Seize Compound Application




Fig. 3-25: Sector Shaft Timing Marks




Fig. 3-27: Locking Pitman Arm Tabs





#### 2.12.10.Installation

 Assemble the support plate to the steering gearbox using five bolts and spacers. Hand-tighten only at this time.



The steering gearbox weighs approximately 110 lbs. ALWAYS use appropriate lifting equipment and the assistance of another person when removing or installing the steering gearbox.

- 2. Use lifting equipment to raise the steering gearbox and support plate into position.
- Align the support plate holes with the holes in the vehicle structure and install fasteners
- 4. Apply NEVER-SEEZ® and torque support plate fasteners to 157 to 173 ft-lb. (213 to 235 Nm).
- Connect drag link to pitman arm and apply NEVER-SEEZ® to the tie-rod end threads. Install castle nut and torque 95 to 115 ft-lb. (129 to 156 Nm).

## ™NOTE:

The mounting bolts may need to be loosened to allow sufficient movement of the steering gearbox to align with the drag link.

 Inspect alignment of slot in castle nut with hole in tie-rod end. If slot is not aligned with hole, continue to tighten castle nut until next slot aligns with hole. Install cotter pin.

- 7. Apply NEVER-SEEZ® to bolt threads and torque steering gearbox mounting bolts 350 ft-lb. (475 Nm).
- 8. Align reference mark on steering U-joint to steering gear input shaft and install using clamp bolt and lock nut. Torque nut to 50 ft-lb. (68 Nm).
- Reinstall diagnostic connector at same angle noted during removal. Lubricate Oring and torque nut to 50 to 60 ft-lb. (68 to 81 Nm).
- Connect -08 pressure hose and torque fitting to 32 to 35 ft-lb. (43 to 47 Nm.)
- 11. Connect -10 return hose and torque fitting to 46 to 50 ft-lb. (62 to 68 Nm.)
- 12. Reinstall and close the removed access doors.
- 13. Lower vehicle and fill reservoir with oil.
- 14.Bleed the system. Refer to 2.12.11. "Bleeding Power Steering Hydraulic System" on page 42 in this section for procedure.
- 15. The steering gear installed on this vehicle is equipped with automatic relief valve plungers which require no adjustment unless the tire size or wheel cut is changed. Refer to 2.5.1. "Steering Stops" on page 5 in this section for procedure should adjustment be required.



# 2.12.11.Bleeding Power Steering Hydraulic System

Air in the fluid system will cause spongy action and noisy operation. The power steering hydraulic system must be bled whenever the power steering hydraulic pump, steering gear assembly, fluid reservoir, filter assembly, or hydraulic lines have been removed.



DO NOT operate power steering pump with an empty reservoir.

#### ™NOTE:

Refer to the Preventive Maintenance Section of this manual for power steering fluid specification. Use only the recommended fluid.

- Fill the hydraulic reservoir tank to the center of the sight glass with recommended oil. Let steering fluid remain undisturbed for about two or three minutes.
- Raise vehicle until front wheels are off the ground. Refer to the General Information Section of this manual for recommended lifting procedures.



DO NOT hold the wheel in the fully locked position, nor allow the wheel to contact the mechanical stop while bleeding the system. Damage to the steering gearbox could result under this condition if the hydraulic relief plunger is not properly adjusted.

- Start engine and operate at fast idle speed for two or three minutes. Turn front wheels to the right and left making three complete cycles to remove all air from system.
- Maintain fluid level in hydraulic reservoir tank to the center of the sight glass. Check system lines and connections for leaks. Continue these procedures until fluid in pump reservoir tank is clear and free of air bubbles.
- Increase engine speed to approximately half throttle and run engine at this speed until all signs of air bubbles cease to exist in reservoir tank.

Turn wheels to right and left as before, making three complete cycles.

## 2.12.12.Functional Tests

- 1. Check fluid level in reservoir.
- Start the vehicle and check steering operation.
- 3. Test drive vehicle.



## 3. HYDRAULIC SYSTEM

## 3.1. Description

The hydraulic system supplies hydraulic power to the power steering gear at the front axle. The hydraulic system consists of the following components:

- □ Power Steering Pump
- ☐ Hydraulic Fluid Reservoir & Filter

## 3.2. Power Steering Pump

## 3.2.1. Description

The power steering pump is a vane-type hydraulic unit which supplies hydraulic power for operation of the power steering gear.

The pump is flange-mounted to the air compressor. See "Fig. 3-28: Power Steering Pump Installation" on page 43. The hydraulic fluid reservoir and filter is remotely mounted and is connected to the power steering system by hoses.

#### 3.2.2. Power Steering Pump Specifications

Manufacturer	IXETIC
Displacement	25 cc/rev (1.53 in <sup>3)</sup>
Flow control	16L/min (4.23 U.S. gpm)
Pressure relief	150 bar (2176 psi)
Rotation	CW
Mounting	SAE A 2-bolt flange
Inlet port	12 ORB
Outlet port	8 ORB




Fig. 3-28: Power Steering Pump Installation



#### 3.2.3. Pump Operation

The major pump components are: a pressure plate, ring, rotor and vanes contained in a multi-ported housing. The pump rotor is driven within the pump ring by a drive shaft, coupled to the fan drive pump.

As the rotor speed increases, centrifugal action causes the vanes and rotor to generate flow by carrying fluid around the elliptical cam ring contour. System pressure, fed behind the vanes, assures sealing contact of vanes on ring contour during normal operation.

The ring is shaped so that two opposing pumping chambers are formed. Radial movement of the vanes, and rotation of the rotor, causes the chamber area between vanes to increase in size at the inlet (large diameter) of the ring. This results in low pressure, or a vacuum in the chamber. The fluid in the pump reservoir is under atmospheric pressure. This pressure differential causes fluid to flow into the pump housing inlet, where it is trapped between the rotating vanes. The fluid is then forced through porting in the pressure plate and discharges into the system at the pressure quadrant (small diameter) of the ring.

Maximum pump delivery and maximum system pressure are determined by the flow control and relief valve located in the pump housing. An orifice in cover limits maximum flow. A pilot-operated type control valve shifts to divert excess fluid delivery to reservoir, thus limiting system pressure to a prescribed maximum.

The total pump delivery can pass through the orifice usually only at low drive speeds.

The large spring chamber is connected to the pressure port through an orifice. Pressure in this chamber equalizes pressure at the other end of the relief valve spool and the light spring holds the spool closed. Pump delivery is blocked from the reservoir port by the spool land.

When pump delivery is more than the flow rate determined by the orifice plug, a pressure build-up forces the spool open against the light spring. Excess fluid is throttled past the spool to the reservoir port. If pressure in the system builds up to the relief valve setting the pilot poppet is forced off its seat. Fluid in the large spring chamber flows through the spool and out to reservoir. This flow causes a pressure differential on the spool, shifting it against the light spring. All pump delivery is thus permitted to flow to reservoir.



Failure to observe the following precaution can result in scoring and possible seizure of the pump due to a lack of oil for lubrication.

Normally these pumps require no manual priming. However, after engine start up, allow the engine to idle for a short period of time, with no load, until the power steering pump picks up its prime and pressure is built up in the power steering system.

Refer to the Preventive Maintenance Section of this manual for specifications.



DO NOT use a cloth when adding fluid to the reservoir. Lint will contaminate the fluid and damage the pump.

When adding fluid to the reservoir, pour through a fine wire mesh (200 mesh or finer). Also make sure that air is purged from the pump and lines before operation.



#### 3.2.4. Removal



Escaping hydraulic fluid under pressure can have sufficient force to penetrate your skin causing serious injury. This fluid may also be hot enough to burn. Serious infection or reactions can develop if proper medical treatment is not administered immediately.

## PNOTE:

The power steering pump is replaced with either a new or remanufactured unit.

- 1. Place a clean container under the power steering pump to remove the inlet and pressure lines.
- 2. Remove the mounting bolts attaching the power steering pump to the air compressor and remove the pump.
- 3. Remove and discard the gasket.

#### 3.2.5. Installation

- 1. Ensure mating surface between power steering pump and air compressor are scraped clean.
- Lubricate male splines on power steering pump and female splines on air compressor driveshaft with Molykote "G" grease (Chevron 23003, GR-25 or equivalent).
- Apply new gasket to sealing surface of power steering pump.
- 4. Install power steering pump onto air compressor. Ensure splines on pump shaft mate correctly with air compressor.
- Apply Loctite-242 to bolts and install bolts and washers. Torque bolts to 33 ft-lb. (45 Nm).
- 6. Connect hoses and fittings to pump. Tighten fittings securely.
- 7. Refill hydraulic system and bleed system.



## 3.2.6. Power Steering Pump Troubleshooting

POWER STEERING PUMP TROUBLESHOOTING		
TROUBLE	POSSIBLE CAUSE	REMEDY
Pump not Delivering Fluid	Fluid intake pipe in reservoir restricted	Check all strainers and filters for dirt and sludge. Clean if necessary.
	Fluid viscosity too heavy to pick up priming	Completely drain the system. Add new filtered fluid of the proper viscosity.
	Air leaks at the intake. Pump not priming	Check the inlet connections to determine where air is being drawn in. Tighten any loose connections. See that the fluid in the reservoir is above the intake pipe opening.
	Relief valve stuck open. (Models with integral relief valve only)	Replace pump.
Insufficient Pressure Build-Up	Relief valve stuck	Replace pump.
	Complete loss of flow from pump	A valve is stuck open permitting free flow to tank. Broken inlet or pressure line.
Pump Making Noise	Pump intake partially blocked	Service the intake strainers. Check the fluid condition and, if necessary, drain and flush the system. Refill with clean fluid.
	Air leaks at the intake or shaft seal. (Oil in reservoir would probably be foamy)	Check the inlet connections and seal to determine where air is being drawn in. Tighten any loose connections and replace the seal if necessary. See that the fluid in the reservoir is above the intake pipe opening.



## 3.3. Reservoir

#### 3.3.1. Description

The hydraulic reservoir is bracket mounted in the engine compartment at the rear of

the vehicle. The tank has a filter and a hydraulic fluid level sight glass. A dipstick is provided to verify fluid level. See "Fig. 3-29: Power Steering Drive Reservoir Assembly" on page 47. See "Fig. 3-30: Hydraulic Steering Schematic" on page 48.




Fig. 3-29: Power Steering Drive Reservoir Assembly






Fig. 3-30: Hydraulic Steering Schematic



#### 3.3.2. Maintenance

Install a new filter and hydraulic fluid. Refer to the Preventive Maintenance Section of this manual for replacement schedule.

#### ™NOTE:

Hydraulic fluid may drain out of the filter as it is removed from the mounting base. The amount may depend on how much time the fluid has had to drain down from the filter. Have shop rags handy to catch fluid that may drain from the filter.

- Disconnect hose from reservoir outlet and drain fluid.
- 2. Remove filler cap and dipstick assembly.
- 3. Remove cover bolt and washer.



Hold cover so compression of spring will not cause it to fly off.

Remove cover, hold-down spring and washer.

- 5. Remove filter element cartridge.
- Rinse filler cap in suitable solvent. Remove accumulated dirt.
- Wipe reservoir shell with dry, clean lint-free cloth.



Ensure packaging and labels have been removed from the element cartridge prior to installing it in the reservoir.

- 8. Install new element cartridge.
- 9. Install washer and hold-down spring.
- Install new gasket in cover. Place cover on shell.
- Install cover bolt and washer to secure cover.
- 12. Connect hose at reservoir outlet and tighten firmly.
- 13. Fill reservoir with fluid and bleed system as previously described.
- 14. Install filler cap and dipstick assembly.



#### 3.3.3. Pressure Filling



NEVER fill the Hydraulic System while the engine is running. Hydraulic fluid is flammable and under pressure. ALWAYS wear protective gloves and eye protection when handling hydraulic fluid. Avoid breathing vapors. Hydraulic fluid is poisonous and must not be ingested.



The following pressure fill procedure should ALWAYS be used after performing any maintenance on the hydraulic/steering system where a significant quantity of fluid has been lost. The use of pressure filling equipment will force fluid through the lines and minimize air entrapment in the system.

1. Set the Battery Disconnect switch to the OFF position.



Ensure that the fluid supply is clean and filtered to 10 micron absolute or finer.

- 2. Connect a supply hose to the pressure fill coupling located on the power steering reservoir mounting bracket.
- 3. Fill system until fluid level can be seen in the sight glass.
- 4. Disconnect the pressure-filling equipment.
- 5. Start the engine for 15 seconds maximum and stop engine.
- 6. Top up the reservoir as necessary and check system for leaks.
- 7. Repeat steps 5 and 6 until the fluid level in the sight glass is stable.
- Bleed air from the power steering system. Refer to 2.12.11. "Bleeding Power Steering Hydraulic System" on page 42 in this section for procedure.
- Shut of the engine and top up the reservoir.



# **Engine System**

1.	SAFET	Ύ	4-1
	1.1. Saf	fety Procedures	4-1
2.	ENGIN	E & ACCESSORIES	4-2
		mmins ISL 9.0L (EPA 2015) Engine	
	2.1.1.		
	2.1.2.		
	2.1.3.	ŭ i	
	2.1.4.		
	2.2. End	gine Mount Replacement	
	2.2.1.	-	
	2.2.2.		
	2.2.3.		
	2.2.4.	Rear Mount Removal	4-11
	2.2.5.	Rear Mount Installation	4-12
	2.3. Eng	gine Struts	4-13
	2.3.1.	Description	4-13
	2.3.2.	Removal	4-14
	2.3.3.	Installation	4-14
	2.4. Air	Intake & Air Cleaner Assembly	4-15
	2.4.1.	Description	4-15
	2.4.2.	Operation	4-15
	2.4.3.		
	2.4.4.	· · · · · · · · · · · · · · · · · · ·	
	2.4.5.		
	2.4.6.		
	2.4.7.		
	2.4.8.		
	2.5. Ext	haust & Aftertreatment System	
	2.5.1.	=p	
	2.5.2.		
	2.5.3.	,	
		2.5.3.1. Description	
		2.5.3.2. Operation	
		2.5.3.4. Disassembly	
		2.5.3.5. Inspection	
		2.5.3.6. Assembly	
		2.5.3.7. Installation	
	2.5.4.	Muffler Filter Regeneration	4-24

# Table of Contents



	2.5	5.4.1. Automatic Regeneration	4-24
	2.5	5.4.2. Stationary Regeneration	4-25
	2.5.5.	Selective Catalytic Reduction Unit (SCR)	4-26
		5.5.1. Description	
		5.5.2. Operation	
	2.5	5.5.3. Removal	4-26
		5.5.4. Disassembly	
		5.5.5. Inspection	
	2.5	5.5.6. Assembly	4-29
	2.5	5.5.7. Installation	4-29
	2.5.6.	Decomposition Reactor	4-30
	2.5	5.6.1. Description	4-30
	2.5	5.6.2. Cleaning & Inspection	4-31
		5.6.3. Final Inspection	
	2.5	5.6.4. Installation	4-32
	2.5.7.	SCR Dosing Supply Unit	4-33
	2.5	5.7.1. Description	4-33
		5.7.2. Operation	
		5.7.3. Maintenance	
	2.5	5.7.4. Removal	4-34
	2.5	5.7.5. Cleaning & Inspection	4-34
		5.7.6. Installation	
		Diesel Exhaust Fluid (DEF) Tank	
		5.8.1. Description	
		5.8.2. DEF Tank Specifications	
		5.8.3. Operation	
		5.8.4. Removal	
		5.8.5. Disassembly	
		5.8.6. Assembly	
		5.8.7. Installation	
		DEF Tank Filling	
		Nitrous Oxide (NOx) Sensors	
		5.10.1.Description	
		5.10.2.Operation	
		5.10.3.Removal	
		5.10.4.Cleaning & Inspection	
		5.10.5.Installation	
		Exhaust Tubes, Exhaust Flex Connector & Exhaust Blankets	
		5.11.1.Removal	
		5.11.2.Installation	
2.6	. Dies	sel Exhaust Fluid	_
	2.6.1.	Description	
	2.6.2.	Diesel Exhaust Fluid Specifications	4-45
	2.6.3.	Operation	4-46
	2.6.4.	Handling	
	2.6.5.	Shelf Life	
	2.6.6.	Storage	
	2.6.7.	Cleanliness Practices	
	2.6.8.	Disposal & Cleaning	
	2.6.9.	First Aid	
		Testing	
	۷.0.۱۵.	resuring	4-4/



	2.6.11. Contamination/Incorrect Fluid	4-48
	2.6.12. Freezing	4-48
	2.7. Front Onboard Diagnostic Connector	4-49
	2.7.1. Description	4-49
	2.8. Engine Switch Box	
	2.8.1. Description	
	2.8.2. Operation	
	2.8.3. CAN Communicator	
	2.8.3.1. Description	
	2.8.3.2. Operation	
	2.8.3.3. Data Parameters	4-52
	2.8.3.4. Popup Warning Messages	4-52
	2.9. Fire Suppression System	4-53
	2.9.1. Description	4-53
	2.9.1.1. Agent Cylinder Assembly	4-55
	2.9.1.2. Actuation Switch	4-55
	2.9.1.3. Discharge Tubes	4-55
	2.9.1.4. Discharge Nozzles	
	2.9.1.5. Control Panel	
	2.9.1.6. Operation	
	2.9.1.7. Backup Battery	
	2.9.2. Maintenance	
	2.9.3. Fire Suppression System Troubleshooting	4-59
3.	VENDOR SERVICE INFORMATION	4-63
	3.1. Cummins ISL (2015) Manuals	4-63
	3.2. Forster Manual	
	3.3. Amerex Fire Suppression Manuals	
	and b. and an in manage	







# 1. SAFETY

# 1.1. Safety Procedures

This section of the service manual contains procedures which require the mechanics to strictly observe safety procedures in order to ensure personal and equipment safety.

Refer to the General Information Section of this manual for information on types of hoists, hoisting procedures, jackstands and related safety information. Refer to this information and read carefully before lifting, hoisting or jacking the vehicle.

Always ensure that the vehicle is appropriately hoisted and blocked for procedures which require elevating the vehicle. Be aware of the limitations of the blocking equipment, and always ensure that the jarring and shaking created by component removal and installation procedures does not overload the blocks, or cause the vehicle to become unstable.

Certain procedures may require the vehicle be operated in an elevated position in order to accurately troubleshoot and diagnose a problem. If the vehicle must be running while elevated, become familiar with the repair area prior to starting the engine. Take special care in noting areas which will become hot, electrically energized, and areas where moving and rotating components are located. Limit the work in these areas as personal and equipment safety is at risk.

For procedures which involve air lines, ensure the line is safely depressurized prior to disconnecting. Disconnecting pressurized lines will cause solid particles deposited in the line to be uncontrollably propelled, and will also cause the hose end to whip randomly as the air escapes.



# 2. ENGINE & ACCESSORIES

# 2.1. Cummins ISL 9.0L (EPA 2015) Engine

# 2.1.1. Description

The Cummins ISL9 engine is an 8.9 liter, four-stroke, inline, six cylinder, diesel engine. See "Fig. 4-1: Engine Views" on page 3.

The major components and accessories of the engine are:

- ☐ Fuel System (Refer to Section 7 of this manual).
- ☐ Engine Protection System
- ☐ Air Intake System
- □ Exhaust System
- ☐ Engine Switch Box
- ☐ Electronic Control Module (ECM)

# 2.1.2. Engine Specifications

Rated Power280 HP @ 2200 RPM
Peak Torque 900 ft-lb. @ 1300 RPM
Displacement
Firing Order1-5-3-6-2-4
AspirationTurbo Charge
Engine Weight (dry)1678 lb. (761 kg)
Oil Capacity (including filter)28 U.S. qt. (26.5 liters)
Coolant Capacity (engine only)13.1 U.S. qt. (12.4 liters)

Refer to the Cummins Operation & Maintenance Manual for further information on the engine.






Fig. 4-1: Engine Views



### 2.1.3. Removal

- Set the Battery Disconnect switch in the streetside battery compartment to the OFF position.
- Unlatch the belt guard door and swing open. Remove cotter pins from upper and lower hinge pivots and lift off the belt guard. See "Fig. 4-2: Bumpers & Belt Guards" on page 5.
- 3. At the rear interior of the vehicle, raise the rear seats and set the prop rods to retain the seats in an elevated position. Remove the interior engine access door cover.

# ™NOTE:

The engine can be removed from the vehicle without removing the engine struts. If struts are to be removed, Refer to 2.3. "Engine Struts" on page 13 in this section for procedure.

- Remove the drain plug from the lower radiator tube and open the petcock drain valve at the bottom of the radiator. Drain the coolant using a suitable container to catch the fluid.
- 5. Support the bumper with a suitable lifting device, remove the 4 retaining bolts and remove the bumper.
- Raise the vehicle. Refer to the General Information Section of this manual for procedure.
- Drain the vehicle air tanks. Refer to the General Information Section of this manual for tank drain locations.
- Loosen the HVAC compressor belt tightening and remove the belt from the compressor.
- 9. Disconnect all the wire harnesses from engine switch box.
- 10. Pull out the battery tray.
- 11. Underneath the vehicle in the transmission area, disconnect the driveshaft from the transmission. Allow the driveshaft to hang onto the rear axle bunk. See "Fig. 4-3: Disconnecting the Driveshaft" on page 6.
- Disconnect the transmission main harness and speed sensor electrical connector.

- 13. Disconnect the transmission cooler hoses from the transmission. Plug ports to prevent contamination of fluid.
- 14. Disconnect engine air compressor and governor lines at the compressor and the inlet hose at the engine air filter elbow.
- 15. Disconnect charge air tube.
- Disconnect starter motor electrical connectors.
- 17. Disconnect electrical harnesses from engine.
- 18. Disconnect electrical wires from alternator.
- Disconnect clamps on left-hand side engine rail which support lower coolant tube.
- 20. Disconnect fuel line from engine.
- 21. Remove tube between surge tank and lower coolant tube.
- 22. From inside of vehicle, remove air intake clamp at turbo and separate air intake tub from turbo.
- 23.Loosen and remove the 2 V-band clamps retaining the exhaust elbow. Unbolt the bracket from the engine and remove the elbow.
- 24. Disconnect the coolant bleed line at the top of the engine.
- 25. Disconnect coolant lines from thermostat housing.
- 26. Disconnect and plug the pressure and return hoses at the hydraulic pump mounted at the rear of the engine air compressor.
- 27. Disconnect the output hose from the muffler tank.
- 28. Check to ensure that all hoses and connectors are disconnected and out of the way.
- 29. Remove the 3/4" bolt, snubbing washer, flat washer, and lock nut from the rear engine mounts. See "Fig. 4-4: Engine Mounts" on page 6.
- 30. Break loose the four 5/8" bolts that attach the front mount bracket to the main frame rails. Do not attempt to remove bolts at this time.



31. Raise vehicle sufficiently to allow engine dolly to slide into position. See "Fig. 4-5: Engine Support Dolly" on page 7.

# **CAUTION**

The following procedure requires the engine dolly to support the weight of the engine sufficiently to have the rear engine mounts and front mount support bracket in a state of neutral load.

- 32.Lower vehicle slowly until light contact is made equally with front mount support bracket and transmission. Adjust engine dolly as necessary to support the front mount support bracket and transmission equally.
- 33. Continue to lower the vehicle slightly until the front engine mount support bracket is unloaded.

# ™NOTE:

The bolts on the front engine mount bracket should turn easily once the mount bracket is unloaded.

- 34. Remove the bolts, washers, and lock nuts from the front mount support bracket.
- 35. Lower the vehicle slightly and just enough to clear rear mount bracket during removal of engine dolly.

### ™NOTE:

Ensure that the rear engine mounts are clear of the mount support brackets but DO NOT lower the vehicle more than necessary, otherwise clearance between the air intake tube and the engine door opening will be compromised.

36.Perform a final inspection to ensure all lines, hoses and electrical harnesses have been disconnected and safely tied out of the way.




Fig. 4-2: Bumpers & Belt Guards






Fig. 4-3: Disconnecting the Driveshaft

37. Carefully pull the engine dolly out from the engine compartment.



Engine lifting brackets are required when hoisting the engine to ensure safe, secure, and properly distributed lifting points. DO NOT attempt to lift engine with brackets or lifting equipment not designed for this purpose.

38. Install lifting brackets on the engine if the engine is to be removed from the dolly. Remove the existing brackets from the engine that are used to support the CAC tubes and exhaust tubes. Install approved engine lifting brackets at these locations. Retain original brackets for reinstallation.

# ™NOTE:

The original Cummins engine brackets were supplied loose with the vehicle at time of delivery.




Fig. 4-4: Engine Mounts






Fig. 4-5: Engine Support Dolly

#### 2.1.4. Installation

# ™NOTE:

If engine was fitted with lifting brackets during removal from engine dolly, then replace lifting brackets with original CAC and exhaust tube mounting brackets.

- 1. Slide the engine dolly into position and align the engine mounts with the chassis mounting brackets.
- Raise the vehicle slightly to align the holes in the front mount support bracket with the corresponding holes in the vehicle frame.
- 3. Insert front mounting bolts.

# ™NOTE:

Use an alignment punch, if necessary, to aid insertion of mounting bolts. DO NOT force or hammer bolts into place.

- 4. Use a separate wrench to hold lock nuts and torque front mounting bolts to 160 ft-lb. (215 Nm).
- 5. Insert rear mounting bolts with flat washer and snubbing washer.

# ™NOTE:

Use an alignment punch, if necessary, to aid insertion of mounting bolts. DO NOT force or hammer bolts into place.

- 6. Install lock nuts and flat washer and tighten until snug only.
- 7. Raise vehicle slightly to ensure full weight of engine is taken by rear mounts.
- 8. Torque rear mounting bolts to 250 ft-lb. (339 Nm).
- 9. Raise vehicle slightly to allow removal of engine dolly.
- Connect coolant hoses disconnected during removal.
- 11. Connect engine air compressor, governor pressure and air inlet hoses.
- 12. Connect the muffler tank outlet hose.
- Connect wires to starter motor.
- 14. Connect engine ECU connectors.
- 15. Connect alternator electrical connections.
- 16. Connect hydraulic pump pressure and return hoses at the pump.

# **Cummins ISL 9.0L (EPA 2015) Engine**



- 17.Install exhaust elbow to turbo and to exhaust outlet.
- 18. Connect fuel line to engine.
- 19. Install charge air intake lines.
- 20. Install HVAC compressor drive belt. Adjust belt tension using mounting base turnbuckle. Refer to Section 10 of this manual for further information on compressor installation.
- 21.Install lower radiator tube drain plug and shut radiator petcock drain valve.
- 22. From underneath vehicle, attach driveshaft to transmission. Install driveshaft guard.
- 23. Attach transmission cooler hoses to the transmission.
- 24. Attach transmission electrical main harness and speed sensor connector.
- 25. Lower the vehicle.

- 26.Install engine belt guard to engine struts and support tubes using 3/8" bolts, washers and lock nuts.
- 27. Connect all the wire harnesses to the engine switch box.
- 28.Check to ensure that all hoses and connectors are connected, properly routed and secured
- 29. Fill hydraulic reservoir.
- 30.Lift the bumper in place with a suitable lifting device. Install and tighten the 4 mounting bolts.
- 31. Top up coolant level in surge tank.
- 32. Check engine and transmission fluid levels.
- 33. Slide the battery tray back into position. Set the Battery Disconnect switch in the battery compartment to the ON position.
- 34. Run the engine at idle and check for leaks.



# 2.2. Engine Mount Replacement



The following procedure requires lifting the vehicle and supporting heavy components with lifts and/or stands. ALWAYS ensure that the equipment being used is designed for the application and that proper lifting procedures are followed. Refer to the General Information Section of this manual for further information on lifting, hoisting, or jacking the vehicle.

### 2.2.1. Description

The following replacement procedures provide instructions on how to replace front and/or rear engine mounts without removing the engine from the engine compartment. For purposes of reference, the front engine mounts are at the accessory drive pulley end of the engine and the rear mounts are at the flywheel end of the engine.

When replacing a worn or broken engine mount, it is recommended that the mount on the opposite side be replaced as well.

### 2.2.2. Front Mount Removal

- 1. Set the Battery Disconnect switch to the OFF position.
- 2. Unlatch and remove the belt guard.
- Relieve the tension on the HVAC compressor drive belt.
- 4. Raise the vehicle to allow for the use of a floor jack.
- Remove the 5/8" bolt, flat washer, engine rebound washer, spacer, and lock nut that secure the rubber mount to the top engine mount assembly and lower crossmember assembly. See "Fig. 4-6: Front Engine Mounts" on page 9.

- 6. Remove the two 1/2" bolts, washers, and lock nuts that secure the rubber mount to the lower crossmember assembly.
- 7. Position a floor jack beneath the engine and place a board across the width of the front portion of the oil pan.



Assess whether raising the engine will have any affect on components directly attached to the engine or components in the immediate area of the engine. Loosen clamps and/or disconnect any lines, tubes, harnesses that may be affected.

Raise the engine sufficiently to allow removal of the rubber mount.




Fig. 4-6: Front Engine Mounts



### 2.2.3. Front Mount Installation

- Install a new rubber mount and align the two mounting holes with the two holes in the lower crossmember.
- 2. Install the two 1/2" bolts, washers, and lock nuts that secure the rubber mount to the lower crossmember. Hand-tighten only at this time.
- Lower the engine so that the weight of the engine is supported by the rubber mount.
   Use a tapered punch, if necessary, to ensure the hole in rubber mount aligns with hole in upper engine mount assembly.
- 4. Install the 5/8" bolt, flat washer, spacer, engine rebound washer, and lock nut. See "Fig. 4-7: Front Engine Mount Cross-Section" on page 10.

### ™NOTE:

Ensure the recessed side of the engine rebound washer faces the spacer.

- 5. Torque the 1/2" lock nuts to 70 ft-lb. (95 Nm).
- Torque the 5/8" lock nut to 160 ft-lb. (217 Nm).

# ™NOTE:

Ensure the spacer is properly installed and there is clearance between the engine rebound washer and the underside of the crossmember. The spacer is designed to establish this clearance and prevent the rubber mount from being excessively compressed.

- Check belt tension and alignment and adjust if necessary. Refer to Section 10 of this manual for HVAC belt adjustment procedure.
- 8. Reinstall and latch belt guard.




Fig. 4-7: Front Engine Mount Cross-Section



### 2.2.4. Rear Mount Removal

### ™NOTE:

The following procedure describes removal of the rubber mount only. There is insufficient access to remove the complete mounting bracket assembly from the engine.

- 1. Set the Battery Disconnect switch to the OFF position.
- Raise the rear passenger seat and open and secure the interior engine access door.
- Raise the vehicle to working height. Refer to the General Information Section of this manual for lifting procedures. The vehicle must be supported by wheel lifts or axle stands. Do not allow axle assembly to hang unsupported.
- Disconnect the rear leveling valves and bleed air out of both air springs evenly until air springs are deflated and rubber stop on vehicle body contacts the axle housing.

### MOTE:

The leveling valves need to be disconnected and air springs deflated to prevent the suspension leveling system from reacting to the lifting force on the engine when replacing the rear mounts.

- Remove the 3/4" bolt, washers, snubbing washer, and lock nut that secure the rubber mount to the side engine mount bracket and frame rail bracket. Note the location of the snubbing washer for reinstallation. See "Fig. 4-8: Rear Engine Mount" on page 12.
- Position a lift table, transmission jack, or similar lifting equipment, beneath the transmission and use wooden blocks to support the weight of the transmission. Spread the lifting load over the width of the transmission to prevent damaging the oil pan.
- 7. Locate the transmission oil cooler hoses and loosen the clamps and brackets that

- secure the hoses to the vehicle structure. This will allow the engine to be raised without putting stress on the hoses.
- Loosen the clamps that secure the CAC tube where it crosses over the rear of the engine. This will allow the engine to be raised without putting stress on the CAC tube
- Loosen the clamps that secure the wiring harness running above and across the rear of the engine. This will allow the engine to be raised without damaging the harness.
- 10.Loosen the clamps that secure the SCR coolant supply and return lines that run above and across the rear of the engine.



Assess whether raising the engine will have any affect on components directly attached to the engine or components in the immediate area of the engine. Loosen clamps and/or disconnect any lines, tubes, harnesses that may be affected.

### ™NOTE:

In the following step it will be necessary to raise the engine slightly to gain access to the head of the 7/16" engine mount bolts. For the streetside mount, it is recommended that one person restrain the head of the bolt from beneath while the second person removes the lock nut from the interior side of the vehicle.

- 11. Raise the engine sufficiently to access and remove the two 7/16" bolts, washers, and lock nuts that secure the rubber mount to the engine side mount assembly.
- 12. Continue to slowly raise the engine while observing all surrounding components and structure for clearance. The engine will need to be raised approximately 2 1/4", until the rubber portion of the mount can clear the mounting bracket. Slide the rubber mount out from the bracket.






Fig. 4-8: Rear Engine Mount

### 2.2.5. Rear Mount Installation

- 1. Install new rubber mount into the engine side mount assembly and secure with the two 7/16" bolts, washers, and lock nuts. Hand-tighten only at this time.
- Align the hole in the rubber mount with the hole in the frame rail bracket and install the 3/4" bolt, washers, snubbing washer, and lock nut.
- Torque the 7/16" lock nuts to 50 ft-lb. (68 Nm).
- 4. Lower the engine, allowing the full weight of the engine to be supported by the mount assembly.
- 5. Torque the 3/4" lock nut to 250 ft-lb. (339 Nm).
- 6. Tighten all U-clamps and P-clamps that were previously loosened.
- 7. Connect leveling valves and allow suspension to reach normal ride height.
- 8. Lower the vehicle and secure all access doors.



# 2.3. Engine Struts

### 2.3.1. Description

The engine struts connect the main frame rails to the vehicle structure and are used

to tension the main frame rails and support the engine. See "Fig. 4-9: Engine Struts" on page 13.




Fig. 4-9: Engine Struts



### 2.3.2. Removal

- 1. Loosen the jam nut and remove the 1" upper nut on the engine strut.
- 2. Remove the 3/4" lock nut, bolt, and washers that attach the lower end of the engine strut to the main frame rail bracket.
- 3. Remove the engine strut.

### 2.3.3. Installation

- 1. Thread a 1" nut on the upper end of the strut until nearly bottomed.
- Install threaded end of engine strut into upper mounting bracket and loosely install upper nut.
- 3. Align hole in lower end of strut with hole in main frame rail mounting bracket and secure engine strut to frame rail bracket with 3/4" bolt, washers, and lock nut.
- 4. Apply Never-Seez to bolt threads and torque lock nut to 336 ft-lb. (456 Nm).
- 5. Ensure lower 1" nut is backed off, then tighten upper 1" nut until contact is made with upper mounting bracket.
- Measure the distance between the lower frame rail and upper vehicle structure. See "Fig. 4-10: Engine Strut Tensioning" on page 14.

- 7. Continue to tighten upper nut until the 44.84" dimension is achieved, and then tighten an additional two turns.
- 8. Apply Never-Seez to threaded area of engine strut and tighten lower 1" jam nut to 426 ft-lb. (576 Nm).




Fig. 4-10: Engine Strut Tensioning



# 2.4. Air Intake & Air Cleaner Assembly

### 2.4.1. Description

The air intake system includes the air inlet grille, air intake box, air cleaner assembly, air filter restriction indicator and interconnecting steel tubing, rubber hump hoses and elbows, and clamps. See "Fig. 4-11: Engine Intake System" on page 16.

The air cleaner assembly is a molded plastic housing with a removable access cover for servicing the primary and safety filter elements. The air filter restriction indicator is remotely located near the engine switchbox and is connected to an air intake tube with a flexible hose.

### 2.4.2. Operation

Air enters the vehicle through a perforated mesh air inlet grille located on the upper rear curbside corner of the vehicle. The air intake box inlet is sealed against the air intake grille with a bulb seal and is internally baffled to prevent moisture intrusion. Air flows downward through primary and safety elements which capture any airborne contaminants. The air filter restriction gauge registers the level of air intake restriction.


#### 2.4.3. Maintenance

Refer to the Preventive Maintenance section of this manual for scheduled inspections on the air filter restriction indicator and air filter element replacement procedures.

# 2.4.4. Air Intake & Air Cleaner Troubleshooting

AIR INTAKE & AIR CLEANER TROUBLESHOOTING				
PROBLEM	CAUSE	SOLUTION		
Short filter element life	Defective or inaccurate filter restriction indicator	Replace indicator.		
	Incorrect air filter application	Refer to your New Flyer Parts Manual for correct air filter element.		
	Air leakage upstream of filter	Ensure all clamps are tight and no holes or damage is evident on tubes and hoses. Check air cleaner service cover for leakage.		
Premature engine wear	Air leakage downstream of filter element	Ensure all clamps are tight and no holes or damage is evident on tubes and hoses. Ensure turbocharger and engine compressor connections are tight.		
	Leakage at filter element	Ensure filter element is properly seated and forms a tight seal with the air filter housing.		





- 4. Washer, Flat 1/4"
- 5. Clamp, T-Bolt w/Spring
- 6. Filter, 1/8 PT
- 7. Nut, Lock Nylon 1/4" 20 UNC
- 8. Bolt, Hex 3/8" 16 UNC x 1 1/4" Lg.
- 9. Insert, Monel #10 - 32 UNF x .020" - .130"
- 10. Washer, Flat 3/8"
- 11. Washer, Flat #6
- 12. Clamp, Air Tube

- #10 32 UNF x 3/4" Lg.
- 15. Screw, Hex SST #10 - 24 UNC x 1" Lg.
- 16. Indicator, Air Restriction
- 17. Nipple, Reducing
- 18. Bracket, Air Intake Tube
- 19. Bracket, Air Filter
- 20. Tube, Air Intake ISL
- 21. Air Intake Tube
- 22. Hose Assembly, EQ1 4 FL20.0

- 26. Hose, Hump 5.0" I.D.
- 27. Clamp, Hose 5 1/2"
- 28. Elbow, Street 1/8"
- 29. Connector, Bulkhead 1/4"
- 30. Elbow, 90°
- 31. Bushing, Reducer
- 32. Sensor, TBAP
- 33. Loctite, 242
- 34. Loctite, PST

s0164217a.svg

Fig. 4-11: Engine Intake System



### 2.4.5. Removal

### ™NOTE:

The following procedure describes removal of the air cleaner assembly and air intake box as an assembly from the vehicle and assumes that the air cleaner assembly and/or air intake box are damaged and require replacement. Routine servicing procedures for the air cleaner elements are covered in the Preventive Maintenance section of this manual.

- 1. Open the curbside corner pillar access door and rear engine access door.
- Clean the air cleaner assembly, engine air intake tubes and surrounding areas prior removing any components so as to prevent any contamination from entering the engine air intake system.
- Loosen the two T-bolt clamps on the rubber elbow located at the base of the vertical air intake tube.
- Remove the rubber elbow and clamps from the vehicle and immediately cap the horizontal air intake tube leading to the turbocharger to prevent entry of contaminants.
- 5. The outlet of the air cleaner assembly is attached to a vertical air intake pipe with a hump hose and two clamps. Loosen the lower clamp on the hump hose and separate the hump hose from the air intake tube.
- 6. Remove the two bolts and washers from the mounting brackets on either side of the the air cleaner assembly.

### ™NOTE:

It is not necessary at this time to remove the single straight support bracket that attaches the air cleaner assembly to the air intake box. Carefully support and tilt the air cleaner assembly outward and remove from the vehicle.

### 2.4.6. Disassembly

- Remove the support bracket that attaches the air intake box to the air cleaner assembly. See "Fig. 4-12: Air Intake Box/Cleaner Assembly" on page 17.
- Loosen the upper clamp and slide the air intake box upwards and off the air cleaner assembly.
- Loosen the lower clamp on the air clean assembly outlet and remove the hump hose.




Fig. 4-12: Air Intake Box/Cleaner Assembly



### 2.4.7. Assembly

- Slide the air intake box with T-bolt clamp over the inlet of the air cleaner assembly. Do not tighten the T-bolt clamp at this time.
- Align the intake box with the air cleaner assembly and install the single support bracket.



DO NOT exceed the specified torque value for clamp installation. Excessive tightening will cause the plastic inlet of the air cleaner assembly to distort and possibly crack. ALWAYS use a calibrated torque wrench with a torque range suitable to the application.

- 3. Torque the T-bolt clamp on the air cleaner inlet to 40 in-lb.
- 4. Slide the hump hose with T-bolt clamp onto the outlet of the air cleaner assembly. Ensure that the hump hose fully engages the throat of the air cleaner outlet and that the hose clamp is positioned above the sealing bead on the air cleaner outlet and is properly centered.



DO NOT exceed the specified torque value for clamp installation. Excessive tightening will cause the plastic outlet of the air cleaner assembly to distort and possibly crack. ALWAYS use a calibrated torque wrench with a torque range suitable to the application.

5. Torque the T-bolt clamp on the air cleaner outlet to 40 in-lb.

#### 2.4.8. Installation

- Loosely install T-bolt clamp on hump hose before installing air cleaner and intake box assembly into vehicle.
- 2. Inspect and clean the vertical intake pipe.
- Support the air cleaner and intake box assembly and carefully align and slide the hump hose over the vertical air intake pipe while simultaneously aligning the air cleaner housing with the mounting brackets on either side.
- Apply Loctite 242 threadlocker to the threads of the bolts and install bolts with washers through mounting bracket and into threaded holes of air cleaner housing. Do not over tighten mounting bolts.
- Ensure hump hose is properly seated over vertical air intake tube and T-bolt clamp is properly positioned. Torque T-bolt clamp to 85 in-lb.
- Remove the protective cover from the horizontal air intake tube and install the lower rubber elbow and torque T-bolt clamps to 85 in-lb.
- Close the corner pillar access doors and check to ensure the bulb seal on the air intake box forms a proper seal against the access door.

# **Exhaust & Aftertreatment System**

# 2.5. Exhaust & Aftertreatment System

### 2.5.1. Description

The exhaust and aftertreatment system processes the gaseous waste products from engine combustion to ensure the chemical composition being released into the atmosphere complies with established environmental regulations. The exhaust system consists of the following components:

- ☐ Diesel Particulate Filter (DPF)
- ☐ Exhaust Tubes, Blankets, & Bellows
- ☐ Selective Catalytic Reduction (SCR) Unit including supply module
- Decomposition Reactor with dosing module
- □ Diesel Exhaust Fluid (DEF) Tank
- ☐ Nitrogen Oxide (NOx) Sensors (2)
- □ Tailpipe

The exhaust system is mounted using mounting brackets, DPF clamps, V-bands, and U-clamps.

# 2.5.2. Inspection

The exhaust system should be inspected for restrictions and leaks whenever exhaust system components are serviced or replaced. Kinks or crimped piping can result in excessive back-pressure which can cause increased fuel consumption, power loss and possible engine damage. Exhaust leaks are commonly the result of loose clamps, corroded or punctured exhaust tubes or DPF. Damaged parts should be replaced and loose clamp should be tightened securely.

# ™NOTE:

When installing new parts into the exhaust system, leave the clamps loose until the components have been installed. After complete installation of parts, the system should be aligned to allow clearance of engine and exhaust system piping. The clamps should now be tightened firmly to hold the piping in this alignment. Replace U-clamps and V-band clamps at the same time as the connecting component.



### 2.5.3. Diesel Particulate Filter (DPF)

### 2.5.3.1. Description

The DPF consists of three segments: a diesel oxidation catalyst in the inlet section, a particulate filter, and an outlet section. The particulate filter is constructed of a chemically coated ceramic material. The particulate filter removes particles from the exhaust. An ash deposit forms from this process. This deposit must be periodically removed by cleaning.

The DPF also incorporates three temperature sensors and two differential pressure sensors. One temperature sensor is mounted in the DPF diesel oxidation catalyst inlet section; the second and third are mounted in the fore and aft portions of the particulate filter segment. The differential pressure sensors are mounted in the fore and aft portions of the particulate filter segment. A sensor table, mounted on the side of the DPF, provides a stable platform for the electrical connectors that interface with the engine harness.

### 2.5.3.2. Operation

The engine ECM monitors the outputs from the sensors. The pressure sensor output is used to determine the ash or soot content of the particulate filter portion. Filter regeneration or filter maintenance will occur dependent on this signal.


### 2.5.3.3. Removal



Diesel oxidation catalyst elements used in the DPF are made from brittle material. DO NOT drop or strike the DPF; damage to the diesel oxidation catalyst element may result.

- 1. Set the Battery Disconnect switch to the OFF position.
- 2. Open the DPF access door to gain access to the DPF.
- Disconnect the pressure and temperature sensor electrical connectors from the DPF sensor table. See "Fig. 4-13: Diesel Particulate Filter Removal & Installation" on page 21.
- Remove the V-clamp connector from the DPF inlet. Discard the gasket.
- Remove the two U-clamps from the DPF outlet mounting bracket.
- 6. Remove the V-clamp connector from the DPF outlet. Discard the gasket.
- 7. Loosen the DPF base support clamp.
- 8. Attach lifting equipment to DPF and remove DPF assembly from vehicle.





- 1. Washer, Lower Rad 1.5" O.D.
- 2. Plug, 1/4"
- 3. Bolt, Hex 1/4" 20 UNC x 1" Lg.
- 4. Bolt, Hex 3/8" 16 UNC x 1 3/4" Lg.
- 5. Washer, Flat 3/8"
- 6. Clamp Assembly, Support
- 7. Bracket, DPF/Tail Pipe Support
- 8. Blanket, Ancillary Exhaust Tube
- 9. Clamp, Spherical 4"
- 10. Gasket, Spherical 4"

- 11. DPF Assembly
- 12. Ancillary Spherical Tube Assembly
- 13. Bracket, Ancillary Tube Support
- 14. Nut, Lock Nylon 5/16" 18 UNC
- 15. Never Seize
- 16. Washer, Flat SS 5/16"
- 17. Clamp, 4"
- 18. Bracket, Exhaust Tube Support
- 19. Bracket Assembly, Support
- 20. Clamp, DPF Support

- 21. Nut, Lock Nylon 1/4" 20 UNC
- 22. Wire, SS Exhaust Tubing
- 23. Washer, Flat 1/4"
- 24. Bolt, Hex 3/8" 16 UNC x 1" Lg.
- 25. Bolt, Hex SS 3/8" - 16 UNC x 1 1/4" Lg.
- 26. Washer, Flat SS 3/8"
- 27. Washer, Lock Spring Type 3/8"
- 28. Washer, Lock Spring Type SS 3/8"
- 29. Nut, Hex SS 3/8" 16 UNC

s126836a.svg

Fig. 4-13: Diesel Particulate Filter Removal & Installation



# 2.5.3.4. Disassembly

- Disconnect the aftertreatment exhaust gas inlet temperature sensor connector from the sensor interface module. See "Fig. 4-14: Diesel Particulate Filter Assembly" on page 22.
- Remove the V-band clamps from the inlet and outlet flanges of the DPF. Separate the flanges by 1/2" to allow removal of the gaskets. Discard the gaskets.
- Mark the direction of the exhaust flow, and draw an orientation reference line across each segment and V-band clamp, to aid in reassembly.
- Remove the exhaust gas temperature sensors from the DPF.
- Remove the differential pressure sensor tubes from the DPF.
- 6. Remove the sensor table from the DPF.




Fig. 4-14: Diesel Particulate Filter Assembly

# **Exhaust & Aftertreatment System**

### 2.5.3.5. Inspection

# ™NOTE:

If the muffler particulate filter is being replaced, clean the exhaust tube from the turbocharger outlet to the muffler catalyst section, including the muffler inlet.



DO NOT use a grinder to remove residual gasket material. Damage to muffler flanges may result.

DO NOT use an open flame to burn off accumulated muffler soot residue.

DO NOT scrape accumulated soot residue from the face of the muffler.

- 1. Use a scraping tool to remove any gasket material which has stuck to the muffler.
- Inspect V-band clamps and straps for overextension, bends, and damage to clamps or strap threads. Replace clamps and straps which exhibit any damage.
- 3. Replace particulate filters which exhibit any of the following conditions:
  - Shifting, moving or looseness of filter in canister
  - b. Cracking or damage of canister
- Send particulate filters to an authorized Cummins repair location for cleaning or replacement. Specialized cleaning equipment is required for the cleaning procedure.

### 2.5.3.6. Assembly

- 1. Install new gaskets into inlet and outlet segments of the DPF.
- Install new (or cleaned) particulate filter and attach to DPF sections using V-clamps. Do not tighten V-clamps until

final installation to allow section rotation and alignment of differential pressure sensor tubes.

- Install the sensor table onto the DPF.
- 4. Install differential pressure sensor tubes into the DPF.
- Install exhaust gas temperature sensors into the DPF and connect electrical connectors to the senor table.

### 2.5.3.7. Installation

- 1. Use lifting equipment and carefully lower DPF assembly into base support clamp.
- Align DPF and attach the inlet exhaust tube to the DPF inlet using a V-clamp and a new gasket. Torque clamp to 10 ft-lb. (14 Nm).
- Attach the outlet exhaust tube to the DPF outlet using a V-clamp and a new gasket. Torque clamp to 10 ft-lb. (14 Nm).
- Attach the two U-clamps to the DPF outlet mounting bracket.
- 5. Tighten the lower mounting bracket bolts.

### RNOTE:

Ensure that adequate minimum clearance of 1" exists between exhaust system components and vehicle structure.

- Connect the temperature and pressure sensor electrical connectors.
- Torque the DPF V-clamps 150 in-lb. (17 Nm).
- 8. Set the Battery Disconnect switch to the ON position.
- Run up the engine and check the exhaust system for correct operation and to ensure there are no leaks.
- 10. Close the DPF access door and secure in place.



### 2.5.4. Muffler Filter Regeneration

Regeneration is the process by which soot is removed from the muffler particulate filter. This regeneration can be automatic or stationary.

### 2.5.4.1. Automatic Regeneration



If the Exhaust High Temp indicator on the instrument panel illuminates, ensure the exhaust outlet is not located where it could cause damage to persons or any materials which could melt or explode and that nothing is within 2 feet of the outlet. Ensure no combustible materials are within 5 feet of the outlet. Exhaust outlet temperatures can reach 1500°F (800°C) during regeneration.

Passive regeneration occurs during vehicle operation when exhaust temperatures are naturally high enough to oxidize the soot collected in the muffler particulate filter. If the exhaust temperatures are not high enough to oxidize the soot, then the engine ECM will increase the exhaust temperature by typically injecting a small amount of diesel fuel into the exhaust system. This additional fuel is oxidized by the muffler catalyst which creates the heat necessary to regenerate the muffler particulate filter. No operator intervention is required during this automatic regeneration mode (also referred to as active regeneration). Although high exhaust temperatures occur during active regeneration, the High Exhaust Temp indicator on the instrument panel is programmed not to illuminate during the process. This indicator will illumias a warning that exhaust nate temperatures are excessive during normal, non-regeneration operation. The indicator will also illuminate during forced stationary regeneration.

# **Exhaust & Aftertreatment System**

### 2.5.4.2. Stationary Regeneration

Stationary regeneration is performed when the vehicle duty cycle is not sufficient for automatic regeneration to occur. If the Exhaust Regen Needed indicator on the instrument panel illuminates, the vehicle operator should immediately change to a more challenging duty cycle, or maintenance personnel should perform stationary regeneration. Refer to Section 19 of this manual for information on this indictor. Stationary regeneration is performed as follows:



During the stationary regeneration process exhaust gas temperatures can reach 1500°F (800°C) and exhaust system component temperatures can reach 1300°F (700°C). These temperatures can cause severe burns to persons and damage to property. Engine speed will also increase during this process.

- Park the vehicle in a secure and safe location on a stable surface which will not burn where nothing is within 2 feet of the exhaust outlet and no combustible materials are within 5 feet of the outlet.
- 2. Apply the parking brake.
- Press the Neutral button on the transmission shift selector.

- 4. Place wheel chocks in front of the front tires and behind at least one rear tire.
- 5. Place barriers at the rear of the vehicle which will keep persons at least 5 feet from the exhaust outlet region of the vehicle.
- If the vehicle is located indoors, attach an exhaust outlet tube rated to at least 1500°F (800°C).
- Ensure a fire extinguisher is located nearby.
- Inspect exhaust system surfaces to ensure nothing is interfering with them.
- 9. Start the engine.
- 10.Locate the Exhaust Filter switch inside the front destination sign compartment. Set the switch to the REGEN position. Engine speed and exhaust temperatures will increase while the muffler regenerates.
- 11. Monitor the area surrounding the vehicle to ensure nothing and no one interferes with the exhaust system components during the regeneration process. If required, shut off the engine to stop the process. Engine speed will return to low idle once the process is complete. Once the process is complete, exhaust system components will remain excessively hot for three to five minutes. The Exhaust High Temp indicator on the instrument panel will remain illuminated during the regeneration process.
- 12. Return the Exhaust Filter switch to the NORMAL position once the regeneration process is complete.



# 2.5.5. Selective Catalytic Reduction Unit (SCR)

### 2.5.5.1. Description

The Selective Catalytic Reduction Unit (SCR) is an assembly of two major components:

- An aftertreatment device similar to the Diesel Particulate Filter
- A Decomposition Reactor.

Both are horizontally mounted on a support cradle which is mounted in the rear ceiling area of the roof. Access to the SCR can be gained through the rear roof grill access panel and side access doors.

### 2.5.5.2. Operation

SCR systems inject urea (known as a reducing agent) and water, into the exhaust stream. In this first stage, the urea is converted into ammonia. In the second stage, which takes place in the SCR, the nitrous oxide combines with the ammonia to produce water and harmless nitrogen.



During regeneration, exhaust gas temperature can reach 800 °C [1500°F], and exhaust system surface temperature can exceed 700 °C [1300°F], which is hot enough to ignite or melt common materials, and to cause serious personal injury. The exhaust and exhaust components can remain hot after the vehicle has stopped moving. To avoid the risk of fire, property damage, burns or other serious personal injury, allow the exhaust system to cool before beginning this procedure or repair and make sure that no combustible materials are located where they are likely to come in contact with hot exhaust or exhaust components.

### 2.5.5.3. Removal

- Set the Battery Disconnect switch to the OFF position.
- 2. Remove the rear roof grill access panel and roof exhaust plate.
- 3. Open the DPF access door.
- Disconnect the electrical connectors from the SCR electronic control module and the dosing valve. See "Fig. 4-15: Selective Catalytic Reduction Removal & Installation" on page 27.
- Remove the tail pipe U-clamp and loosen the exhaust seal clamp, then remove the tailpipe.
- Remove the V-clamp at the decomposition reactor inlet and outlet. Discard the gaskets
- Disconnect DEF supply hose and coolant supply/return lines at the dosing module on the Decomposition Reactor.

### ™NOTE:

It is acceptable to remove the dosing valve without removing the DEF and coolant lines. Always support the DEF dosing valve. Do not let it suspend freely, for it may damage the fluid connectors and lines.

- 8. Remove the clamps securing the SCR electronic control module wiring and remove the NOx sensor mounting bolts.
- Remove the U-clamp securing the decomposition reactor and remove the decomposition reactor from the vehicle.
- Remove the bolts, washers and nuts from the securing straps holding the SCR catalyst.
- 11. Attach lifting equipment to the SCR catalyst and remove from the vehicle.






Fig. 4-15: Selective Catalytic Reduction Removal & Installation

### 2.5.5.4. Disassembly

- Disconnect the SCR temperature sensors from the SCR catalyst temperature sensor interface module. See "Fig. 4-16: Selective Catalytic Reduction Assembly" on page 28.
- 2. Remove the SCR temperature sensors from the SCR catalyst.
- 3. Remove the SCR temperature sensor interface module.
- 4. Remove the SCR catalyst temperature sensor interface module mounting bracket.






Fig. 4-16: Selective Catalytic Reduction Assembly

# **Exhaust & Aftertreatment System**

### 2.5.5.5. Inspection

 Inspect the SCR catalyst for cracks or puncture holes especially around the weld areas. Replace the aftertreatment SCR catalyst if it is damaged.



DO NOT use a metallic object to clean the SCR catalyst. This will scratch the surface of the SCR catalyst which may cause future excessive DEF crystallization build up.

Inspect the SCR catalyst inlet for diesel exhaust fluid deposits. If buildups are present carefully scrape with a non-metallic object to clean the majority of the buildup.



DO NOT use a pressure washer to remove diesel exhaust fluid deposits from the SCR catalyst.

### ™NOTE:

If crystallization buildup is found, be sure to complete a stationary regeneration once the exhaust system is reassembled. This will ensure the remaining diesel exhaust fluid crystallization has been removed from the SCR catalyst.

Inspect the exhaust flanges for corrosion or other damage.  Use a putty knife to remove any residual gasket material from the flanges on the SCR catalyst.



Avoid dropping fragments of gasket material into the SCR catalyst.

Do not grind on the flange surface, as this can damage the flange and cause the connection to leak.

- Inspect the v-band clamps and mounting straps for signs of over-extension. The band must not be bent or damaged.
- Inspect the v-band clamp and mounting strap threads for damage. Replace v-band clamps if necessary.

### 2.5.5.6. Assembly

- Install the SCR catalyst temperature sensor interface module mounting bracket.
- Install the SCR temperature sensor interface module.
- Install the SCR temperature sensors to the SCR catalyst.
- Connect the SCR temperature sensors to the SCR catalyst temperature sensor interface module.

# 2.5.5.7. Installation

### ™NOTE:

The decomposition reactor is installed as part of the Selective Catalytic Reduction (SCR) Unit. Refer to 2.5.6.4. "Installation" on page 32 in this section for procedure.



# 2.5.6. Decomposition Reactor

### 2.5.6.1. Description

The Decomposition tube is composed of a DEF dosing valve mount and decomposition tube mixer. The valve mount is where

the DEF dosing valve is mounted to allow DEF spray into the exhaust stream. The decomposition tube mixer creates a swirl pattern exhaust stream to help mix the DEF and engine exhaust. See "Fig. 4-17: Decomposition Reactor Assembly" on page 30.




Fig. 4-17: Decomposition Reactor Assembly

# **Exhaust & Aftertreatment System**

### 2.5.6.2. Cleaning & Inspection

- 1. Inspect all the joints for any signs of leaks. Leaking DEF will leave white deposits.
- 2. Inspect the DEF dosing valve mount for a buildup of crystallized DEF.
- 3. Inspect the DEF dosing valve mount for a buildup of crystallized DEF.
- Check the inlet of the SCR catalyst for buildup.
- 5. Inspect the outlet of the diesel particulate filter (DPF) for crystallization.
- Inspect the elbow and exhaust pipes connected to the decomposition tube for DEF buildups.

### MOTE:

If the crystallization is excessive and blocking a majority of the exhaust passages, there may be a problem with the DEF dosing valve. Refer to OEM information for complete fault code troubleshooting procedure.

- If buildups are present, carefully scrape with a non-metallic object to clean the majority of the build-up. Use a pressure washer to dissolve the remaining crystallization.
- 8. Inspect the exhaust flanges for corrosion or other damage.
- Use a putty knife to remove any residual gasket material from the flanges on the decomposition tube.



DO NOT grind on the flange surface, as this can damage the flange and cause the connection to leak.

- 10.Inspect the DEF dosing valve mounting area.
- 11. Check the threaded capscrew holes for damaged threads.
- 12.If the threads are damaged, the decomposition tube can be repaired using M6 x 1.0 helicoil inserts.
  - a. Bore out the hole down 12 mm and install the threaded coil. Use only the wire type coil inserts, since the amount of material around the threaded capscrew hole is limited.
  - Follow the manufacturer's recommended guidelines to install the coiled threaded insert.

### 2.5.6.3. Final Inspection

### ™NOTE:

The decomposition tube should be smooth and free of scratches or other damage. If the decomposition tube has any structural defects or material degradation, replace the decomposition tube.

Check the fo	llowing areas o	carefully	:
--------------	-----------------	-----------	---

	Aftertreatment dosing valve mount
П	Mixer

Insulation

Welded joints.



### 2.5.6.4. Installation

- 1. Attach lifting equipment to the SCR device and install it onto its support cradle.
- Secure the SCR device with the securing straps. Torque bolts which secure straps to 20 ft-lb. (27 Nm).
- Install the decomposition reactor and ensure the dosing module is rotated and aligned 60 +/- 10° from the vertical. See "Fig. 4-18: Decomposition Reactor Alignment" on page 32.
- 4. Secure the decomposition reactor in the proper position with a U-clamp.
- Mount the SCR electronic control module and secure that NOx sensor cable with clamps.
- 6. Connect DEF supply hose and coolant supply/return lines at the dosing module on the Decomposition Reactor.

- Install new gaskets and install the Vclamps at the Decomposition Reactor inlet and outlet.
- 8. Install the tailpipe and secure it in place with the U-clamp.
- Check alignment of all components and tighten all camps including the seal clamp on the tailpipe.
- Reinstall rear roof grill access panel and roof exhaust plate.
- 11.Set the Battery Disconnect switch to the ON position.
- 12. Start the vehicle and check for leaks. Check for active fault codes.
- 13. If DEF buildups where present, complete a stationary regeneration to make sure that any of the remaining diesel exhaust fluid crystallization has been removed from the SCR catalyst.
- 14. Continue to monitor for leaks at the exhaust joints.




Fig. 4-18: Decomposition Reactor Alignment



# 2.5.7. SCR Dosing Supply Unit

# 2.5.7.1. Description

The SCR dosing supply unit consists of a pump, filter, inlet, outlet, and backflow

ports, and an electrical connector. The dosing supply unit is mounted on the curbside in the engine compartment. See "Fig. 4-19: SCR Supply" on page 33.




Fig. 4-19: SCR Supply



### 2.5.7.2. Operation

The dosing supply unit is controlled by the engine ECM and draws diesel exhaust fluid from the DEF tank, pressurizes the fluid, and delivers the fluid through a filter to the dosing valve located on the decomposition reactor. Unused diesel exhaust fluid is returned to the DEF tank.

#### 2.5.7.3. Maintenance

Refer to the Preventive Maintenance Section of this manual for scheduled maintenance requirements and intervals.

#### 2.5.7.4. Removal



Wear eye protection when servicing the SCR supply module. Do not open any SCR fittings for five minutes after the engine has been turned off to allow the automatic purge cycle to complete.

- 1. Set the Battery Disconnect switch to the OFF position.
- Label each DEF line and its mating parts prior to removal to ensure correct reinstallation.
- Remove the DEF lines in the following order:
  - a. Backflow return line to the DEF tank.
  - b. Inlet supply line from the DEF tank.
  - c. Outlet delivery line to the dosing valve.
- 4. Cap all open lines and fittings to prevent contamination.

- Disconnect the 12-pin electrical connector from the dosing supply unit by sliding the yellow portion of the connector outward and lifting the connector straight upwards.
- Remove the three mounting bolts and remove the dosing supply unit from the vehicle.
- Inspect the supply module for damage or corrosion.

### 2.5.7.5. Cleaning & Inspection

- Inspect for signs of leakage as evidenced by a white residue around fittings, connections, and the filter cap. Examine these areas carefully for damaged connection fittings or sealing surfaces.
- 2. Use only a clean damp cloth to wipe down the unit. Do not immerse the unit in any type of cleaning solution and do not wash the unit with any detergents.

#### 2.5.7.6. Installation

- 1. Position the dosing supply unit on the upper rear panel and secure with three bolts, flat washers, and lock washers. Torque bolts to 14 ft-lbs. (19 Nm).
- Insert the 12-pin electrical connector into the socket and slide the yellow portion of the connector inward.
- Install the DEF lines in the following order, ensuring the lines snap and lock in place:
  - a. Backflow return line to the DEF tank.
  - b. Inlet supply line from the DEF tank.
  - c. Outlet delivery line to the dosing valve.

# **Exhaust & Aftertreatment System**

### 2.5.8. Diesel Exhaust Fluid (DEF) Tank

### 2.5.8.1. Description

The DEF tank is a molded polyethylene tank. It is mounted at the rear curbside of the vehicle and accessed through the rear curbside access door. The tank consists of the following components:

- □ Tank sensor assembly
- ☐ Float switch (normally closed)
- ☐ Filler neck with cap

### 2.5.8.2. DEF Tank Specifications

Fluid Capacity ...... 10.64 usable gallons (40 litres)

### 2.5.8.3. Operation

The engine ECU control module determines when and how much diesel exhaust fluid will be injected into the Decomposition Reactor. The SCR supply module pumps the fluid to the dosing module which then injects the fluid into the Decomposition Reactor.

### 2.5.8.4. Removal

- Turn the main Battery Disconnect switch to the OFF position. Open the fusebox access door and the rear engine access door.
- 2. Close the engine coolant valves.
- Remove the fill cap and drain plug from the DEF tank and drain it into a clean, properly labeled container.




Use eye protection and protective clothing.

### ™NOTE:

Refer to 2.6. "Diesel Exhaust Fluid" on page 45 in this section for proper handling procedures.

- 4. Mark, disconnect and plug hoses from the multi-function head unit assembly.
- Disconnect electrical connector from the multi-function head unit assembly See "Fig. 4-20: Diesel Exhaust Fluid Tank Removal & Installation" on page 36.
- Remove the mounting clamp from the tank.
- Use lifting equipment or the assistance of another person to remove the tank from the vehicle.





- 1. Hose, Silicone 3/4" I.D.
- 2. Clamp, Gear .56" .87"
- 3. Screw, PH Cross Recess SST #6 32 UNC x 1/2" Lg.
- 4. Channel, Rubber
- 5. Mount, Cable Tie 3/16" Eye
- 6. Bumper, Rubber
- 7. Cable Tie, 4/5" W x 8 1/2" Lg.
- 8. Spacer, Dual Swivel Saddle

- 9. Hose, Rubber 5/16" I.D.
- 10. Nut, Lock Nylon #6 32 UNC
- 11. Tray, DEF Tank
- 12. Clamp, Breeze .81" Dia. 1.5" Dia.
- 13. Screw, PH Cross Recess SST #10 24 UNC x 1 1/4" Lg.
- 14. Washer, Flat SST #6
- 15. DEF Tank Assembly
- 16. Screw, Hex HD #10 TRI-LOB

s1268112a.svg

Fig. 4-20: Diesel Exhaust Fluid Tank Removal & Installation



#### 2.5.8.5. Disassembly

- Mark the position of the Multi-Function Head Unit (MFHU) relative to the DEF tank.
- 2. Remove the two T25 Torx screws securing the retaining ring to the tank and remove the retaining ring.



DO NOT pull on wiring harnesses or fittings when trying to remove filter head from tank.

3. Use a flat head screwdriver to gently pry under the head unit while simultaneously pulling on the top of the unit. Continue prying and pulling until the mounting base is free from the tank.



DO NOT pull directly upward on MFHU when removing it from the tank as this might damage the head unit and seal bore. ALWAYS angle the unit out of the tank to prevent damage.

4. Pull the MFHU out of the tank until the inlet filter approaches the opening in the tank. Angle the MFHU and fold the filter element upwards. Continue to carefully remove the MFHU until completely free of the tank bore. See "Fig. 4-21: DEF Tank Assembly" on page 37.




Fig. 4-21: DEF Tank Assembly



#### 2.5.8.6. Assembly

- Clean and inspect the tank and all sealing surfaces.
- 2. Clean and install the drain plug. Torque to 40 to 60 in-lb. (4.5 to 6.7 Nm). dry.
- Service the multi-function head unit as follows:
  - a. If the level sensor needs to be replaced, remove the focus tube by hand, turning counter-clockwise until free. Then snip the ties holding the wire harness. Next, grip the sensor with a pair of pliers below its head and turn it counter clockwise.
  - b. Lubricate the gasket of a new level sensor with a thin layer of DEF compatible petroleum jelly or oil. Screw the new level sensor into place until the bottom lip of the level sensor is touching the top of the head unit.
  - c. Reinstall the focus tube tightening until hand snug. Resecure the wire harness.
- 4. Replace the suction filter on the multi-function head unit by removing the screw securing the filter. Install a new filter and align the screw hole in the multi-function head unit. Secure the filter with the screw.
- 5. Install a new O-ring on the MFHU.
- 6. Install the MFHU as follows:
  - a. Apply a thin layer of O-ring lubricant to the bore seal O-ring.



# DO NOT push the MFHU directly into the tank as this could damage the unit.

Fold the filter element upward and position the bottom of the MFHU inside the tank bore at an angle. Carefully work

the unit through the bore until the bottom of the unit and filter are inside the tank.



# DO NOT press directly on the fittings when installing the MFHU into the tank.

- c. Position the MFHU as marked during removal and press on the top of the blue mounting base until completely seated in the tank bore.
- d. Replace the retaining ring on the MFHU and install the two T25 Torx screws. Torque the screws 20 to 30 in-lb. (2 to 3 Nm).
- 7. Reinstall the filler cap on the tank.

#### 2.5.8.7. Installation

- Use lifting equipment to place the tank in the DEF tank tray.
- 2. Install mounting clamp onto the tank.
- 3. Tighten the tank straps until the strap springs are compressed to 1.4".
- Route the vent and drain hoses so that there is a continuous slope for draining. Torque the hose clamps to specifications. Refer to Section 6 of this manual for specification.
- Connect the hoses onto the tank sensor assembly.
- Connect the electrical connector to the tank sensor assembly.

#### 2.5.9. DEF Tank Filling

The Diesel Exhaust Fluid (DEF) tank can be filled manually at the fill location in the fusebox access door.

## **Exhaust & Aftertreatment System**

#### 2.5.10. Nitrous Oxide (NOx) Sensors

#### 2.5.10.1.Description

Two NOx sensors are mounted in the exhaust system piping. One is located after the turbocharger, the other is located after the SCR catalyst. Both NOx sensors are made up of a small electronic module with a wired connection to the sensor body that is installed in the exhaust system. These two parts are permanently connected and can not be separated. The wiring harness connector on the intake NOx sensor is keyed differently from the outlet NOx sensor.

#### 2.5.10.2.Operation

The NOx sensors monitor the level of nitrous oxide in the exhaust system. This information is used to control the regeneration cycles and the amount of Diesel Exhaust Fluid that gets injected into the exhaust stream.

#### 2.5.10.3.Removal

- Set the Battery Disconnect switch to the OFF position.
- Disconnect the vehicle harness from the electronic control module. See "Fig. 4-22: NOx Sensor Removal & Installation" on page 40.
- Disconnect any wire clips that are securing the cable between the sensor body and the electronic module.
- 4. Remove the mounting hardware from the sensor electronic control module.
- 5. Remove the NOx sensor from the exhaust system piping.
- 6. Remove the sensor.






Fig. 4-22: NOx Sensor Removal & Installation

## **Exhaust & Aftertreatment System**

#### 2.5.10.4. Cleaning & Inspection



DO NOT clean the NOx sensor with any kind of fluid. Damage to the sensor can occur.

DO NOT immerse the NOx sensor in water or any kind of chemical wash. Damage to the sensor can occur.

DO NOT jet wash or steam clean the NOx sensor. Damage to the sensor can occur.

- 1. Inspect the NOx sensor for damage to the wiring or to the body of the sensor.
- Inspect the electrical connector pins in the sensor and in the engine wire harness for signs of corrosion.
- Replace the intake NOx sensor if any damage is found.
- Inspect the engine NOx mounting hardware and replace any damaged isolator mounts.

#### ™NOTE:

This sensor is placed before the diesel particulate filter. It is not uncommon to have soot on the tip of the sensor. Do not try to clean the intake NOx sensor tip unless directed by fault codes or other trouble-shooting symptoms. Refer to Cummins OEM information for fault code trouble-shooting procedures.

Inspect the tip of the NOx sensor for damage. Replace the NOx sensor if any damage is found.

#### 2.5.10.5.Installation

- Apply a light coating of never-seez to the threads of the NOx sensor.
- Install the NOx sensor in the exhaust system and tighten the retaining nut. Torque to 37 ft-lb (50Nm).
- 3. Route the sensor wire in the same orientation as removed and clamp in place.
- Install the NOx sensor electronic module using the original mounting hardware. Torque the mounting screws to 39 in-lb (4.4 Nm).
- Connect the vehicle wire harness to the NOx sensor electronic module.
- 6. Switch the battery disconnect switch on.
- 7. Run the engine and check the exhaust system to ensure no leaks.

# 2.5.11. Exhaust Tubes, Exhaust Flex Connector & Exhaust Blankets

#### 2.5.11.1.Removal

- Cut the stainless steel wire using side cutters and unlace the exhaust blankets. Remove exhaust blankets.
- Remove the V-band clamps from the exhaust tube at the muffler inlet and from one end of the exhaust connector. Remove exhaust tube. See "Fig. 4-23: Exhaust Tube Removal" on page 42.
- Remove V-band clamp from other end of exhaust connector and remove exhaust connector.
- 4. Remove U-clamp from mounting bracket and V-band clamp from turbo outlet. Remove the exhaust tube.






Fig. 4-23: Exhaust Tube Removal

17. Gasket, Marmon 3.5"

s1268115a.svg

9. Spacer, Exhaust Tube

## **Exhaust & Aftertreatment System**

#### 2.5.11.2.Installation

- Loosely assemble and install V-clamp on the exhaust tube at the turbo outlet and loosely install the U-clamp to the mounting bracket.
- Loosely assemble remaining exhaust tube on muffler inlet.
- Align the exhaust tubes using the Flex Connector Alignment Tool. Refer to New Flyer Parts Manual for tool part number.
- 4. Collapse alignment tool and position in between the exhaust tubes.
- 5. Rotate both ends of the alignment tool until it locks into the expanded position (locating pin should be out of the slot and in contact with edge of the slotted end of the tool). Make sure that the flanged end of the exhaust tubes are properly seated to the tool. See "Fig. 4-24: Flex Connector Alignment Tool" on page 44.

#### ™NOTE:

Adjustment of muffler and/or exhaust tubes might be necessary to achieve proper alignment. If the tool does not align or does not fit between the exhaust tube ends, loosen the following: upper muffler clamp and 3 lower muffler base bolts, muffler elbow V-Band clamp, downpipe V-band, downpipe U-Bolt and turbo charge connection V-Band Install the tool to exhaust tubes.

- After verifying that the tubes and tool are all aligned, tighten the V-band clamp on the turbo charger connection to 75 in-lb (8.5 Nm). Tighten U-clamp. Tighten V-band clamp on the muffler connection to 75 in-lb (8.5 Nm). Tighten bolts on the muffler base if these were loosened.
- Loosen V-band clamps on the tool and slide them out of the way. Collapse the tool by rotating both ends and slipping the pin to the slot. Remove the tool.

- 8. Install exhaust flex connector and attach loosely to exhaust tube with V-clamp.
- The following criteria must be met while aligning exhaust tubes and exhaust flex connector:
  - Adequate clearance must be maintained between exhaust components and vehicle structure.
  - Ensure the exhaust flex connector is installed without any twisting applied to it so that its convolutions are straight and equally spaced from one end to the other.
  - Directional flow arrow on the exhaust flex connector outlet flange must point towards the muffler side of the installation.
  - d. The exhaust flex connector length shall be 10.00 ± 0.18" when measured between the crimping rings on either end. Adjust muffler exhaust tube as required to achieve this dimension. See "Fig. 4-25: Exhaust Flex Connector Installation" on page 44.
  - e. Examine the tubes and flex connector from above and below, with a 90° angle between the viewing points. The exhaust tubes on either side of the exhaust flex connector must be aligned parallel with each other and display no offset.
- 10. When installation is correct, torque the V-band clamps to 75 in-lb. (8.5 Nm).
- 11.Install each section of exhaust blanket by wrapping the blanket around the tube so that the seam is at the bottom. Compress the blanket sufficiently so that the seam is closed with ends of the insulation butting together. Ensure seam is overlapped with the blanket flap.
- 12. Secure the blanket using spring retainers.






Fig. 4-24: Flex Connector Alignment Tool




Fig. 4-25: Exhaust Flex Connector Installation



#### 2.6. Diesel Exhaust Fluid

#### 2.6.1. Description

Diesel Exhaust Fluid is a urea-based chemical reactant designed specifically for use in Selective Catalytic Reducing (SCR) systems to reduce Nitrous Oxide (NOx) emissions. The raw materials used to produce DEF include natural gas, coal or other petroleum products. DEF is prepared by dissolving solid high purity urea in deionized water to create a 32.5% solution in water.

Urea is:

- Nontoxic and nonpolluting
- □ Nonflammable
- ☐ Stable and colorless
- Composed of urea and water.

Diesel Exhaust Fluid may be called by other names, including:

- □ Urea
- ☐ AUS 32 (Aqueous Urea Solution 32)
- ☐ AdBlue™
- ☐ NOx Reduction Agent
- Catalyst Solution
- ☐ Stableguard 32.



Any Diesel Exhaust Fluid used in this vehicle must meet the requirements as outlined in the specifications section.

#### 2.6.2. Diesel Exhaust Fluid Specifications

The urea content of the solution must be 32.5 percent  $\pm$  0.7 percent by weight and must meet the International Standard ISO 22241-1 for diesel engines. There is no acceptable substitute.

Diesel exhaust fluid should be certified by the American Petroleum Institute (API), Indicated by the symbol on the container/ dispensing system. See "Fig. 4-26: Diesel Exhaust Fluid Certification Symbol" on page 45.



NEVER add water or any other fluid to the diesel exhaust fluid tank. Damage to the aftertreatment system may result. Adding water to the diesel exhaust fluid tank:

- Will change the diesel exhaust fluid concentration levels, which may affect SCR efficiency.
- May add contaminates and/or affect the chemical properties of the diesel exhaust fluid, which may damage the aftertreatment system.
- Will alter the freeze point and characteristics of the diesel exhaust fluid solution, potentially leading to damaged diesel exhaust fluid dosing system components during cold weather operation.




Fig. 4-26: Diesel Exhaust Fluid Certification Symbol



#### 2.6.3. Operation

Diesel Exhaust Fluid is injected into the exhaust stream where the urea is converted into ammonia. Nitrous oxide in the exhaust gasses combines with the ammonia to produce water and harmless nitrogen. Refer to 2.5.4. "Muffler Filter Regeneration" on page 24 and Refer to 2.5.6. "Decomposition Reactor" on page 30 in this section for more information on the components involved in this process.



It is unlawful to tamper with or remove any component of the aftertreatment system. It is also unlawful to use diesel exhaust fluid that does not meet the specifications provided or to operate the vehicle/equipment with no diesel exhaust fluid.



Diesel exhaust fluid contains urea. Do not get the substance in your eyes. In case of contact, immediately flush eyes with large amounts of water for a minimum of 15 minutes. Do not swallow internally. In the event the diesel exhaust fluid is ingested, contact a physician immediately.

#### 2.6.4. Handling

Diesel exhaust fluid is not harmful to handle, but can be reactive and/or corrosive to the following materials over time:

- Carbon steels, zinc coated carbon steels, and mild iron
- ☐ Nonferrous metals and alloys: copper, copper alloys, zinc, and lead

- □ Solders containing lead, silver, zinc, or copper
- Aluminum and aluminum alloys
- ☐ Magnesium and magnesium alloys
- Plastics or metals coated with nickel.

If diesel exhaust fluid comes in contact with any of these materials, clean immediately. Refer to 2.6.8. "Disposal & Cleaning" on page 47 in this section.

#### 2.6.5. Shelf Life

The following conditions are ideal for maintaining diesel exhaust fluid quality and shelf life during prolonged storage:

- ☐ Storage temperature between -5°C to 25°C [23°F to 77°F]
- Storage in sealed containers to reduce the possibility of contamination
- Storage in an area that avoids direct sunlight.

In these conditions, diesel exhaust fluid has a minimum expected shelf life of 18 months. However, each 5°C [9°F] increment above recommended temperatures reduces shelf life by 6 months (for example 30°C [86°F] = 12 month shelf life, 35°C [95°F] = 6 month shelf life, etc.).

#### 2.6.6. Storage

Long term storage in a vehicle (in excess of 6 months) is **not** recommended. If long term storage is necessary, periodically test the diesel exhaust fluid to make sure the concentration does **not** fall out of specification. Refer to 2.6.10. "Testing" on page 47 in this section for procedure.

Refer to ISO 22241-3 for detailed information on handling, transportation, and storage of Diesel Exhaust Fluid.



#### 2.6.7. Cleanliness Practices

Materials that come into contact with diesel exhaust fluid **must** be free from any contamination, oil, fuel, dust, detergents, and any other chemicals.

#### ™NOTE:

Spilled DEF, if left to dry or wiped away with a cloth only, will leave a white residue. Failure to clean the spilled diesel exhaust fluid from a surface may result in an incorrectly diagnosed leak of the diesel exhaust fluid dosing system.

Thoroughly wash any containers or funnels that will be used to dispense, handle, or store diesel exhaust fluid. Wash them thoroughly to remove any contaminants and then rinse with distilled water.



DO NOT use tap water to rinse components that will be used to deliver diesel exhaust fluid. Tap water will contaminate the diesel exhaust fluid. If distilled water is not available, rinse with tap water and then rinse with diesel exhaust fluid.

#### 2.6.8. Disposal & Cleaning

Transfer spilled DEF into a suitable container or cover the spill using an absorbent material. Disposed of DEF according to local environmental regulations.



Containers used to store disposed DEF must be labeled correctly. DO NOT empty waste DEF into the drainage system. DO NOT empty/release waste DEF into surface water.

#### 2.6.9. First Aid

In case of contact with eyes, immediately flush eyes with large amounts of water for a minimum of 15 minutes.

In the event that diesel exhaust fluid is ingested, contact a physician immediately.

#### 2.6.10. Testing

Having the correct concentration of Diesel Exhaust Fluid is critical for proper engine and aftertreatment system performance. Test the concentration of the Diesel Exhaust Fluid using a Diesel Exhaust Fluid Refractometer. See "Fig. 4-27: Diesel Exhaust Fluid Refractometer" on page 48. Refer to your New Flyer Parts Manual for tool part number. Follow the instructions provided with the service tool.

Correct urea concentration level is  $32.5 \pm 1.2\%$ 

#### ™NOTE:

The specification listed above is from the ISO 22241-1 standard. When measuring the Diesel Exhaust Fluid concentration, consideration of the tool tolerances, variability and calibration should be factored before condemning the diesel exhaust fluid.

If the DEF concentration is outside of this specification, drain the DEF tank, flush it clean with distilled water and fill with new or known good Diesel Exhaust Fluid, then recheck the Diesel Exhaust Fluid concentration.

The concentration of the DEF should be checked when:

- ☐ The vehicle has been stored for an extended period of time.
- ☐ It is suspected that water has been added to the Diesel Exhaust Fluid tank






Fig. 4-27: Diesel Exhaust Fluid Refractometer

#### 2.6.11. Contamination/Incorrect Fluid



NEVER add water or any other fluid to the Diesel Exhaust Fluid (DEF) tank. Damage to the aftertreatment system may result.

In the event that the incorrect fluid is added to the Diesel Exhaust Fluid tank, contact a local Cummins Authorized Repair location to determine the appropriate repair. If only water has been added to the Diesel Exhaust Fluid tank, drain the tank, flush with distilled water and refill with new Diesel Exhaust Fluid. Check the concentration after completing the refill.

#### 2.6.12. Freezing



DO NOT add any chemicals/additives to the diesel exhaust fluid in an effort to prevent freezing. If chemicals/additives are added to the diesel exhaust fluid, the aftertreatment system may be damaged.

Diesel exhaust fluid freezes at approximately 12°F (-11°C). The diesel exhaust fluid system on the vehicle is designed to accommodate this and does not require any intervention by the vehicle operator.

## **Front Onboard Diagnostic Connector**

# 2.7. Front Onboard Diagnostic Connector

#### 2.7.1. Description

The Onboard Diagnostic Connector is located under the dash next to the outboard side of the steering column. The connector is labeled "OBD" for easy identification. See "Fig. 4-28: Onboard Diagnostic Connector" on page 49.

This connector is a standard 9-pin diagnostic connector containing diagnostic drops for the engine J1939/J1708 and the vehicle Multiplexing system J1939 networks.




Fig. 4-28: Onboard Diagnostic Connector



## 2.8. Engine Switch Box

#### 2.8.1. Description


The engine switch box is located in the engine compartment and is visible immediately upon opening the engine door. It contains the following:

See "Fig. 4-29: Engine Switch Box" on page 51.

- ☐ Rear Engine Run switch used to select front or rear engine starting.
- ☐ Start Button used for starting the engine from the rear of the vehicle.

- ☐ Compartment Lights switch used to illuminate engine compartment.
- ☐ Wait To Start lamp indicates when the engine is ready to start.
- ☐ Engine Coolant Fill Mode switch used during coolant filling process to open all heating system solenoid valves.
- Engine Diagnostic Connector used for connecting diagnostic hardware during service.
- ☐ CAN Communicator used to display engine data and diagnostic information.





- 1. Engine Switch Box Assembly, (Incl. 2-24)
- 2. Pin, #18 16 AWG
- 3. Loctite, 243 Blue
- 4. Switch, SPST WP Maintain
- 5. Switch, Toggle SPDT Maintained On-Off-On
- 6. Screw, PH Cross Recess SST #10 24 UNC x 3/4" Lg.
- 7. Screw, PH Cross Recess SST #8 32 UNC x 5/8" Lg.
- 8. Screw, PH Cross Recess SST #10 32 UNF x 1/2" Lg.
- 9. Adhesive, SIKA 221 White
- 10. Mount, Cable Tie 3/16" Eye
- 11. Lamp, LED Amber 12V
- 12. Gasket, Switch Box

- 13. Bracket, Switch Box Side
- 14. Washer, SST Cup .664" O.D. x .466" I.D.
- 15. Bracket, 3 Pin Connector
- 16. Switch Box Assembly
- 17. Gauge, Can Communicator
- 18. Switch, Push Button
- 19. Harness, Engine Compartment Switch Box
- 20. Plate, Switch Box
- 21. Washer, Flat SST #10
- 22. Washer, Flat SST #8
- 23. Never Seize
- 24. Guard, Toggle Switch

s0166560a.svg

Fig. 4-29: Engine Switch Box



#### 2.8.2. Operation

Before attempting to start the engine from the engine compartment make certain that:

- 1. The parking brakes are applied.
- Master Run switch is turned to the STOP-ENGINE position.
- 3. Shift selector is in neutral [N] position.
- 4. Check that the Battery Disconnect switch is in the ON position.



# DO NOT switch from REAR to FRONT while engine is running.

Locate the Engine Run switch on the engine compartment switch box and set the switch to the REAR position. Check for any obstructions to the moving parts of the engine before starting. Push and hold the start push button to engage the starting system. Release as soon as engine starts. The engine can be stopped by setting the Engine Run switch to the OFF position.

#### 2.8.3. CAN Communicator

#### 2.8.3.1. Description

The CAN-Communicator provides a graphic display in a compact form. This gauge is connected to the vehicle SAE J1939 (CAN) data bus. The gauge can display data and diagnostics, both active and stored faults from the individual ECMs, directly from the vehicle data bus.

#### 2.8.3.2. Operation

There are 3 buttons for navigating through the screens of its menu system which display's diagnostics, parametric data and popup warnings.

Diagnostic capabilities include both active and stored fault codes from the ECU. Data can be viewed as a single parameter or as three parameters, which the user can scroll through to view additional data. C-COM is also populated with warning messages to alert the user to conditions on the vehicle.

The setup menu screens provide customization to the data line items and warning messages that can be displayed. The setup menus allow users to change measurement units and to set the display contrast and brightness.

The backlit liquid crystal display (LCD) is 106 pixels wide and 56 pixels high, providing clear, legible graphics. Backlighting can be controlled through the menu. A deadfronted warning indicator is positioned above the graphic display window and is capable of illuminating as an amber or red warning for active fault codes and popup warnings, respectively.

#### 2.8.3.3. Data Parameters

The tol	lowing	are the	stanc	lard o	lata p	aram-
eters.						

Vehicle Speed
Engine RPM
Engine Oil Pressure
Coolant Temperature
Engine Oil Temperature

Battery Voltage
Turbo Boost Pressure

☐ Transmission Oil Temperature

Engine Hours

#### 2.8.3.4. Popup Warning Messages

The following are the standard popup warning messages.

	Coolant Temperature
	Engine Oil Pressure
	Engine Oil Temperature
	Transmission Temperature
	Battery Voltage
П	Check Engine

☐ Check Transmission

Stop Engine

Refer to 3. "VENDOR SERVICE INFOR-MATION" on page 63 in this section for more information on this device.

## **Fire Suppression System**

#### 2.9. Fire Suppression System

#### 2.9.1. Description

The Fire Suppression System monitors a small flow of electrical current through system circuits. A disruption of this flow prompts the system to react. Major components of the system include the following:

☐ Three heat sensors in the engine compartment. See "Fig. 4-30: Fire Suppression System" on page 54.

- ☐ Four extinguishing agent discharge nozzles in the engine compartment, connected to a common distributor.
- ☐ An extinguishing agent cylinder located in an overhead streetside light compartment.
- ☐ An actuation switch located in the driver's overhead panel.
- ☐ A control panel located in the driver's overhead panel to provide audible and visual warnings of system operation.






Fig. 4-30: Fire Suppression System



#### 2.9.1.1. Agent Cylinder Assembly

The agent cylinder is filled with an extinguishing chemical and is charged to 350 psi. It is fitted into a welded steel cylinder bracket. The cylinder is fitted with an actuating solenoid which controls cylinder discharge.

#### 2.9.1.2. Actuation Switch

An electrical actuation switch is mounted in the driver's overhead panel for remote operation of the system.

#### 2.9.1.3. Discharge Tubes

The discharge tubes carry the chemical extinguishing agent to the discharge nozzles. They are constructed of 1/2" SS tubing with fittings.

#### 2.9.1.4. Discharge Nozzles

The discharge nozzles are of brass construction and serve to distribute the chemi-

cal agent in a conical pattern. Nozzles come with a heat and weather resistant blow-off cap to prevent entry of contaminants and obstructions into the nozzle outlets.

#### 2.9.1.5. Control Panel

The Modular Control Panel III provides electrical supervision of the power, detection, and releasing (suppression) circuits. The control panel features visual LED system status indicators and an audible alarm that can be silenced. The system provides a test mode to verify LED and alarm function. The panel is supplied with a backup battery to provide protection to the vehicle in the event of temporary power loss. The control panel also includes an adjustable time delayed releasing circuit and an adjustable time delayed relay circuit. The test mode for the control panel verifies LED, alarm function, and relay function. See "Fig. 4-31: Fire Suppression Control Panel" on page 55.




Fig. 4-31: Fire Suppression Control Panel



#### 2.9.1.6. Operation

#### System OK

The "System OK" green LED will illuminate to indicate that the panel is plugged into an operational configuration.

#### System Alarm

The following sequence of events will occur when either the heat detection circuit has detected a fire or the manual actuation switch has been activated:

"System OK" LED will extin
----------------------------

The alarm buzzer will sound continuou
---------------------------------------

☐ The "FIRE" red LED will illuminate.

The	system	will	discharge	after	pro-
gram	med dela	ιy.			

☐ The relay will engage after programmed delay.

☐ The "Relay Reset" LED will illuminate.

☐ The "Service System" LED will illuminate.

☐ The "Service System" LED will flash four times to indicate actuator trouble.

When the "FIRE" LED first illuminates, it will flash a number of times to indicate which hazard zone is in alarm. The alarm blink codes are as follows:

SYSTEM ALARM			
ALARM SOURCE	NUMBER OF FLASHES		
Heat zone #1	1		
Heat zone #2	2		
Both heat zones	3		

The system will remain in alarm until the system has been serviced and the actuator has been replaced.

#### Service System

The following sequence of events will occur in the event of a system fault:

☐ The "Service System" LED will illuminate.

☐ The audible alarm will pulse.

☐ The "Service System" LED will flash to indicate the fault source.

The source of the fault can be determined as follows:

SERVICE SYSTEM		
TROUBLE SOURCE	NUMBER OF FLASHES	
Main power supply	1	
Heat zone #1	2	
Heat zone #2	3	
Actuator	4	
Backup battery	5	
Pressure switch	7	

There is a five second delay before notification when a system fault occurs and a 20 second delay before notification when a main power fault occurs.



#### Alarm Silence

In the event of a System Alarm of System Service, the buzzer can be silenced by using the "Alarm Silence" button. The "Alarm Silence" LED will illuminate when the "Alarm Silence" button is pressed. The other LED's will continue to show the alarm of service system fault status. The alarm will remain silent for six hours and then reactivate to remind personnel that a problem condition is present.

#### **Push to Test**

All LED's will illuminate, the alarm will sound, and the relay will be engaged when the "Push to Test" button (Amerex diamond) is pressed. This allows verification of system notification and relay functions. The "Push to Test" function will not cause a system discharge.

The control panel will also signify the programmed relay delay and discharge delay (default delay for both is 0 seconds). The relay delay is shown by the number of flashes of the "Relay Reset" LED. The discharge delay is shown by the number of flashes of the "Alarm Silence" LED.

The programmed time delays can be determined as follows:

PUSH TO TEST				
NO. OF FLASHES	RELAY DELAY	DISCHARGE DELAY		
0	0 sec	0 sec		
1	5 sec	5 sec		
2	10 sec	10 sec		
3	15 sec	15 sec		

#### **Relay Reset**

Pressing the "Relay Reset" button, in the event of an alarm condition, will reset the relay delay to the programmed delay time. The relay function can also be maintained by continuously pressing the "Relay Reset" button.

Pressing the "Relay Reset" button, once the alarm condition has been serviced and the system recharged, will reset the relay and allow normal vehicle operation.



# Discharge Delay & Relay Delay Programming

The delays for discharge and relay activation can be programmed using the control panel. The default delay for both is 0 seconds. The delays can be set from 0 seconds to 15 seconds in 5 second intervals use the following procedure to program the delays:

- 1. Press and hold the "Relay Reset" and "Alarm Silence" buttons for 20 seconds.
- The panel will chirp once and the "System OK" LED will flash.
- 3. Press the "Alarm Silence" button "x" times for the discharge delay.
- 4. Press the "Relay Reset" button "x" times for the relay delay.
- Allow 10 seconds for the panel to reprogram the delays. After approximately 10 seconds the panel will chirp twice and the "System OK" LED will stop flashing.

The discharge and relay delays with be set according to the number of times the button is pressed. The delay values are as follows:

DISCHARGE DELAY & RELAY DELAY PROGRAMMING		
NUMBER OF BUTTON PRESSES	DELAY (IN SECONDS)	
1	0	
2	5	

DISCHARGE DELAY & RELAY DELAY PROGRAMMING		
NUMBER OF BUTTON PRESSES	DELAY (IN SECONDS)	
3	10	
4	15	

# Setting the Delays to Factory Default Values

Press and hold the "Push to Test" button for five seconds in order to return the discharge and relay delays to their factory default values. The alarm will sound and the "Relay Reset" LED and "Alarm Silence" LED will flash once to acknowledge that the delays have been reset to their factory default setting of 0 seconds (no delay).

#### 2.9.1.7. Backup Battery

The Modular Control Panel III) contains a Nickel Metal Hydride 8.4V olt backup battery to maintain vehicle protection in the event of loss of the main vehicle power source. The backup battery will maintain operation of the fire suppression system for 24 hours without the vehicle main power source. After 20 seconds of removing all field wiring from the panel, the trouble condition will stop and unit will go into hibernation mode to maximize backup battery life.

#### 2.9.2. Maintenance

Refer to the Preventative Maintenance section of the manual for scheduled maintenance activities and intervals.



# 2.9.3. Fire Suppression System Troubleshooting

Diagnose electrical problems in the power circuit, detection circuit, actuator circuit, backup battery, and pressure switch circuit as follows:

FIRE SUPPRESSION SYSTEM TROUBLESHOOTING			
ELECTRICAL CIRCUIT OR DEVICE	CONDITION	POSSIBLE CAUSE	ACTION OR SOLUTION
Power circuit	No green "System OK" LED on the panel. Red "Service System" LED flashes one time.	LED on the being supplied to the panel. Vehicle em" LED power to the panel	Check the Amerex main power fuse located inline on the red positive (+) lead at the battery. Replace fuse as necessary with a 10 Amp fast-blow fuse. Do not substitute with fuse of higher or lower rating.
			Unplug the red color coded main power lead from the panel pig-tail lead and check to see if 9 to 30 Volts DC is being supplied to the system. If vehicle battery power has been restore vehicle battery power has been lost, restore power. If more than 30 volts is being applied to the panel, the internal circuit breaker will trip, and shut off the panel. The breaker will automatically reset when cool and when 9 to 30 Volts DC is supplied to the panel.
			Ensure that all the circular locking pigtail lead plugs on the bottom or back of the panel are securely attached and locked.
			Plug power lead back into panel pigtail. Check for green "System OK" LED.



FIRE SUPPRESSION SYSTEM TROUBLESHOOTING			
ELECTRICAL CIRCUIT OR DEVICE	CONDITION	POSSIBLE CAUSE	ACTION OR SOLUTION
Detection circuit	Detection circuit  No green "System OK" LED on the panel. Red "Service System" LED flashes two or three times.  Open or short circuit in thermostat, actuation button, and/or thermostat circuit wiring.	circuit in thermostat, actuation button, and/or thermostat	Determine from the "Service System" LED which zone is in failure (2 blinks for Zone 1, 3 blinks for Zone 2).
			Ensure that all the circular locking pigtail lead plugs on the bottom or back of the panel are securely attached and locked.
			Unplug both the green color coded detection circuits from the green color coded panel pigtail leads at the panel. Plug an End of Line Module that is known to be good into each green color coded pig-tail lead from the panel. Check to see if green "System OK" LED is now illuminated. If green LED is illuminated, the panel is good.
		To find the faulty circuit or component, remove the End of Line Module from one of the green color coded pig-tail leads, plug the first circuit component back into the corresponding green color coded pig-tail from the panel. Now plug the End of Line Module into the male plug at the end of that component. If the green LED on the panel again illuminates, that component is good.	
		Repeat this process, one component at a time, until the faulty component is found.	
			NOTE: There are two green color coded circuits.



FIRE SUPPRESSION SYSTEM TROUBLESHOOTING			OUBLESHOOTING
ELECTRICAL CIRCUIT OR DEVICE	CONDITION	POSSIBLE CAUSE	ACTION OR SOLUTION
Actuator circuit  Red "F"RE" LED is illuminated, audible alarm is sounding, and internal relay is engaged. Red "Service System" LED is flashing. When the "FIRE" LED first comes on it will blink a number of times to indicate which zone is in alarm. Refer to "System Alarm" in this section for definition of blink codes.	illuminated, audible alarm is sounding, and internal relay is engaged. Red "Service System"	System has discharged	Recharge system. Refer to 3.  "VENDOR SERVICE INFORMATION" on page 63 in this section for instructions on how to recharge the system. Return system to service once recharged.
	"FIRE" comes on a number o indicate e is in fer to Alarm" in on for	Ensure that proper vehicle battery power is being supplied to the panel. Refer to "Power Circuit" in this troubleshooting chart for procedure.	
		Ensure that all the circular locking pigtail lead plugs on the bottom or back of the panel are securely attached and locked.	
		Unplug the yellow color coded actuation lead from the yellow color coded panel pigtail lead at the panel. Plug a Fire Alarm Test Module P/N 14027 into the yellow color coded pigtail lead from the panel. If the red "FIRE" LED on the panel turns off and the green "System OK" LED illuminates, the panel is good.	
		To find the faulty circuit or component, remove the Fire Alarm Test Module from the yellow color coded pig-tail lead, plug the first circuit component back into the corresponding yellow color coded pig-tail from the panel. Now plug the Fire Alarm Test Module into the female plug at the end of that component. If the red "FIRE" LED on the panel turns off, that component is good.	
			Repeat this process, testing one component at a time, until the faulty component is found.



FIRE SUPPRESSION SYSTEM TROUBLESHOOTING			
ELECTRICAL CIRCUIT OR DEVICE	CONDITION	POSSIBLE CAUSE	ACTION OR SOLUTION
Pressure switch circuit	No green "System OK" LED on the panel. Red "Service System" LED flashes 7 times.	System is equipped with agent cylinder pressure switch and agent cylinder	Ensure that all the circular locking pigtail lead plugs on the bottom or back of the panel are securely attached and locked.
		has depressurized.	Verify the agent cylinder is equipped with an agent cylinder pressure switch and that the switch is plugged in. The agent cylinder pressure switch circuit must be closed. If the circuit is open, the panel registers a fault condition. If switch is unplugged or the circuit is otherwise broken, the circuit is open.
			Verify that the agent cylinder has proper pressure indicated by the green pie area of the pressure gauge. Repair and re-pressurize agent cylinder.
		System is not equipped with agent cylinder pressure switch and unused agent cylinder pressure switch circuit is open.	Repair unused agent cylinder pressure switch wire. Splice unused leads together. The switch leads are red and black in a two conductor parallel lead. This lead is marked with a blue protective tube on the free end. They exit the panel in the same circular connector as the red, black and white relay leads.
Backup battery diagnostics	"Service System" LED flashes 5 times	Backup battery is run down or defective	Replace backup battery. Refer to 2.9.1.7. "Backup Battery" on page 58 in this section for replacement procedure.



## **Cummins ISL (2015) Manuals**

# 3. VENDOR SERVICE INFORMATION

The following supplier manuals contain additional reference information.

## 3.1. Cummins ISL (2015) Manuals

- Custom Parts Manual
- □ Troubleshooting Manual
- ☐ Service Manual

- ☐ Operation & Maintenance Manual
- ☐ Owner's Manual

#### 3.2. Forster Manual

☐ Can-Communicator User Guide

# 3.3. Amerex Fire Suppression Manuals

- ☐ V25ABC Operation & Maintenance
- ☐ SafetyNet Operation & Maintenance

## **Amerex Fire Suppression Manuals**





# **Transmission System**

1.	SAFETY	5-1
	1.1. Safety Procedures	5-1
2.	TRANSMISSION SYSTEM	5-2
	2.1. Description	
	2.2. Operation	
3.	ALLISON B400R TRANSMISSION	5-3
	3.1. Description	5-3
	3.2. Transmission Specifications	
	3.3. Operation	
	3.3.1. Reduced Engine Load At Stop (RELS)	
	3.3.2. Auto-Neutral	
	3.3.3. Retarder Operation	
	3.4. Maintenance	
	3.4.1. Transmission Oil Maintenance	
	3.4.1.1. Oil Storage & Handling	5-6
	3.4.1.2. Proper Oil Level	
	3.4.2. Oil Check Procedure	
	3.4.2.1. Cold Check	
	3.4.2.2. Hot Check	
	3.5. Transmission Troubleshooting	
	3.6. Removal	
	3.7. Disassembly	
	• · · · · · · · · · · · · · · · · · · ·	
	3.9. Installation	
	3.9.1. Installing Transmission Output Drive Yoke	
	3.9.2. Installing Oil Filler Tube & Seal	
	3.9.3. Installing Transmission	
	3.9.3.2. Torque Converter Adapter Installation	
	3.9.3.3. Transmission Join-Up & Alignment	
	3.9.3.4. Flexplate Attachment to Torque Converter Housing	
	3.9.3.5. Final Installation	5-15
4.	PUSH BUTTON SHIFT SELECTOR	5-17
	4.1. Description	5-17
	4.2. Operation	5-18

## Table of Contents



4.2.1.	Shift Selector Operation	5-19
4.2.2.	Shift Inhibits	5-20
4.2.3.	Electronic Fluid Level Check	5-20
4.2	2.3.1. Invalid for Display Codes	5-21
4.2.4.	Prognostics	5-22
4.2.5.	Diagnostic Trouble Code Check	5-23
4.3. Shif	ft Selector Troubleshooting	5-24
	<u> </u>	
4.0. 11130		
<b>RETAR</b>	DER ACCUMULATOR	5-26
5.1. Des	cription	5-26
_		
	•	
5.5. Clea	aning & Inspection	5-28
5.6. Ass	embly	5-28
5.6. i uii	otional rost	J-20
VENDO	R SERVICE INFORMATION	5-29
6.1. Allis	son B400 Transmission Manuals	5-29
	4.2.2. 4.2.3. 4.2.4. 4.2.5. 4.3. Shift 4.4. Ren 4.5. Inst  RETAR 5.1. Des 5.2. Ope 5.3. Ren 5.4. Disa 5.5. Clea 5.6. Ass 5.7. Inst 5.8. Fun  VENDO	4.5. Installation  RETARDER ACCUMULATOR  5.1. Description  5.2. Operation  5.3. Removal  5.4. Disassembly  5.5. Cleaning & Inspection  5.6. Assembly  5.7. Installation  5.8. Functional Test



#### 1. SAFETY

#### 1.1. Safety Procedures

This section of the service manual contains procedures which require the mechanics to strictly observe safety procedures in order to ensure personal and equipment safety.

YOU ARE RESPONSIBLE for becoming completely familiar with the warnings and cautions described in this section regarding the Allison B400R transmission. These warnings and cautions advise against the use of specific service methods that can result in personal injury, damage to the equipment, or cause the equipment to be made unsafe. Anyone who uses a service procedure or tool which is not recommended by New Flyer Industries or Allison Transmission must first be thoroughly satisfied that neither personal safety nor equipment safety will be jeopardized by the service methods selected.

Proper service and repair is important to the safe, reliable operation of the equipment. The service procedures recommended by Allison Transmission are described in this section and are effective methods for performing service operations. Some of these service operations require the use of tools specially designed for the purpose. The special tools should be used when and as recommended.

Refer to the General Information Section of this manual for information on types of hoists, hoisting procedures, jackstands and related safety information. Refer to this information and read carefully before lifting, hoisting or jacking the vehicle.

Always ensure that the vehicle is appropriately hoisted and blocked for procedures which require elevating the vehicle. Be aware of the limitations of the blocking equipment, and always ensure that the jar-

ring and shaking created by component removal and installation procedures does not overload the blocks, or cause the vehicle to become unstable.

Certain procedures may require the vehicle be operated in an elevated position in order to accurately troubleshoot and diagnose a problem. If the vehicle must be running while elevated, become familiar with the repair area prior to starting the engine. Take special care in noting areas which will become hot, electrically energized, and areas where moving and rotating components are located. Limit the work in these areas as personal and equipment safety is at risk.

For procedures which involve air lines, ensure the line is safely depressurized prior to disconnecting. Disconnecting pressurized lines will cause solid particles deposited in the line to be uncontrollably propelled, and will also cause the hose end to whip randomly as the air escapes.

During electrical diagnosis procedures an understanding of the vehicle's electric circuits is important to anticipate the results of connecting test equipment. During component removal or installation, ensure the Battery Disconnect switch is in the OFF position.

Failure to follow this procedure may result in personal injury or component failure.

Observe the following procedures involving hydraulic line removal.

- ☐ Hydraulic fluid is corrosive and should not be exposed to skin for extensive periods of time.
- Wear eye protection at all times.
- Pressurized lines should not be disconnected until the pressure is safely and controllably released.



#### 2. TRANSMISSION SYSTEM

## 2.1. Description

The Transmission System consists of the following components. See "Fig. 5-1: Transmission System Layout" on page 2.

- ☐ Allison B400R Transmission
- ☐ Push Button Shift Selector (PBSS)

- ☐ Transmission Control Module (ECU)
- □ Retarder Accumulator
- Hydraulic & Air Hoses & Electrical Harnesses

### 2.2. Operation

The transmission couples the engine's output to the input of the vehicle's drive axle. It provides fully automatic power shifting to maintain control of the vehicle speed.




Fig. 5-1: Transmission System Layout



# 3. ALLISON B400R TRANSMISSION

#### 3.1. Description

The major modules of the B400R transmission include the input module, main housing and gear module, control module and output module. The transmission incorporates six forward speeds, lockup clutch with torsional damper, integral retarder, integral oil filters, and an adaptive electronic closed-loop control system with self-diagnostic capabilities. The input module mates to the engine flywheel housing and serves as the main support point for the transmission as well as providing a connection to the engine through a flexplate and adapter. The transmission output shaft

is splined to accept a 1710 series 1/2 round yoke that connects to the driveline. See "Fig. 5-2: Transmission Assembly Views" on page 4.

## 3.2. Transmission Specifications

Manufacturer	. Allison Transmission
Product Family	3000 Series
Model	B400R
Controls	5th Generation
Dry Weight	615 lbs. (279 kg)
Length	28.29" (718.6 mm)
Depth (centerline to lo	west point) 12.9 in. (327.7 mm)






Fig. 5-2: Transmission Assembly Views



#### 3.3. Operation

The ECU receives control inputs from the shift selector and inputs from the sensors in the transmission control module. It processes this information and sends shift commands to the control module. The ECU also provides diagnostic information, which can be read as codes through the shift selector or downloaded using the Allison DOC diagnostic tool.

#### 3.3.1. Reduced Engine Load At Stop (RELS)

This transmission implements the RELS feature allowing the engine to improve fuel efficiency every time the vehicle stops. The driving load is released (similar to neutral) whenever the vehicle comes to a stop and the brake treadle is applied. The vehicle multiplexing system is programmed to also apply and latch the brake interlocks whenever the RELS feature is active. This is a safety feature intended to prevent vehicle rollback during the time span between when the brake treadle is released and the accelerator is applied. The interlocks will not unlatch until the accelerator treadle is pressed slightly.

#### 3.3.2. Auto-Neutral

The transmission uses J1939 CAN messaging to automatically select neutral whenever the parking brake is applied. The vehicle multiplexing is also programmed to select auto-neutral whenever the brake interlocks have been applied for five minutes. Auto-neutral is sometimes referred to as "forced neutral" because the transmis-

sion is forced into neutral without operator intervention. The shift selector drive indicator [D] will begin flashing when entering auto-neutral mode. To re-engage the drive mode, the operator must apply the brake treadle, select neutral [N], then select drive [D].

#### 3.3.3. Retarder Operation

The retarder is a hydro-dynamic brake. It consists of a fluid accumulator and a retarder housing. A rotor in the retarder housing is splined to the transmission output shaft. Fluid from the accumulator fills and pressurizes the retarder housing when the retarder is applied. This slows the rotor, the transmission output shaft and the vehicle.

The retarder is applied in three successive stages as follows:

- 25% applied when the operator releases the accelerator treadle.
- 66% applied when the operator applies sufficient pressure to the brake treadle to produce 1 psi pressure in the rear brake circuit as measured by a pressure transducer.
- □ 100% applied when the operator applies sufficient pressure to the brake treadle to produce 4 psi pressure in the front brake circuit as measured by a pressure switch.

The retarder disengages when the operator releases the brake treadle. At speeds below 6 mph (10 km/h) the retarder is inactive.



#### 3.4. Maintenance

#### MOTE:

Refer to the Preventive Maintenance Section of this manual for scheduled maintenance requirements.

#### 3.4.1. Transmission Oil Maintenance

#### 3.4.1.1. Oil Storage & Handling

Oil must be handled in clean containers and fillers to prevent foreign material entering the transmission. Lay dipstick in a clean place while filling the transmission.



Containers or fillers that have been used to handle antifreeze or engine coolant solution must not be used for transmission fluid. Antifreeze and coolant solutions contain ethylene glycol which, if introduced into the transmission, can cause the clutch plates to fail.

#### 3.4.1.2. Proper Oil Level

Because the transmission oil cools, lubricates, and transmits hydraulic power it is important that the proper oil level is maintained at all times. If the oil level is too low

the converter and clutches will not receive an adequate supply of oil. If the level is too high the oil will aerate, the transmission will overheat, and oil may be expelled through the breather or dipstick tube. See "Fig. 5-3: Transmission Fluid Level Dipstick" on page 6.




Fig. 5-3: Transmission Fluid Level Dipstick



#### 3.4.2. Oil Check Procedure

Clean around the end of the fill tube before removing the dipstick. Dirt or foreign matter must not be permitted to enter the oil system because it can cause valves to stick, cause undue wear of transmission parts, or clog passages. Check the oil level by the following procedures and record level on your maintenance records.



When checking the oil level, be sure that the parking brake and/or emergency brakes are set and properly engaged. Unexpected and possibly sudden vehicle movement may occur if these precautions are not taken.

Always check the oil level at least twice. Consistency is important in maintaining accuracy. If inconsistent readings persist, check the transmission breather to ensure it is clean and not blocked with debris.

#### 3.4.2.1. Cold Check

#### ™NOTE:

The only purpose of the Cold Check is to determine if the transmission has enough oil to be safely operated until a Hot Check can be made.

1. Park the vehicle on a level surface and apply the parking brake.



The oil level rises as sump temperature increases. DO NOT fill above the Cold Check band if the transmission oil is below normal operating temperature.

- Run the engine for at least one minute. Shift to first (drive) [1 or D] and then to reverse [R] to clear the hydraulic circuits of air. Then shift to neutral [N] and allow the engine to idle (500 to 800 RPM).
- After wiping the dipstick clean, check the oil level. If the oil on the dipstick is within the Cold Check band, the level is satisfactory for operating the transmission until the oil is hot enough to perform a Hot Check.
- If the oil level is not within the Cold Check band, add or drain oil as necessary to bring the level to the middle of the Cold Check band.

#### 3.4.2.2. Hot Check

 Perform a Hot Check at the first opportunity after the normal operating temperature 160 to 200°F (71 to 93°C) has been reached.



The oil must be hot to ensure an accurate check. The oil level rises as temperature increases.

- Operate the transmission in drive range until normal operating temperature is reached: 160 to 200°F (71 to 93°C) sump temperature, 180 to 220°F (82 to 104°C) converter-out temperature.
- Park the vehicle on a level surface and shift to neutral. Apply the parking brake and allow the engine to idle (500 to 800 RPM).
- After wiping the dipstick clean, check the oil level. The safe operating level is anywhere within the Hot Check band on the dipstick.
- 5. If the level is not within this band, add or drain oil as necessary to bring the level to the top of the Hot Check band.



#### 3.4.2.3. Oil Contamination

#### Examining Oil Condition

At each oil change, examine the oil which is drained for evidence of dirt or water. A normal amount of condensation will emulsify in the oil during operation of the transmission. However, if there is evidence of water, check the cooler (heat exchanger) for leakage between the water and oil area. Oil in the water side of the cooler (heat exchanger) is another sign of leakage. This, however, may indicate leakage from the engine oil system.

#### Metal Particles

Metal particles in the oil (except for the minute particles normally trapped in the oil filter) indicate damage has occurred in the transmission. When these particles are found in the sump, the transmission must be disassembled and closely inspected to find the source. Metal contamination will require complete disassembly of the transmission and cleaning of all internal and external circuits, cooler, and all other areas where the particles could lodge.



If excessive metal contamination has occurred, replacement of the oil cooler and replacement of all bearings within the transmission is recommended.

#### □ Coolant Leakage

If engine coolant leaks into the transmission oil system, immediate action must be taken to prevent malfunction and possible serious damage. The transmission must be completely disassembled, inspected,

and cleaned. All traces of the coolant, and varnish deposits resulting from coolant contamination must be removed. Friction clutch plates contaminated with ethylene glycol must be replaced.

#### ☐ Filling Transmission Oil

The refill amount is less than the initial fill because some of the oil remains in the external circuits and transmission cavities. Refer to 3.4.2. "Oil Check Procedure" on page 7 in this section for checking the oil level after refill.

#### ™NOTE:

Refer to the Preventive Maintenance Section of this manual for oil change procedure.

#### □ Breather

The breather is located at the top of the transmission converter housing. it serves to prevent pressure buildup within the transmission and must be kept clean and the passage open. The prevalence of dust and dirt will determine the frequency at which the breather requires cleaning.



Use care when cleaning the transmission. Spraying steam, water or cleaning solution directly at the breather can force the water or solution into the transmission.

Always use a proper size wrench to remove or replace the breather. Pliers or a pipe wrench can crush or damage the stem and produce metal chips which could enter the transmission.

### **Transmission Troubleshooting**

#### 3.5. Transmission Troubleshooting

The transmission will display diagnostic trouble codes and fluid levels on the shift selector. Refer to 4. "PUSH BUTTON SHIFT SELECTOR" on page 17 in this section for more information on accessing diagnostic trouble codes and fluid level information. Refer to 6. "VENDOR SERVICE INFORMATION" on page 29 in this section for complete information on troubleshooting the transmission system.

#### 3.6. Removal



Before attempting any work on the transmission ensure the following:

- ☐ Master Run switch is in the OFF position
- ☐ Rear Engine Service switch in the OFF position.
- Disconnect battery via Battery Disconnect switch.
- Clean exterior of transmission and adjoining surfaces with either steam or a solvent.
- DO NOT directly use pressure or steam on electrical connections, seal areas, or at the breather. Water/solvent may be forced into these areas causing damage or corrosion.
- Observe all safety precautions related to overhead procedures if vehicle is to be hoisted.

Transmission removal can be performed three possible ways. Ensure your work place fits the project.

- ☐ The vehicle is placed over the top of a service pit.
- ☐ The vehicle may be hoisted in the air at all wheels using approved wheel hoists.
- ☐ The engine and transmission are removed from the rear of the vehicle.

#### ™NOTE:

In some cases, it may be easier to remove the engine and transmission as a unit and then separate the transmission from the engine flywheel housing. However, the transmission can be separated from the engine in the engine bay and removed as a separate unit. The following removal procedure is based on removing the transmission separately. Refer to Section 4 of this manual for procedure when the engine and transmission assembly are removed together. When the transmission is removed from the vehicle without removal of the entire engine and transmission assembly, the transmission must be lowered through the bottom of the vehicle.

- 1. Raise the vehicle.
- Set the Battery Disconnect switch to the OFF position.
- Drain transmission fluid.
- 4. Disconnect driveshaft from transmission yoke.
- 5. Disconnect oil cooler and retarder lines.
- Disconnect transmission module wiring harness and sensor connectors.
- Remove access cover to expose the flexplate to flywheel bolts. See "Fig. 5-4: Flexplate Access Cover" on page 10.
- 8. Manually rotate engine until one flexplate to flywheel bolt is centered in opening.



- Remove bolt and rotate engine until next bolt is centered in the opening. Repeat process until all 6 - M10 bolts are removed.
- 10. Remove clamp securing transmission dip stick tube and remove tube assembly.
- 11. Support transmission with a commercial transmission jack.



Before disconnecting the transmission from the engine, ensure that it is properly secured to prevent it from falling. Use a hoist or jack that can safely support the weight. DO NOT use makeshift lifting devices.

- 12.Loosen but do not remove completely four equally spaced transmission to flywheel housing bolts. See "Fig. 5-5: Transmission to Engine Connection" on page 11.
- Loosen and remove the eight remaining bolts.
- 14. Carefully separate transmission from engine until heads of loosened bolts contact mounting flange.



Make absolutely sure the transmission will not slip or roll. Retain the transmission to the lift with straps or chains.



Severe damage to the torque converter may occur if the transmission is not supported properly.

- 15. Remove final four bolts and move transmission away from engine.
- 16. Ensure all items are disconnected before lowering the transmission.
- 17.Lower transmission and hoist to a work stand or work area.




Fig. 5-4: Flexplate Access Cover






Fig. 5-5: Transmission to Engine Connection



#### 3.7. Disassembly

Refer to 6. "VENDOR SERVICE INFOR-MATION" on page 29 in this section for complete information on transmission disassembly.

#### 3.8. Assembly

Refer to 6. "VENDOR SERVICE INFOR-MATION" on page 29 in this section for complete information on transmission assembly.

#### 3.9. Installation

## 3.9.1. Installing Transmission Output Drive Yoke

If the output drive yoke was removed from the transmission splined output shaft for servicing or parts replacement, Install as follows:

- 1. Install the output drive yoke onto the transmission splined output shaft.
- 2. Tighten the bolt retaining the output drive yoke to 52 to 59 ft-lb. (71 to 80 Nm).

#### 3.9.2. Installing Oil Filler Tube & Seal

The transmission has oil filler tube openings on both the left and right sides. Combinations of tubes or expansion plugs may be used. Make sure the unused tube opening has a plug installed.

 The oil filler tube may be installed before the transmission is installed into the vehicle, unless doing so will interfere with transmission installation.



Use the existing fasteners to install the oil filler tube. Using fasteners that are too long may cause cracks (leaks) in the main housing.

 Install the oil filler tube seal into the main housing. Install the filler tube through the oil seal. Align the tube bracket with its attachment location. Tighten the oil fill tube bolt to 18 to 21 ft-lb. (24 to 29 Nm). 3. If only one filler tube is used, a plug and seal are installed on the opposite side. The plug is fully seated when the underside of the plug head contacts the seal.

#### 3.9.3. Installing Transmission

#### ™NOTE:

The following installation procedure assumes that the engine is installed in the vehicle. Refer to Section 4 of this manual for instructions on removing and installing the engine and transmission as a unit.

#### 3.9.3.1. Hub Adapter Installation

#### ™NOTE:

The following procedure details the installation of the hub adapter and flexplates onto the engine, if they were previously removed.

- 1. Install hub adapter onto engine crankshaft. See "Fig. 5-6: Transmission to Engine Cross-Section" on page 13.
- Install four flexplates onto hub adapter with wear plate.

#### ™NOTE:

One of the flex plates has bolt plates on the outer bolt circle and should be installed facing the engine.

- The wear plate that attaches the flex plates to the hub adapter should be installed with the stamped part number facing away from the engine.
- 4. Center and secure the wear plate and flexplates to the hub adapter by installing two M6 x 1.0 x 16 mm bolts and torque to 88 to 115 in-lb. (10 to 13 Nm). Ensure that the outer holes in the flexplates are still aligned with one another.
- Install eight crankshaft bolts and torque to 101 ft-lb. (137 Nm).
- Rotate the engine crankshaft so that one of the flexplate holes is centered within the flywheel housing access opening.

5 - 12






Fig. 5-6: Transmission to Engine Cross-Section



#### 3.9.3.2. Torque Converter Adapter Installation

#### ™NOTE:

The following procedure details the installation of the torque converter adapter and ring gear onto the engine, if they were previously removed.

- Install torque converter adapter/ring gear assembly onto the torque converter housing using ten M8 x 1.25 x 25 mm bolts. Torque bolts to 27 ft-lb. (36 Nm).
- Apply molybdenum-disulfide grease (Molykote) to nose of torque converter where it pilots into crankshaft hub adapter.

#### 3.9.3.3. Transmission Join-Up & Alignment

 Raise the vehicle. Refer to the General Information Section of this manual for recommended lifting procedures.



The transmission weighs approximately 610 lbs (279 kg). Use appropriate lifting equipment.

- 2. Lift the transmission with the special lifting apparatus located on the four assembly pads cast into the transmission housing. See "Fig. 5-7: Lifting Transmission" on page 15.
- 3. Position the transmission onto a transmission jack, lifting table, or other equipment designed specifically for this purpose and secure to prevent movement.
- 4. Move the transmission into position so that it is aligned with engine but separated by several inches. Align the threaded hole in the torque converter adapter with the hole in the flexplate.

#### ™NOTE:

Insert a long tapered punch through the engine flywheel access opening and through the hole in the flexplate. Rotate the torque converter by hand until the alignment punch enters the threaded hole in the torque converter adapter.

Slowly slide the transmission into place ensuring that the pilot nose of the torque converter engages the engine hub adapter

#### ™NOTE:

The use of threaded guide pins in the engine flywheel housing will aid alignment of the transmission housing mounting holes with engine flywheel housing.



DO NOT use excessive force or mounting bolts to draw the transmission against the flywheel housing.

- Ensure that the transmission housing seats squarely against the engine flywheel housing. If interference is encountered, move the transmission away from the engine and investigate the cause.
- 7. Remove guide pins and install all twelve M10 bolts but hand-tighten only.
- Ensure transmission is fully seated and then final tighten four bolts located at 90° intervals to 38 to 45 ft-lb. (52 to 61 Nm). Torque remaining bolts to 38 to 45 ft-lb. (52 to 61 Nm).






Fig. 5-7: Lifting Transmission

## 3.9.3.4. Flexplate Attachment to Torque Converter Housing

- View through the flywheel access opening and inspect the alignment of the hole in the flexplate with the threaded hole in the torque converter adapter. If necessary, use a tapered punch to align the holes.
- 2. Install one M10 x 1.5 x 30 mm bolt through the flexplate and into the adapter. Fingertighten only at this time.
- Remove plug and install engine barring tool into opening located above starter motor, rotate crankshaft 180°, and install another bolt and finger-tighten.
- Rotate crankshaft to align next bolt hole, install bolt and finger tighten. Repeat procedure until all twelve bolts are installed.
- Final tighten all six bolts to 50 ft-lb. (68 Nm) using the previous barring tool procedure to rotate the engine.
- 6. Remove barring tool and reinstall plug into opening.
- Reinstall flywheel access cover plate and secure with two bolts.

#### 3.9.3.5. Final Installation

- Connect driveshaft to output yoke of transmission. Refer to Section 2 of this manual for procedure.
- Connect transmission module and sensor harness connectors. See "Fig. 5-8: Transmission Wiring Harness" on page 16.
- Install transmission fill tube and retaining clamp.
- Install transmission cooler and retarder hoses.

#### ™NOTE:

If the transmission was removed for repair because of an internal failure, the transmission cooler, and interconnecting hoses will have to be cleaned and flushed.

- 5. Fill transmission with fluid to correct level. Refer to the Preventive Maintenance Section of this manual for fluid specification.
- Set the Battery Disconnect switch to the ON position.
- Start engine and check for leaks. Top up fluid level if necessary. Refer to 3.4.2. "Oil Check Procedure" on page 7 in this section for procedure.






Fig. 5-8: Transmission Wiring Harness



## 4. PUSH BUTTON SHIFT SELECTOR

#### 4.1. Description

The Push Button Shift Selector (PBSS) is the driver interface module used to command and control the transmission system. See "Fig. 5-9: Push Button Shift Selector" on page 17. It is mounted in the instrument panel with brackets and hardware and connected to the transmission system via an electrical harness.




Fig. 5-9: Push Button Shift Selector



#### 4.2. Operation

The PBSS is used by the operator to select Neutral [N], Reverse gear [R], or a range of forward gears. When a forward gear range has been selected, the transmission starts in the lowest gear of the range and, as conditions permit, automatically upshifts to the highest gear in the selected range.

### ™NOTE:

During certain operating conditions the control system may inhibit transmission operation or range shifts.

The following table indicates the information that will be displayed on the shift selector during normal operation:

SHIFT SELECTOR DISPLAY INFORMATION				
DISPLAY	DESCRIPTION			
SELECT	Indicates the gear range selected			
MONITOR	Indicates the actual gear being operated in			
SERVICE INDICATOR (Wrench Icon)	Displayed at start-up for a bulb check and will turn off if no service conditions exist.			



#### 4.2.1. Shift Selector Operation



If you leave the vehicle and the engine is running, the vehicle can move suddenly and you or others could be injured. If you must leave the engine running, do not leave the vehicle until you put the transmission in NEUTRAL, and ensure that the engine is at low idle, and apply the park brake and emergency brakes and make sure they are properly engaged, and chock the wheels and take any other steps necessary to keep the vehicle from moving.

The vehicle service brakes, park brake, or emergency brake must be applied whenever NEUTRAL is selected to prevent unexpected vehicle movement. Selecting NEUTRAL does not apply the vehicle brakes.

- ☐ [R] REVERSE selects Reverse gear.
- □ [N] NEUTRAL selects Neutral. The area around the [N] button is a raised ridge so the driver can identify the pushbuttons by touch, without looking at the display. It is not necessary to press this button prior to starting the vehicle.
- [D] DRIVE selects the highest available forward range. The transmission shifts to the starting gear and will automatically upshift through the gears, as operating conditions permit, until the highest available gear is attained.
- ☐ UPSHIFT and DOWNSHIFT Arrow Buttons these buttons are used to change the range selected to a higher or lower forward range:
  - One press of the DOWNSHIFT button sets range SELECT to the same range as the current range attained, shown in

- the MONITOR position on the display. This is referred to as Express Preselect.
- ☐ Each subsequent press of the DOWN-SHIFT button decreases the range selected by one range.
- One press of the UPSHIFT button increases the range selected by one range.
- ☐ If the UPSHIFT or DOWNSHIFT button is held continuously, the selected range will continue to change up or down until the button is released or until the highest or lowest possible range of gears is selected.
- MODE Button pressing the MODE button invokes a secondary shift schedule or a special operating function. Pressing the MODE button also toggles to the next Diagnostic Trouble Code (DTC) while in the DTC display mode. And it clears active and inactive DTCs from the ECU memory.
- □ Select & Monitor during normal operation with [D] Drive selected, the SELECT section of the display shows the highest attainable forward range for the shift schedule in use. The MONITOR section displays the gear range that has been commanded in the transmission. Reverse [R] and Neutral [N] are likewise displayed when appropriately selected and in use. The display of any other character in the SELECT or MONITOR section denotes a nonstandard operating condition.
- Backlighting all six keypad buttons are continually backlit during normal vehicle operation.
- ☐ Diagnostic Functions pressing the UPSHIFT and DOWNSHIFT buttons simultaneously with the transmission in Neutral invokes a service or diagnostic function as shown in the following table:

UPSHIFT & DOWNSHIFT DIAGNOSTIC FUNCTION								
1st PRESS 2nd PRESS 3rd PRESS 4th PRESS								
Oil Level Sensor (OLS)	Prognostics	Diagnostics	Normal Range Display					



#### 4.2.2. Shift Inhibits

The control system will invoke built-in logic to protect against certain types of abusive operation. These inhibits are designed to protect the transmission in the event of abusive operation. The following shift inhibits may occur:

Engine Speed Inhibit - Inhibits neutral-torange shifts when engine speed is greater than 900 rpm. The ECU indicates that a shift has been inhibited by flashing the range SELECT digit on the shift selector.

#### ™NOTE:

If the engine speed drops below the inhibit speed within 3 seconds, the inhibit will self-clear and the requested shift will be commanded.

- Direction Change Inhibit Inhibits forward/ reverse directional changes if one of the following conditions is detected:
  - ☐ Output shaft speed of approximately 225 rpm or higher.
  - ☐ Throttle position greater than approximately 40%.

The ECU indicates that a shift has been inhibited by flashing the range SELECT digit on the shift selector.

#### MOTE:

If the output shaft speed or throttle position drops below the inhibit threshold within 3 seconds, the inhibit will self-clear and the requested shift will be commanded.

#### 4.2.3. Electronic Fluid Level Check

Check the fluid level electronically from the shift selector as follows:

#### ™NOTE:

The ECU delays the fluid level check until the fluid temperature is above 104°F (40°C) or below 220°F (104°C). Check transmission fluid only once the water temperature gauge has stabilized.

- 1. Park the vehicle on a level surface and shift to neutral [N].
- 2. Apply the parking brake and allow the engine to idle at 500 to 800 rpm.
- 3. Make sure the transmission output shaft speed is at 0 rpm.
- 4. Allow a settling period of two minutes to allow the oil to return to the sump.
- Simultaneously press the Upshift and Downshift arrows once. If conditions do not allow fluid level to be checked, a code will appear. Refer to 4.2.3.1. "Invalid for Display Codes" on page 21 in this section for information.
- 6. If the oil level is OK the display will state: "TRANS OIL LEVEL OK".
- If the oil level is Low the display will state: "OIL LOW X QTS" where X represents the quantity of quarts.
- 8. If the oil level is High the display will state: "OIL LEVEL X QTS HI" where X represents the quantity of quarts.
- Exit the fluid level display mode by pressing any range button on the shift selector.

#### ™NOTE:

Recheck oil levels if oil is added or removed as a result of this check. The Oil Level Sensor (OLS) has a range of LO 4 to HI 3. Actual levels may exceed these limits.



#### 4.2.3.1. Invalid for Display Codes

Invalid for Display is activated when conditions do not allow the fluid level to be

determined. Use the following chart to help determine the cause and solution.

INVALID FOR DISPLAY CODES				
DISPLAY	DESCRIPTION			
SETTLING / OK	Settling time too short			
ENG RPM / TOO LOW	Engine RPM too low			
ENG RPM / TOO HIGH	Engine RPM too high			
MUST BE / IN NEU	[N] Neutral must be selected			
OIL TEMP / TOO LOW	Sump fluid temperature too low			
OIL TEM / TOO HIGH	Sump fluid temperature too high			
VEH SPD / TOO HI	Output shaft speed			
SENSOR / FAILED	Sensor failure			



#### 4.2.4. Prognostics

Prognostics maximize fluid and filter use as well as providing an indication when clutch wear is significant enough to require transmission repair. The Wrench Icon (TRANS SERVICE indicator) in the shift selector display will illuminate when a specified threshold is detected for any serviceable conditions listed in the following chart:

PROGNOSTICS						
PROGNOSTIC FUNCTION NAME	DESCRIPTION					
Oil Life Monitor (OM)	Displays the percentage of fluid life remaining					
Filter Life Monitor (FM)	Notifies that main and lube filters require changing					
Transmission Health Monitor (TM)	Notifies that one or more clutches, C1-C5, requires replacement					

#### ™NOTE:

Failure to attend to service conditions identified by Prognostics and to reset the TRANS SERVICE indicator within a defined operating period will result in the illumination of the CHECK TRANS text message.



Failure to attend to a service condition identified by Prognostics increases the probability that the service condition will develop into a more serious condition.

Enter the Prognostics mode on the shift selector as follows:

- Park the vehicle on a level surface, apply the parking brake and switch the engine off.
- 2. Rotate the Master Run switch to the DAY-RUN or NIGHT-RUN position.
- Simultaneously pushing the UPSHIFT and DOWNSHIFT buttons twice for Oil Life Monitor, three times for Filter Life Monitor and four times for Transmission Health Monitor.

The Oil Life Monitor (OM) mode will display a number between 0 and 99 indicating the percentage of fluid life remaining before a change is required.

#### ™NOTE:

A fluid life of 1% will activate the Prognostics wrench icon on the shift selector.

The Filter Life Monitor will display "OIL FILTER OK" or "REPLACE FILTERS" depending on the condition of the filters.

#### ™NOTE:

Diagnostic Trouble Code P088A will be set along with the Trans Service wrench icon and if the filters are not changed within a certain amount of time will illuminate the Check Trans text message. Refer to the Preventive Maintenance Section of this manual for more information on fluid and filter change intervals and procedures.

The Transmission Health Monitor will display "TRANS HEALTH OK" or "TRNS HEALTH LO" depending on the condition of clutch life status.

#### ™NOTE:

A clutch life of 10% remaining will activate the Prognostics Wrench icon on the shift selector. Diagnostic Trouble Code P2789 will be set and the Check Trans message will appear if multiple warnings have occurred due to the TM actively detecting issues with the clutch system.

Refer to 6. "VENDOR SERVICE INFOR-MATION" on page 29 in this section for more information on accessing and resetting Prognostic data.



#### 4.2.5. Diagnostic Trouble Code Check

Active and historic Diagnostic Trouble Codes (DTC) can be displayed on the display portion of the shift selector. Active DTCs are current in the ECU and affect the processing decisions. Historic codes are retained in memory and don't necessarily affect the ECU's processing decisions.

Up to five DTCs may be displayed, one-ata-time, from the selector once the diagnostic display mode has been initiated by the operator. Each DTC is 5 characters in length and will be labelled "Active" or "Inactive".

Read DTCs from the shift selector as follows:

- Park the vehicle on a level surface, apply the parking brake and switch the engine off.
- Rotate the Master Run switch to the DAY-RUN or NIGHT-RUN position.
- Simultaneously pushing the UPSHIFT and DOWNSHIFT buttons five times to enter the diagnostic mode.
- 4. Press the MODE button to read the next code, if any, in the queue. Refer to 6. "VENDOR SERVICE INFORMATION" on page 29 in this section for a complete listing and description of all DTCs.

Clear active DTCs by pressing and holding the MODE button for ten seconds.

#### ™NOTE:

Any codes that cause the CHECK TRANS message to appear are considered severe enough to warrant immediate attention.

If an active indicator is cleared while the transmission is locked in range because of an active code, the transmission remains in that locked range even after clearing. Neutral [N] must be manually selected or the ignition must be cycled.

Some Codes will self-clear once the conditions that caused the active code are not present. Some codes require the Master Run switch to be cycled off before they can be cleared from active status.

If the conditions that activated the code are still present, the code will become active again.

Exit the diagnostic mode by simultaneously pressing the Upshift and Downshift arrows once.

#### ™NOTE:

The diagnostic mode can also be exited by pressing any range button [D] Drive, [N] Neutral or [R] Reverse. After approximately 10 minutes of inactivity at the PBSS the diagnostic mode automatically exits and returns to normal operating mode.



#### 4.3. Shift Selector Troubleshooting

In the event of loss of the CAN communications link, limited communication between the ECU and PBSS continues through the Direction Signal wire 134. This limited communication permits the operator to select the operating direction to allow the vehicle to be removed from service or driven to a service location. Range upshifts and downshifts during CAN communications loss will not be recognized. The shift selector will not display the transmission range. The selector will display "cat eyes" (-/- -/-).

Refer to 6. "VENDOR SERVICE INFOR-MATION" on page 29 in this section for complete information on troubleshooting the Push Button Shift Selector and Transmission System.

The following table indicates the information that will be displayed on the shift selector during diagnostic or inhibited conditions:

SHIFT SELECTOR TROUBLESHOOTING					
DISPLAY	DESCRIPTION				
SELECT (Blank)	Diagnostic code is set which holds the transmission in the current range. The MONITOR display will indicate the range in which the transmission is locked.				
	© NOTE:				
	The CHECK TRANS indicator on the instrument panel will be activated.				
SELECT (Flashing)	Indicates a requested shift is either temporarily or permanently inhibited. The inhibit may clear if the cause of the inhibit clears within 3 seconds of the shift request. Otherwise the operator must reselect the desired range.				
SERVICE INDICATOR (Wrench Icon)	Alerts of a service issue related to the clutch, filter or fluid life. The indicator will be lit steadily or flashing depending on the condition monitored.				
INIT FAULT	Displayed if the ECU does not complete initialization after the Master Run switch has been switched to DAY-RUN or NIGHT-RUN.  **NOTE:*  A diagnostic code will be activated in association with this condition.				
Blank Display	Indicates a lack of power to the selector or failure of the CAN (J1939) link.				
Double Cat-Eyes (-//-)	Indicates a failure of the CAN communication link. The cat-eyes are illuminated in both the SELECT and MONITOR locations after approximately 12 seconds of blank display.  NOTE:				
	A diagnostic code will be activated in association with this condition.				



#### 4.4. Removal

- Park the vehicle on a level surface, apply the parking brake and chock the wheels to prevent vehicle movement.
- 2. Rotate the Battery Disconnect switch to the OFF position.
- Gain access to the shift selector in the dash.
- 4. Disconnect the electrical connectors at the rear of the shift selector.
- 5. Remove and retain the mounting hardware and mounting brackets holding the shift selector to the instrument panel.
- 6. Remove the shift selector.

#### 4.5. Installation

- 1. Install the shift selector into the cut-out on the instrument panel and hold in place.
- 2. Install the mounting brackets onto the rear of the shift selector and secure with the mounting hardware.
- 3. Tighten the mounting hardware until the shift selector is securely held in the cut-out but do not over-tighten.
- Connect the electrical harnesses to the shift selector.
- 5. Test the operation of the shift selector.



#### 5. RETARDER ACCUMULATOR

#### 5.1. Description

The retarder accumulator is remotely mounted near the transmission on a curb-side vehicle frame member. The oil side of the retarder accumulator is connected to the transmission with a hydraulic hose. The accumulator solenoid is mounted on the air side end cap of the accumulator. Air is supplied from the accessory air tank via

an air hose and a pressure reducing valve to the solenoid. See "Fig. 5-10: Accumulator Removal & Installation" on page 26.

The retarder accumulator is comprised of the following:

- piston
- cylinder
- ☐ two end caps




Fig. 5-10: Accumulator Removal & Installation



#### 5.2. Operation

The retarder accumulator serves as an oil storage device to provide immediate response to retarder demand and allow quick filling of the transmission retarder module. The ECU determines retarder demand and energizes the accumulator solenoid, which applies air pressure to the top of the accumulator piston. The piston is driven downward, rapidly expelling the oil within the cylinder and filling the transmission retarder housing. The retarder stator, rotor, and housing all have integral vanes, which react to pressurize the oil and thereby resist output shaft rotation. During retarder inactivity, oil is evacuated from the retarder housing and the accumulator is recharged.

A pressure reducing valve lowers system air pressure to 100 psi for accumulator operation. Refer to Section 8 of this manual for more information on the pressure reducing valve.

#### 5.3. Removal

- Drain transmission oil and disconnect oil line from accumulator.
- Drain air system and disconnect air lines from accumulator solenoid.
- 3. Disconnect wiring from solenoid.
- Remove mounting bolts, accumulator, and solenoid.

#### 5.4. Disassembly

#### ™NOTE:

Accumulator solenoid is non-serviceable and is to be replaced as an assembly.

- Remove solenoid and fitting from accumulator end cap. See "Fig. 5-11: Accumulator Assembly" on page 27.
- Remove four tie rod bolts and separate hydraulic and gas end caps from cylinder body.
- 3. Remove piston and discard lip seals and seal ring.




Fig. 5-11: Accumulator Assembly



#### 5.5. Cleaning & Inspection

- Thoroughly clean all parts in mineral spirits.
- Inspect piston for evidence of wear or scoring.
- Inspect cylinder for scoring or wear. I.D. of cylinder not to exceed an average bore diameter of 4.010" (four measurements taken approximately 45° apart).
- 4. Inspect condition of internal threads on gas end cap.
- 5. Inspect tie rod bolts for deformation or thread damage.

#### 5.6. Assembly

- 1. Install two new lip seals and seal ring on piston.
- 2. Lubricate piston seals with transmission fluid and install piston into cylinder bore.
- Install new end seals into grooves in end caps and assemble to cylinder body with tie rod bolts.

- Torque tie rod bolts 24 to 27 ft-lb. (32 to 36 Nm).
- Install solenoid and fitting on accumulator end cap.

#### 5.7. Installation

- Install accumulator and solenoid assembly to mounting bracket using four bolts. Torque bolts 50 to 60 ft-lb. (68 to 81 Nm).
- Install oil line from transmission to top of accumulator.
- 3. Connect air lines to solenoid.
- Connect wiring to solenoid valve.
- Fill transmission with oil to correct level. Refer to the Preventive Maintenance Section of this manual for oil specifications and filling procedures.

#### 5.8. Functional Test

Test drive vehicle to check for proper retarder operation.



### **Allison B400 Transmission Manuals**

# 6. VENDOR SERVICE INFORMATION

The following supplier manuals contain additional reference information.

## 6.1. Allison B400 Transmission Manuals

□ Parts Manual

	Service Manual
	Quick-Tech Troubleshooting Guide
	Troubleshooting Manual
	Principles of Operation
	Mechanics Tips
	Operators Manual

### **Allison B400 Transmission Manuals**





# **Cooling System**

1.	SAFET	Ύ	6-1
	1.1. Saf	ety Procedures	6-1
2.	COOLI	NG SYSTEM	6-2
	2.1. Des	scription	6-2
		olant Circulation	
	2.2.1.		
	2.2.2.	· ·	
		gine Coolant	
	2.3.1.		
	2.3.2.	Inspection Capacity	
	2.3.3.	·	
		.3.3.1. Engine & Radiator	
		.3.3.2. Vehicle Cooling/Heating System	
	2.3.4.	Filling & Deaeration	6-5
	2.3.5.	Cooling System Flushing	6-6
	2.4. Mai	intenance	6-6
	2.5. Rad	diator/Charge Air Cooler	6-8
	2.5.1.		
	2.5.2.	Radiator/Charge Air Cooler Specifications	
	2.5.3.	Operation	
	2.5.4.	Maintenance	6-12
	2.5.5.	Radiator/Charge Air Cooler Troubleshooting & Repair	6-12
	2.5.6.	Removal	6-12
	2.5.7.	Installation	6-13
	2.6. Tra	nsmission Cooler	6-14
	2.6.1.	Description	6-14
	2.6.2.	Removal	6-14
	2.6.3.	Disassembly	6-15
	2.6.4.	Cleaning	6-16
		.6.4.1. Oil Side	
		.6.4.2. Water Side	
		Assembly	
		rge Tank	
	2.7.1.	Description	
	2.7.2.	Surge Tank Specification	
	2.7.3.	Operation	
	2.7.4.	Filler Cap with Pressure Control & Relief Valve	
	2.7.5.	Coolant Level Sensors	
	2.7.6.	Fluid Level Gauge	6-19

### Table of Contents



2.7.7.	. Removal	6-21
2.7.8.	. Installation	6-21
2.8. Co	olant Recovery Tank	6-23
2.8.1.	. Description	6-23
2.8.2.	Coolant Recovery Tank Specifications	6-23
2.8.3.	Operation	6-23
2.8.4.	. Removal	6-23
2.8.5	. Installation	6-23
2.9. Ho	se Clamp Torque Specifications	6-25
	oolant Filter & Conditioner	
2.10.	1. Description	6-27
3. VEND	OR SERVICE INFORMATION	6-28
3.1. En	gineered Machined Products (EMP) Manual	6-28



#### 1. SAFETY

#### 1.1. Safety Procedures

This section of the service manual contains procedures which require the mechanics to strictly observe safety procedures in order to ensure personal and equipment safety.

Refer to the General Information Section of this manual for information on types of hoists, hoisting procedures, jackstands and related safety information. Refer to this information and read carefully before lifting, hoisting or jacking the vehicle.

Always ensure that the vehicle is appropriately hoisted and blocked for procedures which require elevating the vehicle. Be aware of the limitations of the blocking equipment, and always ensure that the jarring and shaking created by component removal and installation procedures does not overload the blocks, or cause the vehicle to become unstable.

Certain procedures may require the vehicle be operated in an elevated position in order to accurately troubleshoot and diagnose a problem. If the vehicle must be running while elevated, become familiar with the repair area prior to starting the engine. Take special care in noting areas which will become hot, electrically energized, and areas where moving and rotating components are located. Limit the work in these areas as personal and equipment safety is at risk.

For procedures which involve air lines, ensure the line is safely depressurized prior to disconnecting. Disconnecting pressurized lines will cause solid particles deposited in the line to be uncontrollably propelled, and will also cause the hose end to whip randomly as the air escapes.

During electrical diagnosis procedures an understanding of the vehicle's electric circuits is important to anticipate the results of connecting test equipment. During component removal or installation, ensure the Battery Disconnect switch is in the OFF position.

Failure to follow this procedure may result in personal injury or component failure.

Observe the following procedures involving hydraulic line removal.

- Hydraulic fluid is corrosive and should not be exposed to skin for extensive periods of time.
- Wear eye protection at all times.
- Pressurized lines should not be disconnected until the pressure is safely and controllably released.



#### 2. COOLING SYSTEM

#### 2.1. Description

#### ™NOTE:

Refer to the Power Plant Cooling Circulation Diagram when reviewing this information



Operate the pressure relief valve located on the surge tank, before doing any work on the cooling system. Severe injury can occur if this is not observed.

The Mini-Hybrid electronic cooling system installed on this vehicle is an electric only fan system that replaces the traditional hydraulic driven mechanical fan. The Mini-Hybrid is electronically controlled to cool both charged intake air and engine coolant separately. The Electric fans are divided into 3 groups: Charge Air Cooler fans, Engine Coolant fans and Shared fans. The fans operate at variable speeds and intervals as dictated by the Electronic Fan Con-The Mini-Hybrid troller. system independent of engine speed and control capable provide full load cooling at engine idle and reduces thermal events by eliminating the hydraulic fan system. Maintenance is performed with the manual reverse feature. The Mini-Hybrid system comes with both a diagnostic light and service technician tool.

- 1. The cooling system includes the following essential components:
  - □ Radiator/charge air cooler
  - □ Engine water pump

	Coolant recovery tank
	Transmission cooler
	Connecting hoses, tubes, & piping
	Heating system (Refer to Section 10 of this manual)

☐ Surge tank

- 2. The fan system draws cooling air through the radiator/charge air cooler core.
- A liquid coolant constantly flows throughout the sealed cooling system when the engine is running. The engine is cooled by this liquid. In addition, this liquid:

Cools jacket.	air	compressor	via	а	water

Cools	trans	smiss	ion	oil	by	carrying	heat
away	from	heat	exc	char	nger	(transmi	ssion
oil cod	oler).						

	Cools	the	turbocharger	oil	sump
_	00010		tarbooriargor	011	Carrip

Cools the	exhaust	gases	by	carrying	away
heat from	the EGR	coole	٠.		

	Cools	the	dosing	module	in	the	exhaust
aftertreatment system							

Warms	the	Diesel	Exhaust	Fluid	(DEF
tank					

- Is used in heating system of the vehicle.
- Liquid coolant for the cooling system is added through surge tank filler cap and pressure within the cooling system is maintained by a pressure cap on the surge tank.
- Low coolant and hot engine indicators on the instrument panel warn the operator if liquid in the cooling system becomes too low or too hot. An alarm buzzer will also sound.



#### 2.2. Coolant Circulation

Coolant circulation during warm-up differs from circulation after engine has reached normal operating temperature as explained in the following sections.

#### 2.2.1. Engine Warm-Up

Engine water pump circulates coolant into cylinder block by way of engine oil cooler. After circulating through block and cylinder heads, coolant enters thermostat housing.

When engine is cold (below 180°F or 82°C) the thermostats are closed and they prevent coolant from flowing into radiator, so the coolant returns to the water pump through by-pass openings in housing.

During warm-up, coolant also circulates through the air compressor cylinder head, transmission oil cooler, heater lines in vehicle body, and the surge tank.

#### 2.2.2. After Engine Warm-Up

When coolant reaches the temperature at which engine thermostats open, coolant begins to flow through radiator. Heat at this time is sufficient to actuate the fan control module and cause the electric fans to operate. Coolant continues to circulate through the air compressor, transmission oil cooler and vehicle heating system, and when required, surge tank.

#### 2.3. Engine Coolant

#### 2.3.1. Description

This vehicle has been prefilled with an antifreeze solution composed of 50% ethylene glycol, 50% distilled water, plus corrosion inhibitors. This concentration is recommended for best overall performance. Use of antifreeze concentrations over 67% (67% antifreeze and 33% water) will lead to poor heat transfer and freeze protection and possible silicate dropout. Concentrations below 33% (33% antifreeze and 67% water) offer too little freeze and corrosion protection and are not recommended.



Use extreme care when depressurizing and removing the filler cap from the surge tank. The sudden release of pressure from a heated cooling system can result in loss of coolant and possible personal injury (scalding) from the hot liquid.

#### 2.3.2. Inspection Capacity

The capacity of the basic engine cooling system cylinder block, head, thermostat housing and oil cooler housing is 13.1 quarts (12.4 liters).

To obtain the total amount of coolant required in the cooling system of a unit, the additional capacity of related equipment should be obtained from the equipment supplier. Otherwise, capacity of the particular cooling system may be determined by filling the system with water, then draining and measuring the amount required.



#### 2.3.3. Draining



DO NOT work on the cooling system if the engine is hot. Hot engine coolant is under pressure and can cause scalding burns if filler caps are opened or lines are disconnected. ALWAYS allow time for the coolant temperatures and pressure to drop before servicing the system.

The following procedures provide information on how to isolate and drain the engine and radiator from the entire vehicle cooling/heating system as well as how to drain the entire vehicle cooling/heating system. The method chosen will also affect the procedure to be used for filling and deaeration.

#### 2.3.3.1. Engine & Radiator

Isolate the engine and radiator from the rest of the vehicle cooling/heating system as follows:

- 1. Ensure that the coolant temperature is 122°F (50°C) or lower.
- 2. Open the rear engine access door.
- 3. Open the interior engine access door.
- Close the coolant supply valve. This valve is located in the coolant line between the engine and the booster pump. Refer to the HVAC System Layout for valve location.

- Close the heating system return valve. This valve is located in the heating system return line close to the lower radiator tube. Refer to the HVAC System Layout in the Vehicle System Drawings Manual for valve location.
- 6. Open the surge tank access door.
- Relieve the cooling system pressure by depressing the pressure relief valve on the surge tank. Open the fill cap once the pressure has been relieved.
- Raise the vehicle to gain access to radiator drain cock and under vehicle coolant hoses. Refer to the General Information Section of this manual for approved lifting procedures.
- Place a suitable container under the radiator drain cock. Open the drain cock and drain coolant.

#### RNOTE:

Drain all liquids into suitable containers for disposal. Coolant must be recycled or disposed of in accordance with all applicable regulations. If coolant is to be recovered, make sure all containers are clean and chemical free.

- Locate and remove any drain plugs from coolant tubes and transmission oil cooler, if equipped.
- 11. Replace the coolant filter and record installation date and vehicle mileage.
- 12. Reinstall and tighten all drain plugs and close all drain cocks once engine and radiator are completely drained.



#### 2.3.3.2. Vehicle Cooling/Heating System

Drain the entire vehicle cooling/heating system, including engine and radiator as follows:

- 1. Ensure that the coolant temperature is 122°F (50°C) or lower.
- 2. Open the rear engine access door.
- 3. Open the interior engine access door.
- 4. Open the defroster access door.
- 5. Open the surge tank access door.
- Relieve the cooling system pressure by depressing the pressure relief valve on the surge tank. Open the fill cap once the pressure has been relieved.
- Raise the vehicle to gain access to radiator drain cock and under vehicle coolant hoses. Refer to the General Information Section of this manual for approved lifting procedures.
- Place a suitable container under the radiator drain cock. Open the drain cock and drain coolant.

#### ™NOTE:

Drain all liquids into suitable containers for disposal. Coolant must be recycled or disposed of in accordance with all applicable regulations. If coolant is to be recovered, make sure all containers are clean and chemical free.

- Locate and remove any drain plugs from coolant tubes and transmission oil cooler, if equipped.
- Replace the coolant filter and record installation date and vehicle mileage.
- 11.Open the defroster access door and open the drain cock at the bottom of the driver's heater/defroster unit. Drain coolant into a suitable container.

#### ™NOTE:

It may be necessary to remove coolant hoses from vehicle heating units in order to ensure complete draining of vehicle heating system.

12. Reinstall and tighten all drain plugs and close all drain cocks once engine and radiator are completely drained.

#### 2.3.4. Filling & Deaeration



Allow the cooling system to cool below 120°F (49°C) before servicing. Relieve system pressure using the pressure relief lever at the surge tank. Severe injury can occur from hot coolant, and surfaces.



The following fill and deaeration procedure must be performed any time maintenance has been performed on the heating/cooling system or engine/cooling system components. It is necessary to bleed the systems of any air pockets prior to running the engine in service; otherwise damage to the engine will likely occur.

Check that the ENG CLNT FILL MODE switch is in the OFF position prior to filling the system. Otherwise damage to the booster pump will likely occur.

Keep all manual valves open if the vehicle cooling/heating system was drained. Keep all manual isolation valves closed if the engine/radiator system was drained.

#### ™NOTE:

The surge tank can be filled through the pressure fill connector at a rate of 5 gallon per minute (GPM).

#### ™NOTE:

For emergency fill applications, where pressure fill equipment is not available, wait for the engine and coolant to cool then remove the surge tank pressure cap. Manually fill through the fill port.

- 1. Check that the drain cocks are closed and the drain plugs are installed.
- Set the driver's heater/defroster temperature to the OFF position.
- Open the pressure relief on the surge tank pressure cap and loosen the coolant recovery tank cap.



#### ™NOTE:

A coolant pressure fill connector is located at the rear street side of the engine compartment. Ensure pressure fill equipment is pressure regulated to 10 psi or less. Dispense coolant at less than 6 gallons per minute. Supply reservoir must be of adequate volume to ensure pump does not draw air during fill process. Supply coolant must be clean and of the same specification required for the vehicle cooling system. Refer to the Preventive Maintenance Section of this manual for coolant specification. Refer to your New Flyer parts manual for part numbers and ordering information for the pressure fill equipment.

- Add coolant through the pressure fill connector until the surge tank is full. Stop when the coolant starts entering the coolant recovery tank. See "Fig. 6-1: Coolant System Fill Levels" on page 7.
- 5. Check that all manual valves are open.
- Set the Master Run switch to DAY-RUN, set the defroster to HOT and the defroster fan to LOW.
- At the engine switch box set the engine run switch to REAR and turn the coolant fill mode switch to the ON position.
- 8. Check that the booster pump is operating.
- Observe the fluid level gauge on the surge tank. The coolant will drop during the fill mode.
- Keep adding coolant until the surge tank is full. Allow the fill mode to run for 5 to 7 minutes.
- 11. Close the pressure relief on the surge tank pressure cap.

- 12. Start the engine and run it at low idle for 2 minutes. Ensure that the level in the surge tank does not drop.
- 13. Run the engine at full RPM until the thermostat opens at approximately 180°F (82°C).
- 14. Continue operating the engine for 2 minutes at low idle speed.
- Turn off the engine and the fill mode switch.
- 16. Keep adding coolant until the surge tank is full and the coolant level in the coolant recovery tank is between cold max and hot max level.
- 17.Close the coolant recovery tank cap and check that there are no coolant leaks.
- 18. Disconnect the pressure fill equipment.
- 19.Allow the engine to cool below 120°F (49°C).
- 20. Check that the surge tank is full and the coolant level in the coolant recovery tank is above the cold minimum level.

#### 2.3.5. Cooling System Flushing

Refer to the Preventive Maintenance Section of this manual for scheduled flushing intervals. Also refer to Cummins Operation and Maintenance Manual for recommended cleaning and flushing procedures.

#### 2.4. Maintenance

#### ™NOTE:

Refer to the Preventive Maintenance Section of this manual for scheduled maintenance procedures and intervals.






Fig. 6-1: Coolant System Fill Levels



#### 2.5. Radiator/Charge Air Cooler



Make sure the vehicle is in neutral, the parking brake is applied, and the wheels are blocked before doing any work or diagnostic procedures on the radiator/ charge air cooler.

Disconnect the main negative battery cable and/or switch off the Battery Disconnect switch first before installation or servicing.

Use extreme caution when working on systems under pressure (for example; coolant, hydraulic fluids, air, and so forth).

Make sure the work area is ventilated and well lit.

Make sure charged fire extinguishers are in the work area.

Reinstall all safety guards, shields, and covers after servicing the vehicle.

Make sure all tools, parts, and service equipment are removed from the engine compartment and vehicle after all work is done.

Use extreme caution when working on systems containing fluids which may be hot, corrosive or hazardous.

Ensure that all system power and ground connection points are torqued to specifications to prevent system damage. Failure to follow specified torque requirements at any point of the vehicle system power and ground can result in loose connections which can damage electronic components on the system.

#### 2.5.1. Description

#### ™NOTE:


For orientation purposes, the left and right sides of the radiator/charge air cooler unit are determined by standing on the streetside of the vehicle and facing the electric cooling fans.

This vehicle is equipped with an EMP M9 combined radiator/charge air cooler assembly. The assembly includes the following major components:

Radiator
Charge air cooler
Nine electric fans
TMC system controller
Wiring harness
J1939 CAN vehicle interface cable
Power and ground studs
LED diagnostic lamp
Fan reverse button
Grounding wire

The radiator/charge air cooler assembly is located at the streetside rear corner of the vehicle. The assembly is cushion-mounted to the vehicle structure and can be accessed by a hinged door that is grilled for ventilation. The charge air cooler is stacked on top of the radiators and are enclosed by a fan shroud which provides a mounting location for the electric cooling fans. The system controller is bracket-mounted to the left side of the radiator/charge air cooler assembly. See "Fig. 6-2: Radiator/Charge Air Cooler Installation" on page 9.





- 1. Washer, Lower Rad
- 2. Mount, Rubber
- 3. Bolt, Hex 1/2" 13 UNC x 2 3/4" Lg.
- 4. Nut, Hex Jam 3/8" 16 UNC
- 5. Washer, Flat Hardened 1/2"
- 6. Washer, Snubbing
- 7. Bolt, Hex 3/8" 16 UNC x 7.0" Lg. Fully Threaded
- 8. Nut, Lock Nylon 3/8" 16 UNC
- 9. Nut, Lock Nylon 1/2" 13 UNC
- 10. Radiator/Charge Air Cooler Assembly
- 11. Mount, Center Bonded

- 12. Clamp, "P" .563" SST/HT
- 13. Screw, PH Cross Recess Tpg. Type F #10 24 UNC x 5/8" Lg.
- 14. System Controller
- 15. Washer, Flat 1/4"
- 16. Bolt, Hex 1/4" 20 UNC x 3/4" Lg.
- 17. Nut, Lock Nylon 1/4" 20 UNC
- 18. Clamp, "P" .375" SST/HT
- 19. Spacer, Dual Swivel Saddle
- 20. Cable Tie, 4/5" W x 8 1/2" Lg.

s0197139a.svg

Fig. 6-2: Radiator/Charge Air Cooler Installation

### Radiator/Charge Air Cooler



## 2.5.2. Radiator/Charge Air Cooler Specifications

Manufacturer				
Products (EMP)	Engineered Machined			
Model	XPL2D-M9			
Lower Radiator Aluminum tai with 8.5 fins/inch &	nks and bar/plate core 36 Hot Row Core			
Upper Radiator Aluminum tai with 10 fins/inch &	nks and bar/plate core 16 Hot Row Core			
Charge Air Cooler Aluminum tar with 8.5 fins/inch &	nks and bar/plate core a 16 Hot Row Core			

Cooling FansNine EMP FiL-11 11" diameter electric fans (pusher type)	•
Fan Speed Variable speed 0 - 5500 RPM (default ON @ 4000 RPM)	l
Current draw @28 VDC225 amps max	x
CAN CommunicationSAE J1939 protocol with diagnostic system reporting	ì
Fan ControlIndependent temperature contro for coolant and charge air via J1939	I



## 2.5.3. Operation

The radiator consists of an upper and lower section and is a welded aluminum assembly which functions as a liquid-to-air heat exchanger and is mounted beneath the charge air cooler. Hot engine coolant is received from the upper radiator hose, circulates through the upper and lower sections, and is drawn back to the engine by the water pump via the lower radiator hose. Cooling fans draw ambient air from outside the vehicle through the access door grille, and direct the air through the radiator core thereby lowering and maintaining the coolant temperature to the degree necessary for efficient engine operation.

The charge air cooler is a welded aluminum assembly which functions as an airto-air heat exchanger and is mounted on top of the radiator. Compressed air from the engine turbocharger is directed through the charge air cooler before being delivered to the engine air intake manifold. Cooling fans draw ambient air from outside the vehicle through the access door grille, and direct the air through the charge air cooler core thereby lowering the temperature of the compressed air which results in denser air being sent to the engine intake manifold for increased engine efficiency.

A bulb seal used to increase cooling efficiency and is fastened around the radiator to provide an airtight seal against the radiator access door and to prevent recirculation of the hot air exiting through the radiator/charge air cooler assembly. This hot air, if permitted to pass around the sides or bottom of the radiator/charge air cooler, will reduce system efficiency and may cause overheating of the engine.

The FiL-11 fans are individually controlled by the TMC system controller. The TMC system controller commands fan speed by referencing the charge air cooler and radiator temperatures received on the vehicle J1939 CAN bus. The TMC system controller will command the appropriate fans to a speed based on the high and low temperature set points for the charge air cooler or radiator. This is done to minimize the amount of electrical power being consumed by the radiator for the amount of cooling required for the vehicle.

The radiator/charge air cooler diagnostic lamp and cooling fan reverse button are located on a bracket mounted beneath the engine compartment gauges. The fan reverse button is used to verify system operation and/or clean out debris from the radiator/charge air cooler cores. Setting the Master Run switch to either DAY-RUN or NIGHT-RUN and pressing the button will operate the fans in reverse direction at high speed for 20 seconds, followed by operation in the normal direction at low speed for 10 seconds. This process will assist in removing debris from the radiator and charge air cooler cores and also confirm proper operation of all cooling fans.

The J1939 CAN vehicle interface cable provides a communication link between the radiator/charge air cooler system and the vehicle multiplexing system. System diagnostics and operating parameters can be accessed via the J1939 network using a personal computer and EMP diagnostic software.

Stray voltage can be carried by the coolant when coolant tubes are separated from the radiator via a non-conducting hose connection. With the coolant tubes and radiator not bonded to the same ground point, electrolysis can occur between the pipes and the radiator, causing accelerated corrosion. The grounding wires from the radiator and coolant tubes connect to the vehicle chassis, eliminating the electrical potential and stopping the electrolytic corrosion.



#### 2.5.4. Maintenance

## ™NOTE:

Refer to the Preventive Maintenance Section of this manual for scheduled maintenance intervals and requirements.

## 2.5.5. Radiator/Charge Air Cooler Troubleshooting & Repair

## ™NOTE:

Refer to 3. "VENDOR SERVICE INFOR-MATION" on page 28 in this section for further information.

#### 2.5.6. Removal

## ™NOTE:

The following procedure covers removal of the radiator and charge air cooler assemblies as a unit from the vehicle.

- Set the Battery Disconnect switch to the OFF position.
- 2. Open the engine compartment and the radiator compartment access doors.



Ensure that the cooling system has been depressurized at the surge tank. Close the heating system supply and return shutoff valves, located in the engine compartment, prior to draining the cooling system. Refer to HVAC System layout for shutoff valve locations.

- Remove the drain plug from the lower radiator tube and drain the engine coolant into a suitable container.
- Loosen the hose clamps and remove the two upper CAC hoses from the charge air cooler.
- 5. Loosen the hose clamps and remove the radiator hoses from the radiator.

- 6. Disconnect the wiring harness from the fan reverse switch/LED diagnostic lamp.
- Pull back the protective covers on the positive (+) and negative (-) power studs and disconnect the positive and negative power cables.
- Loosen the jam nuts and remove the lock nut from the upper mounting bolt.
- Disconnect the ignition input signal wire connector and the J1939 CAN vehicle interface wire connector, both located on the right hand side of the unit.
- 10. Disconnect the grounding wire from the chassis connection point.



Radiator/charge air cooler assembly is very heavy. Use a forklift or other appropriate lifting system to support and remove the unit. Strap the radiator/ charge air cooler assembly to prevent the unit from tipping during removal and transportation to a work area.

- 11.Support the weight of the radiator/charge air cooler and remove the fasteners that attach the upper mounting link rod to the radiator mounting bracket and vehicle structure. Remove the link rod.
- 12. Remove the two fasteners that attach the left side of the radiator support channel to the rear mounting bracket.
- 13. Remove the two fasteners that attach the right side of the radiator support channel to the vehicle structure.

#### ™NOTE:

The lower radiator support channel will remain attached to the radiator as the unit is being removed from the vehicle.

14. Carefully remove the radiator/charge air cooler assembly from the vehicle.

## Radiator/Charge Air Cooler

#### 2.5.7. Installation

- Use appropriate lifting equipment and move the radiator/charge air cooler assembly into position.
- Align the mounting holes in the radiator support channel with the vehicle structure and install the bolts, washers and nuts on the left side and right side. Do not tighten fasteners at this time.
- Align the holes in the upper mounting brackets on the charge air cooler and vehicle structure. Install the upper mounting bolt, washers, jam nuts and locking nut but don't final tighten at this time.
- Adjust the position of the radiator to ensure full contact of the bulb seal with the radiator access door closed. Tighten the upper mounting jam nuts to maintain radiator position and torque to 43 ft-lb. (58 Nm).
- 5. Tighten all mounting hardware. Torque the lower mounting bolts to 50 ft-lb. (68 Nm).
- Pull back the protective covers on the positive (+) and negative (-) power studs and connect the positive and negative power cables using lock washer and nut. Torque nut to 15 ft-lb. (20 Nm).
- Connect the grounding wires to the chassis connection point. Torque to 14 ft-lb. (19 Nm). Apply Zinc primer, if necessary, to cover base metal.

- Connect the ignition input signal wire connector and the J1939 CAN vehicle interface wire connector, both located on the left hand side of the unit, to vehicle wiring harness.
- Connect the wiring connector on the right hand side of the unit to the fan reverse switch/LED diagnostic lamp harness.
- 10. Connect the two upper CAC hoses to the charge air cooler and tighten the hose clamps.
- 11. Connect the radiator hoses to the radiator and tighten the hose clamps.

## ™NOTE:

Be sure to reinstall the lower radiator hose drain plug.

- 12.Set the Battery Disconnect switch to the ON position.
- 13. Refill the cooling system and purge air out of the system before starting the vehicle. Refer to 2.3.4. "Filling & Deaeration" on page 5 in this section for procedure. Also refer to the Preventive Maintenance Section of this manual for fluid specification.



## 2.6. Transmission Cooler

## 2.6.1. Description

The oil cooler is used to cool the transmission fluid by transferring heat from the fluid to the engine coolant. Hot fluid from the transmission is cooled as it circulates around the cooler core assembly before returning to the transmission.

Coolant from the engine cooling system is circulated through the cooler core assembly where it absorbs heat before returning to the engine. At regular service intervals the oil cooler and its external connections should be inspected for evidence of water or fluid leaks. Remove and clean cooler when inspection indicates any leakage or malfunction or at the time the transmission is repaired or overhauled.

#### 2.6.2. Removal

- 1. Close the coolant supply and return shutoff valves located in the engine compartment.
- Clean the area around inlet and outlet ports, then disconnect the two transmission fluid lines. Plug the open ends of both lines to prevent fluid loss and contaminants from entering. See "Fig. 6-3: Transmission Cooler Installation" on page 14.
- Loosen and disconnect the coolant lines. Plug the lines to prevent dust from entering.
- Remove the bolts attaching the cooler to the mounting bracket and remove the cooler.
- Clean the exterior of the cooler, then drain the fluid and coolant remaining in the cooler.




Fig. 6-3: Transmission Cooler Installation



## 2.6.3. Disassembly

- If the mounting brackets are being replaced, mark their positions and spacing relative to the housing before removing. See "Fig. 6-4: Transmission Cooler Assembly" on page 16.
- 2. Mark the positions of both end caps relative to the housing.
- Remove the bolts from both end caps and remove the end caps. Discard the gaskets and O-rings.
- 4. Remove the division rib and seal from the bundle assembly.
- Note that one end of the bundle, with the larger cupped tube plate, protrudes from the housing. Mark the rotational position of the bundle cupped tube plate (header plate) relative to the housing.
- 6. Press the bundle assembly from the housing as follows:
  - a. Support the bundle assembly on an arbor press with the smaller, non-protruding end facing upward.

## ™NOTE:

Support the housing on its mounting flange so that sufficient room will be provided to press out the bundle from the housing.

- b. Cut a circular piece of plywood to match the diameter of the cooling tube bundle.
- c. Place the piece of plywood on top of the tubes of the smaller diameter cupped tube plates.



Use care not to bend the sides of the cup or any of the tubes that pass through the cooler.

- d. Use the arbor press to carefully press the bundle assembly out of the housing.
- 7. Remove and discard the O-rings in the grooves of the housing at either end.






Fig. 6-4: Transmission Cooler Assembly

## 2.6.4. Cleaning

#### 2.6.4.1. Oil Side

The oil cooler should be cleaned at every transmission overhaul or whenever the transmission fluid becomes contaminated.

 Immerse the bundle assembly and housing in a paraffin or degreasing tank to remove all traces of oil.



DO NOT use a heated cleaning bath if using vapor solvents for cleaning.

 Immerse the bundle assembly in a heated detergent bath and move back and forth vigorously to remove stubborn carbon deposits.



NEVER use stiff metal brushes or probes which may damage the tubes, baffles, and/or headers.

## ™NOTE:

Agitation of the detergent by a steam or compressed air jet will expedite the cleaning process. DO NOT exceed 10 psi pressure.



#### 2.6.4.2. Water Side

A badly scaled cooler can be cleaned by immersing the bundle assembly in suitable inhibited acid solvent. Ensure the oil side of the bundle has been thoroughly cleaned before proceeding with an acid bath.



ALWAYS wear protective clothing and a face shield when working with acids. NEVER add water to acid.

- Mix a 4% solution of hydrochloric acid with water. Ensure that the acid is added to the water and not vice-versa.
- Heat the solution to 120°F to promote the descaling process.
- Immerse the bundle in the acid solution and allow the effervescent action to take place.
- Remove the bundle from the bath once the effervescing has ceased and rinse in hot water.
- 5. Inspect for cleanliness and, if necessary, repeat the cleaning process.
- Once the bundle is clean, neutralize by immersing the bundle in a boiling solution of soda. Use one pound soda crystals to five gallons water.
- 7. Final rinse bundle in hot fresh water.

### 2.6.5. Assembly

 Lubricate the inside of the housing with a light coating of oil.

## ™NOTE:

Use new O-rings and gaskets during assembly.

- Lubricate the small O-ring and insert in the housing groove. This O-ring goes on the end of the housing that does not have a machined step.
- Lubricate and install the larger O-ring in the groove at the opposite end of the housing.
- Inspect the bundle assembly for any handling damage and ensure that the tube plate cups are not damaged.

- 5. Place the housing on a clean flat surface with the large end facing up.
- Lubricate around the O.D. of the tube plate cups.
- Insert the smaller end of the bundle assembly into the housing by hand while ensuring the marks made during removal are aligned.

## ™NOTE:

It is important that original alignment is maintained to ensure that internal baffles on the bundle align with the oil ports on the housing.

- 8. Continue to press the bundle assembly as far as possible by hand, using care not to pinch or nick the O-rings.
- Move the partially installed assembly to the arbor press. Support the housing with the large end up.
- 10. Place the wooden pressing plate on top of the cooler tubes of the bundle assembly.



DO NOT use excessive force to press the bundle assembly. If installation does not go smoothly, remove the bundle, inspect, and reinstall.

- 11. Carefully press the bundle assembly into the housing until it seats against the machined groove.
- Lubricate and install O-rings on the tube plate cups in the chamfers provided in the housing.
- 13.Install new gasket and end cap on the smaller end of the housing. Install bolts and washers and hand-tighten only at this time.
- 14.Install a new division rib and seal at the opposite (large) end of the bundle. Ensure that the division rib is properly oriented with respect to the coolant ports on the end cap. Press the division rib into the tubes of the bundle so that the tangs of the division rib engage the tubes.
- 15.Install end cap with coolant ports in same position as marked during removal.



- 16.Install bolts and washers and tighten in a two-stage criss-cross pattern. Final torque bolts to 20-22 ft-lbs. (27-30 Nm).
- 17. Torque bolts on the opposite end cap using the same procedure.
- 18. Reinstall the mounting brackets, if previously removed, in the same position and spacing as marked during removal. Torque U-bolt nuts to 10 ft-lbs. (14 Nm).



## 2.7. Surge Tank

## 2.7.1. Description

The surge tank is located in the engine compartment on the streetside of the vehicle, adjacent to the radiator. The surge tank includes the following components:

- ☐ Filler Cap with Pressure Control & Relief Valve
- Coolant Level Sensors
- ☐ Fluid Level Gauge
- ☐ Schrader Valve

The surge tank access door provides access to the filler cap, pressure relief valve, fluid level gauge, pressure test Schrader valve. The coolant sensors are accessible from the engine compartment. See "Fig. 6-5: Surge Tank Assembly" on page 20.

## 2.7.2. Surge Tank Specification

Туре	Welded steel construction
Size	9.5" Dia. x 23.50" high
Capacity	4.6 gal
	atingsi (172 kPa) with water tesi
o	elief Valve sure rating 16 psi (110 kPa) operating range 14 to 18 psi (97 to 124 kPa)

#### 2.7.3. Operation

The surge tank provides a reservoir for the cooling system and allows for coolant expansion. The surge tank also removes air entrapped in the system using hose connections to locations where air may be entrapped. The coolant is routed to the coolant recovery tank when the pressure in the surge tank exceeds the relief valve pressure rating. The Schrader valve is used to check the cooling system pressure.

## 2.7.4. Filler Cap with Pressure Control & Relief Valve



Allow engine cooling system to cool, relieve cooling system pressure and open filler cap slowly. Keep away from hot coolant and surfaces to avoid injury.

The pressure control and a relief valve are integral with the filler cap. The pressure control maintains cooling system pressure preventing the loss of coolant. A vacuum valve in the filler cap opens to prevent the collapse of hoses when the cooling system cools and creates a vacuum.

Clean and inspect the filler cap when the cooling system is serviced. Also test the operation of the control cap pressure relief valve and vacuum valve.

## RNOTE:

Use a commercially available cooling system pressure tester to pressurize and test both the cooling system and pressure control cap.

## 2.7.5. Coolant Level Sensors

Two coolant level sensors are used in the surge tank to detect the absence of fluid at the probe tip. One sensor is used to activate the Low Coolant indicator (red) on the instrument panel and the other is used to send a signal to the engine ECU and initiate an engine shutdown. The sensors are accessible from the engine compartment and are non-serviceable. No adjustments are required.

#### 2.7.6. Fluid Level Gauge

A fluid level gauge is mounted on the side of the surge tank to provide a quick visual indication of the fluid level in the surge tank. The gauge is connected with an adapter at the bottom and a hose at the top. The fluid level gauge is graduated with a cold and a hot mark.






Fig. 6-5: Surge Tank Assembly



- 1. Surge Tank Assembly, (Incl. 2-10, 13-22)
- 2. Clamp, "P" .625" SST/HT
- 3. Fitting, Barbed 1/4" MPT x 3/8" I.D. Barb
- 4. Clamp, Flexgear .56" Dia. 1.06" Dia.
- 5. Fitting, Barb Hose 1/4" x 3/8" I.D.
- 6. Screw, PH Cross Recess #10 24 UNC x 3/4" Lg.
- 7. Hose, Silicone Rubber 9mm I.D. 13' Long
- 8. Nut, Lock Nylon #10 SST
- 9. Sensor, Low Coolant Level
- 10. Sensor, Low Fluid Assembly (Incl. 11-12)
- 11. Sensor, Low Coolant Level

- 12. Sensor Assembly, Coolant Level
- 13. Adapter, 1/2" NPT x 6 JIC Brass
- 14. Washer, Flat SST #10
- 15. Surge Tank, Welded
- 16. Gauge, Coolant Level
- 17. Never Seize
- 18. Tee, Street 1/4" PT
- 19. Adapter, 1/4" NPT x 3/8" JIC Brass
- 20. Loctite, PST
- 21. Plug, Pipe 1/2" 14 Brass
- 22. Elbow, 45° 1/4" NPT

## Surge Tank Assembly (parts list)

#### 2.7.7. Removal

- Relieve system pressure using the manual pressure relief valve on the filler cap. Remove the filler cap. See "Fig. 6-6: Surge Tank Installation" on page 22.
- 2. Close manual shutoff valves located in the supply and return lines.
- 3. Drain the cooling system until the coolant fluid is below the level of the surge tank.
- Disconnect and tag all hoses and electrical connections from the surge tank.
- 5. Remove the fastener securing the surge tank to the top mounting bracket.
- 6. Remove the fasteners securing the surge tank to the middle bracket.

- 7. Remove the fasteners securing the surge tank to the bottom bracket.
- 8. Remove the surge tank from the vehicle.
- 9. Clean the surge tank and inspect it for damage.

#### 2.7.8. Installation

- 1. Install the surge tank in reverse order using Loctite-243 on the screw threads.
- 2. Reconnect all hoses and electrical connectors to the surge tank.
- 3. Add coolant to the cooling system. Refer to 2.3.4. "Filling & Deaeration" on page 5 in this section for procedure.






Fig. 6-6: Surge Tank Installation



## 2.8. Coolant Recovery Tank

## 2.8.1. Description

The coolant recovery tank is mounted in the engine compartment and is accessible from the engine access door. It is a nonpressurized translucent tank vented to the atmosphere and graduated with COLD FULL and HOT FULL marks for servicing.

## 2.8.2. Coolant Recovery Tank Specifications

Type M	olded Translucent Plastic
Capacity	2.5 gal. (9.5 L)
Cap	Top Vented, Nylon

## 2.8.3. Operation

The coolant recovery tank is connected to the surge tank's pressure control cap with a hose. As coolant in the surge tank heats up it expands, increasing the coolant system pressure. When the coolant system pressure exceeds the relief valve setting on the pressure control cap, the coolant is released to the coolant recovery tank. As the system cools and the coolant contracts a vacuum is formed in the surge tank, drawing the coolant from the recovery tank back into the surge tank.

#### 2.8.4. Removal



Allow engine cooling system to cool before servicing.



Relieve pressure in cooling system before servicing. Open pressure cap slowly.

- 1. Remove the remote pressure cap.
- Disconnect the hose from the coolant recovery tank and drain the coolant into a suitable container.
- Remove the two bolts securing the tank clamp to the tank mounting bracket at the front of the tank. See "Fig. 6-7: Coolant Recovery Tank" on page 24.
- Remove the bolt securing the tank clamp to the tank mounting bracket at the rear of the tank and remove the clamp portion of the bracket.
- 5. Remove the coolant recovery tank from the mounting bracket.
- 6. Clean the coolant recovery tank and inspected it for damage.

#### 2.8.5. Installation

1. Position the coolant recovery tank on the vehicle-mounted support bracket.

### ™NOTE:

The tank has raised circular surfaces that must clear the circular openings in the tank clamp. The clamp should sit flat on the top of the tank without causing any deformation to the tank.

- Align and install the tank clamp. Install and tighten the front two bolts, washers and lock nuts.
- Install the bolt washer and lock nut at the rear of the tank clamp. Tighten the nut until it contacts the clamp and then tighten three more turns.
- Connect the hose to the fitting on the bottom of the coolant recovery tank.
- 5. Install the pressure cap.
- Add coolant to cooling system. Refer to 2.3.4. "Filling & Deaeration" on page 5 in this section for procedure.






Fig. 6-7: Coolant Recovery Tank



## **Hose Clamp Torque Specifications**

- 1. Clamp, "P" .625" SST/HT
- 2. Clamp, "P" 3/4" SST/HT
- 3. Clamp, "P" Cushion SST/HT 1.313"
- 4. Bolt, Hex 1/4" 20 UNC x 3/4" Lg.
- 5. Bolt, Hex 1/4" 20 UNC x 1" Lg.
- 6. Bolt, Hex 1/4" 20 UNC x 1 1/4" Lg.
- 7. Washer, Flat #10
- 8. Washer, Flat 1/4"
- 9. Screw, PH Cross Recess SST #10 24 UNC x 3/4" Lg.

- 10. Loom
- 11. Screw, PH Cross Recess Tpg. Type F #10 24 UNC x 3/4" Lg.
- 12. Screw, PH Cross Recess Tpg. Type F #10 24 UNC x 1 1/2" Lg.
- 13. Hose, Silicone 5/16" I.D. Drain
- 14. Spacer, .5" O.D. x .75" Thk.
- 15. Nut, Lock Nylon #10 24 UNC
- 16. Nut, Lock Nylon 1/4" 20 UNC
- 17. Bracket

- 18. Bracket
- 19. Rivet, Mono Blind SST 3/16" x .064/.270
- 20. Bracket
- 21. Shield, Heat Coolant Recovery
- 22. Tank Assembly, Coolant Recovery
- 23. Clamp, Hose 5/16"

Fig. 6-8: Coolant Recovery Tank (parts list)

## 2.9. Hose Clamp Torque Specifications

The following torque chart provides a listing of the various hose clamps used in the

cooling system and the applicable torque for the specific clamp. The size of clamp (clamp width) will determine the torque value.

HOSE CLAMP TORQUE SPECIFICATIONS				
Item	Description	Application	Clamp Width	Torque (in-lb.)
1	Breeze Stainless Steel Clamp	Rad Tubes & Surge Tank Drop Tube	0.625	90 to 125 in-lb.
2	Breeze Stainless Steel Clamp	Rad Tubes & Heater Lines	0.562	30 to 70 in-lb.






Fig. 6-9: Coolant Filter Installation



## **Coolant Filter & Conditioner**

- 1. Valve Teflon Ball
- 2. Connector, Straight 3/8" I.D. x 3/8" Male NPT
- 3. Bushing, Reducing 3/4" PT x 3/8" PT
- 4. Bolt, Hex 1/4" 20 UNC x 1" Lg.
- 5. Washer, Flat 1/4"
- 6. Filter, Water
- 7. Nut, Lock Nylon 1/4" 20 UNC
- 8. Bracket, Water Filter
- 9. Hose, Silicone Rubber

- 9mm I.D. 4' Long
- 10. Elbow, 90° Street 1/4" MPT x 1/4" FPT
- 11. Clamp, Flexgear .56" Dia. 1.06" Dia.
- 12. Bushing, 3/8" MPT x 1/4" FPT
- 13. Elbow, 90° ext Pipe to ext Pipe
- 14. Connector, 1/4" MPT x -06 Hose Barb
- 15. Loctite, 567 White
- 16. Bolt, Hex 1/4" 20 UNC x 3/4" Lg.

- 17. Clamp, "P" 3/4" SST/HT
- 18. Clamp, "P" 2.375" SST/HT
- 19. Head
- 20. Bolt, Hex 3/8" 16 UNC x 1 1/4" Lg.
- 21. Washer, Flat 3/8"
- 22. Loctite, 243 Blue
- 23. Cable Tie, 4/5" W x 8 1/2" Lg.
- 24. Spacer, Dual Swivel Saddle

Coolant Filter Installation (parts list)

## 2.10. Coolant Filter & Conditioner

## 2.10.1. Description

The engine cooling system filter and conditioner is a compact bypass type unit with a spin-on type element. See "Fig. 6-9: Coolant Filter Installation" on page 26.

A correctly installed and properly maintained coolant filter and conditioner provides a cleaner engine cooling system, greater heat dissipation, increased engine efficiency through improved heat conductivity and contributes to longer life of engine parts.

The filter provides mechanical filtration by means of a closely-packed element through which the coolant passes. Any impurities such as sand and rust particles suspended in the cooling system will be removed by the straining action of the ele-

ment. The removal of these impurities will contribute to longer water pump life and proper operation of the thermostat.

The filter also serves to condition the coolant by softening the water to minimize scale deposits, maintain an acid-free condition and act as a rust preventive.

Corrosion inhibitors are placed in the element and dissolve into the coolant, forming a protective rustproof film on all of the metal surfaces of the cooling system. The other components of the element perform the function of cleaning and preparing the cooling passages while the corrosion inhibitors protect them.

#### MOTE:

Refer to the Preventive Maintenance Section of this manual for filter replacement intervals and procedures.





# 3. VENDOR SERVICE INFORMATION

The following supplier manuals contain additional reference information.

## 3.1. Engineered Machined Products (EMP) Manual

☐ MH9 Cooling System Service Manual



# **Fuel System**

1.	SAFET	Υ	7-1
		ety Procedures	
2.	FUEL S	SYSTEM	7-2
	2.1. Des	scription	7-2
		eration	
	•	el Tank	
	2.3.1.	Description	
	2.3.1.	Removal	
	2.3.3.	Disassembly	
	2.3.4.	Cleaning & Inspection	
	2.3.5.	Assembly	
	2.3.6.	Installation	
	2.3.7.	Anti-Spill System	
	2.3.8.	Level Control Valve Replacement	
	2.3.9.	Pressure Relief Valve Replacement	7-9
	2.3.10	. Fuel Level Sending Unit	7-10
		3.10.1.Description	
		3.10.2.Removal	-
		3.10.3.Installation	
		mary Fuel Filter	
	2.4.1.	Safety	
	2.4.2.	Description	
	2.4.3.	Primary Fuel Filter Specifications	
	2.4.4.	Operation	
	2.4.5.	Maintenance	
	2.4.6.	Primary Fuel Filter Troubleshooting	
		condary Fuel Filter	
	2.5.1.	Description	
	2.5.2.	Secondary Fuel Filter Specifications	
	2.5.3.	Operation	
	2.5.4.	Maintenance	
		el Lines & Flexible Hoses	
	2.6.1.		
	2.6.2.		
	2.7. Fue	el System Leak Test	7-17
3.	DIESEL	_ FUEL	7-18
	3.1. Des	scription	7-18

## Table of Contents



3.2. Storage	7-18
3.2.1. System Fuel Tanks	
3.3. Fuel Contaminants	
3.3.1. Preventing Algae Contamination	7-19





## 1. SAFETY

## 1.1. Safety Procedures

This section of the service manual contains procedures which require the mechanics to strictly observe safety procedures in order to ensure personal and equipment safety.

Refer to the General Information Section of this manual for information on types of hoists, hoisting procedures, jackstands and related safety information. Refer to this information and read carefully before lifting, hoisting or jacking the vehicle.

Always ensure that the vehicle is appropriately hoisted and blocked for procedures which require elevating the vehicle. Be aware of the limitations of the blocking equipment, and always ensure that the jarring and shaking created by component removal and installation procedures does not overload the blocks, or cause the vehicle to become unstable.

Certain procedures may require the vehicle be operated in an elevated position in order to accurately troubleshoot and diagnose a problem. If the vehicle must be running while elevated, become familiar with the repair area prior to starting the engine. Take special care in noting areas which will become hot, electrically energized, and areas where moving and rotating components are located. Limit the work in these areas as personal and equipment safety is at risk.

For procedures which involve air lines, ensure the line is safely depressurized prior to disconnecting. Disconnecting pressurized lines will cause solid particles deposited in the line to be uncontrollably propelled, and will also cause the hose end to whip randomly as the air escapes.



## 2. FUEL SYSTEM

## 2.1. Description

The fuel system includes the fuel tank, a primary fuel filter, a secondary fuel filter, lift pump, fuel pump, fuel manifold, and fuel lines.

The fuel tank is mounted in the vehicle chassis, forward of the rear wheels. Supply and return fuel lines run between the tank and the engine at the rear of the vehicle. Engine-mounted fuel components include a lift pump, main fuel pump and the injection system. Refer to the OEM Engine Maintenance Manual for further information on the engine fuel system.

## 2.2. Operation

On engine start-up the lift pump draws fuel from the fuel tank, through a primary fuel filter. The low pressure side of the fuel pump discharges fuel through the fuel manifold, the secondary fuel filter and to the inlet of the high pressure fuel pump. High pressure fuel is delivered through a common fuel rail to the fuel injectors. Surplus fuel returns to the fuel tank through a return line.



## 2.3. Fuel Tank

## 2.3.1. Description

A single fuel tank is mounted transversely in the vehicle chassis, forward of the rear axle. A fuel filler neck assembly is bolted to the tank and provides mounting locations for the fuel filler adapter, pressure relief valve, and fuel level control valve. Fuel tank fill access is provided through a hinged door on the curbside of the vehicle. Supply and return fuel hoses connect the fuel tank with the engine. The fuel tank is equipped with the following components:

- □ Pressure Relief Valve
- □ Fuel Level Control Valve
- Whistle Valve
- Fuel Level Sending Unit

#### 2.3.2. Removal



Diesel fuel is flammable. Keep open flames and sparks away from work area. Work in a well ventilated area. Wear proper eye protection and protective clothing.

- 1. Set the Battery Disconnect switch to the OFF position.
- 2. Remove the fuel filler adapter from the fill tube and remove adapter through the fuel filler access door. Plug the filler tube to prevent debris from entering. See "Fig. 7-1: Fuel Tank Installation" on page 4.
- 3. Disconnect the pressure relief vent hose and tie it away from the fuel tank.
- Disconnect the two wire leads from the fuel level sending unit. Note the location of the wire leads for installation.
- Raise the vehicle. Refer to the General Information Section of this manual for lifting procedures.
- Remove the drain plug from the bottom of the fuel tank and drain the fuel into a clean container. Temporarily plug the drain port to prevent contamination.

## ™NOTE:

The fuel tank capacity is 125 U.S. gal.

- Disconnect the fuel supply and return lines from the fuel tank and tie them away from the fuel tank. Plug all fuel lines to prevent contamination.
- Mark position and remove the fuel line fittings from the fuel tank. Plug all fuel tank openings.

## ™NOTE:

The fuel line fittings need to be removed in order to provide clearance when the fuel tank is lowered.



Use proper lifting equipment and procedures when removing the fuel tank. The fuel tank weighs approximately 255 lbs and the center support frame weighs approximately 60 lbs.

- Position a lift table or similar lifting device beneath the fuel tank center support frame. Arrange wood blocks on the lift so that the weight of the center support frame is taken by the lift.
- 10.Remove the fasteners holding the center support frame, lower the frame and move away from the vehicle.

#### ™NOTE:

Record quantity and position of any shims installed between support frame and vehicle structure. Retain shims for reassembly.

- 11. Reposition the lift under the fuel tank. Place wooden blocks under the streetside and curbside tank support channels so that the weight of the fuel tank is evenly distributed and taken by the lifting equipment.
- 12.Check that the fuel tank is properly supported, and then remove the fasteners holding the streetside and curbside supports.
- 13. Carefully lower the fuel tank and move it to a clean work area.






Fig. 7-1: Fuel Tank Installation



## 2.3.3. Disassembly

- Mark the position of the streetside and curbside support channels to ensure proper location during assembly.
- 2. Remove the support channels from the bottom of the fuel tank by removing the lock nuts from each strap T-bolt. Remove straps and supports from fuel tank.
- 3. Remove fuel tank components. See "Fig. 7-2: Fuel Tank Accessories" on page 5.

## ™NOTE:

Refer to specific replacement instructions in this section for information on replacing fuel tank mounted components.

 Remove the filler neck assembly from the fuel tank by removing the eight bolts from the mounting plate. Remove and discard gasket.




Fig. 7-2: Fuel Tank Accessories



## 2.3.4. Cleaning & Inspection

- 1. Inspect fuel tank for dents, cracks, corrosion, or other damage.
- 2. Clean all threaded fittings and ports of any thread sealant or thread locking residue.
- Inspect all fittings and ports for thread damage.
- Inspect filler neck welded joint at mounting plate for cracks.
- 5. Inspect all mounting flanges and sealing surfaces for flatness, scoring, corrosion, or other damage.
- Inspect all neoprene isolator strips located on the side and center support channels and tank straps. Replace damaged or worn neoprene strips using 3M Fastbond 30H adhesive.
- 7. Inspect interior of tank for rust particles, sludge, water, or microbial growth. Clean and flush tank as required.

### 2.3.5. Assembly

- Install drain plug using Loctite 567 thread sealant.
- Install filler neck assembly onto tank with new gasket. Apply Loctite 222 to eight mounting bolts and tighten.
- 3. Install fuel tank mounted components.

## ™NOTE:

Refer to specific replacement instructions in this section for information on replacing fuel tank mounted components.

### ™NOTE:

Perform a fuel tank pressure test if any components were replaced or repairs undertaken. Refer to 2.7. "Fuel System Leak Test" on page 17 in this section for test procedure.

- Position streetside and curbside support channels on underside of fuel tank at locations marked during disassembly. Ensure neoprene isolator strips are in good condition and properly bonded to the support channels.
- Attach the tank straps to the fuel tank support channels using T-bolt, washer, and lock nut. Ensure neoprene isolator strips are in good condition and properly bonded to underside of tank strap. Torque lock nuts 56 to 61 ft-lb. (76 to 83 Nm).



#### 2.3.6. Installation

- Raise fuel tank into position, aligning streetside and curbside support channels with threaded mounting holes in vehicle structure.
- Secure support channels to vehicle structure by applying Loctite 272 thread locker to mounting bolts and installing with washers Torque bolts 82 to 90 ft-lb. (111 to 122 Nm).
- Use lifting equipment to raise the center support frame into position. Ensure that the neoprene isolator strips are in good condition and properly bonded to the underside of the support frame.
- 4. Replace shims, if applicable, in quantity and locations noted during removal. Do not exceed two shims per location.
- Secure center support frame to vehicle structure using original fasteners. Torque fasteners 155 to 175 ft-lb. (210 to 237 Nm).

- 6. Install fuel line fittings in the same orientation and position as marked during removal. Install all pipe thread fittings using Loctite 567 thread sealant.
- Connect fuel supply and return lines to tank.
- 8. Connect vent hose to pressure relief valve.
- Attach wire leads to fuel level sending unit using 10 - 24 UNC screws with Loctite 222 thread locker. Torque screws 10 to 15 in-lb.
- 10. Apply protective covering of dielectric grease to the terminals of the fuel level sending unit.
- 11. Attach pressure-fill adapter to fuel filler pipe using a new gasket. Torque fasteners 75 to 85 in-lb.
- 12. Fill the fuel tank.
- 13. Set the Battery Disconnect switch to the ON position.
- 14. Purge the fuel system, start the vehicle, and check for leaks.



## 2.3.7. Anti-Spill System

The fuel tank has a Emco anti-spill filler system. The system prevents the fuel from spilling during fuel filling. The Emco system allows for fast pressure filling.

The anti-spill system is mounted on the fuel tank. It consists of a filler neck adapter, level control valve, a whistle valve, and a pressure relief valve.

The fueling nozzle is mechanically locked to the filler neck adapter during fueling, but is easily removed when the tank has been filled to 95% of its maximum capacity.

## ™NOTE:

To engage or disengage the nozzle from the adapter, rotate the nozzle approximately 30° clockwise to engage and counter-clockwise to disengage.

A whistle valve, attached to the level control valve, emits a whistle sound when the tank is being filled. The whistling sound continues until the level control valve automatically shuts off the whistle valve.

When the fuel level approaches 95% of the tank capacity, the level control valve shuts off the air vent and whistle valve, allowing a slight pressure build-up in the tank. This

results in back pressure on the trip mechanism in the nozzle, causing the nozzle to shut off the fuel flow.

### ™NOTE:

The shut-off pressure is approximately 0.7 to 1.1 psi.

The pressure relief valve functions if the nozzle fails to shut off and fuel continues to fill the tank. When the pressure reaches 3.1 to 3.3 psi in the tank, it causes a spring-loaded poppet in the pressure relief valve to lift off its seat. This allows pressure and fuel to escape via a fuel discharge hose.

Once the flow is shut off, the operator pulls the disconnect handle on the side of the nozzle, thereby activating the pressure relief valve. The pressure relief valve vents the pressure build up in the tank to the atmosphere.

### ™NOTE:

The pressure relief valve activates at 3.1 psi.

When the venting "hiss" has stopped, the operator keeps the disconnect handle pulled out and rotates the nozzle to disengage it from the adapter.



#### 2.3.8. Level Control Valve Replacement

- Unscrew the whistle valve from the level control valve.
- Remove screws securing the control valve to the fuel tank. Disconnect the overflow hose and remove from the level control valve. Remove control valve and gasket.
- 3. Clean mounting surface of the control valve.
- Position a new gasket and control valve on the fuel tank, install mounting screws to tighten them. Connect overflow hose to control valve.

## ™NOTE:

DO NOT exceed 10 to 15 in-lb. (1.1 to 1.7 Nm) torque when installing gasket mounting screws. DO NOT use power tools to install these screws.

- Clean the whistle valve in a suitable solvent. Replace the internal spring in the valve if necessary. Make sure to place the seal, float, and ball in proper positions. See "Fig. 7-3: Level Control Valve" on page 9.
- 6. Install whistle valve by screwing it into control valve and tightening it securely.




Fig. 7-3: Level Control Valve

## 2.3.9. Pressure Relief Valve Replacement

- Disconnect hose and remove from relief valve.
- Remove screws securing the pressure relief valve to the fuel tank.
- 3. Remove the relief valve and its gasket from the fuel tank.
- 4. Clean mounting surface of the relief valve.
- Position a new gasket and relief valve on the fuel tank, install mounting screws and tighten.

## ™NOTE:

DO NOT exceed 10 to 15 in-lb. (1.1 to 1.7 Nm) torque when installing gasket mounting screws. DO NOT use power tools to install these screws.

6. Connect hose to relief valve.



## 2.3.10. Fuel Level Sending Unit

## 2.3.10.1.Description

The fuel level sending unit consists of a fuel tank mounted bracket and plate, and a float connected to a resistor case by a float arm. As the float rises and falls in the tank with varying fuel levels, it varies the resistance on the rheostat in the resistor case. This reading is transmitted to the Low Fuel indicator on the instrument panel.

## ™NOTE:

Fuel sending unit operating range is 29 to 33.5 ohms at full and 244 to 250 ohms at empty. Replace unit if it fails to meet above values.

#### 2.3.10.2.Removal

## ™NOTE:

Fuel tank must be removed from vehicle to replace fuel level sending unit.

- 1. Clean accumulated debris from around fuel level sending unit.
- 2. Remove screws securing fuel level sending unit to fuel tank.
- Remove fuel level sending unit and gasket from fuel tank.
- Clean fuel level sending unit mounting surface on fuel tank.

#### 2.3.10.3.Installation

- Adjust the new fuel level sending unit bracket to the same length as the old bracket and tighten the two adjusting screws.
- Install new gasket and fuel level sending unit into fuel tank.
- Apply Loctite 222 thread adhesive to the screws mounting the fuel level sending unit. Install the screws and tighten 10 to 15 in-lh



## 2.4. Primary Fuel Filter

### 2.4.1. Safety



- □ Scalding hazard: When diesel fuel is circulated through an operating engine, it can become very hot. DO NOT allow fuel to come in contact with eyes or unprotected skin. Allow the engine and fuel to cool to ambient temperature before replacing the fuel filter or performing service operations which could result in spillage of fuel from the fuel system. If this is not possible, protective equipment (face shield, insulated hat, gloves, and apron) must be worn.
- ☐ Fire Prevention: Heated fuel can form combustible vapor mixtures in the area around the fuel source. To eliminate the potential for fire, keep open flames, sparks or other potential ignition sources away from the work area. DO NOT smoke during filter replacement or service operations.
- Inhalation Precaution: ALWAYS perform engine or vehicle fuel system maintenance in a well ventilated area that is kept free of bystanders.
- □ The Master Run Switch must be in the OFF position, unless otherwise directed. To avoid unintentional engine startup, use a lockout and/or signage to alert personnel that work is being performed.

## 2.4.2. Description

The Fuel Pro-382+ primary fuel filter is installed inline between the vehicle fuel tank and the engine lift pump. The primary filter is remotely-mounted in the rear curbside corner of the engine compartment. The filter assembly consists of a valve body, filter element, and clear filter cover. A water-in-fuel sensor is located on the bottom of the filter body. See "Fig. 7-4: Fuel Lines & Primary Fuel Filter Installation" on page 12.

## 2.4.3. Primary Fuel Filter Specifications

Manufacturer	Davco Element
Mounting	Spin-on
Particle Size	10 micron
Sensorwith shut resistor	integral water-in-fuel
Drain Valvei at bottom of filter	ntegral threaded valve

## 2.4.4. Operation

The fuel filter is plumbed into the suction side of the lift pump. Fuel from the tank enters the filter and passes through the filter media which removes moisture and contaminants. The filtered fuel is delivered to the engine fuel supply port.

#### 2.4.5. Maintenance

Refer to the Preventive Maintenance Section of this manual for filter draining, removal and installation intervals and procedures.






Fig. 7-4: Fuel Lines & Primary Fuel Filter Installation





- 1. Plug, M14 x 1.5
- 2. O-Ring, 9/16" I.D.
- 3. Adapter, M14 x 1.5 x -6 JIC
- 4. Hose Assembly, GH100-06 FL 52.0
- 5. Hose Assembly, GH100-06 FL 13.0
- 6. Connector, Straight M12 x 1.50 6 JIC

- 7. Clamp, 5/8" Dia. Twin
- 8. Loctite, PST
- 9. Adapter, ext Pipe to 37° Flare
- 10. Washer, Flat 1/4"
- 11. Bolt, Hex 1/4" 20 UNC x 3" Lg.
- 12. Bolt, Hex 3/8" 16 UNC x 1 1/2" Lg.
- 13. Washer, Flat 3/8"

- 14. Clamp, "P" .625" SST/H
- 15. Elbow,  $90^{\circ}$  -6 JIC M14 x 1.5
- 16. Filter Assembly, Primary Fuel
- 17. Hose Assembly, GH100-06 FL 38.0
- 18. Plate, Cover
- 19. Nut, Lock Nylon 1/4" 20 UNC
- 20. Nut, Lock Nylon 3/8" 16 UNC

Fuel Lines & Primary Fuel Filter Installation (parts list)

## 2.4.6. Primary Fuel Filter Troubleshooting

PRIMARY FUEL FILTER TROUBLESHOOTING		
PROBLEM	POSSIBLE CAUSE	
Fuel level is not at the top of the fuel filter.  Normal - Do not change the filter.	Fuel level is at the top of the filter. Low power. Change the filter at the first available opportunity.	
Fuel level is at the top of the filter and appears to be full of wax. Change the filter - Run the engine for a minimum of 25 minutes at idle. Do not run at full RPM.	There is a power complaint and the fuel level is below the collar. Check for a missing grommet at the lower end of the filter or missing/broken spring at top of filter.	
Bubbles are seen flowing in with the fuel. Check all fittings and lines from the fuel tank to the fuel processor. Check lower and upper collar o- rings.	Water is noticed in the cover. Drain the water. If engine coolant is visible, follow proper engine pressure testing procedures to determine root cause.	
Fuel drains back to the fuel tank when changing the fuel filter or draining separator. Remove the check valve assembly. Clean or replace and retest. Check air leaks in the fuel system.	No engine coolant flow to the heater. Check for closed cutoff valves at the coolant lines to the fuel processor. Make sure the heater valve is open.	






Fig. 7-5: Secondary Fuel Filter Installation

7 - 14





- 1. Clamp, Double 1/2" Tube
- 2. Bolt, Hex 1/4" 20 UNC x 2" Lg.
- 3. Bolt, Hex 3/8" 16 UNC x 1" Lg.
- 4. Bracket, Fuel Line Support
- 5. Washer, Flat 1/4"
- 6. Bolt, Hex 1/4" 20 UNC x 3/4" Lg.
- 7. Bracket, Fuel Line Support
- 8. Plate, Cover
- 9. Nut, Lock Nylon 3/8" 16 UNC
- 10. Nut, Lock Nylon 1/4" 20 UNC

- 11. Spacer, Dual Swivel Saddle
- 12. Bracket, Fuel Filter Secondary
- 13. Spacer, Dual Swivel Saddle
- 14. Filter Assembly, Secondary Fuel
- 15. Clamp, "P" 1/2" SST/H
- 16. Clamp, "P" .875" SST/HT
- 17. Clamp, "P" 1.375" SST/H
- 18. Hose Assembly
- 19. Screw, M8 x 16 mm

Secondary Fuel Filter Installation (parts list)

## 2.5. Secondary Fuel Filter

## 2.5.1. Description

The secondary fuel filter is bracketmounted on the curbside of the engine compartment. The filter assembly consists of a filter head and a replaceable spin-on filter element. See "Fig. 7-5: Secondary Fuel Filter Installation" on page 14.

## 2.5.2. Secondary Fuel Filter Specifications

Mounting	Spin-on
Particle Size	4 micron
Liquid Capacity	0.21 gal (0.8 L)
Rated Flow 1	.2 gal/min (4.6 L/min)

## 2.5.3. Operation

The fuel filter is plumbed into the pressure side of the lift pump. Fuel from the tank enters the filter and passes through the filter media which removes contaminants. The filtered fuel is delivered to the engine high pressure fuel pump.

#### 2.5.4. Maintenance

Refer to the Preventive Maintenance Section of this manual for filter draining, removal and installation intervals and procedures.



## 2.6. Fuel Lines & Flexible Hoses

## 2.6.1. Description

The performance of engine and auxiliary equipment is greatly dependent on the ability of flexible hoses to transfer lubricating oil, air, coolant, and fuel oil. Diligent maintenance of hoses is an important stop in ensuring efficient, economical and safe operation of the engine and related equipment.

Investigate leaks immediately to determine if hoses have ruptured or worn through. Take corrective action immediately. Leaks are not only potentially detrimental to machine operation, but they also result in added expense caused by the need to replace lost fluids.



Personal injury and/or property damage may result from fire due to the leakage of flammable fluids such as fuel or lube oil.

A hose has a finite service life. The service life of a hose is determined by the temperature and pressure of the air or fluid within it, its time of service, its mounting, the ambient temperatures, and amount of flexing and vibration it is subjected to.

## 2.6.2. Locating Air Leaks in Fuel Lines

Air drawn into the fuel system may result in uneven running of the engine, black or white smoking and stalling when idling, or a loss of power. Poor engine operation is particularly noticeable at the lower engine speeds. If air is found in the fuel, the source will normally be between the fuel tank and the fuel pump.

Check for loose, faulty, or improper fuel line connectors.



### 2.7. Fuel System Leak Test

The fuel system can be tested for leaks by attaching an Emco Wheaton P/N G2287-001 test kit and a source of shop air to the fuel tank as follows:

- Open the fuel filler access door on the curbside of the vehicle.
- Gain access to the fuel tank fittings on top of the fuel tank by removing the seat and fuel tank access cover in front of the riser on the streetside of the vehicle.
- Plug the level control valve outlet with a 1" NPT plug.
- 4. Attach the regulator adapter to the fuel tank filler. See "Fig. 7-6: Fuel System Leak Test" on page 17.

### ™NOTE:

DO NOT attach the regulator at this time.

- 5. Connect a supply of shop air to the regulator and open the ball valve.
- 6. Set the regulator to 2 psi by pulling out the regulator knob and turning it to decrease the pressure.

- When the gauge reads 2 psi, push in the regulator knob to lock it and disconnect the shop air.
- 8. Connect the regulator to the adapter.

### ™NOTE:

Ensure that the ball valve is closed.

- Rotate the adapter lever to open the poppet on the tank filler.
- 10. Connect a supply of shop air to the regulator and open the ball valve.
- 11.Pressurize the tank and fuel lines. When the pressure has stabilized at 2 psi, close the ball valve and disconnect the shop air.
- 12. After 5 minutes check the gauge for any pressure loss.
- 13.If the gauge shows a pressure loss, repressurize the tank to 2 psi, soap test all fittings and repair all leaks.
- 14.Once all repairs have been completed, open the ball valve and drain the system of air.
- 15. Disconnect all test fittings, remove the level control valve plug and fit the dust cap.
- 16. Install the fuel tank access cover and seat.




Fig. 7-6: Fuel System Leak Test



### 3. DIESEL FUEL

### 3.1. Description

Diesel fuel performs two major functions in a diesel engine:

- ☐ It supplies all of the energy for the engine.
- ☐ It cools and lubricates the fuel pump and injectors.

### ™NOTE:

Refer to the OEM Engine Maintenance Manual for required fuel specifications for this engine.

Wax crystals begin to form in diesel fuels at a certain cold temperature called cloud point. During cold weather operation, the selected fuel should have a cloud point at least 6°C (10°F) below the lowest expected fuel temperature. This will prevent forming of the wax crystals to clog the fuel filters.

Vehicle that operates at temperature below -29°C (-20°F) requires special attention to the cooling system, lubricating system, fuel system, electrical system, and cold weather starting aids for efficient engine starting and operation. Consult an authorized service outlet from your engine manufacturer for recommendation.

Using a lighter distillate fuels may be more practical for any one of the following operating conditions:

- □ Prolonged idling period.
- ☐ Cold weather below 0°C (32°F).
- ☐ Altitudes above 5,000 feet.

### 3.2. Storage

Fuel oil should be clean and free of contamination. Storage tanks and stored fuel should be inspected regularly for dirt, water and sludge; they should be cleaned if contaminated. Diesel fuel tanks can be made of monel, stainless steel, black iron, welded steel or reinforced (non-reactive) plastic.



DO NOT use galvanized steel or sheet metal tanks and galvanized pipes or fittings in any diesel fuel storage, delivery, or fuel system. The fuel oil will react chemically with the zinc coating, forming a compound which can clog filters and cause engine damage.

### 3.2.1. System Fuel Tanks

Keep the fuel tank filled to reduce the condensation to a minimum. Select the proper grade of fuel in accordance with the Fuel Specifications.





### 3.3. Fuel Contaminants

The most common form of diesel fuel contamination is water. Water is harmful to the fuel system in itself, but it also promotes the growth of microbiological organisms (microbes). These microbes clog fuel filters with a "slime" and restrict fuel flow.

Water can be introduced into the fuel supply through poor maintenance (loose or open fuel tank caps), a contaminated fuel supply or condensation.

Condensation is particularly prevalent on units that stand idle for extended periods or time. Ambient temperature changes cause condensation in partially filled fuel tanks.

Units in storage are particularly susceptible to microbe growth. The microbes live in the fuel-water interface. They need both liquids to survive. These microbes find excellent growth conditions in the dark, quiet, non-turbulent nature of the fuel tank.

Microbe growth can be eliminated through the use of commercially available biocides. There are two basic types on the market:

☐ The water soluble type treats only the tank where it is introduced. Microbe growth can start again if fuel is transferred from a treated to an untreated tank.

☐ The diesel fuel soluble type, such a "Biobor" manufactured by U.S. Borax (or equivalent), treats the fuel itself, and therefore, the entire fuel system.

Any units that will sit idle for extended periods, or any units being stored, should be treated as follows: add the biocide according to the manufacturer's instructions. This operation is most effective when performed as the tank is being filled. Add dry gas (isopropyl alcohol) in the correct proportions.

If the fuel tanks were previously filled, add the chemicals and stir with a clean rod.

### 3.3.1. Preventing Algae Contamination

Algae formation is harmful to the fuel system of a diesel engine. Algae grows and thrives on water. It multiplies rapidly and can quickly clog the fuel filters and injector nozzles, stopping fuel flow to the cylinders.

To avoid algae contamination, eliminate the presence of water in the fuel system by:

- Purchasing fuel from reputable dealers where their fuel is fresh.
- ☐ Filling up the fuel tank to prevent moisture condensation, especially if the vehicle is parked for an extended time.





# **Air System**

1.	SAFET	Ύ	8-1
		ety Procedures	
2.	GLOSS	SARY OF ACRONYMS	8-2
3.	AIR SY	/STEM	8-3
	3.1. Des	scription	8-3
		in Air Supply System	
		Compressor & Governor Operation	
	3.2.2.		
	_	ont Brake System	
		Air Supply	
	3.3.2.	· · ·	
		ar Brake System	
	3.4.1.	•	
	3.4.2.	• • •	
	3.4.3.	• •	
	3.4.4.	. •	
		ake Interlock System	
		ergency/Parking Brake System	
	3.6.1.		
	3.6.2.		
	3.6.3.	9	
	3.6.4.		
	3.7. Acc	cessories, Suspension & Leveling System	
	3.7.1.	• •	
	3.	.7.1.1. Leveling Valve Air Flow	
		.7.1.2. Normal Front Suspension Leveling Operation	
	3.	.7.1.3. Normal Rear Suspension Leveling Operation	
	3.7.2.	· · · · · · · · · · · · · · · · · · ·	
	3.7.3.	=:::: = :::: g::::; : ::::::::::::::::::	
	3.7.4.		
		.7.4.1. Retarder Applied	
		.7.4.2. Retarder Deactivated	
		eeling System	
	3.8.1.		
	3.8.2.	Raising Front Suspension	
		System Functional Tests	
	3.9.1.	System Pre-Test	8-13

### Table of Contents



	3.9.2.	Governor Cut-Out & Compressor Test	8-13
	3.9.3.	Reservoir Supply Leakage Test	8-14
	3.9.4.	Delivery Leakage Test	8-14
	3.9.5.	Emergency/Parking Brake & Check Valve Integrity Test	8-14
4.	MAIN A	AIR SUPPLY SYSTEM COMPONENTS	8-16
	4.1. Wa	bco Twin Cylinder Air Compressor	8-17
	4.1.1.		
	4.1.2.	Operation	8-17
	4.1.3.	Air Compressor Troubleshooting	8-18
	4.1.4.	Removal	8-22
	4.1.5.	Installation	8-24
	4.1.6.	Cylinder Head Components	8-25
		.1.6.1. Disassembly	
		.1.6.2. Cleaning & Inspection	
		.1.6.3. Assembly	
		Rear Seal & Adapter	
		.1.7.1. Disassembly	
		.1.7.2. Assembly	
	4.1.8.	1 3	
		.1.8.1. Disassembly	
		Compressor Head Torque Specifications	
		vernor D-2	
	4.2.1.	Description	
	4.2.2.	·	
	4.2.3.	·	
	4.2.4.	Leakage Test	
	4.2.5.	Removal	
	4.2.6.	Adjustment	
	4.2.7.	Installation	
		-3 Pressure Reducing Valve	
	4.3.1.	Description	8-32
	4.3.2.	·	
	4.3.3.	•	
	4.	.3.3.1. Operating Test	
	4.	.3.3.2. Leakage Test	8-33
	4.3.4.	Removal	8-33
	4.3.5.	Installation	8-33
	4.4. Inte	erlock Solenoid Valve	8-34
	4.4.1.	Description	8-34
	4.4.2.	Interlock Solenoid Valve Specifications	
	4.4.3.	Operation	
	4.4.4.	Removal	
	4.4.5.	Installation	8-34
	4.5. Hal	dex Tandem Air Dryer	
	4.5.1.	Description	
	4.5.2.	Operation	
		,	



		5.2.1. Charge Cycle	
		5.2.2. Purge Cycle	
	4.5.3.	Removal	
	4.5.4.	Installation	
	4.5.5.	Desiccant Cartridge Replacement	8-39
	4.5.6.	Check Valve Replacement	8-39
	4.5.7.	Safety Valve Replacement	8-39
	4.5.8.	Valve Pack Replacement	8-40
	4.5.9.	Functional Test	
	4.5.10.	Haldex Tandem Air Dryer Troubleshooting	8-41
		Oil/Water Separator	
		5.11.1.Description	
		5.11.2.Oil/Water Separator Specifications	
		5.11.3.Operation	
		5.11.4.Automatic Drain Valve Operation	
	4.5	5.11.5.Removal	8-43
		5.11.6.Disassembly, Cleaning & Repair	
		5.11.7.Assembly	
		5.11.8.Installation	
		5.11.9.Condenser Operation Test	
		5.11.10.Electrical Connections	
4.6	. Air	Fanks	8-47
	4.6.1.	Description	8-47
	4.6.2.	Operation	8-47
	4.6	S.2.1. Operation of Integral Check Valve	8-47
	4.6.3.	Cleaning & Inspection	8-47
	4.6.4.	Removal	8-48
4.7	. ST-1	Safety Valve	8-49
	4.7.1.	Description	8-49
	4.7.2.	•	
	4.7.3.	Removal	
	4.7.4.	Installation	
	4.7.5.	Disassembly	
	4.7.6.	Cleaning & Inspection	
	4.7.7.	Assembly	
	4.7.8.	Adjustment	
		7.8.1. Raising Pressure Setting	
		7.8.2. Lowering Pressure Setting	
		Operating Test	
		Leakage Test	
Λ Q		_ines & Fittings	
4.0			
		Description	
	4.8.2.	Inspection	
		3.2.1. Air Line Replacement	
	4.8	3.2.2. Thread Sealant	8-52
Pi		SYSTEM COMPONENTS	0 50
5.1	. Des	cription	8-53
5.2	. Sing	le Check Valve	8-55

5.

### Table of Contents



	5.2.1.	Description	8-55
	5.2.2.	Operation	8-55
	5.2.3.	Removal	8-55
	5.2.4.	Installation	8-55
	5.2.5.	Operating & Leakage Test	8-55
5.3	. Dou	ıble Check Valve	8-56
	5.3.1.	Description	8-56
	5.3.2.	Operation	8-56
	5.3.3.	Disassembly	8-56
	5.3.4.	Cleaning & Inspection	8-57
	5.3.5.	Assembly	8-57
	5.3.6.	Operating & Leakage Test	8-57
5.4	. E-6	Brake Valve	8-58
	5.4.1.		
	5.4.2.		
		4.2.1. Applying: Normal Operation - No. 1 Circuit Portion	
		4.2.2. Applying: Normal Operation - No. 2 Circuit Portion	
		4.2.3. Applying: Loss of Air in the No. 2 Circuit	
	5.4	4.2.4. Balanced: No. 1 Circuit Portion	8-60
	5.4	4.2.5. Balanced: No. 2 Circuit Portion	8-60
		4.2.6. Releasing: No. 1 Circuit Portion	
		4.2.7. Releasing: No. 2 Circuit Portion	
	5.4.3.		
	5.4.4.	Disassembly	
	5.4.5.	Cleaning & Inspection	
	5.4.6.	Assembly	
	5.4.7.	Operating Check	8-63
	5.4.8.	Leakage Check	8-64
	5.4.9.	Installation	8-64
5.5	. Bra	ke Valve Actuator	8-65
	5.5.1.	Description	8-65
	5.5.2.	Operation	8-65
	5.5.3.	Removal of BVA from Brake Valve	8-65
	5.5.4.	Installation	8-65
5.6	. R-14	4 Relay Valve	8-66
		Description	
	5.6.2.	Operation	
		6.2.1. Application	
		6.2.2. Balance	
	5.6	6.2.3. Exhaust or Release	8-66
	5.6.3.	Removal	8-67
	5.6.4.	Installation	8-67
	5.6.5.	Operation & Leakage Test	8-67
5.7	. SR-	7 Spring Brake Modulating Valve	
	5.7.1.	Description	
	5.7.2.	Operation	
		7.2.1. Charging Spring Brake Actuators below 107 psi	
		7.2.2. Charging Spring Brake Actuators above 107 psi	
		7.2.3. Normal Service Application	





5.	7.2.4. Parking Brake Application	8-69
5	7.2.5. Service Application with Loss of Primary Circuit	8-69
5	7.2.6. Service Application with Loss of Secondary Circuit	8-69
	7.2.7. Anti-Compounding	8-70
5.7.3.	Maintenance	8-70
5.7.4.	Removal	8-70
5.7.5.	Installation	8-70
5.8. PR-	2 Pressure Protection Valve	8-71
5.8.1.	Description	8-71
5.8.2.	Operation	
5.8.3.	Removal	
5.8.4.	Installation	
5.8.5.	Operating & Leakage Check	
	8.5.1. Operating Check	
	8.5.2. Leakage Check	
	-1 Quick Release Valve	
5.9.1.	Description	
5.9.2.	Operation	
5.9.3.	Removal	
5.9.4.	Installation	
5.9.5.	Disassembly	
5.9.5. 5.9.6.	Cleaning & Inspection	
	9 1	
5.9.7.	Assembly	
5.9.8.	Operating & Leakage Test	8-/ວ
- 40 B	and the second s	
	ssure Switches	8-76
5.10.1	. Front Brake Circuit Pressure Switch	<b> 8-76</b> 8-76
5.10.1 5	Front Brake Circuit Pressure Switch	<b> 8-76</b> 8-76 8-76
5.10.1 5 5	Front Brake Circuit Pressure Switch	<b> 8-76</b> 8-76 8-76
5.10.1 5 5 5	Front Brake Circuit Pressure Switch	8-76 8-76 8-76 8-76
5.10.1 5 5 5 5 5	Front Brake Circuit Pressure Switch  10.1.1.Description  10.1.2.Operation  10.1.3.Removal  10.1.4.Installation	8-76 8-76 8-76 8-76 8-76
5.10.1 5 5 5 5 5.10.2	Front Brake Circuit Pressure Switch  10.1.1.Description  10.1.2.Operation  10.1.3.Removal  10.1.4.Installation  Brake Application Pressure Transducer	8-76 8-76 8-76 8-76 8-76
5.10.1 5 5 5 5 5 5.10.2	Front Brake Circuit Pressure Switch  10.1.1.Description  10.1.2.Operation  10.1.3.Removal  10.1.4.Installation  Brake Application Pressure Transducer  10.2.1.Description	8-768-768-768-768-768-77
5.10.1 5 5 5 5 5.10.2 5	Front Brake Circuit Pressure Switch  10.1.1.Description  10.1.2.Operation  10.1.3.Removal  10.1.4.Installation  Brake Application Pressure Transducer  10.2.1.Description  10.2.2.Brake Application Pressure Transducer Specifications	8-768-768-768-768-768-778-77
5.10.1 5 5 5 5 5.10.2 5 5	Front Brake Circuit Pressure Switch  10.1.1.Description  10.1.2.Operation  10.1.3.Removal  10.1.4.Installation  Brake Application Pressure Transducer  10.2.1.Description  10.2.2.Brake Application Pressure Transducer Specifications  10.2.3.Operation	8-768-768-768-768-768-778-778-77
5.10.1 5 5 5 5 5.10.2 5 5	Front Brake Circuit Pressure Switch  10.1.1.Description  10.1.2.Operation  10.1.3.Removal  10.1.4.Installation  Brake Application Pressure Transducer  10.2.1.Description  10.2.2.Brake Application Pressure Transducer Specifications  10.2.3.Operation  10.2.4.Removal	8-768-768-768-768-778-778-778-77
5.10.1 5 5 5 5 5.10.2 5 5 5	Front Brake Circuit Pressure Switch  10.1.1.Description  10.1.2.Operation  10.1.3.Removal  10.1.4.Installation  Brake Application Pressure Transducer  10.2.1.Description  10.2.2.Brake Application Pressure Transducer Specifications  10.2.3.Operation  10.2.4.Removal  10.2.5.Installation	8-768-768-768-768-778-778-778-778-778-77
5.10.1 5 5 5 5.10.2 5 5 5 5 5.10.3	. Front Brake Circuit Pressure Switch  10.1.1.Description  10.1.2.Operation  10.1.3.Removal  10.1.4.Installation  . Brake Application Pressure Transducer  10.2.1.Description  10.2.2.Brake Application Pressure Transducer Specifications  10.2.3.Operation  10.2.4.Removal  10.2.5.Installation  Parking Brake/Stop Light Switch	8-768-768-768-768-768-778-778-778-778-77
5.10.1 5 5 5 5 5.10.2 5 5 5 5 5.10.3	. Front Brake Circuit Pressure Switch  10.1.1.Description  10.1.2.Operation  10.1.3.Removal  10.1.4.Installation  . Brake Application Pressure Transducer  10.2.1.Description  10.2.2.Brake Application Pressure Transducer Specifications  10.2.3.Operation  10.2.4.Removal  10.2.5.Installation  Parking Brake/Stop Light Switch  10.3.1.Description	8-768-768-768-768-778-778-778-778-778-778-77
5.10.1 5 5 5 5.10.2 5 5 5 5 5.10.3	Front Brake Circuit Pressure Switch  10.1.1.Description  10.1.2.Operation  10.1.3.Removal  10.1.4.Installation  Brake Application Pressure Transducer  10.2.1.Description  10.2.2.Brake Application Pressure Transducer Specifications  10.2.3.Operation  10.2.4.Removal  10.2.5.Installation  Parking Brake/Stop Light Switch  10.3.1.Description  10.3.2.Operation	8-768-768-768-768-778-778-778-778-778-788-78
5.10.1 5 5 5 5.10.2 5 5 5 5 5.10.3 5	Front Brake Circuit Pressure Switch  10.1.1.Description  10.1.2.Operation  10.1.3.Removal  10.1.4.Installation  Brake Application Pressure Transducer  10.2.1.Description  10.2.2.Brake Application Pressure Transducer Specifications  10.2.3.Operation  10.2.4.Removal  10.2.5.Installation  Parking Brake/Stop Light Switch  10.3.1.Description  10.3.2.Operation  10.3.3.Removal	8-768-768-768-768-778-778-778-778-778-788-788-78
5.10.1 5 5 5 5 5.10.2 5 5 5 5 5.10.3 5 5	Front Brake Circuit Pressure Switch  10.1.1.Description  10.1.2.Operation  10.1.3.Removal  10.1.4.Installation  Brake Application Pressure Transducer  10.2.1.Description  10.2.2.Brake Application Pressure Transducer Specifications  10.2.3.Operation  10.2.4.Removal  10.2.5.Installation  Parking Brake/Stop Light Switch  10.3.1.Description  10.3.2.Operation	8-768-768-768-768-768-778-778-778-778-788-788-788-78
5.10.1 5 5 5 5 5.10.2 5 5 5 5 5.10.3 5 5	Front Brake Circuit Pressure Switch  10.1.1.Description  10.1.2.Operation  10.1.3.Removal  10.1.4.Installation  Brake Application Pressure Transducer  10.2.1.Description  10.2.2.Brake Application Pressure Transducer Specifications  10.2.3.Operation  10.2.4.Removal  10.2.5.Installation  Parking Brake/Stop Light Switch  10.3.1.Description  10.3.2.Operation  10.3.3.Removal  10.3.3.Removal	8-76 8-76 8-76 8-76 8-76 8-77 8-77 8-77
5.10.1 5 5 5 5 5.10.2 5 5 5 5.10.3 5 5	Front Brake Circuit Pressure Switch  10.1.1.Description  10.1.2.Operation  10.1.3.Removal  10.1.4.Installation  Brake Application Pressure Transducer  10.2.1.Description  10.2.2.Brake Application Pressure Transducer Specifications  10.2.3.Operation  10.2.4.Removal  10.2.5.Installation  Parking Brake/Stop Light Switch  10.3.1.Description  10.3.2.Operation  10.3.3.Removal  10.3.4.Installation  10.3.5.Leakage Test	8-76 8-76 8-76 8-76 8-76 8-76 8-77 8-77
5.10.1 5 5 5 5.10.2 5 5.10.3 5 5.10.3 5 5.10.4	Front Brake Circuit Pressure Switch  10.1.1.Description  10.1.2.Operation  10.1.3.Removal  10.1.4.Installation  Brake Application Pressure Transducer  10.2.1.Description  10.2.2.Brake Application Pressure Transducer Specifications  10.2.3.Operation  10.2.4.Removal  10.2.5.Installation  Parking Brake/Stop Light Switch  10.3.1.Description  10.3.2.Operation  10.3.3.Removal  10.3.4.Installation  10.3.5.Leakage Test  10.3.6.Operating Test	8-76 8-76 8-76 8-76 8-76 8-76 8-77 8-77
5.10.1 5 5 5 5 5.10.2 5 5 5 5.10.3 5 5 5 5	. Front Brake Circuit Pressure Switch  10.1.1.Description  10.1.2.Operation  10.1.3.Removal  10.1.4.Installation  . Brake Application Pressure Transducer  10.2.1.Description  10.2.2.Brake Application Pressure Transducer Specifications  10.2.3.Operation  10.2.4.Removal  10.2.5.Installation  . Parking Brake/Stop Light Switch  10.3.1.Description  10.3.2.Operation  10.3.3.Removal  10.3.4.Installation  10.3.5.Leakage Test  10.3.6.Operating Test  . Brake Tank Pressure Sending Units	8-76 8-76 8-76 8-76 8-76 8-76 8-77 8-77
5.10.1 5 5 5 5 5.10.2 5 5 5.10.3 5 5 5.10.4 5	. Front Brake Circuit Pressure Switch  10.1.1.Description  10.1.2.Operation  10.1.3.Removal  10.1.4.Installation  . Brake Application Pressure Transducer  10.2.1.Description  10.2.2.Brake Application Pressure Transducer Specifications  10.2.3.Operation  10.2.4.Removal  10.2.5.Installation  . Parking Brake/Stop Light Switch  10.3.1.Description  10.3.2.Operation  10.3.3.Removal  10.3.4.Installation  10.3.5.Leakage Test  10.3.6.Operating Test  . Brake Tank Pressure Sending Units  10.4.1.Description	8-76 8-76 8-76 8-76 8-76 8-76 8-77 8-77
5.10.1 5 5 5 5 5.10.2 5 5 5.10.3 5 5 5 5.10.4 5 5	. Front Brake Circuit Pressure Switch  10.1.1.Description  10.1.2.Operation  10.1.3.Removal  10.1.4.Installation  Brake Application Pressure Transducer  10.2.1.Description  10.2.2.Brake Application Pressure Transducer Specifications  10.2.3.Operation  10.2.4.Removal  10.2.5.Installation  Parking Brake/Stop Light Switch  10.3.1.Description  10.3.2.Operation  10.3.2.Operation  10.3.4.Installation  10.3.5.Leakage Test  10.3.6.Operating Test  Brake Tank Pressure Sending Units  10.4.1.Description  10.4.2.Brake Tank Pressure Sending Units Specifications	8-76 8-76 8-76 8-76 8-76 8-76 8-77 8-77



6.	EMERG	SENCY & PARKING BRAKE SYSTEM COMPONENTS.	8-82
	6.1. Em	ergency Brake Release Valve	8-82
	6.1.1.	Description	
	6.1.2.	Operation	
	6.1.3.	Removal	8-83
	6.1.4.	Installation	8-84
	6.1.5.	Disassembly	8-84
	6.1.6.	Operating & Leakage Test	8-84
	6.2. Par	king Brake Control Valve	8-85
	6.2.1.	Description	8-85
	6.2.2.	Operation	8-85
	6.2.3.	Removal	8-85
	6.2.4.	Installation	8-87
	6.2.5.	Disassembly	8-87
	6.2.6.	Operating & Leakage Test	8-88
		SORIES, SUSPENSION, LEVELING & KNEELING M COMPONENTS	8-89
	7.1. Lev	eling Valves	8-89
	7.1.1.	<u> </u>	
	7.1.2.	Operation	
	7.1.3.	Removal	
	7.	1.3.1. Air Leakage Test - Valve Removed	8-93
	7.1.4.		
	7.	1.4.1. Air Leakage Test - Valve Installed	8-93
	7.2. Kne	eling Valve	8-94
	7.2.1.	Description	8-94
	7.2.2.	Operation	
	7.2.3.	Kneeling Valve Port Designations	
	7.2.4.	Maintenance	
	7.2.5.	Removal	
	7.2.6.	Installation	8-97



### 1. SAFETY

### 1.1. Safety Procedures

Refer to the General Information Section of this manual for information on types of hoists, hoisting procedures, jackstands and related safety information. Refer to this information and read carefully before lifting, hoisting or jacking the vehicle.

When working on or around a vehicle, the following precautions should be observed.

- Park the vehicle on a level surface, apply the parking brakes and always block the wheels.
- ☐ Stop the engine when working around the vehicle.
- If the vehicle is equipped with air brakes, make certain to drain the air pressure from all reservoirs before beginning ANY work on the vehicle.
- Before performing maintenance on components, deactivate the electrical system as follows:
  - Ensure Master Run switch on the side console is positioned to STOP-ENGINE (OFF).
  - Locate Battery Disconnect switch in the rear battery compartment. Set switch to OFF position.
- □ When working in the engine compartment, the engine should be shut off. Where circumstances require that the engine be in operation, EXTREME CAUTION should be used to prevent personal injury resulting from contact with moving, rotating, leaking, heated, or electrically charged components.

- Never connect or disconnect a hose or line containing pressure; it may whip. Never remove a component or plug unless you are certain all system pressure has been depleted.
- ☐ Never exceed recommended pressures and always wear safety glasses.
- Do not attempt to install, remove, disassemble or assemble a component until you have read and thoroughly understand the recommended procedures. Use only the proper tools and observe all precautions pertaining to use of those tools.
- □ Replacement hardware, tubing, hose, fittings and so forth, should be of equivalent size, type, and strength as original equipment and be designed specifically for such application and systems.
- Components with stripped threads or damaged parts should be replaced rather than repaired. Repairs requiring machining or welding should not be attempted unless specifically approved and stated by the vehicle or component manufacturer.
- Prior to returning the vehicle to service, make certain all components and systems are restored to their proper operating condition.

Observe the following procedures involving hydraulic line removal.

- Hydraulic fluid is corrosive and should not be exposed to skin for extensive periods of time.
- Wear eye protection at all times.
- Pressurized lines should not be disconnected until the pressure is safely and controllably released.



2. G	LOSSARY OF ACRONYMS	MV4	Magnetic Valve (NC) - Entrance Door Dump
ABL	Air Bag Left	MV6	Magnetic Valve (NC) - Retarder
ABR	Air Bag Right		Accumulator
ABS	Anti-Lock Braking System	Р	Pressure Port
ACCUM	Accumulator - Transmission Retarder	PC	Park Control Port
В	Balance Port	PP1	Parking Brake Control Valve
BRV	Brake Relay Valve	PPV	Pressure Protection Valve
BVA	Brake Valve Actuator	PS	Pressure Switch
С	Control Port	PS4	Pressure Switch - Parking Brake/Stop Light
CV	Check Valve	PS5	Pressure Switch - Front Brake Circuit
D	Delivery Port	PS6	Pressure Switch - Entrance Door
DCV	Double Check Valve	PS8	Pressure Switch - Interlock Warning
DS	Driver's Seat	PT3	Pressure Transducer - Rear Brake
DV	Drain Valve	1 10	Circuit
Е	Exhaust Port	PTV	Pressure Test Valve
E-6	Brake Application Valve	QR-1	Quick Release Valve
EBR	Emergency Brake Release	R	Reservoir Port
KBL	Kneeling Block	R14	Relay Valve w/Double Check
LV	Leveling Valve	RDV	Rotary Dump Valve
LVL	Leveling Valve Left	RV1	Pressure Reducing Valve
LVR	Leveling Valve Right	RV3	Pressure Reducing Valve
MODV	Modulator Valve (ABS)	S	Supply Port
MV	Magnetic Valve	SERV	Service Port
MV NC	Magnetic Valve - Normally Closed	SR7	Spring Brake Modulating Valve
MV NO	Magnetic Valve - Normally Open	SV	Safety Valve
MV3	Magnetic Valve (NC) - Door Control	TRNSDCR	Transducer - Air Tank
		UNL	Unload Port - Governor



### 3. AIR SYSTEM

### ™NOTE:

For a better overall understanding of the air system have the color schematic available when reviewing this section.

### 3.1. Description

The New Flyer Industries air system is comprised of several interconnected components which supply air pressure for the brake system, suspension system and optional air operated components.

Various types of valves are used to control system pressures in several areas of the vehicle and are connected with other components by means of air lines.

Three types of air lines are used in the construction of the New Flyer Industries vehicle. These being copper, flexible Teflon with a braided stainless steel jacket and color coded nylon tubing.

Air system pressure is monitored on the driver's dash panel by means of front and rear brake circuit air pressure gauges. Integral safety systems, including check valves and spring brake chambers, are incorporated to provide for emergency brake application in the event of a line rupture or air system leak.

### 3.2. Main Air Supply System

(Refer to Main Air Supply System Schematic No.1)

#### 3.2.1. Compressor & Governor Operation

The on board air supply is from an engine driven Air Compressor (1) running at engine speed. The compressor is supplied air through a Tube (2) connected to the engine's air intake system.

The air compressor is controlled by a Governor (3). When air pressure in the Wet Tank (9) is below 117 psi, a signal is sent to the Governor (3) to close the valves and start the compressor. When air pressure reaches 131 psi, the governor is signaled to stop the compressor from pumping air.

Wet tank air pressure can be checked at a Pressure Test Valve (4) at the governor.

Air flows from the Compressor (1) through a teflon hose to the Muffler Tank (5) which acts as a shock absorber and carbon trap. The muffler tank is equipped with a Safety Valve (6) and a Drain Valve (7).

Compressed air passes from the Muffler Tank (5) to the Oil Separator (21) and to the Air Dryer (8) where it is filtered and dried, passes through an internal check valve and then enters the Wet Tank (9). A Drain Valve (10) is provided for draining off accumulated moisture or oil.

When the wet tank reaches 131 psi it signals the compressor to unload. When the compressor is in the unload mode (131 psi air pressure), the Air Dryer (8) is signaled to purge and expel moisture and oil.

The Muffler Tank Safety Valve (6) is set at 200 psi, the Wet Tank Safety Valve (11) is set at 150 psi, and the Air Dryer (8) Safety Valve is set at 175 psi to protect the system against over-pressurization if the compressor doesn't cut out.

### ™NOTE:

The cascading type air system used in this vehicle requires all tanks to reach 131 psi in order for the wet tank to reach 131 psi.

### 3.2.2. Service & Towing Air Supply

The vehicle air system can be charged, during servicing, with compressed air from an outside source by coupling an air hose to the Rear Charging Fitting (15) which is connected through a Check Valve (16) to the Muffler Tank (5).

A Front Charge Fitting (12) and Air Towing Connector (13) are provided for towing purposes. The towing vehicle provides system air pressure through the Charge Fitting (12) and Check Valve (14). The Towing Connector (13) receives the towing vehicle's brake application pressure.



### 3.3. Front Brake System

(Refer to Front Brake System Schematic No. 2)

### 3.3.1. Air Supply

Air from the wet tank feeds the two brake system tanks simultaneously. A 2150 in<sup>3</sup> Front Brake Reservoir Tank (1) provides air pressure for the front axle brakes. The reservoir is protected by a Check Valve (2) which maintains operating pressure if there is a leak in any other area of the system. A Drain Valve (3) is provided for manually draining condensation from the tank.

An Air Pressure Transducer (4) activates an alarm and illuminates the Low Air (red) indicator LED in the gauge until the system pressure is at 75 psi. Front Brake Reservoir pressure is indicated on the dashmounted pressure gauge.

### 3.3.2. Service Brake Application

The front brakes are applied by depressing the brake foot treadle to activate the Brake Foot Valve (5). This causes air to flow from the supply (S2) side of the valve to the delivery (D2) side. Delivery (D2) pressure flows through a Quick Release Valve (7), continues through the ABS Modulator Valves (8) and is applied to the left and right Brake Chambers (9).

The Brake Foot Valve (5) delivery pressure (D2) closes the contacts in the Stop Light Pressure Switch (6) at 4 psi, which illuminates the brake lights.

Delivery pressure (D2) is also supplied to the control (C) port of the Spring Brake Modulating Valve (10).

### RNOTE:

Refer to 3.6. "Emergency/Parking Brake System" on page 8 in this section for information on the Spring Brake Modulating Valve.



### 3.4. Rear Brake System

(Refer to Rear Brake System Schematic No. 3)

### 3.4.1. Air Supply

Air pressure for the rear axle brakes is supplied by a 1200 in<sup>3</sup> Rear Brake Reservoir Tank (1). A Drain Valve (3) is provided for manually draining condensation from the tank.

The Rear Brake Reservoir (1) provides a constant supply of air to the supply (S) port and the (B) port, of the Rear Brake Relay Valve (5) and the supply (S1) port of the Brake Foot Valve (4).

An Air Pressure Transducer (2) activates an alarm and lights the Low Air (red) indicator LED in the gauge until the rear brake system pressure is at 75 psi. Rear Brake Reservoir pressure is indicated on the dash-mounted pressure gauge.

### 3.4.2. Service Brake Application

The rear brakes are applied by depressing the brake foot treadle to activate the Brake Foot Valve (4) causing air to flow through from the supply (S1) to the delivery (D1) side of the valve. A Pressure Transducer (12) monitors brake application pressure and provides a signal to the brake light circuit and transmission retarder system. This pressure transducer also provides a reference signal to the interlock system.

Delivery (D1) pressure flows to the control (C) port of the Rear Brake Relay Valve (5). The delivery (D1) pressure received at the

Brake Relay Valve (5), directs air flow from the supply (S) side to the delivery (D) side of the valve.

### RNOTE:

A 5.5 psi differential is built into the Brake Relay Valve. As an example, a 10 psi signal equates to 4.5 psi delivery pressure.

The air then flows through the ABS Modulator Valves (9) to the service side of the Rear Axle Brake Chambers (10), applying the brakes. A Pressure Switch (11) is located in each brake line, downstream of the Modulator Valves (9).

### 3.4.3. Spring Brake Release

Delivery (D) side air from the Brake Relay Valve is also supplied to the balance (B) port of the Spring Brake Modulating Valve (7) to direct system pressure to the emergency side of the Rear Brake Chambers (10). This system ensures the brakes are not "compounded", that is, both spring brake and service brakes applied at the same time. A Pressure Transducer (8) monitors air pressure applied to the emergency side of the rear brake chambers.

#### MOTE:

Spring brakes apply when no air pressure is in the spring brake chamber.

### ™NOTE:

Refer to 3.6. "Emergency/Parking Brake System" on page 8 in this section for detailed information on the Spring Brake Modulating Valve.



## 3.4.4. Anti-Lock Braking System (ABS) Operation

ABS control is provided on the front and rear axle brake systems. Operation is typical for both axles. During normal brake application the Modulator Valves (9) are inactive and do not affect the brake application.

If the ECU detects an ABS event (impending wheel lock-up) it will energize the solenoids in the Modulator Valves (9) to control the brake application pressure to the Service Brake Chambers (10).

To decrease brake application pressure, the ECU will energize the inlet and outlet solenoids of the Modulator Valve (9) which will close the supply port and open the delivery and exhaust ports. To hold brake application pressure at a given value, the ECU will energize the inlet solenoid and de-energize the outlet solenoid of the Modulator Valve (9), which will close the supply and exhaust ports.

This modulation of brake application pressure will continue until the impending wheel lock-up condition is alleviated.





### 3.5. Brake Interlock System

(Refer to Brake Interlock System Schematic No. 4)

### ™NOTE:

Brake interlock application is functional only if the parking brake is released. Both front and rear brakes are applied during interlock operation.

The Double Check Valve (1) receives air supply from the front or rear brake tanks and delivers to the Pressure Reducing Valve (2) through the normally open (non-applied) Parking Brake Control Valve (16) and Emergency Brake Release Valve (17).

This air supply from the Parking Brake Control Valve is also supplied as a parking brake control signal (PC) to the Spring Brake Modulating Valve (12). A Pressure Switch (3) is located in the parking brake control line and provides a signal to extinguish the Park Brake indicator on the instrument panel when the parking brakes are released.

The Pressure Reducing Valve (2) reduces system pressure to 70 psi and directs to the Brake Valve Actuator (BVA) Solenoid (4). A Pressure Test Valve (5) is located in the supply line to the BVA solenoid and is used to check regulated pressure setting.

The BVA Solenoid (4) is energized open whenever interlock application is required, such as exit door or wheelchair ramp operation. Air flows from the supply (S) to the delivery (D) side of the BVA Solenoid (4) and to the Brake Valve Actuator (7). A Pressure Switch (6) monitors delivery pressure to the Brake Valve Actuator.

The Brake Valve Actuator (7) functions to apply the Brake Foot Valve (8), independent of driver input, and deliver air through the (D1) and (D2) ports.

### ™NOTE:

The Brake Valve Actuator (7) acts on the Brake Foot Valve (8) the same as what would occur during normal service brake application.

Delivery (D1) pressure is directed to the rear brake chambers (11) via the Rear Brake Relay Valve (9) and Modulator Valves (10).

Delivery (D2) pressure from the brake foot valve is directed to the front brake chambers (15) via the Quick Release Valve (13) and Modulator Valves (14).

Once the event that initiated brake interlock application is no longer active, the brake interlocks can be released by applying additional (greater than interlock) pressure on the brake treadle, and then releasing.



# 3.6. Emergency/Parking Brake System

(Refer to Emergency/Parking Brake System Schematic No. 5)

The rear axle is equipped with spring loaded brakes. For both parking and emergency brake operation, the brake chambers apply a predetermined spring force on the brakes.

### 3.6.1. Spring Loaded Brakes

The internal spring in the Rear Brake Chamber (10) will push the rod out if no air pressure is applied. Applying air pressure to the emergency port forces an internal piston to compress the spring and release the brakes.

Applying air to the service side with emergency brakes released applies the brakes in a normal manner.

The Spring Brake Modulating Valve (9) provides anti-compounding protection to the rear axle brakes. This anti-compounding protection prevents both the spring (emergency) brakes and service (normal) brakes from being applied at the same time.

### 3.6.2. Parking Brakes

The parking brakes are applied by pulling UP on the Parking Brake Control Valve Plunger (4) located on the driver's side console. This closes the supply (S) port on the Parking Brake Control Valve (4) and

connects the delivery (D) port to exhaust (E). Air is exhausted from the park control line that signals the Spring Brake Modulating Valve (9).

Loss of air pressure at the Spring Brake Modulating Valve (9) park brake control port opens the delivery ports to exhaust. This action exhausts air from the emergency side of the Brake Chambers (10) allowing the brake chamber springs to extend and apply the parking brakes. The Parking Brake Control Valve (4) is in the APPLY position if there is no air in the system. Above 40 psi the Parking Brake Control Valve (4) can be pushed DOWN to the RELEASE position.

In the RELEASE position, (valve plunger DOWN) air flows to the exhaust (E) port of the Emergency Brake Release Valve (8), out through the delivery (D) port and is applied to the park control (PC) port of the Spring Brake Modulating Valve (9). This activates the Pressure Switch (11), extinguishing the parking brake indicator on the dash.

The Front Brake Air Tank (1) supplies air through a Check Valve (12) to the supply (S) port of the Spring Brake Modulating Valve (9). The park control signal to the Spring Brake Modulating Valve (9) allows air from the supply (S) port to flow through the delivery (D) ports to the emergency side of the Spring Brake Chambers (10). This compresses the internal spring and releases the parking brakes.

### **Emergency/Parking Brake System**

### 3.6.3. Emergency Brake Release

Air is supplied from the Front Brake Tank (1) and the Rear Brake Tank (2) to either side of the Double Check Valve (3) and through a tee connection which directs air to the Parking Brake Control Valve (4) and Emergency Release Tank (5). The Emergency Release Tank (5) is protected by a Check Valve (6) and can be drained of moisture through a Drain Valve (7). If total system air pressure is lost, the Emergency Release Tank (5) retains pressure for emergency brake release.

The Emergency Brake Release (EBR) valve (8) is used to release the spring brakes after they have been automatically applied during an emergency (loss of air supply). Pushing and holding down the button on the EBR valve (8) will allow air pressure from the Emergency Release Tank (5) to flow through the supply (S) and delivery (D) ports of the EBR valve (8) and to the park control (PC) port of the Spring Brake Modulating Valve (9). Air flows from the delivery (D) port of the Spring Brake Modulator Valve (9), to the emergency side of the Rear Brake Chambers (10).

### ™NOTE:

The spring brakes are held in the released position only as long as the EBR button is depressed.

## 3.6.4. Emergency Brake Application & Modulation

A sudden loss of air pressure from the Parking Brake Control Valve (4) will result in immediate application of the Emergency Brakes (10) without modulated control.

A loss of air pressure from the Rear Brake Tank (2) will disable the rear service brakes. To maintain rear brake function in this situation, the Spring Brake Modulating Valve (9) will release a modulated amount of air from the Emergency Spring Brake Chambers (10) when the brake valve treadle is applied.

### ™NOTE:

The amount of air released from the Emergency Spring Brake Chambers (10) will be proportional to brake treadle application.

Lack of air pressure at the balance (B) port of the Spring Brake Modulating Valve (9) will allow the pressure sensed at the control (C) port to control the rate at which air is exhausted through the exhaust port. This action will result in controlled application of the rear spring brakes in relation to brake treadle movement.



# 3.7. Accessories, Suspension & Leveling System

(Refer to Accessories, Suspension & Leveling System Schematic No. 6)

Air from the Front Brake Reservoir Tank (1) supplies the Accessories Tank (3) through a Pressure Protection Valve (2). This valve allows pressure to build in the front brake tank to 90 psi before opening and allowing the Accessories Tank (3) to come to full pressure. If the accessory tank fails or all accessory air is lost, the valve closes at 80 psi ensuring pressure is retained in the braking system.

Check Valves (8 & 15) maintain air pressure in the front and rear suspension and leveling systems in the event of loss of air from the Accessories Tank (3).

The Accessories Tank (3) is fitted with a Manual Drain Valve (6). Air feeds through an in-line Air Strainer (9), to the Driver's Seat (DS), and through Rotary Dump Valve (10) to the entrance door.

### 3.7.1. Suspension & Leveling Valves

### 3.7.1.1. Leveling Valve Air Flow

Leveling Valves (11 & 12) are mounted on the frame on each side of the rear axle suspension. A Single Leveling Valve (13), is mounted on the frame at the left-hand side of the front suspension. A link connects the leveling valves to the suspension. This system keeps the vehicle and suspension at the desired ride height regardless of load.

The valve arm moves up and applied air passes through the valve to the Air Springs (17) when the suspension is compressed. The valves release air when the suspension extends. A 7° (3.5° UP & 3.5° DOWN) neutral zone on each valve allows normal suspension travel during operation without continually correcting the air pressure.

If the Front Air Springs (14) are compressed (deflated), air will flow from the pressure (P) port to the (C1) port in the Leveling Valve (13). If the Air Springs (14) are extended (inflated), air will flow from the C1 port to the exhaust (E) port in the Leveling Valve (13).

## 3.7.1.2. Normal Front Suspension Leveling Operation

Air from the Accessories Tank (3) flows through Check Valve (15) and is applied to the pressure (P) port of the Leveling Valve (13).

If the vehicle is below ride height, the Leveling Valve (13) will direct air from its pressure (P) port through the delivery (C1) port and a tee fitting where air will enter the LVL and LVR ports of the Kneeling Block (16). Air then exits the Kneeling Block through ports ABL and ABR where it is routed to the Air Springs (14).

The Air Springs (14) will continue to fill until vehicle ride height is reached. At that point the Leveling Valve (13) will close the connection between the pressure (P) port and delivery (C1) port and vehicle ride height will be maintained.

If the vehicle should exceed the specified ride height, the Leveling Valve (13) will close the pressure (P) port and direct the delivery (C1) port to the exhaust (E) port. This will reduce air volume in the Air Springs (14) and lower vehicle suspension until the specified ride height is reached.

The Leveling Valve (13) will maintain the required suspension ride height by either admitting air through the pressure (P) port or by exhausting air through the exhaust (E) port.

### **Accessories, Suspension & Leveling System**

## 3.7.1.3. Normal Rear Suspension Leveling Operation

Air from the Accessories Tank (3) flows through a Check Valve (8) to the pressure (P) port of the rear LH and RH Leveling Valves (11 & 12). The Leveling Valves distribute air through ports (C1 & C2) to the fore and aft Air Springs (17).

At normal ride height, the Leveling Valves (11 & 12) ports are closed. If the suspension exceeds the LEVEL position, the Leveling Valves (11 & 12) exhaust air through the exhaust (E) port, reducing volume in the Air Springs (17) until the proper suspension level is reached. The Leveling Valves (11 & 12) will maintain the required suspension ride height by either admitting air through the pressure (P) port or exhausting air through the exhaust (E) port as necessary.

## 3.7.2. Entrance Door Emergency Release Operation

Air from the Accessories Tank (3) is routed through the Strainer (9) and the Rotary Dump Valve (10) to the Mag Valve (23). The air is then directed to the baseplate-mounted Rotary Dump Valve (22) to maintain constant air pressure on the Door Emergency Release Cylinder (21). This pressure is monitored and signalled back to the multiplexing system via a Pressure Sensor (20). Rotating either Rotary Dump Valve (10 or 22) will exhaust air from the emergency release cylinder which will disengage the door operator's clutch. The door can then be operated manually.

## 3.7.3. Exit Door Emergency Release Operation

Air from the Accessories Tank (3) is supplied to the baseplate-mounted Rotary Dump Valve (4) to maintain constant pressure to the Release Cylinder (7). This pressure is monitored and signalled back to the multiplexing system via a Pressure Sensor (5). Rotating an exit door Rotary Dump Valve (4) will exhaust air form the Emergency Release Cylinder (7) which will disengage the door operator's clutch. The door can then be operated manually.

### 3.7.4. Retarder Operation

### 3.7.4.1. Retarder Applied

The retarder is activated in three stages as follows:

- ☐ Release the accelerator first stage (25% applied)
- ☐ 1 psi brake application second stage (66% applied)
- 4 psi brake application third stage (100% applied)

These three stages of activation energize the Retarder Control Mag Valve (19) pressure (P) and (A) ports and apply retarder braking to the Transmission (18).

The Pressure Reducing Valve (14) reduces system pressure to 100 psi before it is applied to the Retarder Control Mag Valve (19).

### 3.7.4.2. Retarder Deactivated

When the brake treadle is lifted, the Retarder Control Mag Valve (19) deenergizes. This isolates the transmission accumulator from the air supply and deactivates transmission retarder braking.



### 3.8. Kneeling System

(Refer to Kneeling System Schematic No. 7)

### 3.8.1. Front Kneeling Operation

Air for the Kneeling System is supplied by the Kneeling Tank (3). The Kneeling Tank receives air from the integral Accessories Tank (1). An internal Check Valve (2) allows air to flow from the Accessories Tank to the Kneeling Tank in one direction only. Air from the Kneeling Tank (3) is directed to the pressure (P) port of the Kneeling Block (4). An inline Check Valve (5) is located at the pressure (P) port of the Kneeling Block (4). The Kneeling Tank (3) can be drained through the Drain Valve (7).

During normal operation the Leveling Valve (8) controls air volume in the front air springs to maintain suspension ride height. Setting the Kneel switch, located on the instrument panel, to the LOWER position closes the (LVL) and (LVR) ports. The KNEEL solenoid on the Kneeling Block (4) energizes and opens the (ABL) and (ABR) ports directing air from the Air Springs (6), through the exhaust port to atmosphere. This action lowers (kneels) the vehicle front suspension. When the vehicle suspension reaches the bottom of the kneeling cycle, the KNEEL solenoid on the Kneeling Block (4) de-energizes and maintains the vehicle front suspension in the lowered kneeling position.

The ride height position of the leveling valve, prior to kneeling, is recorded by the Multiplexing System and is used to restore the vehicle to ride height during the RAISE cycle.

### 3.8.2. Raising Front Suspension

The Kneeling Block (4) provides fast fill operation for air springs in the RAISE mode. The valve is controlled by input from the Multiplexing System, which records the ride height position prior to kneeling, and continues to fill the suspension until the same position is sensed during the RAISE cycle.

### ™NOTE:

A position sensor on the leveling valve provides a ride height signal to the Multiplexing System just prior to kneeling. This information is used for controlling the final RAISE and LOWER position of the vehicle during the KNEELING cycle.

Setting the Kneel switch to the RAISE position energizes the RAISE solenoid on the Kneeling Block (4). This raises the vehicle front suspension by routing air from the Kneeling Tank (3) through the Check Valve (5) to the pressure (P) port of the Kneeling Block (4). Air is now directed from the Kneeling Block pressure (P) port through the (ABL) and (ABR) ports to the Front Air Springs (6). As the Air Springs (6) reach the proper inflation level, the Kneeling Block (4) RAISE solenoid is de-energized. This opens the Kneeling Block (4) leveling valve (LVL) and (LVR) ports to the air spring (ABL) and (ABR) ports. The Leveling Valve (8) will now maintain normal front suspension ride height.

### **Air System Functional Tests**

### 3.9. Air System Functional Tests

### ™NOTE:

These are static tests only.

### 3.9.1. System Pre-Test

- Place blocks behind and in front of the wheels to prevent the vehicle from rolling.
- 2. Examine all air lines for dents or kinks.
- 3. Examine all rubber hoses for deterioration, drying out and overheating.
- Examine hose supports for security of attachment.
- Examine exterior of metal components for corrosion, mechanical damage and security of attachment.
- 6. Examine brake chambers for damage and security of attachment.

### 3.9.2. Governor Cut-Out & Compressor Test

- 1. Ensure air system is fully charged.
- 2. Reduce air system pressure to below 40 psi through multiple applications of the brake treadle.
- Start the engine and run the vehicle at fast idle. Confirm that the ABS indicator on the instrument panel remains illuminated for 4 seconds after vehicle start-up and then extinguishes.

#### ™NOTE:

The Low Air indicator on the instrument panel and the air system warning buzzer will be active until system air pressure reaches approximately 75 psi, at which point they should switch off. Before proceeding with remainder of tests, make repairs if Low Air indicator or warning buzzer do not function as described.

4. When the air pressure gauge reaches 40 psi, start a stopwatch and time how long it takes to reach the governor cut-out pressure. Confirm the following:

- a. The air system builds up to operating pressure within 5 minutes.
- The governor cuts out at system operating pressure (governor cut-out rating).
- Make several brake applications to drop system pressure below the governor cut-in pressure rating. Confirm the governor cuts in and the compressor begins to pump air into the system.
- Adjust or replace governor as required. Refer to 4.2. "Governor D-2" on page 29 in this section for procedures.
- If air system build-up time exceeds the specified rate:
  - a. Check compressor air inlet for restrictions.
  - b. Check compressor discharge port and line for carbon. Clean or replace as required.
  - c. With governor in unloaded mode, listen at compressor inlet for air leakage. If leakage is heard, apply a small amount of oil around unloader pistons. If no leakage is indicated, leakage is through compressor discharge valves.
  - d. Check for damaged or kinked Teflon discharge hoses.
  - e. Check for excessive air leakage throughout the system.
  - f. Check for faulty discharge check valves in air dryers.
  - g. Check for faulty shop-fill single check valve.
  - h. Check for faulty safety valve.
  - Check for plugged or saturated dryer desiccant.
  - j. Check for worn out compressor.
- 8. Repeat test after repairs are made to confirm correct operation.



### 3.9.3. Reservoir Supply Leakage Test

- 1. Start the engine and charge the air system. Stop the engine.
- Allow system air pressure to stabilize for one minute.
- Observe instrument panel air gauges for two minutes. A 2 psi drop within 2 minutes is acceptable.
- If leakage exceeds the allowable limit, check the following using a leak tester or test solution:
  - a. Supply lines and fittings (tighten as required).
  - b. Spring brake modulating valve.
  - c. Brake foot valve.
  - d. Parking brake control valve.
  - e. Emergency brake release valve.
  - f. Spring brake actuators.
  - g. Wet tank safety valve.
  - h. Governor.
  - i. Compressor discharge valves.
- 5. Repair as required. Repeat test to confirm repairs before proceeding.

### 3.9.4. Delivery Leakage Test

- 1. Start the engine and charge the air system. Stop the engine.
- Make and hold a 90 to 100 psi brake application.
- Allow pressure to stabilize for 1 minute. Begin timing for 2 minutes and observe instrument panel air gauge. A 2 psi pressure drop within 2 minutes is acceptable.
- 4. If leakage exceeds allowable limit, check the following using a leak test solution:
  - a. Service lines and fittings (tighten as required).
  - b. Stop light switches.
  - c. Brake chamber diaphragms.
  - d. ABS modulator valves.
  - e. Brake relay valve.
  - f. Spring brake modulating valve.

- g. Check valves.
- h. ATC valve (if equipped).
- Repair as required. Repeat test to confirm repairs before proceeding with remaining tests.

## 3.9.5. Emergency/Parking Brake & Check Valve Integrity Test

### ™NOTE:

The following procedure will test the operation of the parking brake system, emergency brake system, and emergency brake release system (where equipped). This procedure will simulate vehicle operation in emergency mode with loss of air supply at one or more tanks. Perform these tests in the sequence listed in order to avoid duplicate or redundant testing.

- Park the vehicle on level ground and chock the wheels.
- Start the engine and charge the air system to cut-out pressure
- 3. Stop the engine.
- 4. Ensure the wheels of the vehicle are chocked and release the park brake.
- 5. Drain the wet tank. The front and rear brake tanks should retain full pressure.
- Drain the front axle brake tank. The low air warning lamp on the front brake tank gauge should illuminate and the low air buzzer should sound. The rear brake tank should retain full pressure.
- With no air pressure in the front brake tank, make a service brake application. The rear axle brakes should apply and the rear brake lamps should illuminate.
- Slowly drain the rear axle brake tank. The parking brake control valve should pop to the applied position when the rear reservoir reaches approximately 45 psi.

### MOTE:

DO NOT use the brake treadle to bleed down the rear axle brake tank. Rapid pumping of the brake treadle will cause pressure pulsations that can result in premature application of the spring brakes, resulting in a false pressure reading.

### **Air System Functional Tests**

### ™NOTE:

Ensure that the interlocks are NOT applied when bleeding down the system.

### ™NOTE:

The following step applies to vehicles equipped with an Emergency Brake Release (EBR) valve. Otherwise, proceed to step 10.

- 9. Actuate the Emergency Brake Release control by pressing and holding the knob in the down position. The park brakes at the rear axle should release and remain released as long as the control is held in the down position. Release the control. The park brakes at the rear axle should reapply. Repeat this cycle until the park brakes fail to release. Drain the emergency brake release tank. The park brakes should remain in the applied position.
- Close all tank drain valves, start the engine, and recharge the air system to cutout pressure.
- 11.Stop the engine and release the park brake.
- 12. Drain the rear axle brake tank. The low air warning lamp on the rear brake tank gauge should illuminate and the low air buzzer should sound. The front brake tank should retain full pressure

- 13. With no air pressure in the rear brake tank, make a service brake application. The front and rear axle brakes should apply and release at least once, the rear brake lamps should illuminate, and the parking brake should remain released.
- 14. Test is complete. Close all reservoir drain valves, start the engine, and recharge the air system to cut-out pressure.
- 15.If the brakes do not operate as described in the test procedure, check the following for leakage and correct as required:
  - a. Fittings.
  - b. Kinked lines.
  - c. Single check valves.
  - d. Double check valves.
  - e. Parking brake control valve.
  - f. Emergency release valve (if equipped).
  - g. Brake relay valve.
  - h. Spring brake modulating valve.
  - i. Brake foot valve.
  - j. ABS modulator valves.
  - k. ATC valve (if equipped).



# 4. MAIN AIR SUPPLY SYSTEM COMPONENTS



When working on or around air brake systems and components, the following precautions should be observed:

- □ ALWAYS block vehicle wheels. Stop engine when working under a vehicle. Make certain to drain air pressure from all reservoirs before beginning any work on the vehicle. Depleting vehicle air system pressure may cause vehicle to roll. Keep hands away from chamber push rods; they may apply as system pressure drops.
- NEVER connect or disconnect a hose or line containing air pressure. It may whip as air escapes. NEVER remove a component or pipe plug unless you are certain all system pressure has been depleted.
- □ NEVER exceed recommended air pressure and ALWAYS wear safety glasses when working with air pressure. NEVER look into air jets or direct them at anyone
- □ NEVER attempt to disassemble a component until you have read and understand recommended procedures. Some components contain powerful springs and injury can result if not properly disassembled. Use only proper tools and observe all precautions pertaining to use of those tools.

- ☐ Use only approved replacement parts and components.
  - Only components, devices, mounting and attaching hardware specifically designed for use in air brake systems should be used.
  - Replacement hardware, tubing, hose, fittings and so forth, should be of equivalent size, type, length, and strength as the original equipment.
  - Make certain that when replacing tubing or hose, all supports, clamps or suspending devices that were originally installed are reinstalled or replaced if they are missing.
- Devices with stripped threads or damaged parts should be replaced. Repairs requiring machining should not be attempted.



Using alcohol in the air brake system as a means to dry the air or prevent system freezing during cold weather is not acceptable. Studies indicate that alcohol removes the lubrication from the system components, causing faulty system function. Also, the materials used for the seals in these components are not alcohol-safe and will deteriorate at an accelerated rate leaving the brake system prone to failure. Using alcohol or alcohol-based fluids in your air brake system will void the warranty on these components.



### **Wabco Twin Cylinder Air Compressor**

# 4.1. Wabco Twin Cylinder Air Compressor



Refer to "WARNING" and "CAUTION" at the beginning of "Main Air Supply System Components" when performing maintenance on these components.

### 4.1.1. Description

The compressor is mounted to the engine gear case cover and driven by a splined coupling on the engine accessory driveshaft. Engine oil pressure is supplied to the compressor and oil drains back into the engine crankcase from the compressor flange opening. Hoses attached to the cylinder head circulate coolant from the engine to cool the compressor.

### 4.1.2. Operation

The compressor runs continually while the engine is running. Compression of air is controlled by the governor. It sends a signal to unload the compressor when the maximum pre-set pressure (131 psi) is attained or to resume pumping when the system pressure falls to the cut in point (117 psi).



### 4.1.3. Air Compressor Troubleshooting

AIR COMPRESSOR TROUBLESHOOTING			
CONDITION	POSSIBLE CAUSE	SOLUTION	
Compressor passes excessive oil (for example, the presence of oil at exhaust air brake system valve, oil in air dryer desiccant, and so forth)	Blocked or restricted oil return	Clean oil drain passages in the compressor and on the engine surface. Verify proper passage alignment.	
	Contaminated inlet air or oil	Replace damaged, defective or dirty engine air filter. Repair any leaking, damaged or defective compressor air intake components. Change engine lubricating oil.  NOTE:  To avoid this condition, make sure oil and filter maintenance schedules are followed. Refer to the Preventive Maintenance Section of this manual for procedure.	
	Restricted air inlet or excessive vacuum present at compressor inlet	Verify engine or compressor air cleaner is functioning properly. Replace if necessary. Repair compressor air inlet kinks or excessive bends.	
	Excessive engine crankcase pressure	Verify engine crankcase venting is to manufacturer's specification.	
	Compressor duty cycle too high	Check system for leaks. Make necessary repairs.	
	None of the above, but condition persists	Replace the compressor.	
Compressor leaks oil	Physical damage or internal problems with compressor	Replace the compressor.	
Compressor continuously cycles	Compressor unloader piston leaking	With compressor unloaded check for air leakage. If leaking, replace the cylinder head.	
	Governor air leak	Refer to 4.2. "Governor D-2" on page 29 in this section for governor maintenance and troubleshooting procedures.	

AIR COMPRESSOR TROUBLESHOOTING			
CONDITION	POSSIBLE CAUSE	SOLUTION	
	Dryer purge valve air leakage	Check for air dryer malfunction. Refer to 4.2. "Governor D-2" on page 29 in this section for procedure.	
	Air leak at governor-compressor attachment	Inspect connection for physical damage. Inspect and repair connection.	
	Excessive reservoir contamination	Drain reservoirs.	
	None of the above, but conditions persists	Replace the compressor.	
No air delivery Low air delivery Low air pressure	Discharge line blockage	Check for freeze-up in the discharge line. Check low spots and eliminate any traps in the discharge line. Inspect and repair compressor discharge port and clear any line restrictions. Replace damaged lines as necessary. Check for carbon build-up. If carbon has built up, make sure cooling lines are not kinked or restricted. If carbon has built up in the discharge line, replace the line.	
	Inlet line kinked or restricted	Inspect the compressor air induction line for kinks and restrictions. Repair or replace as necessary.	
	Governor malfunction or misadjustment	Check for proper loader/ unloader cycles of compressor. Refer to 4.2. "Governor D-2" on page 29 in this section for governor maintenance and troubleshooting procedures.	
	External contamination	Replace broken, defective or dirty air filter. Clean contaminants from surface of compressor.	
	Air dryer purge valve stuck open or leaking	Check for air dryer malfunction. Refer to 4.5. "Haldex Tandem Air Dryer" on page 35 in this section for procedure.	
	Chafed or worn discharge line	Replace faulty sections of discharge line.	



AIR COMPRESSOR TROUBLESHOOTING			
CONDITION	POSSIBLE CAUSE	SOLUTION	
	Loose or leaking air line connections	Verify all connections are secure. Tighten connections where necessary. Inspect port threads for damage. If damage is extensive, replace cylinder head.	
	Damage to compressor valves and/or valve seats	Replace the cylinder head.	
	Leaking or malfunctioning internal pressure relief valve	Replace the cylinder head.	
Noisy air compressor	Loose drive hub Loose accessory drive coupling	Check fit of drive coupling. Ensure hub is completely seated and crankshaft nut is tight. Inspect crankshaft for damage. Replace compressor if crankshaft is damaged.	
	None of the above, but condition persists	Replace the compressor.	
Broken connecting rod or crankshaft	Oil starvation to crank pin or front main bearing	Check oil pressure. Verify oil passage is free of obstructions. Make necessary repairs.	
	Failed fan drive and power steering pumps	Verify fan drive and power steering pumps are in proper operating order. Refer to Section 6 of this manual for procedure.	
Compressor leaks engine coolant	Loose fitting	Check fittings at compressor and engine for leaks and verify fittings are properly torqued.	
	Cracked coolant port	Replace cylinder head.	
	Porosity in cylinder head	Replace cylinder head.	
	Leaking of gasket internal to the cylinder head	Verify cylinder head bolts are properly torqued. Make necessary adjustments. Inspect gasket for cracks or signs of water. Replace if necessary. Replace cylinder head.	
	None of the above, but condition persists	Replace the compressor.	

## **Wabco Twin Cylinder Air Compressor**

AIR COMPRESSOR TROUBLESHOOTING			
CONDITION	POSSIBLE CAUSE	SOLUTION	
Compressor pressurizes coolant system or coolant leakage to compressor inlet	Leaking of gasket internal to the cylinder head	Inspect gasket. Replace if necessary.	
compressor micr	Cavitation or corrosion in cylinder head	Replace the cylinder head.	
	Porosity in cylinder head or cylinder head cracked	Replace the cylinder head.	
	None of the above, but condition persists	Replace the compressor.	
Unloader leakage	Possible internal damage, including worn or damaged unloader piston O-ring, porosity in unloader piston bore, loose or leaking seal at unloader piston bore	Replace the compressor cylinder head assembly.	
Compressor head gasket failure	Discharge line blocked due to freezing or carbon build-up	Check for trap (low spots) in lines. Make necessary repairs. Clear discharge line. Replace line if necessary. Check for carbon build-up. If carbon build-up is present, replace the discharge line.	
	Frozen or blocked line to governor	Clear blocked line. Replace line if necessary. Check for air dryer malfunction. Repair or replace as required. Refer to 4.5. "Haldex Tandem Air Dryer" on page 35 in this section for procedure.	
	Governor malfunction	Repair or replace the governor. Refer to 4.2. "Governor D-2" on page 29 in this section for procedure.	
	Improper cylinder head bolt torque, machining defect on cylinder head or block, defective cylinder head gasket	Inspect gasket. Replace if necessary. Verify all bolts are properly torqued. If problem persists, replace the cylinder head.	
	None of the above, but condition persists	Replace the compressor cylinder head assembly.	



#### 4.1.4. Removal

- Set the Battery Disconnect switch to the OFF position.
- Drain the wet tank and muffler tank. Refer to the General Information Section of this manual for drain valve locations.
- Close the coolant supply and return shutoff valves.

### ™NOTE:

The coolant supply shutoff valve is located in the booster pump delivery line. The coolant return shutoff valve is located in the radiator return line.

- 4. Raise the vehicle to a suitable working height. Refer to the General Information Section of this manual for lifting procedure.
- 5. Remove the power steering pump from the end of the compressor. It is not necessary to disconnect the hydraulic lines.

### ™NOTE:

Fabricate a blanking plate to match the compressor mounting flange. Use the blanking plate with existing gasket to seal any oil from leaking out of the compressor when removing the unit from the vehicle.

- Disconnect the compressor oil hose at the engine block location. See "Fig. 8-1: Compressor Removal & Installation" on page 23.
- 7. Disconnect the governor air hose from the compressor.
- 8. Loosen the hose clamp and disconnect the air supply line from the compressor.

- Disconnect the delivery hose from the compressor and loosen the 45° ORB fitting.
- Use a thin offset wrench to disconnect the coolant inlet line adjacent to the air delivery port.
- 11. Disconnect the coolant return line from the quick disconnect fitting by compressing the tabs on the connector while pulling upward.



The air compressor is heavy. Use suitable lifting equipment or the assistance of another person to support the weight of the air compressor.

- 12. Remove the two lock nuts that attach the compressor to the engine.
- 13. Support the compressor and remove the two bolts that attach the mounting spacer to the engine block.

### NOTE:

It is not necessary to remove the mounting bracket from the compressor at this time. The oil supply line will also remain attached to the compressor during removal from the vehicle.

- 14. Carefully slide the compressor off the mounting studs and remove from the vehicle.
- 15. Place the compressor on a work bench and remove the oil hose, mounting bracket, and fittings.






Fig. 8-1: Compressor Removal & Installation



#### 4.1.5. Installation

 Transfer and install the fittings, oil hose, and mounting bracket to the replacement air compressor. Clean all mounting surfaces.



The air compressor is heavy. Use suitable lifting equipment or the assistance of another person to install the air compressor.

 Install a new gasket on the compressor mounting flange and carefully slide the compressor over the two engine mounting studs. Secure compressor to engine using two lock nuts.

### ™NOTE:

Twin cylinder air compressors do not require the piston position to be timed to the engine.

3. Align the spacer block with the threaded holes on the engine block and install two bolts. Tighten all mounting fasteners.

- Install the coolant supply and return lines on the compressor.
- Connect the air delivery hose to the 45° elbow fitting. Tighten the nut on the ORB elbow fitting, then tighten the delivery hose fitting.
- Connect the air supply hose to the compressor and tighten the hose clamp.
- Connect the governor air hose to the compressor.
- 8. Connect the oil hose to the engine block.
- Use a new gasket and install the power steering pump on the compressor. Refer to Section 3 of this manual for installation procedure.
- 10. Open the coolant supply and return shutoff valves.
- 11.Lower the vehicle and top up the engine coolant at the surge tank as required.
- 12. Set the Battery Disconnect to the ON position, start the engine, operate at fast idle, and allow the air system to fully charge.
- 13. Check for any air, coolant, or oil leaks.



### 4.1.6. Cylinder Head Components

### 4.1.6.1. Disassembly

- Remove the six M8 head bolts and the three M6 Torx screws holding the head to the compressor. Discard the bolts and screws. See "Fig. 8-2: Air Compressor Assembly" on page 25.
- Remove the head gasket, both intake reed valves and both sliding leaf unloader valves. Discard these parts.
- Carefully separate the upper head/cover and lower manifold assembly. Be careful not to nick or otherwise damage any of the machined surfaces of these parts. Retain the thin aluminum cooling plate and discard the two gaskets.
- 4. Remove the two M5 screws holding each exhaust valve and remove both exhaust valves. Discard these parts.




Fig. 8-2: Air Compressor Assembly

Copyright © 2015 New Flyer Industries Canada ULC



### 4.1.6.2. Cleaning & Inspection

- Carefully remove any remaining gasket material and deposits from machined surfaces.
- Do not soak the head assembly in cleaning solvent as it may damage the unloader Orings. The two unloader plungers in the manifold and the pressure relief valve in the head cannot be serviced. Use caution when cleaning to avoid getting debris in this area.

### 4.1.6.3. Assembly

- Place the manifold on a clean bench and install the two exhaust valves. Torque the M5 screws to 45 ± 4.5 in-lb. (5 ± 0.5 Nm) and then tighten an additional 90° +15°/-5° clockwise rotation.
- 2. Install a new gasket on the manifold, the cooling plate, then the other new gasket.
- Install the head cover onto the assembled manifold and cooling plate assembly. Install and hand-tighten three M6 Torx screws to hold the assembly together. Do not final tighten at this time.
- 4. Turn the head assembly over and place the two unloader valves over their guide pins. Place the two intake valves over their guide pins, ensuring the pads are facing up and the valves will lie flat against the head openings.

### ™NOTE:

Use a small amount of Unisikon GL301 grease under the valves to ensure they remain in place for the remainder of the assembly process.

- Install a new head gasket, ensuring the unloader hole in the gasket aligns with the unloader passageway in the cylinder head. Also ensure the gasket fits over the two guide bushings in the manifold.
- Support the crankcase in an appropriate fixture and install the head assembly onto the crankcase, ensuring the guide bushings enter the counterbores in the crankcase.
- Install six new head bolts, then tighten the six head bolts and three screws to the specified torque and sequence listed in the torque chart. Refer to 4.1.9. "Compressor Head Torque Specifications" on page 28 in this section for torque values. See "Fig. 8-3: Compressor Head Assembly Torque Pattern" on page 27.



It is critical that the torque and rotational tightening procedure be followed exactly as described in order to obtain a successful service life from the unit. Use a calibrated torque wrench and make accurate measurements during the rotational tightening process.






Fig. 8-3: Compressor Head Assembly Torque Pattern

## 4.1.7. Rear Seal & Adapter

## 4.1.7.1. Disassembly

- Remove the fan drive and power steering pumps from the compressor. Refer to Section 6 of this manual for removal procedure.
- Remove the two M6 flat head screws that attach the pump adapter to the compressor housing.
- 3. Remove and discard the pump adapter.
- 4. Remove and discard the O-ring seal.

## 4.1.7.2. Assembly

- Lubricate the new O-ring with engine oil and insert into the fillet pocket formed by the corner of the bearing and the wall of the crankcase.
- 2. Install the adapter into the rear opening of the compressor, ensuring the screw holes in the adapter align with the threaded holes in the compressor.
- Secure the adapter in place using two M6 flat head screws. Torque screws to 60 in-lb. (6 Nm).

4. Install the fan drive and power steering pumps. Refer to Section 6 of this manual for installation procedure.

## 4.1.8. Sump Plug & Seal

#### 4.1.8.1. Disassembly

- 1. Remove the two socket head screws from each of the two sump plugs.
- Carefully pry out the sump plugs from the compressor sump.
- 3. Remove and discard the O-ring.

## 4.1.8.2. Assembly

- Inspect the sump plug bore for nicks or burrs and wipe clean.
- 2. Lubricate the O-rings with engine oil and install onto the sump plugs.
- Press the sump plugs into the bore, ensuring the screw holes in the sump plug align with the threaded holes in the compressor sump.
- Apply medium strength liquid thread lock to the screw threads and install socket head screws. Torque screws to 90 ± 9 inlb. (10 ± 1 Nm).



## 4.1.9. Compressor Head Torque Specifications

COMPRESSOR HEAD TORQUE SPECIFICATIONS				
STEP	BOLT	TORQUE (Nm)	TORQUE (ft-lb.)	ROTATION (Degrees)
1	А	15 (±1.5)	11 (±1)	
2	В	15 (±1.5)	11 (±1)	
3	С	15 (±1.5)	11 (±1)	
4	D	15 (±1.5)	11 (±1)	
5	Е	15 (±1.5)	11 (±1)	
6	F	15 (±1.5)	11 (±1)	
7	А	25 (±2)	18.5 (±1.5)	
8	В	25 (±2)	18.5 (±1.5)	
9	С	25 (±2)	18.5 (±1.5)	
10	D	25 (±2)	18.5 (±1.5)	
11	Е	25 (±2)	18.5 (±1.5)	
12	F	25 (±2)	18.5 (±1.5)	
13	А			270 (±10°)
14	В			180 (±10°)
15	С			180 (±10°)
16	D			180 (±10°)
17	Е			270 (±10°)
18	F			180 (±10°)
19	G	6 (±.6)	4.5 (±.5)	
20	Н	6 (±.6)	4.5 (±.5)	
21	I	6 (±.6)	4.5 (±.5)	
22	G			90° (+15/-5°)
23	Н			90° (+15/-5°)
24	I			90° (+15/-5°)



## 4.2. Governor D-2



Refer to "WARNING" and "CAUTION" at the beginning of "Main Air Supply System Components" when performing maintenance on these components.

## 4.2.1. Description

The governor, operating in conjunction with the compressor unloading mechanism, automatically controls the air pressure in the air brake or air supply system between the desired, predetermined maximum and minimum pressures. The compressor runs continually while the engine runs, but the actual compression of air is controlled by the governor actuating the compressor unloading mechanism which stops or starts compressor when the maximum or minimum reservoir pressures are reached. The D-2 governor has a piston upon which air pressure acts to overcome the pressure setting spring and control the inlet and exhaust valve to either admit or exhaust air to or from the compressor unloading mechanism.

The governor is remotely-mounted to the hydraulic reservoir bracket.

Porting consists of 3 reservoir ports (1/8" PT, 3 unloader ports (1/8" PT) and 1 exhaust port (1/8" PT). See "Fig. 8-4: Governor Exterior Ports" on page 29.




Fig. 8-4: Governor Exterior Ports



## 4.2.2. Operation

Reservoir air pressure enters the governor reservoir port. This pressure moves the piston and the inlet and exhaust valve against the pressure setting spring. As reservoir pressure reaches the cut-out setting of the governor (131 psi), the exhaust stem seats on the inlet and exhaust valve to close the exhaust passage and open the inlet passage. Reservoir pressure then flows around the inlet valve, through a passage in the piston, and out the unloader port. Air also flows around the piston, which is enlarged at one end.

When reservoir pressure drops to the cutin setting of the governor (117 psi), the pressure setting spring overcomes the force exerted on the piston. The inlet valve then closes and the exhaust opens. The air in the unloader line then escapes back through the piston, through the exhaust stem, and out the exhaust port.

## 4.2.3. Operating Test

- Start the vehicle engine and build up air pressure in the air brake system and check the pressure registered by a dash or test gauge at the time the governor cuts out, stopping the compression of air by the compressor.
- With the engine still running, make a series of brake applications to reduce the air pressure and observe the pressure at which the governor cuts-in the compressor.
- Never condemn or adjust the governor pressure settings unless they are checked with an accurate test gauge or a dash gauge that is registering accurately. Refer to 4.2.6. "Adjustment" on page 31 in this section for procedure.

## ™NOTE:

The range between the cut-in and cut-out pressure is not adjustable. Standard cut-in pressure for this vehicle is 117 psi. Standard cut-out pressure is 131 psi.

## 4.2.4. Leakage Test

Leakage tests on the D-2 Governor should be performed in both cut-in and cut-out position.

□ Leakage Test: Cut-In Position

Apply soap solution around cover and on exhaust port. Slight bubble leakage permitted. Excessive leakage indicates a faulty inlet valve or lower piston O-ring.

☐ Leakage Test: Cut-Out Position

Apply soap solution around cover and on exhaust port. Slight bubble leakage permitted. Excessive leakage indicates a faulty exhaust valve seat, exhaust stem, O-ring, or upper piston O-ring.

If the governor does not function as described or leakage is excessive, it is recommended that it be replaced with a new or remanufactured unit, or repaired with approved parts.

#### 4.2.5. Removal



During component removal and installation, ensure the Battery Disconnect switch is in the OFF position.

- Block and hold vehicle by means other than air brakes.
- 2. Drain air brake system.
- Disconnect reservoir air line.
- 4. Remove governor mounting bolts, then governor.



## 4.2.6. Adjustment

- Mount governor on suitable test rack or on vehicle.
- 2. To adjust the D-2 Governor build up reservoir pressure and note at what pressure the governor cuts out. If the cut-out pressure is below the desired pressure, remove the cover, loosen the adjusting screw nut and with a screw driver turn the adjusting screw counter-clockwise until the governor cuts out at the desired pressure. If the cut-out pressure is higher than desired the adjusting screw should be turned clockwise to lower the pressure. After setting the cut-out pressure it is important that the adjusting nut be tightened. See "Fig. 8-5: Governor Adjustment" on page 31.

## ™NOTE:

The range between the cut-in and cut-out pressure is not adjustable. Standard cut-in pressure for this vehicle is 117 psi. Standard cut-out pressure is 131 psi.



DO NOT overadjust. Each 1/4 turn of the screw alters the pressure setting by 4 psi.




Fig. 8-5: Governor Adjustment

#### 4.2.7. Installation



During component removal or installation, ensure the Battery Disconnect switch is in the OFF position.

- Inspect governor body prior to installation to ensure plugs are installed in the ports that are not being used. Also ensure that ports being used are clean and open.
- 2. Use two bolts and washers to attach governor assembly to mounting plate.
- Inspect air lines for cleanliness prior to installing on governor. Install air lines, as marked during removal, to applicable ports on governor body.
- Test governor operation. Refer to 4.2.3. "Operating Test" on page 30 in this section for test procedure.



## 4.3. RV-3 Pressure Reducing Valve



Refer to "WARNING" and "CAUTION" at the beginning of "Main Air Supply System Components" when performing maintenance on these components.

## 4.3.1. Description

The pressure reducing valve is a normally open pressure control device that reduces system air pressure and maintains a constant, specified, pre-set pressure on its output. The pressure reducing valve is not adjustable and is set at 70 psi  $\pm$  5 psi. See "Fig. 8-6: Pressure Reducing Valve Cross Section" on page 32.

The pressure reducing valve is mounted between the wet tank and the front brakes tank as a component of the brake interlock system.




Fig. 8-6: Pressure Reducing Valve Cross Section



## 4.3.2. Operation

With no air pressure present at the supply port, the inlet valve is unseated and open while the exhaust passage through the center of the piston is sealed by the exhaust valve. Compressed air entering the supply port flows out the delivery port. Air simultaneously flows between the piston stem and valve body to the underside of the piston.

When air pressure on the piston overcomes spring force, the piston moves and the valve spring forces the inlet valve on its seat, closing off the supply of air. The exhaust remains closed.

If air pressure in the delivery line drops, spring force on the piston overcomes air pressure. Subsequent piston movement will unseat the inlet valve allowing additional air pressure into the delivery line.

When air pressure in the delivery line exceeds the pressure setting of the valve, the force exerted by the air pressure will be greater than the spring force. The piston will move away from the exhaust valve, permitting air to flow past the exhaust valve, through the hollow piston stem and out the exhaust port. The inlet valve remains seated.

## 4.3.3. Operating & Leakage Test

## ™NOTE:

Test gauges in the supply and delivery lines are required for both of the following tests and should be removed upon completion.

#### 4.3.3.1. Operating Test

Connect accurate test gauges in the supply and delivery lines of the pressure reducing valve, and ensure that supply air pressure is at 131 psi. Delivery pressure should be 70 psi  $\pm$  5 psi. The valve must be replaced if reading is outside this value.

## 4.3.3.2. Leakage Test

Ensure supply air pressure is at 131 psi. Apply a soap solution to the supply port and exhaust port. Leakage should not exceed a 1" diameter bubble in 5 seconds. If leakage exceeds this rate, the valve must be replaced.

#### 4.3.4. Removal

#### ™NOTE:

Operating and leakage tests must be performed after replacing the pressure reducing valve.

- Set the Battery Disconnect switch to the OFF position
- 2. Drain pressure from the vehicle air system.
- Obtain access to the pressure reducing valve.

## ™NOTE:

The pressure reducing valve and solenoid valve must be removed as an assembly

- 4. Disconnect the inlet and outlet air lines from the regulator and solenoid valve.
- 5. Remove the mounting bolts which secure the pressure reducing valve and solenoid valve assembly to the panel.
- 6. Remove the pressure reducing valve and solenoid valve assembly from the vehicle.

#### 4.3.5. Installation

- 1. Secure the pressure reducing valve and solenoid valve assembly to the panel.
- Attach inlet and outlet air lines to the pressure reducing valve and solenoid valve assembly.
- 3. Perform operating and leakage tests.



## 4.4. Interlock Solenoid Valve



Refer to "WARNING" and "CAUTION" at the beginning of "Main Air Supply System Components" when performing maintenance on these components.

## 4.4.1. Description

The Solenoid Valve is mounted on the brake/kneeling valve panel and has threaded fittings with wrench surfaces and a sealed electrical connector. It is constructed with a steel body, brass manifold and viton seats.

## 4.4.2. Interlock Solenoid Valve Specifications

Operating Voltage
..... 12 volt nominal (9-16 volts operating)

Current Draw
...... less than 0.5 amps at 70°F

Rated Pressure...... 150 psi max.

Allowed Leakage
..... no more than 20 SCCW

Fitting Installation Torque
...... 300 in-lbs max.

Weight...... 220 grams (8.0 oz)

## 4.4.3. Operation

The solenoid valve is activated by an electrical signal from the multiplexing system and delivers regulated air pressure from the pressure reducing valve to the Brake Valve Actuator installed at the top of the E-6 brake valve. The Brake Valve Actuator receives the regulated air pressure and

applies the service brakes. Deactivating the solenoid valve removes regulated pressure from the brake valve actuator, releasing the interlocks.

## 4.4.4. Removal

- 1. Set the Battery Disconnect switch to the OFF position.
- Drain the air system to remove pressure in the lines.
- 3. Obtain access to the solenoid valve.

## ™NOTE:

The solenoid valve and pressure reducing valve must be removed as an assembly.

- Tag and disconnect the air lines from the solenoid valve and regulator assembly. Mark lines for later reassembly.
- Disconnect the electrical connector to the solenoid valve.
- 6. Remove the mounting bolts which secure the solenoid valve and pressure reducing valve assembly to the panel.
- Remove the solenoid valve and pressure reducing valve from the vehicle.

#### 4.4.5. Installation

- 1. Install solenoid valve and pressure reducing valve assembly to the panel.
- 2. Connect the airlines to the assembly.
- 3. Connect electrical connector to solenoid valve.
- Set the battery disconnect switch to the ON position.
- 5. Perform operating and leakage tests.



## 4.5. Haldex Tandem Air Dryer



Refer to "WARNING" and "CAUTION" at the beginning of "Main Air Supply System Components" when performing maintenance on these components.

## 4.5.1. Description

The tandem air dryer collects and removes air system contaminants in solid, liquid, and vapor form before they enter the brake system. It provides clean, dry air to the components of the brake system. This increases the life of the system and reduces maintenance costs. Each air dryer consists of a replaceable type desiccant cartridge which mates to a multi port base. These ports include an inlet port which is connected to the muffler tank, a signal port which is connected to the governor unloader port, an exhaust port which vents to atmosphere, a purge volume port which connects to the purge tank, and an outlet port which is connected to the wet tank. The unit also includes an unloader valve, a thermostatically controlled heater, a turbo protection safety valve, and a valve pack.

The Tandem Air dryer consists to two air driers mounted on a bracket and plumbed to operate in parallel and a consep oil/water separator.

## 4.5.2. Operation

The operation of the air dryer is separated into two cycles

- □ Charge Cycle
- □ Purge Cycle

## 4.5.2.1. Charge Cycle

During the charge cycle of the compressor, moist hot compressor air enters the inlet port of the air dryer. Moisture, oil and contamination in the air collect in the sump area. The air is then channeled into the passage between the canister and the interior container wall. The air then passes upwards through a particle filter and into

the desiccant assembly where it is filtered and further stripped of moisture. This cooled, dry air then passes down through the textile filter at the base of the cartridge, then through the air dryer's outlet port to the wet tank and to the purge tank. The air dryer will remain in this charge cycle until the air system pressure builds up to the governor cut-out setting.

## 4.5.2.2. Purge Cycle

When the system is fully pressurized, the compressor unloads and the governor sends a signal to the air dryer's unloader valve. When this valve opens the dry air in the purge tank flows back through the desiccant cartridge and purges it of moisture and contaminants. The purge cycle continues until the purge tank pressure is depleted.

#### 4.5.3. Removal

## ™NOTE:

The following procedure describes removal of the entire tandem air dryer assembly from the vehicle. Access is provided to the individual air dryer mounting hardware so the air dryer's can be removed independently while leaving the other air dryer and bracket mounted in the vehicle.

- 1. Switch Battery Disconnect switch to OFF.
- Raise the vehicle. Refer to the General Information Section in this manual for procedure.
- Disconnect and tag the Air inlet, outlet, purge and unload air lines at the tandem air dryer assembly.
- Disconnect and tag the electrical connectors.
- 5. Remove the mounting fasteners and support the air dryer assembly. See "Fig. 8-7: Air Dryer Installation" on page 36.
- Remove the air dryer assembly and bracket from the vehicle. If necessary remove the threaded fittings from the air dryer noting location for reinstallation. See "Fig. 8-8: Air Dryer Assembly" on page 38.






Fig. 8-7: Air Dryer Installation



## **Haldex Tandem Air Dryer**

- 1. Screw, PH Cross Recess SST 1/4" 20 UNC x 1" Lg.
- 2. Clamp, "P" 1" SST/HT
- 3. Connector, Anchor 3/4"
- 4. Connector, 16 JIC 1 FPT Blkhd.
- 5. Connector, Straight 1" MPT x 1" Tube
- 6. Tube Assembly, Air Dryer
- 7. Tube Assembly, Air Dryer
- 8. Washer, Flat SST 1/4"
- 9. Connector, 3/4" PT x 1" O.D.
- 10. Union, 1" O.D. x 1" O.D.
- 11. Loctite, PST

- 12. Nut, Hex Machine Screw 1/4" 20 UNC
- 13. Clamp, "P" SST 1 1/4" x .2 Mtg.
- 14. Bolt, Hex 5/16" 18 UNC x 1" Lg.
- 15. Bolt, Hex 1/2" 13 UNC x 1 1/2" Lg.
- 16. Washer, Flat #10
- 17. Washer, Flat 5/16"
- 18. Washer, Flat 7/16"
- 19. Washer, Flat 1/2"
- 20. Screw, PH Cross Recess SST #10 24 UNC x 3/4" Lg.
- 21. Nut, Lock Nylon #10 24 UNC
- 22. Nut, Lock Nylon 5/16" 18 UNC

- 23. Nut, Lock Nylon 7/16" 14 UNC
- 24. Nut, Lock Nylon 1/2" 13 UNC
- 25. Purge Tank Assembly
- 26. Bracket, Air Dryer Hose Support
- 27. Air Dryer Assembly, Haldex Tandem
- 28. Tube, Nylon 3/8" Green
- 29. Elbow, 90° 3/4" NTA x 3/4" MPT
- 30. Tube, Nylon 3/4" Green
- 31. Loctite, 243 Blue

## Air Dryer Installation (parts list)

#### 4.5.4. Installation

- 1. Place the mounting bracket on the threaded studs on the vehicle structure.
- 2. Install the nuts and washers to secure the bracket in place.
- 3. Connect the electrical connectors.

- Connect the air inlet, outlet, purge and unload lines.
- 5. Lower the vehicle.
- 6. Switch Battery Disconnect switch to ON. Start the vehicle, test the air dryer and test for leaks.






Fig. 8-8: Air Dryer Assembly





- 1. Air Dryer Assembly, Tandem (Incl. 2-32)
- 2. Bolt
- 3. O-Ring
- 4. Pin, Locking
- 5. Desiccant Cartridge
- 6. Pin, Locking
- 7. Nut
- 8. Heater Assembly
- 9. Valve Assembly, Turbo Protection
- 10. Valve Assembly, No Governor
- 11. Check Valve Assembly
- 12. Plug, Outlet Check Valve
- 13. Washer, M12 Sealing
- 14. Washer, M22 Sealing
- 15. Automatic Drain Valve, Oil/Water Separator
- 16. Housing, Aluminum

- 17. Elbow, 90° 1/4" 14 NPTF x 3/4" Tube
- 18. Elbow, 90° 3/4" 14 NPTF x 3/4" Tube
- 19. Tube, Nylon 3/4" Dia.
- 20. Canister, Cartridge
- 21. Bracket, Air Dryer
- 22. Bracket, Oil/Water Separator
- 23. Manifold, Purge Port
- 24. Manifold, Outlet Port
- 25. Manifold, Inlet Port
- 26. Manifold, Valve Assembly
- 27. Bolt, M22 Banjo
- 28. Bolt, M12 Banjo
- 29. Bracket, Oil/Water Separator
- 30. O-Ring
- 31. Insert, Cyclone
- 32. O-Ring

## Air Dryer Assembly (parts list)

## 4.5.5. Desiccant Cartridge Replacement

- 1. Set Battery Disconnect to OFF position.
- 2. Drain vehicle air tanks.
- 3. Raise vehicle to working height. Refer to the General Information Section of this manual for lifting procedures.
- 4. Use compressed air or a vacuum to clean any debris or grit from the immediate area.
- 5. Remove four bolts retaining canister to dryer housing. Discard the bolts.
- 6. Remove the plastic retaining clips holding the nuts in the air dryer base. Discard the clips and remove and discard the nuts.
- 7. Remove canister.
- Place canister in inverted position on a rubber pad. Push down and rotate the cartridge counter-clockwise to disengage the cartridge from the dimples on the canister. Discard the cartridge.
- Clean the interior of the canister using a clean lint free cloth.
- 10. Ensure wave spring is installed on end of cartridge. Put new cartridge with attached spring into the canister. Ensure the spring on the cartridge contacts the canister surface.
- 11. Align the dimples on the canister with the "OPEN" directional arrows on the cartridge.

- 12. Push down on the cartridge and rotate approximately 1/4 turn clockwise to lock cartridge in place.
- Remove the old O-rings from the dryer housing. Clean the O-ring seat.
- 14. Lubricate new O-rings and place on housing. Do not install O-rings on cartridge.
- 15.Install canister on housing using new bolts and nuts. Torque nuts 33  $\pm$  2 ft-lb. (45  $\pm$  2 Nm) lubricated.
- 16.Recharge the air system and check for leaks.

#### 4.5.6. Check Valve Replacement

Repair kits are available for the check (discharge) valve.

- Unscrew check valve plug and remove check valve.
- Clean check valve seat. Check for correct placement of O-rings in plug.
- Replace check valve. Torque to 20 ft-lb. (27 Nm).

#### 4.5.7. Safety Valve Replacement

When mounting new check valve apply locktite or equivalent and tighten. Valve is factory set to open at 155 psi.

## **Haldex Tandem Air Dryer**



## 4.5.8. Valve Pack Replacement

Repair of valve pack is not possible. Replace if faulty as follows:

- 1. Loosen 6 mounting bolts using a 6 mm hex key and remove the valve.
- 2. Clean the valve pack mounting surface.
- Install new valve. Torque mounting bolts to 5 ft-lb. (6 Nm), starting with two middle bolts.

## 4.5.9. Functional Test

- Start vehicle and allow system air pressure to build up.
- Check connections for leaks using soap solution.
- Allow system pressure to build up to governor cut out.
- When cut-out is reached, air will exhaust from air dryer exhaust port. When cut-in is reached, exhaust will stop. Time from cut-out to cut-in should be a minimum of 20 seconds.



## 4.5.10. Haldex Tandem Air Dryer Troubleshooting

HALDEX TANDEM AIR DRYER TROUBLESHOOTING				
PROBLEM	CAUSE	REPAIR		
Water in air system	Contaminants in desiccant	Change desiccant cartridge. Check compressor for excessive oil passage.		
	Leaks in air system	Tighten air connections, soap connection and check for leaks.		
Constant exhaust of air at dryer and not	Defective dryer outlet check valve	Clean valve seat and replace.		
Blow-Thru Type	Dryer unloading valve not closing	At compressor cut-out there must be a slight bow of regenerated air from the purge tank for approximately 30 seconds. If air flow continues, replace valve pack.		
Excessive compressor cycling	Excessive leaks in air system	Tighten air connections, soap connection and recheck for leaks.		
	Defective dryer outlet check valve	Clean valve seat and replace check valve.		
Safety valve is open	Desiccant cartridge is plugged	Excessive oil passage from compressor. Check for worn compressor. Replace desiccant cartridge.		
	Ice block in dryer	Check heater function.		
	Excessive system pressure	Repair or replace governor.		
Short life of dryer or desiccant cartridge	Air at inlet of dryer exceeds (170°F)	Extend length of compressor discharge line. The 170°F dryer inlet temperature can usually be accomplished with 12' to 15' of compressor discharge line.		
	Duty cycle of compressor does not allow for sufficient time for desiccant regeneration	During normal operation the compressor must remain unloaded for a minimum of 30 seconds to allow for sufficient purge.		
Poor drying efficiency	Air at inlet of dryer exceeds 170°F	Extend length of compressor discharge line. The 170°F dryer inlet temperature can usually be accomplished with 12' to 15' of compressor discharge line.		



## 4.5.11. Oil/Water Separator



Refer to "WARNING" and "CAUTION" at the beginning of "Main Air Supply System Components" when performing maintenance on these components.

## 4.5.11.1.Description

The Haldex consep oil/water separator condenses, separates, and expels the majority of the oil, liquid and other contaminates from the air system. It is mounted to the air dryer. The unit is composed of a condenser tower which is mounted to an automatic drain valve. The drain valve incorporates a heater and a solenoid activated shuttle which causes accumulated oil, water and contaminates to be expelled with each braking application.

## 4.5.11.2.Oil/Water Separator Specifications

Weight	3.97 lbs. (1.8 kg)
Drain Capacity	1.3 cc water
per operation at reservoir pressure	

Rate Voltage & Power Consumption	12V/1A
Air Consumptionper operation	50 cc free air
Ambient Temperature (-40 to 99°C)	40 to 210°F
Inlet Air Temperature (Maximus) (80°C)	mum)176°F

## 4.5.11.3.Operation

- Warm compressed air from the air compressor containing liquid, oil, and contaminates enters the Consep unit at the side port.
- 2. The air spirals downward rotating around the aluminum housing interior baffles.
- Liquid and oil condense and separate as the warm air cools and are deposited into the reservoir.
- 4. The cleansed air enters the interior cylinder, flows upward, and exits through the top port to the air dryer.
- Accumulated water and contaminates are ejected through the automatic drain valve at each braking application.



## 4.5.11.4. Automatic Drain Valve Operation

- Air pressure forces the drain valve shuttle down against the lower seat in the drain valve housing when the ignition is off and the solenoid coil is not powered.
- Switching on the ignition causes the solenoid coil to generate a magnetic field, pulling the shuttle up against the drain valve housing top seat.
- Applying the brakes interrupts current flow to the solenoid coil, causing the shuttle to move down against the drain valve housing lower seat.
- Oil and water accumulated in the condenser tower reservoir flows into the space surrounding the Shuttle.
- Releasing the brakes energizes the solenoid coil, pulling the Shuttle up against the drain valve housing upper seat. The oil and water now automatically drain from around the shuttle out the drain port.
- The condenser can be drained manually by pushing the red manual drain button on the bottom of the drain valve housing. Manually drain only when the ignition is switched off.



DO NOT manually drain the condenser when the ignition is switched on. Switch off the ignition and power down the vehicle by turning the Master Run switch to the OFF position.

#### 4.5.11.5.Removal

## ™NOTE:

Make sure that all supports, clamps or attaching parts originally installed are reinstalled in exactly the same location and in the same way. Replace any parts that are damaged or missing.

- Loosen and remove the side and top 1/2" -14 NPTF air line fittings from the finned aluminum separator tower. See "Fig. 8-9: Oil/Water Separator" on page 44.
- 2. Plug the air line fittings to prevent any dirt or dust from entering the lines.
- Loosen and remove the threaded electrical connection cap from the automatic drain valve housing threaded connector.
- Unplug the power lead crimp connectors from the plugs in the connector housing. If necessary, tag the connector leads for correct hook-up.
- Loosen and remove the nuts fastening the separator H-bracket to the frame mounting brackets.
- 6. Slide the mounting bar bracket from between the separator tower fins.
- 7. Carefully remove the separator from the frame mounting bracket and place on a clean workbench for inspection.






Fig. 8-9: Oil/Water Separator





## 4.5.11.6.Disassembly, Cleaning & Repair

- The automatic drain valve housing can be unthreaded from the separator tower reservoir housing.
- Disassemble the automatic drain valve housing from the base by loosening and removing the bolts, washers and lock nuts holding the assembly together.

## ™NOTE:

The base houses the solenoid coil, shuttle and seat. These parts drop out as a unit.

- Visually inspect all parts for excessive wear or damage. Clean all of the parts carefully, giving special attention to the upper and lower valve seats and shuttle.
- Replace worn or damaged parts using the drain valve repair kit. The kit includes: Automatic Drain Valve, O-Rings and Shuttle
- 5. The separator condenser tower can be disassembled from the reservoir base by loosening and removing the bolts, washers and lock nuts holding the units together.

 After disassembling the separator condenser tower and reservoir base, visually inspect and thoroughly clean condenser tower baffles and reservoir base interior. A separator repair kit is also available.

## 4.5.11.7.Assembly

After thoroughly cleaning the components and installing replacement kits as required, assemble the automatic drain valve, reservoir and separator condenser tower following the reverse order of disassembly.

- Assemble the separator condenser tower and the reservoir base. Install and tighten the bolts, washers and lock nuts to hold the units together.
- Assemble the automatic drain valve housing to the base containing the solenoid coil, shuttle and seat. Install and tighten the bolts, washers and lock nuts to fasten the assembly together.
- Thread the automatic drain valve housing into the separator tower reservoir housing. Hand tighten snugly.



#### 4.5.11.8.Installation

- Align the separator and its H-bracket bolts with the holes in the air dryer mounting bracket.
- Install and hand tighten the four nuts. Make sure that the H-bracket and the air dryer mounting bracket squarely align between the separator tower fins.



DO NOT over torque the bolts. If the bolts are overtorqued, the separator tower could crack or distort and the mounting bar and frame mounting brackets could bend or twist. As a result, the Haldex Concep Condenser/ Separator could be damaged.

- After determining that the brackets, separator tower and hardware align properly, torque the bolts to 15 ft-lb. (20 Nm). Be very careful when torquing the bolts. The separator tower is cast aluminum and can crack or distort easily if the bolts are overtightened.
- Remove plugs or tape from the air line fittings used to prevent any dirt or dust from entering the lines.
- 5. Connect the side and top 3/4" air line fittings to the 3/4" O.D. x 1/2" PT 90° elbows on top and side of the finned aluminum separator tower. The air line connected to the 90° elbow on the side of the separator tower runs from the muffler tank. The air line (green) connected to the top 90° elbow runs to the air dryer.
- Plug the power lead crimp connectors to the plugs in the connector housing, referring to the tags on the connector leads for correct hook-up.

Install the threaded electrical connection cap onto the automatic drain valve housing threaded connector.

#### 4.5.11.9. Condenser Operation Test

- Check the connections at the Consep for air leaks with the compressor cycling and applying full air pressure.
- Switch the ignition on, apply the brakes and release. After each brake application and release, accumulated liquid, oil, and contaminates will be ejected from the bottom of the automatic drain valve.
- Switch the ignition on to check the automatic drain valve heating element. Wait approximately ten minutes, the drain valve housing should be warm to the touch.

## ™NOTE:

The drain valve can be switched from heated to non-heated by changing the electrical connection at the relay. When the connection is made for a heated valve, 13 watts of heat will be constant when the ignition is switched on.

 To manually drain the automatic drain valve the ignition must be switched off. Depress the red button on the bottom of the drain valve housing to manually drain accumulated oil and water.

## 4.5.11.10. Electrical Connections

Check the electrical connections at the relay to make sure the automatic drain valve connectors are attached securely to the proper terminals. The connections must not be corroded or dirty. Accumulated dirt and corrosion attracts moisture and will result in current and voltage drops.

After all connections have been verified, inspected, cleaned and tightened, use a volt/Ohm meter to test for voltage and wire and connector resistance.



## 4.6. Air Tanks



Refer to "WARNING" and "CAUTION" at the beginning of "Main Air Supply System Components" when performing maintenance on these components.

## 4.6.1. Description

Stainless steel air tanks are mounted on either side of the vehicle behind the fluorescent light panels. The tanks supply compressed air to the vehicle's brake, suspension and accessories systems.

New Flyer air tanks are built in accordance with SAE Standard Air Brake Reservoir Test Code and Inspection Procedure SAE J-10-a. They are made from steel sheet, with stamped heads and rolled shells. The seams are electrically welded and each tank is internally coated for corrosion resistance. Each tank is tested at 300 psi hydrostatic pressure.

## 4.6.2. Operation

The reservoirs in an air brake system primarily serve to store energy in the form of

compressed air. They also cool the air as delivered from the compressor and thereby condense water vapor into a liquid and collect oil passed by the compressor. This water and oil collects as an emulsion; the greatest amount in the reservoir nearest the compressor.

## 4.6.2.1. Operation of Integral Check Valve

The integral check valve provides a oneway passage of air from the upstream compartment to the downstream. This protects the service brake system in case of failure in the compressor, discharge lines or first reservoir compartment.

## 4.6.3. Cleaning & Inspection

Wash all metal parts in a good cleaning solvent and dry them thoroughly. All rubber parts should be wiped clean. Inspect springs for distortion, corrosion, and cracks. Inspect valves and valve seats for nicks, cuts and burrs. Inspect all rubber parts for swelling and deterioration.

Replace all parts, particularly rubber parts, not considered serviceable during these inspections.



## 4.6.4. Removal

- 1. Drain pressure from the air system.
- 2. Obtain access to the air tank behind the fluorescent light panels. See "Fig. 8-10: Air Tank Locations" on page 48.
- 3. Disconnect inlet and outlet air lines from both ends of air tank.
- 4. Remove clamps which retain air tank to vehicle structure.
- 5. Remove air tank from vehicle.




Fig. 8-10: Air Tank Locations



## 4.7. ST-1 Safety Valve



Refer to "WARNING" and "CAUTION" at the beginning of "Main Air Supply System Components" when performing maintenance on these components.

## 4.7.1. Description

The safety valve protects the air brake system against excessive air pressure buildup. The valve consists of a spring loaded ball valve which vents pressure to atmosphere if reservoir pressure rises above the pressure setting of the valve, which is determined by the force of the spring. The valve is installed in a port in the wet tank.

## 4.7.2. Operation

The governor cut-out pressure is set at 131 psi. A safety valve with a setting of 150 psi air pressure would force the ball valve off its seat, and allow reservoir pressure to vent to atmosphere through the exhaust port in the spring cage.

When reservoir pressure decreases sufficiently, the spring force will seat the ball check valve, sealing off reservoir pressure. This would occur at approximately 135 psi for the 150 psi valve. It is important to note that the desired pressure setting of the safety valve is determined by the governor cut-out pressure. The opening and closing pressures of the safety valve should always be in excess of the governor cut-out pressure setting. The pressure setting is stamped on the lower wrench flat of the valve.

Normally, the safety valve remains inoperative and only functions if for any reason reservoir pressure rises above the setting of the valve. Constant "popping off" or exhausting of the safety valve can be caused by a faulty safety valve, faulty governor, faulty compressor unloading mechanism, or a combination of any of the preceding.

#### 4.7.3. Removal



During component removal or installation, ensure the Battery Disconnect switch is in the OFF position.

- Block wheels or otherwise secure vehicle and drain reservoirs.
- 2. Using wrench flat closest to wet tank reservoir, unscrew valve from reservoir.

#### 4.7.4. Installation

Safety valve should be installed in same reservoir that compressor discharge line is connected to. Install in a convenient location in a top port of the reservoir. If safety valve is installed horizontally, exhaust port should point down; stem of the valve should face rear of vehicle.

## 4.7.5. Disassembly

- Clamp lower wrench flat in vise (flat nearest pipe thread).
- Using upper wrench flat, unscrew lock nut. Unscrew and remove spring cage from body of valve. See "Fig. 8-11: Safety Valve Assembly" on page 50.
- 3. Remove ball valve, spring and release pin from spring cage.






Fig. 8-11: Safety Valve Assembly

## 4.7.6. Cleaning & Inspection

Clean all parts in mineral spirits. Inspect all parts. All parts not considered serviceable should be replaced.

## 4.7.7. Assembly

- 1. Place the ball valve in body.
- 2. Install spring and release pin in spring cage with adjusting screw.
- Position the release pin over ball valve. Screw body with ball into the spring cage. Tighten securely.
- 4. Adjust for proper setting.

## 4.7.8. Adjustment

The pressure setting of the safety valve is stamped on the cover wrench flat (closest to the pipe thread). If setting is not known, determine governor cut-out pressure setting and adjust safety valve so that the safety valve closes at a pressure setting somewhat above governor cut-out pressure setting.

To adjust, the safety valve must be connected to an air system with air pressure in excess of desired setting. It is important that an accurate gauge be used to check pressure settings while make adjustments.

## 4.7.8.1. Raising Pressure Setting

1. Loosen lock nut.

- 2. Turn adjusting nut clockwise to obtain correct pressure setting.
- Tighten lock nut.

## 4.7.8.2. Lowering Pressure Setting

- 1. Loosen lock nut.
- 2. Turn adjusting nut counter-clockwise to obtain correct pressure setting.
- 3. Tighten lock nut.

## 4.7.9. Operating Test

With air pressure in the system, pull the exposed end of the valve stem removing the spring load from the ball check valve. Air should exhaust from the valve's exhaust port. Release the stem, the air flow should stop. Failure of valve to pass operating test would indicate the valve should be disassembled, cleaned and rebuilt. Refer to 4.7.5. "Disassembly" on page 49 and Refer to 4.7.7. "Assembly" on page 50 in this section for procedure. Refer to 4.7.8. "Adjustment" on page 50 in this section if adjustment is necessary.

#### 4.7.10. Leakage Test

Coat the exhaust port with soap solution. A leakage of a 1" bubble in 5 seconds is permitted. Excessive leakage indicates dirt in valve, faulty ball valve or seat. Valve should be disassembled, cleaned and rebuilt. Refer to 4.7.5. "Disassembly" on page 49 and Refer to 4.7.7. "Assembly" on page 50 in this section for procedure.



## 4.8. Air Lines & Fittings



Refer to "WARNING" and "CAUTION" at the beginning of "Main Air Supply System Components" when performing maintenance on these components.

## 4.8.1. Description

The air system comprises several interconnected components which supply and control air pressure for the brake system, suspension system and operational air operated components. These components are linked together with airlines.

Three types of air lines are used in the air system. These are: copper, flexible Teflon™ with a braided stainless steel jacket, and color coded nylon tubing. Nylon and copper lines are fitted with brass compression fittings that require no special tools and are easily replaced when required.

The tubing is protected, where required, by a sheath of black loom that is both flexible and weather resistant.

System airlines tubing meet both FMVSS and CMVSS air brake specifications for North America.

## 4.8.2. Inspection

A thorough visual inspection includes:

- Checking condition of clamps, guards and shields.
- Removing excess dirt to expose any hidden air line faults.

3. Checking air lines for abnormalities.

The following conditions require immediate shut down and line replacement.

- Damaged or cut areas
- Heat cracked or charred
- ☐ Kinked, crushed, flattened or twisted line
- Blistered or degraded line

A leakage test requires the air system to be charged. Air system pressure is monitored by front and rear brake circuit air pressure gauges located on the driver's instrument panel. A severe leak or rupture in the system will prompt intregal safety systems (check valves, spring brake chambers) to provide brake application.

With the system fully charged check for small leaks by brushing a solution of soap and water onto the air fittings. A leak exists if bubbles occur. Tighten or replace fittings/lines where leakage occurs. To check brake air lines apply brake and coat all tubing and hose connections with solution. No leakage is permissible. Some leaks may be corrected by tightening the connection.



Block and hold vehicle by means other than air brakes before servicing air brake lines.

A trouble symptom such as a slow brake application or release indicates a restricted or clogged air line. Disconnect the suspected line at both ends and clear with a blast of compressed air to correct. Other components will operate abnormally if similar air line blockage occurs.



## 4.8.2.1. Air Line Replacement

To replace flexible Teflon type air line order a complete hose assembly. Color coded nylon and copper air lines are available in one foot increments for field assembly. Associated fittings are supplied with nut, insert and sleeve. All components are available to order from New Flyer Parts.

Nylon and copper air lines are easily assembled without the use of special tools but care must be taken to ensure parts are free of burrs, cuttings and dirt. Foreign particles will destroy sealing seats in air control units. Prior to assembly check that components are the same size and type as the ones being replaced.

- 1. Cut tubing squarely to the required length.
- 2. Place the nut and sleeve over tubing
- 3. Insert tubing into fitting until bottomed onto seat.
- 4. Connect tubing nut to mating fitting component and finger tighten.
- Consult the following table to wrench tighten.

6. Install nut and sleeve at opposite end of line as required.

Ensure that there are no kinks in the tubing when it is installed and secure when necessary. Spare tubing should be stored in clean surroundings with ends plugged.

## 4.8.2.2. Thread Sealant

All fittings, when fitted to valves or other fittings, should be assembled using tape or semi-liquid pipe sealant.

Tape should only be used on tapered pipe threads.

TUBE SIZE	ADDITIONAL NUMBER OF TURNS	
1/4"	3	
3/8" and 1/2"	4	
5/8" and 3/4"	3 1/2"	



# 5. BRAKE SYSTEM COMPONENTS



When working on or around air brake systems and components, the following precautions should be observed:

- ALWAYS block vehicle wheels. Stop engine when working under a vehicle. Depleting vehicle air system pressure may cause vehicle to roll. Keep hands away from chamber push rods; they may apply as system pressure drops.
- □ NEVER connect or disconnect a hose or line containing air pressure. It may whip as air escapes. NEVER remove a component or pipe plug unless you are certain all system pressure has been depleted.
- □ NEVER exceed recommended air pressure and ALWAYS wear safety glasses when working with air pressure. NEVER look into air jets or direct them at anyone.
- □ NEVER attempt to disassemble a component until you have read and understand recommended procedures. Some components contain powerful springs and injury can result if not properly disassembled. Use only proper tools and observe all precautions pertaining to use of those tools.
- ☐ Use only approved replacement parts and components.
  - Only components, devices, mounting and attaching hardware specifically designed for use in air brake systems should be used.
  - □ Replacement hardware, tubing, hose, fittings and so forth, should be of equivalent size, type, length, and strength as the original equipment.

- Make certain that when replacing tubing or hose, all supports, clamps or suspending devices that were originally installed are reinstalled or replaced if they are missing.
- Devices with stripped threads or damaged parts should be replaced. Repairs requiring machining should not be attempted.



Using alcohol in the air brake system as a means to dry the air or prevent system freezing during cold weather is not acceptable. Studies indicate that alcohol removes the lubrication from the system components, causing faulty system function. Also, the materials used for the seals in these components are not alcohol-safe and will deteriorate at an accelerated rate leaving the brake system prone to failure. Using alcohol or alcohol-based fluids in your air brake system will void the warranty on these components.

## 5.1. Description

The front brake system component bracket is mounted to the vehicle structure below the driver's platform. The rear brake system component bracket is mounted to the vehicle structure aft of the rear axle. See "Fig. 8-12: Brake System Components" on page 54. Major brake system components include:

- Quick Release Valves
- Double Check Valves
- □ Brake Relay Valve
- Check Valve
- Spring Brake Modulating Valve
- □ Pressure Transducers






Fig. 8-12: Brake System Components



## 5.2. Single Check Valve



Refer to "WARNING" and "CAUTION" at the beginning of "Brake System Components" when performing maintenance on these components.

## 5.2.1. Description

The In-Line Single Check Valve is a device placed in an air line to allow air flow in one direction only and to prevent flow of air in the reverse direction.

The three types of In-Line Single Check Valves used in service are:

- ☐ The ball type.
- ☐ The disc type with integral seat.
- ☐ The disc type with a replaceable seat; the replaceable seat being made of either metal or rubber.

An arrow indicating the direction of air flow is cast into the body of the valve.

## 5.2.2. Operation

Air flow in the normal direction moves the check valve ball or disc from its seat, and the flow is unobstructed. Flow in the reverse direction is prevented by the seating of the ball or disc, which is caused by a drop in upstream air pressure and assisted by the spring.

#### 5.2.3. Removal

 Block and hold vehicle by means other than air brakes.

- 2. Completely drain all reservoirs.
- Disconnect air lines at single check valve and remove.

## ™NOTE:

Valves which malfunction are replaced with new units.

#### 5.2.4. Installation



During component removal or installation, ensure the Battery Disconnect switch is in the OFF position.

- Check and, if necessary, clean or replace air lines to valve.
- Install valve making certain that it is installed correctly with respect to the desired air flow. An arrow indicating the direction of air flow is cast into the body of the valve.

#### 5.2.5. Operating & Leakage Test

## ™NOTE:

Depending upon installation, it may be easier or necessary to completely remove check valves so that the following checks may be made.

With air pressure present at outlet side of check valve and the inlet side open to atmosphere, coat the open end of the check valve with soap suds; a 1" bubble in 5 seconds is permissible.

If the check valve does not function as described, or leakage is excessive, it is recommended that it be replaced with a new unit.



## 5.3. Double Check Valve



Refer to "WARNING" and "CAUTION" at the beginning of "Brake System Components" when performing maintenance on these components.

## 5.3.1. Description

Double Check Valves are used in an air brake system to direct a flow of air into a common line from either of two sources, whichever is at the higher pressure. They may be used for directing air flow for specific functions or to select the higher pressure of either of two sources of air as a supply source.

HVSG manufactures two types of Double Check Valves: shuttle and disc. Although the valves are somewhat different physically, the same function is performed by both types. The difference in the design of the two valves is that the shuttle type has a movable shuttle to seal off the lower pressure sources, whereas the disc type has a movable disc.

## 5.3.2. Operation

As air under pressure enters either end of the Double Check Valve (inlet port) the moving shuttle or disc responds to the pressure and seals the opposite port, assuming it is at a lower pressure level than the other. The air flow continues out the delivery port of the Double Check Valve. The position of the shuttle or disc will reverse if the pressure levels are reversed. Double Check Valves are designed so that the shuttle or disc can never impede the backflow of air in the exhaust mode.

A Double Check Valve is used to supply air to a system or systems from either of two separate sources, whichever is at the greater pressure level. In this type of installation the pressure differential to which the valve is subjected may under certain conditions be minimal. It is therefore suggested that performance of the Double Check Valve will be optimized if it is mounted in the horizontal position.

## 5.3.3. Disassembly

- Remove end cap from valve. See "Fig. 8-13: Double Check Valve Assembly" on page 57.
- 2. Remove shuttle and/or shuttle guide.






Fig. 8-13: Double Check Valve Assembly

## 5.3.4. Cleaning & Inspection

- 1. Clean all metal parts in a cleaning solvent.
- 2. Inspect all metal parts for signs of cracks, wear or deterioration. Replace all parts not considered serviceable.
- 3. Replace all rubber parts.

## 5.3.5. Assembly

- 1. Install shuttle and shuttle guide.
- Coat all static seals such as O-rings, grommets and so forth with BW 650M Silicone lubricant (BW 291126). It is not necessary to lubricate shuttles or discs.
- 3. Install end cap.

## 5.3.6. Operating & Leakage Test

If Double Check Valve is to be bench tested or tested on the vehicle, two separately controlled air supplies must be connected to the inlet ports.

- 1. Install an accurate test gauge in the outlet port or in a line from outlet port.
- Apply and release air to one inlet port and note that gauge registers application and release.
- 3. Repeat by applying and releasing air to other inlet port.
- 4. Leakage check should be performed at inlet ports of valve in the following manner:
  - a. Disconnect line from one inlet port.
  - Apply air to other inlet port and coat opposite inlet port with soap solution.
     Permissible leakage is a 1" bubble in five seconds.
  - Repeat Step "b" applying air to other inlet port while checking opposite inlet port for leakage.

If Double Check Valve does not function as described or if leakage is excessive, it is recommended that the valve be replaced.



## 5.4. E-6 Brake Valve



Refer to "WARNING" and "CAUTION" at the beginning of "Brake System Components" when performing maintenance on these components.

## 5.4.1. Description

## ™NOTE:

A Brake Valve Actuator (BVA) is attached to the E-6 Brake valve. See "5.5. Brake Valve Actuator" on page 65. in this section for information on this component.

The E-6 Brake Valve is a floor mounted, treadle operated type brake valve with two separate supply and delivery circuits for the primary (Rear) and secondary (Front) braking, which provides the driver with a graduated control for applying and releasing the brakes.

The E-6 Brake Valve is equipped with a rubber spring housed in an upper body assembly. The circuits in the E-6 Brake Valve are identified as follows: The No. 1 circuit portion is that portion of the valve between the spring seat which contacts the plunger and the relay piston; the No. 2 circuit portion is that portion between the relay piston and the exhaust cavity. See "Fig. 8-14: E-6 Brake Valve Assembly" on page 59.

The No. 1 circuit portion of the valve is similar in operation to a standard single-circuit air brake valve, and under normal operating conditions the No. 2 circuit portion is similar in operation to a relay valve.

Both No. 1 and No. 2 circuit portions of the Brake Valve use a common exhaust protected by an exhaust diaphragm.






Fig. 8-14: E-6 Brake Valve Assembly



## 5.4.2. Operation

## 5.4.2.1. Applying: Normal Operation - No. 1 Circuit Portion

When the brake treadle is depressed, the plunger exerts force on the spring seat, graduating spring, and No. 1 piston. The No. 1 piston which contains the exhaust valve seat, closes the No. 1 exhaust valve. As the exhaust valve closes, the No. 1 inlet valve is moved off its seat allowing air to flow out the No. 1 delivery port.

# 5.4.2.2. Applying: Normal Operation - No. 2 Circuit Portion

When the No. 1 inlet valve is moved off its seat, air is permitted to pass through the bleed passage and enters the relay piston cavity. The air pressure moves the relay piston, which contains the exhaust seat and closes the No. 2 exhaust valve. As the No. 2 exhaust valve closes, the No. 2 inlet valve is moved off its seat allowing the air to flow out the No. 2 delivery port. Because of the small volume of air required to move the relay piston, action of the No. 2 circuit portion of the valve is almost simultaneous with the No. 1 circuit portion.

## 5.4.2.3. Applying: Loss of Air in the No. 2 Circuit

Should air be lost in the No. 1 circuit, the function will be as follows: As the brake treadle is depressed and no air pressure is present in the No. 1 piston will mechanically move the relay piston allowing the piston to close the No. 2 exhaust valve and open the No. 2 inlet valve and allow air to flow out the No. 2 delivery port.

#### 5.4.2.4. Balanced: No. 1 Circuit Portion

When the No. 1 delivery pressure acting on the piston equals the mechanical force of the brake pedal application, the No. 1 piston will move and the No. 1 inlet valve will close, stopping the further flow of air from the No. 1 supply line through the valve. The exhaust valve remains closed preventing any escape of air through the exhaust port.

#### 5.4.2.5. Balanced: No. 2 Circuit Portion

When the air pressure on the No. 2 side of the relay piston approaches that being delivered on the No. 1 side of the relay piston base, the relay piston moves closing the No. 2 inlet valve and stopping further flow of air from the supply line through the valve. The exhaust remains closed as the No. 2 delivery pressure balances the No. 1 delivery pressure.

When applications in the graduating range are made, a balanced position in the No. 1 portion is reached as the air pressure on the delivery side of the No. 1 piston equals the effort exerted by the driver's foot on the treadle. A balanced position in the No. 2 side of the relay piston closely approaches the air pressure on the No. 1 side of the relay piston. See "Fig. 8-15: E-6 Dual Brake Valve Cross Section" on page 60.

When the brake treadle is fully depressed, both the No. 1 and No. 2 inlet valves remain open and full reservoir pressure is delivered to the actuators.




Fig. 8-15: E-6 Dual Brake Valve Cross Section



## 5.4.2.6. Releasing: No. 1 Circuit Portion

With the brake treadle released, mechanical force is removed from the spring seat, graduating spring, and No. 1 piston. Air pressure and spring load moves the No. 1 piston, opening the No. 1 exhaust valve, allowing air pressure in the No. 1 delivery line to exhaust out the exhaust port.

## 5.4.2.7. Releasing: No. 2 Circuit Portion

With the brake treadle release, air is exhausted from the No. 1 circuit side of the relay piston. Air pressure and spring load move the relay piston, opening the No. 2 exhaust valve allowing air pressure in the No. 2 delivery line to exhaust out the exhaust port.

#### 5.4.3. Removal

 Set the parking brake and block the wheels of the vehicle.

## ™NOTE:

Refer to 1.1. "Safety Procedures" on page 1 in this section for complete information on securing the vehicle for servicing.

- 2. Drain the air pressure from the air system.
- Open the side console access door located below the driver's window.
- Hoist the vehicle to gain access to the brake valve. Refer to "Raising the Vehicle" in the General Information section.
- 5. Remove the front steering gearbox access panel below the vehicle.
- Locate the brake valve assembly under the driver's platform and mark the orientation for correct reinstallation.
- Tag the electrical harnesses and air lines connecting to the brake valve and disconnect them.
- Temporarily support the brake valve under the vehicle.
- From inside the vehicle, remove the two cotter pins and pins securing the treadle to the brake treadle assembly. Remove the treadle.
- 10. Remove the three countersunk bolts and washers from the brake treadle mount.
- 11.Remove the brake valve from below vehicle



## 5.4.4. Disassembly

- Remove Brake Valve Actuator (BVA). Refer to 5.5. "Brake Valve Actuator" on page 65 in this section for procedure.
- Remove the Phillips head screw securing the exhaust diaphragm and washer to the exhaust cover.
- Remove the four screws that secure the exhaust cover to the lower body.
- Remove the No. 2 inlet and exhaust valve assembly from the lower body.
- Remove the four hex head cap screws securing the lower body to the upper body and separate the body halves.
- Remove the rubber seal ring from the lower body.
  - a. While depressing spring seat, remove retaining ring.
  - b. Remove spring seat and coil spring.
- Using a 3/8" wrench, hold the lock nut on the threaded end of the stem in the primary piston. Insert a screwdriver in the exhaust passage through the center of the valve and engage the slotted head of the stem.



Before proceeding with the disassembly, note that the lock nut and stem are used to contain the No. 1 piston return spring, stem spring and the relay piston spring. The combined force of these springs is approximately 50 lbs. and care must be taken when removing the lock nut as the spring forces will be released. It is recommended that the primary piston and relay piston be manually or mechanically contained while the nut and stem are being removed.

- 8. Remove lock nut, spring seat, stem spring, primary piston, and primary piston return spring. Remove O-ring.
- Remove adapter. Remove O-ring from adapter.

#### 5.4.5. Cleaning & Inspection

- Wash all metal parts in mineral spirits and dry.
- Inspect all parts for excessive wear or deterioration.
- 3. Inspect the valve seats for nicks or burrs.
- 4. Check the springs for cracks or corrosion.
- 5. Replace all rubber parts and any part not found to be serviceable during inspection, using only genuine replacement parts.



#### 5.4.6. Assembly

Prior to reassembling, lubricate all O-rings, O-ring grooves, piston bores and metal moving surfaces with Dow Corning 55-M pneumatic grease.

#### ™NOTE:

All torque specified in the manual are assembly torque and can be expected to fall off, after assembly is accomplished. DO NOT torque after initial assembly torque fall.

- Install the No. 1 inlet and exhaust assembly in the upper body and place the retaining ring to secure it. Be sure the retaining ring is seated completely in its groove.
- Place screwdriver, blade up, in vise. Place stem in relay piston - upper body subassembly over the blade of the screwdriver with blade engaged in the slot in the head of the stem.
- 3. Place the washer over the stem. This washer should be installed in all valves.
- Install primary return spring in upper body piston bore.
- Install the primary piston rubber spring sub-assembly over the stem, into the upper body piston bore.
- Compress the primary and relay pistons into the upper body from either side and hold them compressed, either manually or mechanically.



Before proceeding with the disassembly, note that the lock nut and stem are used to contain the No. 1 piston return spring, stem spring and the relay piston spring. The combined force of these springs is approximately 50 lbs. and care must be taken when removing the lock nut as the spring forces will be released. It is recommended that the

primary piston and relay piston be manually or mechanically contained while the nut and stem are being removed.

- 7. Place the stem spring over the spring seat nut and the spring seat over the stem.
- 8. Install the lock nut on the stem and torque to 10 to 20 in-lb.
- 9. Install the primary piston retainer over the piston, making certain all three lock tabs have engaged the outer lip of the body.

#### 5.4.7. Operating Check

Check the delivery pressure of both No. 1 and No. 2 circuits using test gauges known to be accurate. Depress the treadle to several positions between the fully released and fully applied positions, and check the delivered pressure on the test gauges to see that it varies equally and proportionately with the movement of the brake pedal.

After a full application is released, the reading on the test gauges should fall off to zero promptly. It should be noted that the No. 1 circuit delivery pressure will be about 2 psi greater than the No. 2 circuit delivery pressure with both supply reservoirs at the same pressure. This is normal for this valve.

# ™NOTE:

A change in vehicle braking characteristics or a low pressure warning may indicate a malfunction in one or the other brake circuit, although the vehicle air brake system may continue to function, the vehicle should not be operated until the necessary repairs have been made and both braking circuits, including the pneumatic and mechanical devices are operating normally. ALWAYS check the vehicle brake system for proper operation after performing brake work and before returning the vehicle to service.



#### 5.4.8. Leakage Check

- 1. Make and hold a high pressure (80 psi) application.
- 2. Coat the exhaust port and body of the brake valve with a soap solution.
- Leakage permitted is a one inch bubble in 3 seconds.

If the brake valve does not function as described previously or leakage is excessive, it is recommended that it be replaced with a new or remanufactured unit, or repaired.

#### 5.4.9. Installation

- Support the brake valve from below the vehicle and install the countersunk bolts through the treadle base into the brake valve's threaded holes.
- 2. Tighten bolts.
- 3. Reinstall treadle onto base.
- 4. Reconnect the air lines to the brake valve as noted during removal.
- Reconnect the electrical harnesses to the brake valve.
- 6. Reinstall the steering gearbox access panel.
- 7. Close the side console access door.
- 8. Recharge the air system and test the brake system.



#### 5.5. Brake Valve Actuator



Refer to "WARNING" and "CAUTION" at the beginning of "Brake System Components" when performing maintenance on these components.

#### 5.5.1. Description

The Brake Valve Actuator (BVA) is a brake application device that is mounted directly on the E-6 Brake Valve and functions as part of the brake interlock control system.

#### 5.5.2. Operation

The brake interlock control system consists of a pressure reducing valve, a solenoid valve and the brake valve actuator.

The brake interlock pressure reducing valve receives its air supply from the front or rear brake tank via the emergency/parking brake valve system. The pressure reducing valve is set to regulate the interlock pressure to 70 PSI. The outlet of the pressure reducing valve regulator is connected to the brake interlock solenoid valve.

The brake interlock solenoid valve is normally closed. When energized by the Multiplexing system, it opens and applies pressure from the brake interlock pressure reducing valve to the brake valve actuator on the E-6 brake valve.

The brake valve actuator on the E-6 brake valve receives air pressure from the pressure reducing valve and the brake interlock solenoid valve and applies the service brakes. This action will mimic a foot application of the brake treadle and will apply both front and rear service brakes.

#### ™NOTE:

The treadle will fall away from the operator's foot when the interlocks apply.

Releasing the interlocks will require the vehicle operator to push through the interlock application. Applying sufficient pres-

sure on the treadle to exceed interlock pressure by 10 PSI will release the interlocks and the treadle will return to its normal position.

# ™NOTE:

Interlock application and release will be accompanied by a text message on the instrument panel LCD screen. Refer to Section 19 in this manual for more information on the instrument panel text messages.

#### 5.5.3. Removal of BVA from Brake Valve

- Remove the brake valve assembly from the vehicle. Refer to 5.4. "E-6 Brake Valve" on page 58 in this section for procedure.
- 2. Place the brake valve onto a clean work surface with the BVA on top.
- 3. Mark the position of the BVA in relation to the brake vale assembly.
- Remove the three socket screws securing the BVA to the brake valve.
- 5. Remove the BVA from the brake valve.
- Mark the rotation of the elbow fitting and remove it from the BVA.

#### 5.5.4. Installation

- Place the BVA on the brake valve assembly align it with the marks made during removal.
- 2. Install the three socket screws and tighten.
- Inspect the threads of the elbow fitting to be sure they are not damaged or contain slivers, burrs, dirt or other contaminants.
- 4. Apply Loctite 567 evenly, without air pockets, around the circumference of the threads. Leave the first 1/2 to 1 1/2 threads clean and completely cover, at minimum, the next three threads.
- Install the elbow fitting into the BVA and tighten until finger-tight.
- Apply two full turns past finger-tight, rotating until the fitting is 15° past horizontal, as noted during removal.



# 5.6. R-14 Relay Valve



Refer to "WARNING" and "CAUTION" at the beginning of "Brake System Components" when performing maintenance on these components.

#### 5.6.1. Description

The brake relay valve speeds up the application and release of the rear brakes. The valve is mounted on a plate in front of the rear axle. It operates as a remote controlled brake valve that delivers or releases air to the brake chambers in response to the control air delivered to it from the foot brake valve.

#### 5.6.2. Operation

#### 5.6.2.1. Application

Under normal conditions, the internal biased double check valve assures that the primary signal controls the valve. Air pressure delivered to the primary control port is prevented from flowing to the secondary control port by the biasing check valve. The air then enters the cavity above the relay piston and moves the piston down. The exhaust seat moves down with the piston and seats on the bellmouth end of the modulation tube, sealing off the exhaust passage. Further movement of the piston slides the modulation tube down causing the supply valve to unseat, permitting supply air to flow from the reservoir, past the open supply valve and into the service brake chambers. In the event of a loss of the primary control line, the biasing check valve mechanism in the cover of the brake relay valve will move, shutting off the primary control passage, and allow the secondary control line to apply the air pressure needed to operate the valve. See "Fig. 8-16: R-14 Relay Valve Cross Section" on page 66.




Fig. 8-16: R-14 Relay Valve Cross Section

#### 5.6.2.2. Balance

The air pressure being delivered by the open supply valve also is effective on the bottom area of the relay piston. When service air pressure beneath the piston equals the control air pressure above, the piston lifts slightly allowing the modulation tube return spring to slide the modulation tube upwards closing off the supply port. The exhaust remains closed as long as the control line pressure balances the delivery line pressure. If delivered air pressure is changed, the valve reacts instantly to the change, holding the brake application at that level.

#### 5.6.2.3. Exhaust or Release

When control air pressure in the cavity above the relay piston is exhausted from the line, air pressure beneath the piston lifts the relay piston and exhaust seat away from the modulation tube opening the exhaust passage. With the exhaust passage open, the air pressure in the brake chambers is then permitted to exhaust through the exhaust port, releasing the brakes.



#### 5.6.3. Removal

- Block and hold vehicle by means other than air brakes.
- 2. Drain air brake system reservoirs.
- 3. Identify air lines to facilitate reinstallation prior to disassembly.
- Remove as much contamination as possible from the exterior of the valve and disconnect air lines from valve being careful to prevent any foreign matter from entering the open ports.
- Remove mounting bolts and then valve. See "Fig. 8-17: R-14 Relay Valve Installation" on page 67.

#### 5.6.4. Installation

- Clean air lines.
- Inspect all lines and/or hoses for damage and replace as necessary.
- 3. Install valve and tighten mounting bolts.
- Connect air lines to valve (plug any unused ports).
- 5. Test valve.




Fig. 8-17: R-14 Relay Valve Installation

#### 5.6.5. Operation & Leakage Test

- Chock the wheels and fully charge the brake system.
- Make several brake applications and check for prompt application and release at each rear wheel.
- The following test will check for internal air leakage past exhaust valve seat or past the inlet/exhaust valve O-ring.
  - a. Release the service brakes.
  - b. Locate the exhaust valve at the bottom of the relay valve. Use a soap solution and coat the exhaust port and the area around the retaining ring.
  - c. Leakage equivalent to a 1" bubble in 3 seconds is permitted.
- The following test will check for internal air leakage past the relay piston exhaust seat or past the O-ring in the valve body cover.
  - a. Apply and maintain full service brake pressure.
  - b. Locate the exhaust valve at the bottom of the relay valve. Use a soap solution and coat the exhaust port and the area around the retaining ring.
  - c. Leakage equivalent to a 1" bubble in 3 seconds is permitted.
  - d. Use a soap solution and coat the outside of the valve where the cover joins the body. No leakage is allowed in this area.

#### MOTE:

If the valve does not function as described, or if leakage is excessive, it is recommended that the valve be replaced as an assembly. Refer to your New Flyer Parts Manual for correct assembly part number.



# 5.7. SR-7 Spring Brake Modulating Valve



Refer to "WARNING" and "CAUTION" at the beginning of "Brake System Components" when performing maintenance on these components.

### 5.7.1. Description

The SR-7 Spring Brake Modulating Valve (SBMV) is used in conjunction with a dual air brake system and spring brake actuators. The SBMV performs the following functions:

- ☐ Provides a rapid application of the spring brake actuator when the parking brake is applied.
- Modulates the spring brake actuator application using the brake foot valve, should a failure occur in the primary (rear) service brake system.
- Prevents compounding of service and spring brake forces.

The SBMV is configured with the following ports. See "Fig. 8-18: SR-7 Spring Bake Modulating Valve" on page 68.

- ☐ Park control port receives front/rear brake supply pressure via a double check valve and parking brake control valve.
- ☐ Supply port receives constant air pressure from secondary (front) brake reservoir

- ☐ Balance port receives primary (rear) delivery pressure.
- ☐ Control port receives secondary (front) delivery pressure.
- ☐ Delivery ports (2) delivers supply pressure to spring brake chamber.




Fig. 8-18: SR-7 Spring Bake Modulating Valve

# **SR-7 Spring Brake Modulating Valve**

#### 5.7.2. Operation

SBMV operating modes:

- Charging spring brake actuators below 107 psi.
- ☐ Charging spring brake actuators above 107 psi.
- □ Normal service application
- Parking brake application
- Service application with loss of air in primary (rear) circuit
- Anti-compounding

# 5.7.2.1. Charging Spring Brake Actuators below 107 psi

During initial air system charging, with parking brake released, air flows to the parking brake control valve. This air pressure acts on the control piston and main piston to open the inlet valve. The inlet valve allows secondary (front) reservoir pressure to flow from the supply port to the delivery ports. Air will continue to flow to spring brake chambers as system pressure is building and will release the spring brakes. Air flow will cease once spring brake pressure builds to 107 psi.

# 5.7.2.2. Charging Spring Brake Actuators above 107 psi

Once the delivery pressure to the spring brakes reaches 107 psi (nominal), the inlet and exhaust valves close (lap position) and maintain the spring brake hold-off pressure at 107 psi. (nominal).

#### 5.7.2.3. Normal Service Application

During a service brake application, the SBMV remains in the lap position with the inlet and exhaust valves closed and monitors the presence of air pressure in both primary and secondary delivery circuits.

#### 5.7.2.4. Parking Brake Application

During a parking brake application, the air pressure in the parking brake control line is exhausted through the exhaust port in the parking brake control valve. This allows the main and control pistons to move up, thereby seating the inlet valve and unseating the exhaust valve. Air from the spring brakes is exhausted through the SBMV exhaust valve.

# 5.7.2.5. Service Application with Loss of Primary Circuit

The SBMV will function to provide modulated spring brake application in a situation where the primary (rear) brake circuit has lost air pressure. The SBMV senses loss of primary circuit air pressure at the balance port which causes an imbalance on the main piston. Air pressure from the secondary (front) brake application circuit acts on the underside of the main piston forcing it up. This action closes the inlet valve and opens the exhaust valve. As a result, air is exhausted from the spring brakes in proportion to the secondary brake application pressure. A 30 psi secondary brake application will exhaust spring brake pressure to approximately 60 psi.

# 5.7.2.6. Service Application with Loss of Secondary Circuit

The SBMV will function to maintain the spring brakes in the released position in a situation where the secondary (front) brake circuit has lost air pressure. The external check valve in the secondary supply line will seal the SBMB and prevent air leakage to atmosphere. Primary air supply will be delivered through the Parking Brake Control Valve and supplied to the parking brake control port of the SBMV. This supply air will flow through the internal inline check valve and become the delivery pressure to the spring brakes. This delivery air will maintain 107 psi (nominal) in the spring brake chambers.



#### 5.7.2.7. Anti-Compounding

When the parking brake is in the applied position, air pressure is removed from the SBMV park control port, thereby allowing air to exhaust from the spring brakes chamber and allow the spring brakes to apply. A service brake application, with the parking brakes still applied, will cause air pressure received at the SBCS balance and control ports to act on the Control Piston, forcing it downward. This action will allow brake application pressure to flow to the spring brake chamber, thereby releasing the spring brakes and preventing compounded brake application.

#### 5.7.3. Maintenance

Refer to the Preventive Maintenance section of this manual for maintenance intervals and procedures.

#### 5.7.4. Removal

#### ™NOTE:

There are no replaceable parts within the SBMV assembly. Replace the SBMV as a unit.

- 1. Set the Battery Disconnect switch to the OFF position.
- 2. Drain air from all air tanks.
- 3. Locate the SBMV on the rear brake valve plate. See "Fig. 8-19: SR-7 Spring Bake Modulating Valve Installation" on page 70.
- Mark the location and disconnect all air lines from SBMV.
- Unplug electrical connector from the pressure transducer.
- Remove the two lock nuts and washers securing the SBMV to the rear brake valve plate and remove the SBMV from the vehicle.
- 7. Mark the location and position of all fittings prior to removal.
- 8. Remove the check valve, pressure transducer, and all fittings from body of SBMV.




Fig. 8-19: SR-7 Spring Bake Modulating Valve Installation

#### 5.7.5. Installation

- Apply Loctite 567 thread sealant on the threads of all NPT fittings and install in the replacement SBMV at the location and position noted during removal. Tighten all NPT fittings two turns past finger tight or until aligned as originally installed.
- 2. Install and secure the SBMV to the rear brake valve plate using two locknuts and washers.
- 3. Plug the electrical connector from the vehicle harness into the pressure transducer.
- 4. Connect all air lines to locations marked during removal.



#### 5.8. PR-2 Pressure Protection Valve



Refer to "WARNING" and "CAUTION" at the beginning of "Brake System Components" when performing maintenance on these components.

#### 5.8.1. Description

The pressure protection valve is a normally closed, pressure control valve which can be referred to as a non-exhausting sequence valve. See "Fig. 8-20: PR-2 Pressure Protection Valve Cross Section" on page 71. One of these valves is installed in the inlet of the front brake tank to supply specific air pressure to the Accessories tank.

The PR-2 pressure protection valves have one 1/4" N.P.T.F. supply port and one 1/4" N.P.T.F. delivery port which are identified. Valves are provided with two 9/32" mounting holes through the body. The closing pressure of the PR-2 is externally adjustable. See "Fig. 8-21: PR-2 Pressure Protection Valve Assembly" on page 71.




Fig. 8-20: PR-2 Pressure Protection Valve Cross Section




Fig. 8-21: PR-2 Pressure Protection Valve Assembly



#### 5.8.2. Operation

Air entering the supply port is initially prevented from flowing out the delivery port by the inlet valve which is held closed by the pressure regulating spring above the piston. When sufficient air pressure builds beneath the piston to overcome the setting of the regulating spring, the piston will move, causing the inlet valve to unseat (open), and allow air to flow out the delivery port. As long as air pressure at the supply port and beneath the piston remains above the specified closing pressure, the inlet valve will remain open.

#### ™NOTE:

The PR-2 closing pressure is noted on the label affixed to the valve. Opening pressure of the PR-2 valve is 15 to 20 psi higher than closing pressure.

If for any reason system air pressure is decreased below the specified closing pressure, the regulating spring will move the piston, closing the inlet valve. The remaining air pressure at either the supply or delivery side, (depending upon where the pressure drop has occurred) will be retained.

#### 5.8.3. Removal



During component removal or installation, ensure the Battery Disconnect switch is in the OFF position.

- Block or hold the vehicle by means other than air brakes.
- 2. Drain all system reservoirs individually, to 0 psi.
- 3. Disconnect and identify (supply and delivery) the air lines leading to and from the pressure protection valve.
- 4. Remove the mounting bolts, if any, that secure the valve.

#### 5.8.4. Installation

- 1. Reinstall the mounting bolts and secure the replacement valve to the vehicle.
- Reconnect the supply delivery air lines to the proper ports of the replacement valve.



#### 5.8.5. Operating & Leakage Check

After installing a replacement valve, it is recommended that the operating and leakage checks be performed as outlined in this manual. If the closing pressure does not conform to that shown on the valve label or in the vehicle or a different setting is desired, the PR-2 may be adjusted by loosening the locknut and tightening or loosening the adjusting cap as required; however, if the proper setting cannot be attained by moderate adjustment of the cap, the valve may have the wrong spring and will have to be exchanged for the correct valve. (PR-3 and PR-4 valves are not adjustable.)

#### 5.8.5.1. Operating Check

- Provide a pressure gauge and drain valve at the supply side and delivery side of the pressure protection valve being checked.
- 2. Build up the air system to full pressure and shut off the engine.
- While watching the gauges on the supply and delivery sides of the valve, slowly begin to exhaust pressure from the delivery side. Note that both gauges will show pressure loss until the closing pressure of the pressure protection valve is reached.

The pressure protection valve should close at approximately ( $\pm$  5 psi) the pressure indicated on the valve's label. The gauge on the delivery side of the valve should continue to show loss of pressure while the gauge on the supply side should stop at the same pressure as the setting of the valve.

#### 5.8.5.2. Leakage Check

- 1. Build up the air system to full pressure and shut off the engine.
- 2. Apply a soap solution around the cap of the pressure protection valve. A 1" bubble in three seconds or longer is acceptable.
- Drain the air pressure from the delivery side of the pressure protection valve and disconnect the air line to it.
- Apply a soap solution to the delivery port.
   A 1" bubble in five seconds or more is acceptable.

#### ™NOTE:

Replace the pressure protection valve if it does not operate as described or leakage is excessive.



#### 5.9. QR-1 Quick Release Valve



Refer to "WARNING" and "CAUTION" at the beginning of "Brake System Components" when performing maintenance on these components.

#### 5.9.1. Description

The function of the Quick Release Valve is to speed up the exhaust of air from the air chambers. It is mounted close to the chambers it serves. In its standard configuration, the valve is designed to deliver within 1 psi of control pressure to the controlled device; however, for special applications the valve is available with greater differential pressure designed into the valve. Two styles of Quick Release Valves are available and are functionally the same; the QR valve, which is of older design and utilizes a spring and spring seat, and the QR-1 valve, which in its standard configuration does not employ a spring or spring seat.

# ™NOTE:

QR-1 Valves with a pressure differential employ a spring and spring seat.

Porting consists of one brake valve port, two delivery ports and one exhaust port.

#### 5.9.2. Operation

When a brake application is made, air pressure enters the brake valve port; the diaphragm moves down, sealing the exhaust. At the same time, air pressure forces the edges of the diaphragm down and air flows out the delivery port.

When air pressure being delivered (beneath the diaphragm) equals the pressure being delivered by the brake valve

(above the diaphragm), the outer edge of the diaphragm will seal against the body seat. The exhaust port is still sealed by the center portion of the diaphragm when the brake valve application is released; the air pressure above the diaphragm is released back through the brake valve exhaust; air pressure beneath the diaphragm forces the diaphragm to rise, opening the exhaust, allowing air in the chambers to exhaust.

#### 5.9.3. Removal



During component removal or installation, ensure the Battery Disconnect switch is in the OFF position.

- Block vehicle wheels and hold vehicle by means other than air brakes.
- 2. Drain all air brake system reservoirs.
- 3. Disconnect air lines from valve.
- 4. Remove mounting bolts, then valve.

#### 5.9.4. Installation

- 1. Mount valve with exhaust port pointing down; securely tighten mounting bolts.
- 2. Connect air lines to valve (brake valve application line to top port; brake chamber line to side ports).

#### 5.9.5. Disassembly

- 1. Remove four screws.
- Remove diaphragm. See "Fig. 8-22: QR-1 Quick Release Valve Assembly" on page 75.
- 3. Remove cover O-ring.






Fig. 8-22: QR-1 Quick Release Valve Assembly

# 5.9.6. Cleaning & Inspection

Clean all metal parts in mineral spirits. Wipe all rubber parts clean.

It is recommended that all rubber parts and any other part showing signs of wear or deterioration be replaced.

#### 5.9.7. Assembly

- 1. Install diaphragm.
- Install O-ring in cover groove; install cover and tighten screws evenly and securely. (Torque to 30 to 60 in-lb.)
- Perform tests. Refer to 5.9.8. "Operating & Leakage Test" on page 75 in this section for procedure.

#### 5.9.8. Operating & Leakage Test

- While holding a foot brake valve application;
  - Coat exhaust port with soap solution; 1" bubble in three seconds leakage is permitted.
  - b. Coat body and cover with soap solution. No leakage permitted between body and cover.
- If the valve does not function as described, or if leakage is excessive, it is recommended that it be replaced with a new or remanufactured unit, or repaired.



#### 5.10. Pressure Switches



Refer to "WARNING" and "CAUTION" at the beginning of "Brake System Components" when performing maintenance on these components.

#### 5.10.1. Front Brake Circuit Pressure Switch

#### 5.10.1.1.Description

The Front Brake Circuit Pressure switch is an electro-pneumatic 4 psi non-grounded switch used to signal the Multiplexing System when the front brake circuit application pressure reaches or exceeds 4 psi. It is mounted on the E-6 brake valve and accessed through the side console access door.

The switch is not a serviceable item and must be replaced as a unit if found defective

# 5.10.1.2.Operation

When the brakes are applied, air pressure from the brake valve enters the cavity below the switch diaphragm. The air pressure moves the piston until it contacts the leaf spring.

The leaf spring pivots on a fulcrum at 4 psi and snaps a shorting bar which mates with the contact strips. This snap action spring is designed to minimize arcing. The electrical circuit closes, signaling the Multiplexing System.

The Multiplexing System uses the signal from the Front Brake Circuit Pressure switch to activate the brake lights.

#### 5.10.1.3.Removal

- 1. Set the Battery Disconnect switch to the OFF position.
- 2. Drain the air system to remove pressure in the lines.
- Open the access door below the driver's side window and locate the Stop Light Pressure switch.
- Disconnect the electrical connector and air line from the switch.
- 5. Remove switch from the threaded fitting.

#### 5.10.1.4.Installation

- 1. Install switch into the threaded fitting.
- 2. Connect electrical connector to switch.
- 3. Close access door
- Set Battery Disconnect switch to ON position.



#### 5.10.2. Brake Application Pressure Transducer

#### 5.10.2.1.Description

The brake application pressure transducer is ruggedly constructed of a stainless steel or aluminum cylindrical body that encloses one-piece stainless steel sensing elements. The transducer has threads and wrench surfaces at one end and a sealed electrical connector at the opposite end. The pressure transducer monitors brake application pressure on the rear brake circuit and transmits an analog signal to the vehicle's Multiplexing System.

# 5.10.2.2.Brake Application Pressure Transducer Specifications

Pressure Range	0 - 150 psi
Supply Voltage	10 - 32 VDC
Output Voltage	1 - 5 VDC
Supply Current	<10mA
Thread	1/4 NPT

#### 5.10.2.3.Operation

The pressure transducer is connected to the brake foot valve's rear brake circuit delivery port. The Multiplexing System converts the analog signal into pressure readings which are used to illuminate the brake lights and signal both the retarder system and the brake interlock system.

#### 5.10.2.4.Removal

- Set the Battery Disconnect switch to the OFF position.
- Drain the air system to remove pressure in the lines.
- 3. Obtain access to the transducer on the E-6 brake valve assembly.
- 4. Disconnect the electrical connector from the transducer.
- 5. Remove the transducer.

#### 5.10.2.5.Installation

- Inspect the threads to be sure they are not damaged or contain slivers, burrs, dirt or other contaminants.
- Apply Loctite-567 evenly, without air pockets, around the circumference of the thread, leaving the first 1/2 to 1 1/2 threads clean while completely covering a minimum of the next three threads.

#### ™NOTE:

Ensure the sensor port remains unblocked by thread sealant.

- 3. Install the pressure transducer and finger tighten.
- 4. Using a wrench, fully tighten the transducer two full turns past finger-tight.



#### 5.10.3. Parking Brake/Stop Light Switch

#### 5.10.3.1.Description

The Parking Brake/Stop Light switch is a normally closed 60 psi switch used to illuminate the parking brake indicator on the instrument panel when the parking brake is applied. This switch is also used to illuminate the vehicle brake lights and service brake light indicator whenever the parking brake is applied.

The electrical contacts in the switch are held closed by spring pressure until the air brake system pressure below the diaphragm overcomes the 60 psi pressure setting of the switch spring.

#### 5.10.3.2.Operation

When air pressure at the supply port and under the diaphragm is above 60 psi, the electrical contacts remain open because the air pressure underneath the diaphragm overcomes the pressure exerted by the spring above the diaphragm.

When the parking brake is applied and air pressure below the diaphragm drops below 60 psi, the spring pressure overcomes the air pressure below the diaphragm. The diaphragm moves and closes the electrical contacts, illuminating the dash-mounted parking and service brake and also illuminating the brake lights.

#### 5.10.3.3.Removal

- Set the Battery Disconnect switch to the OFF position.
- Drain the air system to remove pressure in the lines.
- Open the access door below the driver's side window and locate the pressure switches installation. See "Fig. 8-23: Pressure & Stop Switches Installation" on page 79.
- 4. Disconnect the electrical connector from the switch being replaced.
- Remove the switch from the threaded fitting.






Fig. 8-23: Pressure & Stop Switches Installation

#### 5.10.3.4.Installation

- 1. Install switch into threaded fitting.
- 2. Connect electrical connector to switch.
- 3. Close access door.

4. Set Battery Disconnect switch to ON position.

# 5.10.3.5.Leakage Test

With air pressure present at the supply port, coat the pressure switch with soap solution. No leakage permitted.



#### 5.10.3.6. Operating Test

- 1. Repeat Leakage Test.
- Ensure the Battery Disconnect switch is ON.
- Locate the rear switch box in the engine compartment. Set the Engine Run switch to the FRONT position.
- 4. Position the Master Run switch on the driver's area side console to DAY-RUN.
- Apply the parking brake. When the parking brake system pressure drops below 60 psi, the contacts on the pressure switch should close, causing the dash-mounted parking and service brake indicators to illuminate.
- 6. If the dash indicators do not illuminate, check switch operation as follows:
  - a. Ensure Battery Disconnect switch is OFF (for example no power to vehicle).

- b. Drop system pressure below 60 psi.
- c. Open the side console access door on the streetside of the vehicle. Locate the parking Brake/Stop Light switch mounted on Spring Brake Control Valve. The contacts on this pressure switch should be in a closed position, due to the drop in system pressure. Position can be verified by measuring resistance at the switch as follows:
- Disconnect the electrical connector.
- ☐ Using an ohmmeter, measure the resistance across the switch terminals. Reading should be zero ohms. Reconnect pressure switch. If the pressure switch contacts do not close when system pressure drops below 60 psi, the ohmmeter will read infinite resistance. Replace switch, and repeat operating test.



# 5.10.4. Brake Tank Pressure Sending Units

#### 5.10.4.1.Description

The pressure transducers are ruggedly constructed of stainless steel cylindrical bodies that enclose one-piece stainless steel sensing elements. The sensors have threads and wrench surfaces at one end and a sealed electrical connector at the opposite end. They are mounted directly on the brake system air tanks.

#### 5.10.4.2.Brake Tank Pressure Sending Units Specifications

Pressure Range	0 - 150 psi
Supply Voltage	10 - 32 VDC
Output Voltage	1 - 5 VDC
Supply Current	<10mA
Thread	1/4 NPT

#### 5.10.4.3.Operation

The pressure transducers transmit an analog signal to the vehicle's multiplexing system. The multiplexing system converts the analog signal into pressure readings are displayed on individual instrument panel gauges corresponding to each brake system air tank. The LED indicator on the gauge face will illuminate and a warning buzzer will sound if the air pressure drops below 70 psi.

#### 5.10.4.4.Removal

- 1. Set the Battery Disconnect switch to the OFF position.
- Drain the air system to remove pressure in the lines.
- Obtain access to the air tank behind the aisle light panels.
- 4. Disconnect the electrical connector from the transducer.
- 5. Remove the transducer.

#### 5.10.4.5.Installation

- Inspect the threads to be sure they are not damaged or contain slivers, burrs, dirt or other contaminants.
- Apply Loctite 567 evenly, without air pockets, around the circumference of the thread, leaving the first 1/2 to 1 1/2 threads clean while completely covering a minimum of the next three threads.

#### ™NOTE:

Ensure the sensor port remains unblocked by thread sealant.

- 3. Install the pressure transducer and finger tighten.
- 4. Using a wrench, fully tighten the transducer two full turns past finger-tight.



# 6. EMERGENCY & PARKING BRAKE SYSTEM COMPONENTS



When working on or around air brake systems and components, the following precautions should be observed:

- □ ALWAYS block vehicle wheels. Stop engine when working under a vehicle. Make certain to drain air pressure from all reservoirs before beginning any work on the vehicle. Depleting vehicle air system pressure may cause vehicle to roll. Keep hands away from chamber push rods; they may apply as system pressure drops.
- □ NEVER connect or disconnect a hose or line containing air pressure. It may whip as air escapes. NEVER remove a component or pipe plug unless you are certain all system pressure has been depleted.
- NEVER exceed recommended air pressure and ALWAYS wear safety glasses when working with air pressure. NEVER look into air jets or direct them at anyone.
- □ NEVER attempt to disassemble a component until you have read and understand recommended procedures. Some components contain powerful springs and injury can result if not properly disassembled. Use only proper tools and observe all precautions pertaining to use of those tools.
- ☐ Use only approved replacement parts and components.
  - Only components, devices, mounting and attaching hardware specifically designed for use in air brake systems should be used.
  - □ Replacement hardware, tubing, hose, fittings and so forth, should be of equivalent size, type, length, and strength as the original equipment.

- Make certain that when replacing tubing or hose, all supports, clamps or suspending devices that were originally installed are reinstalled or replaced if they are missing.
- Devices with stripped threads or damaged parts should be replaced. Repairs requiring machining should not be attempted.



Using alcohol in the air brake system as a means to dry the air or prevent system freezing during cold weather is not acceptable. Studies indicate that alcohol removes the lubrication from the system components, causing faulty system function. Also, the materials used for the seals in these components are not alcohol-safe and will deteriorate at an accelerated rate leaving the brake system prone to failure. Using alcohol or alcohol-based fluids in your air brake system will void the warranty on these components.

# 6.1. Emergency Brake Release Valve



Refer to "WARNING" and "CAUTION" at the beginning of "Emergency & Parking Brake System Components" when performing maintenance on these components.

# 6.1.1. Description

The push pull control valve, located on the parking brake tower on the side of the side console switch panel, is used to release the rear spring brakes after they have been automatically applied after an emergency. This limited operation allows the operator to move the vehicle to a safe area.

# **Emergency Brake Release Valve**

#### 6.1.2. Operation

The valve supplies air pressure from the emergency release tank through the spring brake control valve to release the spring brakes. The spring brakes will automatically apply if the air system pressure drops below 40 psi.

To operate the control valve, push down and hold down. This will allow air pressure to release the brakes. Releasing the valve knob shuts off the air supply and allows the rear spring brakes to reapply.



The emergency release valve is for emergency use only. DO NOT drive the vehicle with defective brakes.

#### 6.1.3. Removal



Securely block and/or hold the vehicle by a means other than the air brakes and drain all reservoirs.

- 1. Open the side console to gain access to the parking brake components.
- Drive the button roll pin out with a punch and remove the button. See "Fig. 8-24: Emergency Release Valve Assembly" on page 84.
- 3. Disconnect and tag the three air lines to the valve.
- 4. Hold the release valve and remove the panel mounting nut, remove the valve from inside the side console panel.

#### ™NOTE:

If the valve is being replaced, remove the three elbow connections and fit to the new valve. Ensure that the elbows are aligned correctly.






Fig. 8-24: Emergency Release Valve Assembly

#### 6.1.4. Installation

Installation is the reverse of removal. Ensure that the valve is located correctly for connection of the air lines.

#### 6.1.5. Disassembly

- Remove the two cap screws which retain the lower cover and remove cover. Remove the sealing ring.
- 2. Insert a small punch through the roll pin hole in the stem and remove the lock nut with a 7/16" wrench.
- Remove inlet-exhaust valve, plunger and spring.
- 4. Remove O-ring from plunger.

#### RNOTE:

Assemble in the reverse order to disassembly.

#### 6.1.6. Operating & Leakage Test

- Connect a 120 psi air source to the supply port. Insert an accurate test gauge into the supply line and provide a means of controlling the supply pressure. A small volume supply, with a gauge, should be connected to the delivery port.
- 2. With a 120 psi supply pressure, the button pulled out (exhaust position), leakage at the exhaust port or plunger stem should not exceed a 1" bubble in 5 seconds. There should be no leakage between the upper and lower body.
- Push the button in and manually hold in this position. Leakage at the exhaust port or plunger stem should not exceed a 1" bubble in 3 seconds.



# 6.2. Parking Brake Control Valve



Refer to "WARNING" and "CAUTION" at the beginning of "Emergency & Parking Brake System Components" when performing maintenance on these components.

#### 6.2.1. Description

The parking brake control valve is a pushpull manually operated control valve with an exhaust function. See "Fig. 8-25: Parking Brake Control Valve Cross Section" on page 85.




Fig. 8-25: Parking Brake Control Valve Cross Section

#### 6.2.2. Operation

When the valve is pulled UP in the APPLY position, air is exhausted from the emergency side of the brake chambers which allows the rear brake chamber springs to extend and apply the brakes.

When the valve is pushed DOWN, air is supplied via various valves to the rear spring brake chambers. This compresses the springs in the chambers and releases the brakes.

The parking brake control valve is in the APPLIED position if there is no air in the system, above 40 psi (276 kPa) the valve can be moved to the RELEASED position.

#### 6.2.3. Removal



Securely block and/or hold the vehicle by a means other than the air brakes and drain all reservoirs.

- Remove the screws from parking brake tower close-out panel and remove panel.See "Fig. 8-26: Parking & Emergency Release Valve Installation" on page 86.
- Drive button roll pin out with a punch and remove button.
- 3. Remove and tag three air lines to valve.
- Remove panel mounting nut and remove valve.

#### ™NOTE:

If the valve is being replaced, remove the three elbow connections and fit to the new valve. Ensure that the elbows are aligned correctly.






Fig. 8-26: Parking & Emergency Release Valve Installation



#### 6.2.4. Installation

Installation is the reverse of removal. Ensure that the valve is located correctly for connection of the air lines.

#### 6.2.5. Disassembly

- Remove two cap screws retaining lower cover and remove cover. Remove sealing ring.
- 2. Insert a small punch through roll pin hole in stem and remove lock nut with a 7/16"

- wrench. See "Fig. 8-27: PP-1 Parking Brake Control Valve Assembly" on page 87.
- 3. Remove inlet-exhaust valve and plunger and spring.
- 4. Remove O-ring from plunger.

#### ™NOTE:

Assemble in the reverse order to disassembly.




Fig. 8-27: PP-1 Parking Brake Control Valve Assembly

# **Parking Brake Control Valve**



# 6.2.6. Operating & Leakage Test

- Connect a 120 psi air source to the supply port. Insert an accurate test gauge into the supply line and provide a means of controlling the supply pressure. A small volume supply, with a gauge, should be connected to the delivery port.
- 2. With a 120 psi supply pressure, the button pulled out (EXHAUST position), leakage at the exhaust port or plunger stem should not exceed a 1" bubble in 5 seconds. There should be no leakage between the upper and lower body.
- 3. Push the button in. Leakage at the exhaust port or plunger stem should not exceed a 1" bubble in 3 seconds.
- Reduce the supply pressure, at a pressure of 40 psi the button should pull out automatically, exhausting the delivery pressure.

#### ™NOTE:

If the valve fails to operate correctly or if leakage is excessive it should be replaced with a New Flyer replacement part.



# 7. ACCESSORIES, SUSPENSION, LEVELING & KNEELING SYSTEM COMPONENTS



When working on or around air brake systems and components, the following precautions should be observed:

- □ ALWAYS block vehicle wheels. Stop engine when working under a vehicle. Make certain to drain air pressure from all reservoirs before beginning any work on the vehicle. Depleting vehicle air system pressure may cause vehicle to roll. Keep hands away from chamber push rods; they may apply as system pressure drops.
- NEVER connect or disconnect a hose or line containing air pressure. It may whip as air escapes. NEVER remove a component or pipe plug unless you are certain all system pressure has been depleted.
- □ NEVER exceed recommended air pressure and ALWAYS wear safety glasses when working with air pressure. NEVER look into air jets or direct them at anyone.
- □ NEVER attempt to disassemble a component until you have read and understand recommended procedures. Some components contain powerful springs and injury can result if not properly disassembled. Use only proper tools and observe all precautions pertaining to use of those tools.
- ☐ Use only approved replacement parts and components.
  - Only components, devices, mounting and attaching hardware specifically designed for use in air brake systems should be used.

- □ Replacement hardware, tubing, hose, fittings and so forth, should be of equivalent size, type, length, and strength as the original equipment.
- Make certain that when replacing tubing or hose, all supports, clamps or suspending devices that were originally installed are reinstalled or replaced if they are missing.
- Devices with stripped threads or damaged parts should be replaced. Repairs requiring machining should not be attempted.



Using alcohol in the air brake system as a means to dry the air or prevent system freezing during cold weather is not acceptable. Studies indicate that alcohol removes the lubrication from the system components, causing faulty system function. Also, the materials used for the seals in these components are not alcohol-safe and will deteriorate at an accelerated rate leaving the brake system prone to failure. Using alcohol or alcohol-based fluids in your air brake system will void the warranty on these components.

# 7.1. Leveling Valves



Refer to "WARNING" and "CAUTION" at the beginning of "Accessories, Suspension, Leveling & Kneeling System Components" when performing maintenance on these components.

# ™NOTE:

Refer to Section 1 and Section 2 of this manual for ride height adjustment procedures.



#### 7.1.1. Description

Three leveling valves are installed on this vehicle and used in the leveling process. Two are mounted at the rear axle and one at the front axle. Each of the valves is equipped with a pressure inlet port, an exhaust port and two outlet ports to supply air to the suspension bellows. The Front axle valve uses only one outlet port to supply the left and the right suspension bellows via the kneeling valve. A position sensor is also attached to the rotary control shaft of the front leveling valve. This sensor is used for properly kneeling and returning the vehicle to ride height. Refer to 7.2. "Kneeling Valve" on page 94 in this section for more information on this component. Refer to 3. "AIR SYSTEM" on page 3 in this section for complete information on leveling valve air flow and operation.

Each valve has a control lever attached to the valve's rotary control shaft. The lever is connected to a linkage that attaches to the vehicle structure. During suspension movement the linkage will either lift the lever up or push the lever down. This movement of the lever causes the control shaft to rotate either clockwise or counterclockwise.

#### 7.1.2. Operation

When the suspension moves down, due to a load placed on the vehicle, the lever will be forced upwards rotating the shaft and thus opening the inlet port to the bellows. This will allow compressed air to fill the bellows causing the vehicle to rise. This rising motion will cause the lever to move down and the control shaft to again rotate and close the ports when the vehicle has reached its operating position. The opposite will occur when the vehicle suspension moves up as it loses its load or weight.

The position sensor, on the front leveling valve, sends a signal to the vehicle's multiplexing system which is used during the kneeling process to lower the vehicle.

#### 7.1.3. Removal



During component removal or installation, ensure the Battery Disconnect switch is in the OFF position.



Before disconnecting any leveling valve air lines, securely support body by placing blocks under vehicle at jack pads. Refer to the General Information Section of this manual for further information on raising the vehicle.

Exhaust air from air supply system by opening drain cock in suspension air tank. After the above precautions have been taken remove leveling valve as follows:

- Disconnect valve over-travel lever from the valve link. Pull lever downward to release compressed air from bellows. See "Fig. 8-28: Front Leveling Valve Installation" on page 91. See "Fig. 8-29: Rear Leveling Valve Installation" on page 92.
- Disconnect air supply line and bellows air line from valve. Tape ends closed.
- 3. Disconnect the electrical connector from the valve sensor (front valve only).
- Remove washers and locknuts attaching valve to mounting bracket and remove valve assembly.






Fig. 8-28: Front Leveling Valve Installation

Rev. A - Jul 27 2015






Fig. 8-29: Rear Leveling Valve Installation





- Valve Assembly, Leveling Streetside (Incl. 2-5)
- 2. Elbow, 90° 1/2" O.D. x 1/4" PT
- 3. Valve, Leveling
- 4. Connector, 3/8" O.D. x 1/4" MPT
- 5. Loctite, 567 White
- 6. Valve Assembly, Leveling Curbside (Incl. 7-13)
- 7. Elbow, 90° 1/2" O.D. x 1/4" PT

- 8. Valve, Leveling
- 9. Adapter, Tee 1/4" PT
- 10. Connector, 3/8" O.D. x 1/4" MPT
- 11. Connector, 1/2" O.D. x 1/4" PT
- 12. Valve, Single Check
- 13. Loctite, 567 White
- 14. Link Assembly, Leveling Valve
- 15. Loctite, 243 Blue
- 16. Nut, Hex Lock Steel 1/4" 20 UNC

- 17. Bolt, Hex SST 1/4" - 20 UNC x 1" Lg.
- 18. Nut, Hex 1/4" 20 UNC
- 19. Bracket, Curbside Leveling Valve
- 20. Bracket, Streetside Leveling Valve
- 21. Washer, Flat SST 1/4"
- 22. Adhesive, SIKA 221 White
- 23. Tube, Nylon 3/8" Blue

Rear Leveling Valve Installation (parts list)

# 7.1.3.1. Air Leakage Test - Valve Removed

# ™NOTE:

The valve must be removed from vehicle for this check.

- 1. Clean exterior of control valve assembly.
- 2. Connect air pressure line to air inlet port, then open the air pressure (80 to 110 psi).
- Submerge valve assembly in a container of water, then watch for air bubbles when the over-travel lever is in the center position. No air should escape from any point of control valve assembly.
- If bubbles appear from the bellows port, the air inlet valve assembly is defective and must be replaced.
- 5. Remove air pressure line from air inlet fitting and connect it to bellows port. If bubbles appear at the air inlet check valve port, check valve unit is defective and must be replaced.

#### 7.1.4. Installation

- Before installing valve, ensure that the air line fittings are clean and undamaged. Replace line connector rubber gaskets if deteriorated or damaged.
- Do not USE sealing compound on threads. Sealer is unnecessary, and if used, may cause valve cores to stick.
- Absolute cleanliness is essential when installing valves. Dirt and sealing compound must be kept out of valves. Even minute particles of foreign matter may become lodged in valve cores or flapper valves and may seriously affect operation of suspension system.

#### 4. Install the valve as follows:

- a. Position valve on mounting bracket.
   Attach with locknuts and washers and tighten to torque. Refer to the General Information Section of this manual.
- b. Connect air supply line to air inlet adapter. Connect bellows air line to bellows adapter. Tighten air line fittings firmly.
- c. Connect electrical connector to the position sensor (front valve only).
- d. Connect valve over-travel lever to valve link. Build up air pressure in system and test for leaks with soapy water solution.

# 7.1.4.1. Air Leakage Test - Valve Installed

#### ™NOTE:

This Air leakage check can be done while valve is installed on the vehicle. In either case (testing on or off the vehicle) air system pressure must be applied to valve.

- Submerge the exhaust line of the valve in a container of water.
- 2. If air bubbles escape with the handle in the center position (normal position), valve is faulty and must be replaced.
- Apply soapy water to body, housing and around shaft.
- 4. If bubbles appear, valve is faulty and must be replaced.



# 7.2. Kneeling Valve



Refer to "WARNING" and "CAUTION" at the beginning of "Accessories, Suspension, Leveling & Kneeling System Components" when performing maintenance on these components.

#### 7.2.1. Description

The kneeling valve is a normally closed (N.C.) four solenoid operated valve, which is used to control the kneeling operation. The kneeling valve is located behind the front axle on the curbside of the vehicle and is accessed from the underside of the vehicle.

# 7.2.2. Operation


Setting the Kneel switch, located on the instrument panel, to the LOWER position energizes the KNEEL solenoid on the kneeling valve and provides a direct path between the (ABL), (ABR), and (EX) ports. This allows air to exhaust from the air springs and the vehicle to lower.

Setting the Kneel switch to the RAISE position energizes the raise solenoid on the kneeling valve and provides a direct path between the (P), (ABR), and (ABL) ports. This allows supply air a direct path to the air springs and allows a quick fill of the air springs to raise the vehicle toward normal ride height.

#### 7.2.3. Kneeling Valve Port Designations

The kneeling valve consists of a multi-port body with four solenoids located on the manifold. The port designations and function are as follows:

KNEELING VALVE PORT DESIGNATIONS		
PORT I.D.	FUNCTION	
Р	Supply pressure from accessory tank	
PS	Alternate supply port, not used	
ABL	Delivery pressure to left side air springs	
ABR	Delivery pressure to right side air spring	
LVL	Delivery port to leveling valve	
LVR	Delivery Port to Leveling Valve	
EX	Exhaust port to atmosphere	





#### 7.2.4. Maintenance

Maintenance on the kneeling valve is limited to replacement of the solenoids, gaskets, and O-rings. The O-rings and gaskets are available as a repair kit. Refer to your New Flyer Parts Manual for part ordering information.

#### 7.2.5. Removal

- Set the Battery Disconnect switch to the OFF position.
- 2. Drain the air system to remove pressure in the lines. See "Fig. 8-30: Front Kneeling Valve Installation" on page 96.

- Locate the kneeling valve. Refer to 7.2.1. "Description" on page 94 in this section the for location.
- 4. Disconnect the three solenoid electrical connectors from the kneeling valve.
- Disconnect and tag all air lines from the valve.
- Remove fasteners that attach mounting bracket to vehicle and remove the kneeling valve, and bracket as an assembly from the vehicle.






Fig. 8-30: Front Kneeling Valve Installation





#### 7.2.6. Installation

- 1. Install kneeling valve and bracket assembly to vehicle using original fasteners.
- Install all air lines to kneeling valve. See "Fig. 8-31: Kneeling Valve Assembly" on page 98.
- 3. Plug in the electrical connectors from the three solenoids to the vehicle harness.
- 4. Set the Battery Disconnect switch to the ON position.
- 5. Start the vehicle and charge the air system to operating pressure.
- Check for air leaks at the kneeling valve connections.
- 7. Operate the Kneel switch through lowering and raising cycles to ensure the kneeling valve is functioning properly.






Fig. 8-31: Kneeling Valve Assembly



# **Electrical System**

	SAFETY	9-1
	1.1. Safety Procedures	9-1
	1.2. Welding Procedures	
	•	
2.		
	2.1. Description	9-2
	2.2. VMM 1615	9-4
	2.2.1. Description	
	2.2.2. Removal	
	2.2.3. Installation	
	2.2.4. VMM 1615 Troubleshooting	
	2.3. J1939 Controller Area Network (CAN) Cable	
	2.3.1. Description	
	2.3.2. CAN Cable Troubleshooting	9-6
3.	ELECTRICAL SYSTEM	9-8
	3.1. Description	
	3.2. Electronic Control Modules	
	3.2.1. Description	
	3.2.1. Description	9-0
4.	CHARGING SYSTEM	9-9
	4.1. Description	9-9
	4.2. Alternator	9-9
	4.2.1. Description	
	4.2.2. Alternator Specifications	
	4.2.2. Alternator Specifications	9-9
		9-9 9-11
	4.2.3. Operation	9-9 9-11 9-11
	4.2.3. Operation	9-9 9-11 9-11 9-11
	4.2.3. Operation 4.2.3.1. Overview 4.2.3.2. Electrical Power Generation 4.2.4. Alternator Troubleshooting 4.2.4.1. Alternator Resistance Values	9-9 9-11 9-11 9-12 9-14
	4.2.3. Operation 4.2.3.1. Overview 4.2.3.2. Electrical Power Generation 4.2.4. Alternator Troubleshooting 4.2.4.1. Alternator Resistance Values 4.2.5. Removal	9-9 9-11 9-11 9-12 9-14
	4.2.3. Operation  4.2.3.1. Overview  4.2.3.2. Electrical Power Generation  4.2.4. Alternator Troubleshooting  4.2.4.1. Alternator Resistance Values  4.2.5. Removal  4.2.6. Disassembly	9-99-119-119-129-149-15
	4.2.3. Operation 4.2.3.1. Overview 4.2.3.2. Electrical Power Generation 4.2.4. Alternator Troubleshooting 4.2.4.1. Alternator Resistance Values 4.2.5. Removal 4.2.6. Disassembly 4.2.6.1. Pulley & Fan	9-9 9-11 9-11 9-12 9-14 9-15 9-17
	4.2.3. Operation 4.2.3.1. Overview 4.2.3.2. Electrical Power Generation 4.2.4. Alternator Troubleshooting 4.2.4.1. Alternator Resistance Values 4.2.5. Removal 4.2.6. Disassembly 4.2.6.1. Pulley & Fan 4.2.6.2. Rear Cover	9-9 9-11 9-11 9-12 9-14 9-15 9-17 9-17
	4.2.3. Operation 4.2.3.1. Overview 4.2.3.2. Electrical Power Generation 4.2.4. Alternator Troubleshooting. 4.2.4.1. Alternator Resistance Values 4.2.5. Removal. 4.2.6. Disassembly. 4.2.6.1. Pulley & Fan 4.2.6.2. Rear Cover 4.2.6.3. F1 & AC Connector Replacement	9-9 9-11 9-11 9-12 9-15 9-17 9-18
	4.2.3. Operation 4.2.3.1. Overview 4.2.3.2. Electrical Power Generation 4.2.4. Alternator Troubleshooting. 4.2.4.1. Alternator Resistance Values 4.2.5. Removal 4.2.6. Disassembly. 4.2.6.1. Pulley & Fan 4.2.6.2. Rear Cover 4.2.6.3. F1 & AC Connector Replacement 4.2.6.4. Power & Ground Studs	9-9 9-11 9-11 9-12 9-15 9-17 9-18 9-19 9-19
	4.2.3. Operation 4.2.3.1. Overview 4.2.3.2. Electrical Power Generation 4.2.4. Alternator Troubleshooting. 4.2.4.1. Alternator Resistance Values 4.2.5. Removal. 4.2.6. Disassembly. 4.2.6.1. Pulley & Fan 4.2.6.2. Rear Cover 4.2.6.3. F1 & AC Connector Replacement	9-9 9-11 9-11 9-12 9-15 9-17 9-18 9-19 9-19
	4.2.3. Operation 4.2.3.1. Overview 4.2.3.2. Electrical Power Generation 4.2.4. Alternator Troubleshooting 4.2.4.1. Alternator Resistance Values 4.2.5. Removal 4.2.6. Disassembly 4.2.6.1. Pulley & Fan 4.2.6.2. Rear Cover 4.2.6.3. F1 & AC Connector Replacement 4.2.6.4. Power & Ground Studs 4.2.6.5. Front & Rear Exciter Leads	9-9 9-11 9-11 9-12 9-14 9-15 9-17 9-18 9-19 9-19
	4.2.3. Operation 4.2.3.1. Overview 4.2.3.2. Electrical Power Generation 4.2.4. Alternator Troubleshooting 4.2.4.1. Alternator Resistance Values 4.2.5. Removal 4.2.6. Disassembly 4.2.6.1. Pulley & Fan 4.2.6.2. Rear Cover 4.2.6.3. F1 & AC Connector Replacement 4.2.6.4. Power & Ground Studs 4.2.6.5. Front & Rear Exciter Leads 4.2.6.6. Front Frame	9-9 9-11 9-11 9-12 9-14 9-15 9-17 9-18 9-19 9-19 9-19

# Table of Contents



	4.2.6.9. Stator Housing Separation	
	4.2.6.10.Rectifier & Rear Frame Separation	
	. Inspection	
	Assembly	
	4.2.8.1. Rectifier & Rear Frame	
	4.2.8.2. Stator Housing	
	4.2.8.3. Rotor & Exciters	
	4.2.8.4. Front Frame & Rotor	
	4.2.8.5. Rotor/Front Frame Assembly & Stator	
	4.2.8.7. Pulley & Fan	
	1. Installation	
	ternator Special Tools	
	•	
	. Alternator Special Tools Chart	
	oltage Regulator	
4.4.1	and the second s	
4.4.2	Voltago i togalato: Troabiconcotting imminimi	
4.4.3		
4.4.4	Replacement	9-34
5. ELEC	TRICAL STARTING SYSTEM	0-35
	escription peration	
•		
	emoval	
5.4. Ma	aintenance	9-37
5.4.1	. Lubrication	9-37
5.4.2	Brush Inspection	9-37
5.4.3	Brush Removal	9-37
5.4.4	Brush Installation	9-37
5.5. Ele	ectrical Starting System Troubleshooting	9-38
5.5.1	. Starter Circuit Inspection	9-38
5.5.2	·	
5.5.3	No-Load Test Result	9-39
5.5.4	Starter Solenoid Switch Troubleshooting	9-39
5.6. Dis	sassembly	9-41
5.6.1	. Inspection, Tests & Repair of Starter	9-43
5.6.2		
5.6.3		
5.6.4		
5.6.5		
5.6.6		
5.6.7	=	
5.6.8	_	
5.6.9	•	
	5.6.9.1. Removal	
	5.6.9.2. Installation	
	ssembly	
	stallation	
2.3		

9 - ii



6.	<b>BATTE</b>	RY SYSTEM	9-50
	6.1. Des	scription	9-50
		ttery Disconnect Switch	
		Description	
		npstart Installation	
		Description	
		sebox Assembly	
		Description	
	6.4.2.	•	
		tteries	
	6.5.1.		
	6.5.2.	Batteries Specifications	
	6.5.3.	Removal	
	6.5.4.	Installation	
	6.5.5.	Inspection	
	6.5.6.	Possible Causes of Battery Failure	
	6.5.7.	Filling Battery	
	6.5.8.	•	
	6	.5.8.1. Slow Charging	9-56
		.5.8.2. Fast Charging	
		.5.8.3. Emergency Boost Charge	
	6.5.9.		
	6.5.9.1. Visual Inspection		
		J. Specific Gravity (Hydrometer) Test	
		nperature Indicator	
		Description	
	6.6.2.	·	
	6.6.3.	·	
	6.6.4.	Removal	
	6.6.5.	Installation	
		tage Equalizer	
	6.7.1.	• .	
	6.7.2.	·	
	6.7.3.	Operation	
	6.7.4.	·	
	6.7.5.	Replacement Procedure	
7.	FXTFR	RIOR LIGHTS	9-64
••	7.1. Headlights		
	7.1.1.	Description	
	7.1.2.	Operation	
	7.1.3.	Removal	
	7.1.4.	Installation	9-66
	7.1.5.	Headlight Aiming	9-68
	7.1.6.	Headlight Aiming (Alternate Procedure)	9-71

# Table of Contents



8.	INTERIOR LIGHTS	9-73
	8.1. Aisle Lights	9-73
	8.1.1. Description	
	8.1.2. Aisle Lights Specifications	
	8.1.3. Operation	
	8.1.4. Aisle Lights Troubleshooting	
	8.1.4.1. Troubleshooting Tips	
	8.1.5. Dimming Adjustments	
	8.1.6.1. Lens	
	8.1.6.2. LED Lighting Board	
	8.1.6.3. Finger Board	
	8.1.7. Installation	9-79
	8.1.7.1. Lens	
	8.1.7.2. LED Lighting Board	
	8.1.7.3. Finger Board	9-79
9.	DOOR MASTER SWITCH	9-80
	9.1. Description	
	9.2. Operation	
	9.3. Functional Tests	
	9.3.1. Normal Operation Test	
	9.3.2. Emergency Operation Test	
	9.4. Door Master Switch Troubleshooting	
4.0		
10	. HORNS & WARNING ALARMS	
	10.1. Electric Horn	9-82
	10.1.1. Description	
	10.2. Warning Alarms	9-82
		0.00
11	. DRIVER/VEHICLE MONITORING SYSTEM	
	11.1. Description	9-83
	11.2. Operation	9-84
12	. AUTOMATIC VEHICLE ANNOUNCEMENT & AUTOMATIC	
	VEHICLE LOCATOR (AVA/AVL) SYSTEM	9-85
	·	
13	. AUTOMATIC PASSENGER COUNTER (APC) SYSTEM	9-86
	13.1. Description	9-86
	·	
14	. VIDEO SURVEILLANCE SYSTEM	9-87
	14.1. Power On/Off	9-88
	14.2. Driver Alert Box	
	14.3. WIFI Radio Mobile Network / Direct Connection Network	
	indication income incom	5-50





15. VIDEO SYSTEM	9-89
15.1. Video System Controller	
15.2. Display Screen	
16. ELECTRICAL SYSTEM SCHEMATICS	9-90
16.1. General	9-90
16.2. Reading Schematics	
16.3. Wire Codes	
16.4. Wire Colors	
16.5. Page Codes	
16.6. Device Nomenclature	
17. VENDOR SERVICE INFORMATION	9-93
17.1 Vanco Manuals	0-03







# 1. SAFETY

# 1.1. Safety Procedures

When performing different types of repair to this vehicle special precautions must be taken. Failure to follow these recommendations and procedures could result in injury or severe damage to vehicle and its components.

☐ Cordon off, mark or use a clearly defined area to work on the vehicle. The purpose of this is to warn personnel that the vehicle is being worked on and it can start at anytime.

Do not start the vehicle with the PC link without first checking that the area is clear of personnel.

# 1.2. Welding Procedures



Before welding anywhere on vehicle, open the Battery Disconnect switch and disconnect all electronic control modules (Multiplexing, engine, transmission, ABS, and so forth). Refer to Section 11 of this manual for additional precautionary information.



# 2. MULTIPLEXING SYSTEM

# 2.1. Description

# ™NOTE:

Refer to the Multiplexing System Layout when reviewing this information.

The Vehicle Multiplexing Module (VMM) system uses a series of remotely-mounted, Controller Area Network (CAN)

connected modules to transmit information and operate components throughout the vehicle. The system consists of several VMM 1615 solid state modules located throughout the vehicle. See "Fig. 9-1: Rear Panel" on page 2. See "Fig. 9-2: Exit Door Module Installation" on page 3. See "Fig. 9-3: Side Console Module Installation" on page 3. The modules are interconnected by a shielded CAN communication cable which is part of the wiring harness.




Fig. 9-1: Rear Panel






Fig. 9-2: Exit Door Module Installation




Fig. 9-3: Side Console Module Installation



#### 2.2. VMM 1615

#### 2.2.1. Description

The VMM1615 is a general purpose electronic controller. It has 16 inputs and 15 outputs as well as two CAN/J1939 communication ports.

The VMM1615 has seven digital inputs; five of the inputs are used for reading active high/low signals, one input is used for reading active high signals, and one input is used for active high power control. In addition, it has eight inputs capable of reading analog voltages, and one DC coupled frequency input.

The VMM1615 has 12 high-side outputs with a maximum Pulse Width Modulation (PWM) frequency of 500 Hz, four of which are capable of accurate current sensing. It also has one low-side output that is capable of current sensing with a maximum PWM frequency of 1500 Hz, and two solid state relay outputs. These outputs can

drive a variety of load types. Built to meet and exceed SAE J1455 environmental standards with enhanced diagnostics and Windows-based ladder logic programming. The modules are plug and play configurable, and have status LEDs that indicate the condition of inputs, outputs, power, and network activity.

The VMM 1615 is equipped with four colorcoded connectors and two high-current power connection points. Connectors J5 and J6 are the high-current power source for the output circuits on the module. Connector J1 (Brown) is an input, output and network connector. Connector J2 (Grey) is an input and output connector. Connector J3 (Green) is an input and output connector. And J4 (Black) contains inputs, outputs and addressing inputs for module configuration. Each module contains a set of diagnostic LEDs which can be used to monitor the inputs and outputs, input power and controller area network (CAN) activity. See "Fig. 9-4: VMM 1615 Module" on page 4.




Fig. 9-4: VMM 1615 Module



#### 2.2.2. Removal

- Open access door or remove panels as required to access module.
- 2. Identify harness connector positions at module.
- Carefully unplug harness connectors from center of module.
- 4. Carefully unplug power connectors from the end of the module.
- Remove four screws and any other hardware retaining the module to the panel and remove the module.

#### 2.2.3. Installation

- Position module on panel, install retaining screws and tighten.
- 2. Install any auxiliary mounting hardware.
- 3. Plug harness connectors into module.
- 4. Plug power connectors in ensuring locking tabs snap into position.
- Install removed panels and close access doors.

#### 2.2.4. VMM 1615 Troubleshooting

The VMM 1615 module has 16 input LEDs, 15 output LEDs, a Standby LED, 2 Network Status LEDs and a power/health indicator LED. The PWR LED has three states, ON, OFF and FLASHING. When the PWR LED is on solid the unit is operating correctly. If the PWR LED is off the module is not receiving power or it is in the power save mode. If the PWR LED is flashing a fault has been detected on one of the outputs.

The NET LED flashes when there is network communication between two or more units in the system. If the NET LED is not flashing, there is a problem with the network cabling. To verify the network cable, measure the resistance between pins 8

and 9 and 10 and 11 on the Brown J1 harness connector. Ohmmeter should indicate approximately 60 ohms resistance. If the measured reading deviates from this value, check for the following:

- Missing terminating resistor in the network cable.
- Bad connections at the network cable Y splices.
- ☐ Broken wire in the network cable.

The input LEDs have an ON and OFF state. If an input LED is ON, the corresponding input for the LED is active. If the LED is OFF the input is inactive. Refer to "ES-I/O Assignment" in the Vehicle Systems Drawing Manual to determine the type and voltage level for each input prior to testing. If there is no change of potential when the input changes from inactive to active, the input device or wiring is defective. Digital inputs must have a ground potential to be activated. Inputs programmed as analog require 0.5 volts to activate the input. Inputs programmed as frequency require a 10 Hz or greater signal to activate.

The output LED's have three states, ON, OFF and FLASHING. If an output LED is ON, the corresponding output for the LED is active. If the LED is OFF the output is inactive. If the LED is flashing the corresponding output is faulted. Five types of faults will cause an output LED to flash:

- Short circuit to power.
- ☐ Short circuit to ground.
- Over current.
- Open load.

Refer to 17. "VENDOR SERVICE INFOR-MATION" on page 93 in this section for more diagnostic and troubleshooting information on the VMM 1615 module.



# 2.3. J1939 Controller Area Network (CAN) Cable

#### 2.3.1. Description

The various ECU's and VMM modules used in the vehicle communicate information using a standard protocol called the SAE J1939 Recommended Practice for Serial Control and Communication Vehicle Network (SAE J1939 CAN). The driveline J1939 network consists of engine, transmission, and ABS ECU's and is separate from the VMM J1939 network, which consists of the VMM 1615 module. Refer to "ES-Network Topology" and "Multiplexing System Layout" for lead connections.

The J1939 network cables consist of twisted pair, shielded cables that connect the various ECU's or VMM modules located throughout the vehicle. Each end of the network cable is terminated with a 120 ohm resistor to reduce reflections of the electrical signals.

#### 2.3.2. CAN Cable Troubleshooting

- Troubleshoot the driveline J1939 network cable as follows:
  - a. Attempt to read the engine, transmission, and ABS codes at each of the diagnostic connectors (engine compartment switchbox, and driver's area). The network cable is intact between the nine-pin diagnostic connector and the ECU if diagnostic codes can be read at each of the diagnostic connectors.
  - b. Set the Battery Disconnect switch to the OFF position.
  - Disconnect the network cable from all driveline ECU's. This is necessary as the ECU's can affect the resistive measurement.

d. Refer to Electrical Schematic "ES-Engine EN" and check continuity of the entire network cable loop between the CAN "+" and CAN "-" wires using an Ohmmeter. Loop resistance should measure 60 Ohms.

## ™NOTE:

The diagnostic connectors located behind the driver's seat or on the engine compartment switch box are convenient places to take the reading.

- e. Check for an open or missing terminating resistor if the loop resistance measures 120 Ohms. Although each resistor is 120 Ohms, they are installed in parallel and the combined resistance value would be 60 Ohms.
- f. Check for an open circuit (break in the wiring) if the Ohmmeter reading indicates infinity or an "out of limits" value. Check for a poor electrical connection if a significant resistance value is measured.
- g. Remove the terminating resistors from either end of the network cable.
- h. Check the CAN "+" wire for continuity by connecting one lead of the Ohmmeter to the CAN "+" terminal at one end of the network cable. Run a jumper wire from the CAN "+" terminal at the opposite end of the cable and connect the other end of the jumper wire to the remaining lead on the Ohmmeter. No significant resistance should be measured.
- If significant resistance or an open condition is measured, move the jumper lead down the network cable to each connector and retest at the connector until the fault is isolated.
- j. Repeat the previous steps for the CAN "-" wire.



# J1939 Controller Area Network (CAN) Cable

- Troubleshoot the VMM J1939 network cable as follows:
  - a. Set the Battery Disconnect switch to the OFF position.
  - Disconnect network cable connections from all VMM's, and SCU, as resistance values could be affected during cable continuity tests.
  - c. Refer to Electrical Schematic "ES-Primary Networks PN" and check continuity of the entire network cable loop between the CAN "+" and CAN "-" wires using an Ohmmeter. Loop resistance should measure 60 Ohms.

## ™NOTE:

The CAN "+" and CAN "-" wires can be easily accessed from any module location where the network cable has been disconnected.

d. Check for an open or missing terminating resistor if the loop resistance measures 120 Ohms. Although each resistor is 120 Ohms, they are installed in parallel and the combined resistance value would be 60 Ohms.

- e. Check for an open circuit (break in the wiring) if the Ohmmeter reading indicates infinity or an "out of limits" value. Check for a poor electrical connection if a significant resistance value is measured.
- f. Remove the terminating resistors from either end of the network cable.
- g. Check the CAN "+" wire for continuity by connecting one lead of the Ohmmeter to the CAN "+" terminal at one end of the network cable. Run a jumper wire from the CAN "+" terminal at the opposite end of the cable and connect the other end of the jumper wire to the remaining lead on the Ohmmeter. No significant resistance should be measured.
- h. If significant resistance or an open condition is measured, move the jumper lead down the network cable to each connector and retest at the connector until the fault is isolated.
- i. Repeat the previous steps for the CAN "-" wire.



# 3. ELECTRICAL SYSTEM

# 3.1. Description

The electrical system is a 12/24 VDC split system, negatively grounded. All components are rated at 12 or 24 Volts DC depending on the system in which they are employed. Care should be taken to ensure all replacement parts are clearly identified on their nameplates as being 12 or 24 Volts rated.

Severe damage to the alternator, regulator, battery cables, starter and so forth may result if the battery is not connected "Negative" to ground. Turn off battery disconnect switch before replacing or servicing a battery.

Ensure cables are securely tightened to battery posts and charging system components. All ground connection points should be checked periodically to ensure proper grounding is maintained.

Circuit breakers and wire gauges are sized based on the individual circuit current requirements. Replacements should be of the same rating and size.

Never replace a wire with one of a smaller size. All wires are color coded with wire markers on both ends to identify circuit function. Harness routing and tie wrapping should be periodically inspected to ensure the system is maintained.



DO NOT turn off the main disconnect switch, or disconnect the battery, or use a defective battery while the engine is running. When this occurs a substantial "load dump" could result that would damage electrical components. "Load dumps" in the electrical system are normally absorbed by the battery.

#### 3.2. Electronic Control Modules

#### 3.2.1. Description

This vehicle is equipped with engine, transmission, and ABS multiplexing equipment. These control modules have preprogrammed diagnostic and control capabilities. Refer to Section 4 and 5 of this manual for engine and transmission control module function and support information. Refer to Section 1 and 2 of this manual for information on the ABS control module.

The +24 VDC electrical bus bar (refer to Electrical Schematics) provides the power source for the engine Electronic Control Module (ECM), and the ABS Electronic Control Unit (ECU).

These control modules also provide direct input to instrument panel warning indicators such as Check Engine, Stop Engine, and ABS Fail.



New Flyer Industries will assume no responsibility for alterations or substitutions to the electrical system without prior authorization from our engineering department.



# 4. CHARGING SYSTEM

# 4.1. Description

The charging system is made up of the alternator and voltage regulator. The function of the charging system is to provide 24V to the electrical/multiplexing system and to recharge the battery system.

# ™NOTE:

Refer to 6. "BATTERY SYSTEM" on page 50 in this section for more information on this component.

#### 4.2. Alternator

#### 4.2.1. Description

This vehicle is equipped with a heavy-duty 450 Amp brushless alternator. The alternator is bracket-mounted on the front of the engine and is belt-driven through the accessory drive pulley. Cooling air is provided to the rear cover of the alternator through a remote mounted air intake box and connecting hose.

The alternator unit consists of a rotor, two stationary exciters (field windings), stator assembly, rectifier assembly, two aluminum frames, rear cover, and a front fan. The two aluminum frames support the rotor and bearings and also accommodate the attachment to the engine mounting cradle. The stator is installed between the front and rear frames and the three pieces are bolted together. The rear cover provides an air inlet duct and access to the power, ground, FI, and AC terminals. The front fan is mounted on the end of the rotor shaft and draws cooling air through the alternator housing. See "Fig. 9-5: Alternator Assembly" on page 10.

#### 4.2.2. Alternator Specifications

Manufacturer EMP Advanced Development LLC
ModelPower 450 w/isolated ground
Rated Voltage28 VDC
Nominal Amps 450 Amps @ 28 VDC
Maximum Continuous Speed6500 RPM
Cooling Air-cooled, front-mounted integral fan
Weight 100 lbs. (45 Kg)






Fig. 9-5: Alternator Assembly



#### 4.2.3. Operation

#### 4.2.3.1. Overview

The brushless alternator operates using a rotating component, called the rotor, which is first magnetized by two stationary exciters (field windings). The magnetized rotor turns within a stationary set of conductors wound in coils called the stator. The rotor's magnetic field cuts across the stator's conductors, generating a source of electrical AC power. The alternator's rectifier converts the AC power into DC power.

#### 4.2.3.2. Electrical Power Generation

The alternator has two field windings or exciters. The exciters are axially aligned by the bearings and the front and rear frames. The front exciter is bolted to the front frame and the rear exciter is bolted to the rear frame. The exciters are stationary field windings with each exciter being positioned in close proximity to the rotor's inner diameter. Each exciter winding has one of the wires terminated to the F1 connector and the other exciter lead is internally grounded.

When the F1 connector is supplied a modulated voltage by the voltage regulator, both exciter coils create a magnetic field which in turn is induced into the rotor. As the magnetized rotor's unique geometry turns inside of the stator, the rotors magnetic field cuts across the stator's conductors and generates electrical AC power. The stator has four independent windings with each stator winding having three wires or conductors which allows for the generation of 3-phase AC power. The four stator windings are wound independently to allow a level of redundancy, as well as to evenly balance the electrical torque induced that is generated during transformer action. This results in smoother operation.

The process of rectifying the AC power into DC power is handled inside the alternator by the rectifier assembly. The rectifier assembly consists of two aluminum castings and four diode bank assemblies, one for each stator winding. The outer aluminum casting is the negative or ground ring and the inner casting is the positive ring. Each of the three stator wires is terminated to a set of diodes, one positive and one negative. Each diode bank has three positive diodes and three negative diodes, for a total of 24 diodes. A diode is a solid state device that allows current to flow in one direction only. The four diode banks are connected to the positive and negative cast rings in a parallel circuit. The rectifier assembly creates a relatively smooth and stable DC output without any moving parts.

There are four electrical connections on the alternator rear cover: the positive (+) output stud, the negative (-) or ground stud, the field winding connection (F1) and the AC connection. The AC harness is connected to one of the 12 stator wires and is used to indicate when the alternator is charging.



#### 4.2.4. Alternator Troubleshooting

# ™NOTE:

The following checks can be performed with the alternator installed on the vehicle. Use a digital multimeter to check all voltage and resistance values. See "Fig. 9-6: Alternator Electrical Schematic" on page 13.

- Remove the alternator belt and attempt to rotate the alternator shaft.
  - a. If the alternator shaft does not rotate freely, the alternator will need to be disassembled and examined to determine the level of repair required.
  - If the alternator rotates freely, but has no output, proceed with the following checks.
- 2. Check AC connector to ensure connector is clean, properly tightened, and wiring harness is not damaged.
- Check F1 connector to ensure connector is clean, properly tightened, and wiring harness is not damaged.
- Verify F1 is receiving 24-28 VDC signal. If not, troubleshoot the voltage regulator or vehicle charging system. Refer to 4.4. "Voltage Regulator" on page 32 in this section for more information on this component.
- 5. Check resistance between the F1 terminal and the ground stud. Refer to 4.2.4.1. "Alternator Resistance Values" on page 14 in this section for specification. Check resistance between the AC terminal and the ground stud. Refer to 4.2.4.1. "Alternator Resistance Values" on page 14 in this section for specification.
- Check resistance between the positive stud and the ground stud. Refer to 4.2.4.1. "Alternator Resistance Values" on page 14 in this section for specification.

# ™NOTE:

The following procedures will require removal of the alternator from the vehicle and partial disassembly.

- Remove rear cover of alternator and disconnect the exciter leads. Refer to 4.2.6.2.
   "Rear Cover" on page 18 in this section for rear cover removal procedure.
- Measure the resistance of both front and rear exciter leads and verify they are within specification. Refer to 4.2.4.1. "Alternator Resistance Values" on page 14 in this section for specification.

#### ™NOTE:

Ensure that the resistance is being measured across the white and red leads from each exciter.

 Disconnect the twelve stator leads from the rectifier assembly. Ensure these leads are completely separated from the rectifier assembly, otherwise the measurements will not be valid and diode damage may occur.



ALWAYS follow the manufacturer's Safety Information when using a Megohmmeter.

- 10. Measure the insulation resistance on all twelve stator leads using a Fluke 1587 Megohmmeter or equivalent.
  - a. Connect the meter's positive lead to the stator lead and connect the meter's negative lead to the stator's steel frame.
  - Set the meter at 250V and measure the resistance. Refer to 4.2.4.1. "Alternator Resistance Values" on page 14 in this section for specification.



- 11.Measure the insulation resistance on both the front and rear exciter coils using a Fluke 1587 Megohmmeter or equivalent.
  - a. Connect the meter's positive lead to either exciter lead and connect the meter's negative lead to the exciter's steel frame.
  - b. Set the meter at 250V and measure the resistance. Refer to 4.2.4.1. "Alternator Resistance Values" on page 14 in this section for specification.
- 12. Test the rectifier diodes using a multimeter on the diode setting.

#### ™NOTE:

A bad diode will be indicated by a continuous tone with a readout of "0.000", or the readout will indicate any number value other than "0.400 - 0.600", or the readout will display "OL".

- a. Connect the negative lead of the diode tester to the positive stud on the rectifier assembly. Connect the positive lead of the diode tester to the stator lead. Repeat test for all twelve stator leads Refer to 4.2.4.1. "Alternator Resistance Values" on page 14 in this section for specification.
- b. Connect the positive lead of the diode tester to the negative stud on the rectifier assembly. Connect the negative lead of the diode tester to the stator lead. Repeat test for all twelve stator leads Refer to 4.2.4.1. "Alternator Resistance Values" on page 14 in this section for specification.
- 13.If all measurements are within specification, then reassemble alternator and verify its operation on a calibrated test stand.




Fig. 9-6: Alternator Electrical Schematic



## 4.2.4.1. Alternator Resistance Values

	ALTERNATOR RESISTANCE VALUES	
LOCATION	RESISTANCE	
F1 Terminal	DMM (-) lead on Ground stud, DMM (+) lead on F1 = 4.1 ± 0.2 ohms	
	DMM (+) lead on Ground stud, DMM (-) lead on F1 = $4.1 \pm 0.2$ ohms	
AC Terminal	DMM (-) lead on AC, DMM (+) lead on Ground stud > 1 kilo ohm	
	DMM (+) lead on AC, DMM (-) lead on Ground stud > 1 kilo ohm	
Positive Stud to Ground Stud	DMM (-) lead on Ground stud, DMM (+) lead on Positive stud > 1 kilo ohm	
Oldd	DMM (+) lead on Ground stud, DMM (-) lead on Positive stud > 1 kilo ohm	
Front Exciter	8.2 ± 0.4 ohms	
Rear Exciter	8.2 ± 0.4 ohms	
Rectifier Diodes	Positive stud to stator lead = 0.5 ± 0.1V	
	Negative stud to stator lead = 0.5 ± 0.1V	
Stator Insulation Test @ 250V	> 1 mega ohm	
Exciter Insulation Test @ 250V	> 1 mega ohm	



#### 4.2.5. Removal

- 1. Set the Battery Disconnect switch to the OFF position.
- 2. Open the rear exterior engine access door and swing open the belt guard.
- 3. Remove the air intake tube that crosses in front of the alternator by removing the U-clamp, and loosening the T-clamps at either end.



DO NOT cut the drive belt to remove it as the spring loaded pulley will snap back violently. This could result in personal injury or damage the pulley stop and render it unserviceable.

4. Release belt tension and remove the alternator drive belt. See "Fig. 9-7: Alternator Removal & Installation" on page 16.

#### ™NOTE:

Use a 1/2" breaker bar to rotate the tensioner pulley upwards and relieve belt tension.

- 5. Enter the interior of the vehicle and raise and secure the rear passenger seat.
- Raise and secure the interior engine access door.

- Remove the two lock nuts and washers that secure the power cable bracket to the rear of the alternator.
- Loosen the T-clamp that secures the rubber elbow to the rear of the alternator and pull back the elbow.
- 9. Unplug the "F1", and "AC" wire connectors from the rear of the alternator.
- 10. Remove the 1/2" nuts and washers that secure the power and ground cables to the terminals on the rear of the alternator.
- 11. Return to the rear of the vehicle and remove the four mounting bolts and washers that attach the alternator to the engine mounting bracket.



Use appropriate lifting equipment to remove the alternator. The alternator weighs 100 lbs. (45 kg).

12. Carefully lift and slide the alternator off the mounting bracket and remove unit from the vehicle.

#### ™NOTE:

The use of a forklift, with the forks drawn together, provides a cradle for the alternator and allows for easy removal from the vehicle.






Fig. 9-7: Alternator Removal & Installation



#### 4.2.6. Disassembly

Assess the condition of the alternator before attempting to disassemble the unit. If the rotor is seized or unable to be rotated, it is unlikely the alternator can be rebuilt. Disassembly may be very difficult and many of the parts inside may not be repairable.

 Use the Base Fixture (Item 4 from Alternator Special Tools List) to support the alternator.

## ™NOTE:

Install a lifting eye or 1/2"-13 bolt into one of the threaded bushings in the front base. Rotate the alternator so that the bolt contacts the base fixture. This technique can be used to resist rotation of the alternator when removing or installing bolts during the repair process.

Mark the alignment of the front and rear frame to the stator housing prior to disassembly. These marks will be used during reassembly to ensure correct orientation of these parts

#### 4.2.6.1. Pulley & Fan

- 1. Use a hammer and chisel to carefully bend back and flatten the locking tab washer.
- Remove the pulley nut, tab lock washer, and flat washer. Discard the tab lock washer. See "Fig. 9-8: Pulley & Fan Removal" on page 18.

#### ™NOTE:

Removal of the pulley nut may require the use of an impact wrench. Wear protective gloves and grasp the fan to keep the shaft from rotating while operating the impact wrench.

3. Mark the front face of the pulley and use a puller (Item 7 from Alternator Special Tools List) to remove the pulley from the shaft.



DO NOT pry the fan off the shaft. The fan is cast aluminum and can be damaged easily if excessive force is used.

4. Slide the fan off the shaft.






Fig. 9-8: Pulley & Fan Removal

#### 4.2.6.2. Rear Cover

- 1. Remove the nuts and washers from the power and ground studs.
- Release the wire terminal from the connector shell on both the "F1" and "AC" connectors.

## ™NOTE:

Use Delphi tool #12014012 (or commercial equivalent) to release terminal from connector.

- 3. Remove the four M6 bolts from the rear cover of the alternator.
- 4. Push the "F1" and "AC" wire lead rubber grommets inward to remove them from the rear cover.
- Use a rubber mallet and carefully tap the rear cover to separate it from the rear frame.
- Slide off the rear cover until it is completely removed. See "Fig. 9-9: Rear Cover Removal" on page 18.




Fig. 9-9: Rear Cover Removal



#### 4.2.6.3. F1 & AC Connector Replacement

#### ™NOTE:

It is recommended to replace the F1 and AC harness and grommets during repair. The following procedure applies to both the AC and F1 harnesses.

- Remove the 8 mm nut that attaches the harness terminal to the rectifier assembly.
- 2. Remove the 8 mm nut that attaches the harness clamp to the rectifier assembly.
- Remove the harness from the rectifier assembly.
- 4. Installation is the reverse of removal. Install new grommets in the rear cover.

#### 4.2.6.4. Power & Ground Studs

Inspect the power and ground studs for any evidence of thread damage. Replace studs at this time if necessary.

#### 4.2.6.5. Front & Rear Exciter Leads

- Note the location of the exciter leads (white wires) at the ground stud and disconnect the ring terminals from the exciter assembly.
- Note the location of the exciter leads (red wires) at the F1 stud and disconnect the ring terminals from the exciter assembly.
- 3. Cut away the two plastic wire ties from the exciter leads sheathing.
- 4. Straighten the ring terminals on the front and rear exciter leads to allow easier removal and insertion through the stator housing.

#### 4.2.6.6. Front Frame

- 1. Scribe mark the alignment of the front frame to the stator housing.
- 2. Remove and discard the six M8 x40 socket head bolts from the center of the front frame. These bolts attach the front frame to the front exciter.

#### ™NOTE:

Ensure that the socket of the bolt head is clean and that the hex drive bit fully enters the bolt head socket before trying to remove the bolts.

3. Remove the eleven M6 x 140 bolts and washers from the outer edge of the front frame. These bolts attach the front frame to the rear frame.

### ™NOTE:

Ensure that the flat washers do not remain stuck to the front frame.

- 4. Ensure that the front and rear exciter ring terminals have been disconnected from the rectifier as previously described. Refer to 4.2.6.5. "Front & Rear Exciter Leads" on page 19 in this section for procedure.
- Use the front frame puller (Item 1 from Alternator Special Tools List) to remove the front frame, front bearing, and front exciter. See "Fig. 9-10: Front Frame Puller" on page 20.
  - a. Install three M8 x 60 flange head bolts into the front frame, utilizing every other bolt hole. Tighten all three bolts evenly until the puller tool is flush with the frame.
  - b. Use an impact wrench with a 3/4" socket to remove the front frame. Ensure that the tool threads are greased.

# ™NOTE:

The disassembly process will damage the front bearing and a new bearing will be required during assembly.

- Mark the location of the front exciter wires with respect to the slots within the stator housing as the front frame is being removed from the stator housing.
- 7. Remove the P-clip that supports the front exciter wires inside the front frame. See "Fig. 9-11: P-Clip Removal" on page 20.

## ™NOTE:

Support the front exciter so that it doesn't fall when removing the P-clip.

- 8. Separate the front exciter from the front frame by tapping them apart.
- Remove the bearing from the front frame.
   If necessary, use a large socket to press the front bearing out of the front frame.
   Discard the front bearing, as the removal process damages the bearing.






Fig. 9-10: Front Frame Puller




Fig. 9-11: P-Clip Removal

#### 4.2.6.7. Rotor Removal

- Remove the six M8 x 35 bolts that attach the rear frame to the rear exciter. See "Fig. 9-12: Rear Exciter Bolts" on page 21.
- Install the rotor removal tool (Item 2 from Alternator Special Tools List) onto the end of the alternator. See "Fig. 9-13: Rotor Removal" on page 21.

# ™NOTE:

The rotor removal tool includes a specially modified front frame.

Install the flat washer and nut onto the threaded end of the rotor.



DO NOT use an impact wrench in the following step.

4. Use a 3/4" socket to evenly tighten the two 1/2" puller bolts to ensure the rotor is pulled straight.

#### ™NOTE:

Ensure that the threads on the puller tool are greased.

- 5. Continue tightening puller bolts evenly until the rotor contacts the front frame.
- Remove the nut and flat washer and then remove the entire rotor puller tool from the alternator.
- Carefully slide the rotor out of the stator housing, ensuring that the previously removed rear exciter wires pass easily through the rear frame. Note the location of the exciter wires with respect to the slot in the rear frame.

#### ™NOTE:

If the rear bearing or stator bearing bore is damaged, it is unlikely that the alternator is repairable. Stop further repair work.






Fig. 9-12: Rear Exciter Bolts

Fig. 9-13: Rotor Removal

s122730a.svg

## 4.2.6.8. Rear Exciter & Bearing Removal

- 1. Assemble the Front Bearing Support Tool (Item 3 from Alternator Special Tools List) into the Base Fixture (Item 4 from Alternator Special Tools List)
- 2. Insert the splined end of the rotor into the Front Bearing Support Tool.
- 3. Use the Rear Bearing Puller (Item 5 from Alternator Special Tools List) to remove the rear exciter and bearing as a unit from the rotor assembly. See "Fig. 9-14: Rear Exciter Removal" on page 21.
  - a. Insert three M8 x 60 flange head bolts through the bearing puller and into the rear exciter utilizing every other bolt hole. Tighten all three bolts evenly until the puller tool is flush with the rear bearing.
  - b. Use an impact wrench on the hex head of the puller screw to remove the rear exciter/bearing from the rotor shaft.




Fig. 9-14: Rear Exciter Removal



## 4.2.6.9. Stator Housing Separation

- Remove all the twelve stator winding ring terminals from the rectifier assembly, being careful not to twist the diode terminals. Use needle-nose vise grips to keep the diode terminals from twisting while loosening the nuts. See "Fig. 9-15: Stator Terminals Removal" on page 22.
- 2. Carefully separate the stator housing from the rectifier assembly.

## 4.2.6.10.Rectifier & Rear Frame Separation

- Remove the fourteen M6 x 25 bolts attaching the rectifier to the rear frame. See "Fig. 9-16: Rectifier Removal" on page 22.
- Separate the rectifier assembly from the rear frame. Discard the isolator gasket and scrape clean any silicone from the mounting surfaces See "Fig. 9-17: Rectifier Separation" on page 22.
- Remove and discard O-ring and spring washer from inside bearing seat in rear frame.




Fig. 9-16: Rectifier Removal




Fig. 9-15: Stator Terminals Removal




Fig. 9-17: Rectifier Separation



#### 4.2.7. Inspection

- Measure the front bearing journal on the rotor. The front journal specification is 40.002 to 40.013 mm. Replace rotor assembly if journal wear exceeds specification.
- Measure the rear bearing journal on the rotor. The rear journal specification is 35.002 to 35.013 mm. Replace rotor assembly if journal wear exceeds specification.
- Measure the front bearing bore in the front frame assembly. The front bearing bore specification is 90.000 to 90.035 mm. Replace rotor assembly if journal wear exceeds specifications
- Measure the rear bearing bore in the rear frame assembly. The rear bearing bore specification is 72.000 to 72.030 mm. Replace rotor assembly if journal wear exceeds specification

### 4.2.8. Assembly

#### 4.2.8.1. Rectifier & Rear Frame

- Assemble the rectifier onto the rear side of the rear frame using a new isolator gasket and silicone provided in the repair kit as follows:
  - a. Apply a thin layer of silicone to the entire surface of the isolator gasket and install the gasket onto the rectifier assembly.
  - b. Apply another thin layer of silicone to the other side of the gasket
  - c. Install the rectifier/gasket assembly onto the rear frame.
- 2. Apply Loctite-242 to the fourteen M6 x 25 bolts and secure the rectifier to the rear frame. Torque bolts to  $80 \pm 8$  in-lb.  $(9 \pm 0.9$  Nm) in a star pattern.
- 3. Install a new O-ring and spring washer into the bearing seat of the rear frame. See "Fig. 9-18: O-Ring & Washer Installation" on page 23.




Fig. 9-18: O-Ring & Washer Installation

#### 4.2.8.2. Stator Housing

- Align the stator housing with the rear frame using the alignment marks made during disassembly.
- Apply Loctite-242 to all stator winding stud terminals
- Install the twelve ring terminals onto diode terminals and secure with washers and nuts. Torque nuts to 44 ± 4 in-lb. (5 ± 0.5 Nm). See "Fig. 9-19: Stator Terminal Installation" on page 24.

#### ™NOTE:

Use needle-nose vise grips to keep the diode terminals from twisting while tightening the nuts.






Fig. 9-19: Stator Terminal Installation

#### 4.2.8.3. Rotor & Exciters



ALWAYS use the special tools designed specifically for pressing on the bearings.

- 1. Assemble the Front Bearing Support Tool with the Base Fixture (Items 3 & 4 from Alternator Special Tools List).
- Position the splined end of the rotor assembly into the Front Bearing Support Tool.

3. Place the rear exciter into the back side of the rotor assembly.

#### ™NOTE:

The rear exciter can be identified as the exciter with the shorter wire leads.

- Lubricate the rotor rear bearing seat with 90W oil and place the rear bearing onto the rotor shaft.
- Use the Rear Bearing Press Tool (Item 6 from Alternator Special Tools List) and press the bearing onto the rotor shaft until fully seated. See "Fig. 9-20: Rear Bearing Installation" on page 25.

#### ™NOTE:

The rear bearing must be pressed flush to the machined step on the rotor.

- 6. Reverse the position of the rotor as follows so that the drive end is facing up:
  - a. Lift the rotor assembly from the Base Fixture and replace the Front Bearing Support Tool with the Rear Bearing Support Tool (Item 6 from Alternator Special Tools List).
  - b. Position the rotor assembly so that the rear bearing is supported with the Rear Bearing Support Tool.
- 7. Place the front exciter (longer wire leads) onto the rotor assembly.
- 8. Lubricate the front bearing inner race or rotor shaft with 90W oil and place the front bearing on the rotor shaft.
- Use the Front Bearing Press Tool (Item 3 from Alternator Special Tools List) to press the front bearing inner race onto the rotor assembly until fully seated. See "Fig. 9-21: Front Bearing Installation" on page 25.






Fig. 9-20: Rear Bearing Installation

# FRONT BEARING PRESS TOOL FRONT EXCITER ROTOR REAR BEARING PRESS/SUPPORT TOOL \$122715b.svg

Fig. 9-21: Front Bearing Installation

#### 4.2.8.4. Front Frame & Rotor

- Use the Rear Bearing Support Tool and Base Fixture (Items 6 & 4 from Alternator Special Tools List) to support the rotor assembly with the splined end of the shaft facing upwards.
- Place the front frame onto the drive end of the rotor assembly while aligning the P-clip mounting hole with the front exciter lead.
- 3. Apply Loctite-242 to the threads of the six new M8 x 40 bolts and install bolts through the center bolt holes of the front frame and into the threaded holes of the front exciter. Torque bolts to  $142 \pm 14$  in-lb. ( $16 \pm 1.6$  Nm) using a star pattern. See "Fig. 9-22: Front Cover Installation" on page 25.




Fig. 9-22: Front Cover Installation



#### 4.2.8.5. Rotor/Front Frame Assembly & Stator

- Position the rotor/front frame assembly so that the splined end of the rotor is supported by the Front Bearing Support Tool and Base Fixture (Items 3 and 4 from Alternator Special Tools List).
- 2. Fasten the front exciter wire to the inside of the front frame using a P-clip. Apply Loctite-242 to the threads of the fastener.
- Use the Stator/Rear Frame Assembly Tool (Item 8 from Alternator Special Tools LIst) and support the stator/rear frame assembly from a hoist and position directly above the front frame and rotor assembly.
- 4. Use a small gauge wire to pull the front exciter wires through the previously marked location in the stator housing.
- Use another small gauge wire to pull the rear exciter wires through the rear frame to the same destination. See "Fig. 9-23: Exciter Wire Assembly" on page 26.
- Carefully lower the stator/rear frame assembly over the rotor assembly until the stator housing is within close proximity, but not yet resting on the front frame.
- 7. Use a 6" long #2 Phillips screwdriver, or similar tool, to align the threaded holes in the rear exciter with the bolt holes in the rear frame. Also align the markings on the front frame with the markings on stator housing.
- 8. Pull the exciter wires through as the stator housing is being lowered.
- Continue to lower the stator housing assembly over the rotor until the rear bearing is seated in the rear frame. Ensure marks made on the front frame and stator housing during disassembly are aligned.
- 10. Apply Loctite-242 to the six M8 x 35 bolts and install bolts through the bolt holes of the rear frame and into the threaded holes of the rear exciter. Torque bolts to  $17 \pm 2$  ft-lb. (23  $\pm$  2.3 Nm) using a star pattern. See "Fig. 9-24: Rear Frame Bolts" on page 27.

11.Apply Loctite-242 to the eleven M6 x 140 bolts and install bolts with washers into the outer row of bolt holes on the front frame. Torque bolts to  $80 \pm 8$  in-lb.  $(9 \pm 0.9 \text{ Nm})$  in a star pattern.

# ™NOTE:

Ensure that each bolt is installed with a flat washer and that no washers remained stuck to the front frame during disassembly.

- 12. Apply Loctite-242 to the exciter wire terminal studs on the rectifier.
- 13. Connect the two red exciter wires and the two white exciter wires to rectifier assembly as marked during disassembly. Torque nuts to  $44 \pm 4$  in-lb.( $5 \pm 0.5$  Nm). See "Fig. 9-25: Stator Connections" on page 27.
- 14. Secure exciter wires with wire ties at same location as removed.




Fig. 9-23: Exciter Wire Assembly




Fig. 9-24: Rear Frame Bolts




Fig. 9-25: Stator Connections

#### 4.2.8.6. Rear Cover

- 1. Position the rear cover above the exciter assembly and align the power and ground studs and mounting holes.
- Slide the rear cover toward the rectifier assembly while guiding the "F1" and "AC" wire leads through the cover.
- Press the "F1" and "AC" wire lead grommets into the holes in the rear cover from the inside.
- Press the rear cover onto the rectifier assembly until seated and carefully pull the "F1" and "AC" wire leads through the grommets
- 5. Apply Loctite-242 to the four M6 x 60 bolts and install bolts through the cover and into the rectifier assembly. Torque bolts to  $80 \pm 8$  in-lb. ( $9 \pm 0.9$  Nm).
- 6. Install the nuts and washers on the power and ground studs.
- 7. Reinsert the wire terminals into the Delphi connectors.

#### ™NOTE:

Spread the latching ears on the Delphi terminals so that they will lock into place on the connector housing.



## 4.2.8.7. Pulley & Fan

- Slide the fan onto the alternator shaft with the fan blades facing inward towards the alternator.
- Slide the pulley onto the alternator shaft with marked side facing outward from the alternator.



#### DO NOT reuse old tab lock washer.

- Install new flat washer, tab lock washer, and nut.
- Torque pulley nut to 180 to 215 ft-lb. (245 to 290 Nm).



Ensure tab lock washer is bent up against one of the flats on the pulley nut.

 Bend one side of the tab lock washer up against the flat of the pulley nut. See "Fig. 9-26: Tab Lock Washer Installation" on page 28.




Fig. 9-26: Tab Lock Washer Installation



#### 4.2.9. Installation



Use appropriate lifting equipment to install the alternator. The alternator weighs 100 lbs. (45 kg).

- Use appropriate lifting equipment, such as a forklift, and position the alternator on the engine mounting bracket.
- 2. Align the four holes in the bracket with the threaded holes in the alternator.
- Install four 1/2" mounting bolts and washers. Ensure transmission dipstick mounting bracket is secured by one of the mounting bolts. Torque the four mounting bolts to 65 to 74 ft-lb. (88 to 100 Nm).
- 4. Use a 1/2" breaker bar to rotate the belt tensioner pulley upwards and then carefully install the alternator drive belt over the accessory drive, idler, and alternator pulleys. Ensure the ribs of the belt are aligned with the pulley grooves then release belt tensioner.
- 5. Install the air intake tube and tighten the T-bolt clamps at either end. Torque T-bolt clamps to 60 to 75 in-lb.

Secure the air intake tube to the mounting bracket using a U-clamp.

#### ™NOTE:

Ensure the U-clamp cushion is properly installed between the air intake tube and mounting bracket. Tighten the U-clamp nuts evenly.

- 7. Close and latch the belt guard.
- 8. Move to the interior of the vehicle and connect the positive and negative cables to the alternator terminals and torque nuts to 30 to 35 ft-lb. (40 to 48 Nm).
- 9. Connect the "F1" and "AC" wire connectors to the vehicle wiring harness.
- 10. Attach the air intake rubber elbow to the rear cover and torque T-bolt clamp nut to 60 to 75 in-lb.
- 11.Install the power cable bracket on the rear cover of the alternator and secure with lock nuts and washers.
- 12.Close the interior engine access door and lower the rear seat.
- 13. Set Battery Disconnect switch to ON position
- 14. Start engine and check charging output using a voltmeter and ammeter.



# 4.3. Alternator Special Tools

# 4.3.1. Alternator Special Tools Chart

Refer to your New Flyer Parts Manual for tool part numbers. See "Fig. 9-27: Alternator Special Tools" on page 31.

SPECIAL TOOLS	DESCRIPTION
1	Puller, Front Frame/Exciter
2	Puller, Rotor
3	Press/Support Tool, Front Bearing
4	Base Fixture
5	Puller, Rear Exciter/Rear Bearing
6	Press/Support Tool, Rear Bearing
7	Puller, Pulley
8	Lifting Tool, Stator/Rear Frame Assembly






Fig. 9-27: Alternator Special Tools



# 4.4. Voltage Regulator



Over-charging a lead acid battery can produce explosive and hazardous gas. Any change in battery configuration from the equipment originally supplied on your New Flyer vehicle may require modification to the charging system voltage levels and battery service procedures to prevent overcharging and equipment damage.

## 4.4.1. Description

The voltage regulator is installed in the rear equipment box. It limits the alternator voltage to a preset value by controlling the alternator field current. The regulator is a sealed unit with an adjustment screw accessible on its face and an integral connector containing Ground, Field, Battery, Ignition and Sense terminals. The Ground terminal is connected to the rear equipment box ground bar. The Field terminal is connected to the alternator Field terminal. The Battery terminal is connected to the vehicle's 24 volt battery bus bar. The Ignition terminal is connected to the vehicle's Multiplexing System, and receives current once the vehicle has been running for three seconds. The Sense terminal is connected to the Battery Disconnect switch via a 2A inline fuse. See "Fig. 9-28: Regulator" on page 32.

Alternator operating voltage is determined by the regulator voltage adjustment. Once adjusted, the alternator voltage remains constant, and is unaffected by length of service, changes in temperature, or changes in alternator output and speed.




Fig. 9-28: Regulator



# 4.4.2. Voltage Regulator Troubleshooting

Trouble in the electrical charging system is usually indicated by one of two conditions an undercharged battery or an overcharged battery. Either condition can result from an improper voltage regulator setting. The ideal voltage setting is the one which will maintain the batteries in a fully charged condition with a minimum use of water.

A record of water usage and battery specific gravity checks over a service period of reasonable length will establish the ideal voltage setting for the vehicle involved. Where maintenance-free batteries are used, the absence of gassing indicates the voltage setting is satisfactory.

#### Undercharged Battery

If the batteries are undercharged and the alternator is producing the correct output, raise the regulator setting by 0.3 volts and check for an improved battery condition over a period of 48 hours. If the voltage cannot be adjusted, replace the regulator.

#### Overcharged Battery

If the batteries are overcharged and the alternator is producing the correct output, lower the regulator setting by 0.3 volts and check for an improved battery condition over a period of 48 hours. If the voltage cannot be adjusted, replace the regulator.

#### 4.4.3. Adjustment

To check the voltage setting, connect a voltmeter across the Battery and Ground terminals on the regulator, and clamp an ammeter around the DC cable at the alter-

nator. See "Fig. 9-29: Regulator Adjustment" on page 33.

Operate the engine at approximately 1000 RPM with an electrical load to produce a 30 amp output. The voltage reading should be  $28.5 \pm 0.3$  VDC.

The voltage should be steady. Adjust the setting by turning the adjusting screw clockwise to increase the voltage and counter-clockwise to decrease the voltage.




Fig. 9-29: Regulator Adjustment



## 4.4.4. Replacement

# ™NOTE:

Besides the adjustment procedure previously described, the unit is non-serviceable and should be replaced if defective. Proceed as follows:

- Gain access to the regulator in the engine compartment box. See "Fig. 9-30: Regulator Removal & Installation" on page 34.
- 2. Set the Battery Disconnect switch to the OFF position.

- 3. Disconnect the harness from the regulator.
- 4. Remove the four lock nuts and washers which secure the unit.
- 5. Remove the unit and install replacement with same mounting hardware.
- Connect vehicle wiring harness to regulator.
- 7. Set the Battery Disconnect switch to ON position.
- 8. Check voltage setting of replacement unit. Refer to 4.4.3. "Adjustment" on page 33 in this section for procedure.




Fig. 9-30: Regulator Removal & Installation



# 5. ELECTRICAL STARTING SYSTEM

# 5.1. Description

The starter is a heavy-duty unit, solenoid operated through an enclosed shift lever and equipped with a sprag-type over-running clutch. A removable plug in the shift lever housing permits adjustment of pinion clearance. The nose housing can be rotated to obtain a number of different solenoid positions with respect to the mounting flange.

Armature shaft is supported in bronze bushings at three points: in commutator end frame, in shift lever housing and in nose housing. Positive lubrication is provided at each bushing and contacts the armature shaft. A waste-filled oil reservoir for each wick provides a large oil supply.

O-ring seals are used between commutator end frame and field frame and between shift lever housing and field frame. A solenoid linkage seal and lip-type armature shaft seal (at shift lever housing) prevent entry of oil into solenoid case and starter main case.

Four brush holders mounted on the brush holder plate carry the one-piece brushes. As shown on internal wiring diagram, two sets of brushes are connected to the

ground terminal stud on commutator end frame; these connections are made through the brush holder mounting plate. The other two sets of brushes are insulated from mounting plate and connect to field coil leads.

# 5.2. Operation

# ™NOTE:

The Multiplexing System limits continuous starter operation to 14 seconds. The starter circuit is then disconnected for 60 seconds to allow the starter to cool down.

The solenoid windings are energized when the ignition start button is pushed. The resulting plunger and shift lever movement causes the pinion to engage the engine flywheel ring gear and the solenoid main contacts to close and cranking takes place. In case of butt engagement, the motor is not energized to prevent damage to the pinion and gear teeth.

When the engine starts, pinion overrun protects the armature from excessive speed until the switch is opened, at which time the return spring causes the pinion to disengage. When the engine starts, the "start" circuit is automatically broken by a starter control circuit (which is sensitive to alternator output). This prevents excessive overrun and damage to the drive and armature windings.



# 5.3. Removal

# ™NOTE:

Before removing starter, make preliminary checks.

1. Turn Battery Disconnect switch off.

- 2. Remove wires and cable from starter and solenoid. Tag all wiring for identification purposes when reinstalling starter.
- 3. Secure a suitable strap around the starter, then remove the three bolts and lock washers attaching starter to engine. Carefully remove starter. See "Fig. 9-31: Starter Motor Installation" on page 36.




Fig. 9-31: Starter Motor Installation



## 5.4. Maintenance

#### 5.4.1. Lubrication

All wicks and oil reservoirs should be saturated with SAE 20 oil and splines underneath the clutch should be lubricated with a light coat of SAE 20 oil, periodically, or at time of engine overhaul.

All connections should be kept clean and tight and brushes inspected for wear.

#### 5.4.2. Brush Inspection

 Remove the four (4) attaching bolts and separate the commutator end cap from field frame. Inspect brushes for wear.

When brushes are worn down to less than 1/2 their original length, they must be replaced. Original length is 3/4" (19.05 mm).

- Ensure that brush holders are clean and brushes are not binding in holders. The full brush surface should ride on the commutator to give proper performance.
- Check by hand to ensure that the brush springs are giving firm contact between the brushes and commutator. If springs are distorted or discolored, they should be replaced.
- Be sure all leads are secure in brushes and that terminal clips are properly soldered to leads.

#### 5.4.3. Brush Removal

- From the insulated/ground terminal, carefully noting orientation, remove all parts including the solenoid ground lead. Check the condition of insulators and sealing features and consider replacing them if they are damaged or excessively worn.
- 2. Remove the four (4) Commutator End (CE) screws and CE housing.

3. Remove the four (4) brush springs, four (4) brush screws, and four (4) brushes. This also releases the ground terminal and lead assembly.

#### 5.4.4. Brush Installation

- Install the four (4) brush springs, ensuring they are in the same position as removed. Hit or press on the spring face until it is completely seated.
- Install ground terminal and lead assembly. Attach the terminal's negative leads and negative brush leads to the brush plate with two (2) screws. Torque the screws 20 to 40 in-lb. (2.3 to 4.5 Nm).
- 3. Attach the positive brush and field leads to the brush plate with two (2) of the brush screws. Torque screws 20 to 40 in-lb. (2.3 to 4.5 Nm).
- Install the square fiber insulator onto the ground stud.
- Apply bearing type grease onto CE housing's inner diameter where the frame O-ring is seated and apply a small amount of SAE 20 oil into the bushing area.
- Install CE housing over the locator pins and CE screws, ensuring the square fiber washer is properly aligned with the antiturn feature on the CE housing.
- 7. Torque the CE screws 40 to 60 in-lb. (4.5 to 6.8 Nm).
- 8. First insert the small round fiber insulator and then the rubber bushing over the Insulated/ground stud into the hole on the CE housing. Installing the rubber bushing prior to installing the CE housing can pinch the bushing and destroy its sealing capabilities
- Install the large round fiber washer and the remaining parts in the same order as were removed. Torque the large nut on the ground stud 20 to 25 ft-lb. (27.0 to 33.8 Nm).



# 5.5. Electrical Starting System Troubleshooting

#### 5.5.1. Starter Circuit Inspection

- Before removing any unit in the cranking circuit for repair, the following preliminary checks should be made:
  - To ensure battery is fully charged, perform battery tests.
  - Wiring: Inspect wiring for damage.
     Inspect all connections for corrosion or looseness. Clean and tighten all cable connections as required.
  - c. Magnetic switch, solenoid and control switches: Inspect all switches to determine their condition. Connect a jumper lead around any switch suspected of being defective. If the system functions properly using this method, check and/ or replace the by-passed switch.
  - d. Motor: If the battery, wiring and switches are in satisfactory condition and the engine is known to be functioning properly, remove the starter motor. With starter motor removed from the engine, check to see that armature is not "frozen" in position by prying on the pinion with a screwdriver. Tight bushings, a bent armature shaft or a loose pole shoe screw will prevent the armature from turning freely. If the armature is frozen or does not turn freely, the motor should be disassembled and the problem corrected. However, if the armature rotates freely, the motor should be given the following no-load test before disassembly.

#### 5.5.2. Starter No-Load Test

To perform test, make test connections as follows:

- Connect an ammeter in series with the positive (+) cable from the two 12-volt batteries and the BAT terminal of the starter solenoid. See "Fig. 9-32: No-Load Test" on page 38.
- Connect a switch in the open position from the starter solenoid BAT terminal to the solenoid switch (S) terminal.

- Connect a lead from the starter commutator end terminal to battery negative (-) terminal.
- Connect a voltmeter from the solenoid motor (M) terminal to commutator end terminal on the starter motor.
- Install RPM indicator (tachometer) to end of armature shaft to determine armature RPM.
- Close the switch and note the RPM, current and voltage reading. It is not necessary to obtain the exact voltage specified.

Reading should be:

Volts - 20 Min. Amps - 50 Max. Amps - 90 Min. RPM - 6300 Max. RPM - 8400

 If exact voltage reading is desired, connect a carbon pile across one of the two 12-volt batteries to reduce voltage to specified value.




Fig. 9-32: No-Load Test



# **Electrical Starting System Troubleshooting**

#### 5.5.3. No-Load Test Result

- Rated current draw and no-load speed indicates normal condition of the starter motor.
- Low free-speed and high current draw indicates:
  - Excessive friction: tight, dirty, or worn bushings, bent armature shaft or loose pole shoes allowing armature to drag.
  - Shorted armature: this can be further checked on a growler after disassembly.
  - Grounded armature of fields: check further after disassembly.
- Failure of starter to operate with high current draw indicates:
  - a. A direct ground in the terminal or fields.
  - b. "Frozen" bushings. This should have been determined by turning the armature by hand.
- Failure to operate with no current draw indicates:
  - a. Open circuit: this can be checked after disassembly by inspecting internal connections and tracing circuit with a test lamp.
  - Open armature coils: inspect the commutator for badly burned bars after disassembly.
  - c. Broken brush springs, worn brushes, high insulation between the commutator bars or other causes which would prevent good contact between the brushes and commutator.
- Low no-load speed and low current draw indicates high internal resistance due to poor connections, defective leads, or commutator "varnish" and causes listed under step 4 preceding.
- High free-speed and high current draw indicates shorted fields. If shorted fields are suspected, replace the field coil assembly and check for improved performance.

# 5.5.4. Starter Solenoid Switch Troubleshooting

The basic solenoid circuit with dual windings is shown. The hold-in winding is connected from the (S) terminal to the (M) terminal.

- When the start switch is closed: both windings are energized and the magnetism produced by each acts together to strongly attract the plunger into the core. The pull-in winding current returns to the battery through the motor windings. See "Fig. 9-33: Solenoid Winding Check" on page 40.
- With the motor cranking: the hold-in winding magnetism is sufficient to hold the plunger in and the contact disc shorts out the pull-in winding, thereby avoiding excessive heat.
- 3. When the switch is opened: battery current flows through the contact disc to the (M) terminal and through the pull-in winding in the reverse direction and the hold-in winding in the normal direction. The two magnetic fields oppose and essentially cancel out each other. The return springs cause the solenoid to return to its original position thus completing the cranking cycle.
- 4. The solenoid can be checked electrically by connecting a battery of the specified voltage, a switch and an ammeter to the two solenoid windings. With all leads disconnected from the solenoid, make test connections as shown.
- ☐ Connect switch and ammeter to the (S) and (M) terminals.
- ☐ To reduce the voltage to the specified value, if needed, connect the carbon pile between the battery and (M) terminal as shown.
- If a carbon pile is not needed, connect a jumper directly from the battery to the (M) terminal.



To prevent overheating, DO NOT leave the pull-in winding energized more than 15 seconds. The current draw will decrease as the winding temperature increases.



An operational method is as follows:

- a. Connect battery to (S) terminal and to (G) terminal. See "Fig. 9-34: Testing Solenoid Winding" on page 40.
- b. A plunger inserted inside solenoid should be magnetically attracted. If not, hold-in winding is open.
- c. Connect battery to (S) terminal and to (M) terminal. See "Fig. 9-35: Testing Solenoid Pull-In Winding" on page 41. A plunger inserted inside solenoid should be magnetically attracted. If not, pull-in winding is open.
- d. Connect battery to (M) terminal and to (G) terminal. A plunger inserted inside solenoid should not be magnetically attracted. If it is, windings are shorted.
- e. Connect battery from (G) terminal to solenoid case or metal ground. A plunger inserted inside solenoid should not be magnetically attracted. If it is, windings are grounded.
- Solenoid requires no periodic maintenance other than keeping the terminals clean and tight.
- 6. Always check action of solenoid if it has been removed. If unit fails to function, first check wiring before condemning the solenoid. Solenoid windings can be checked for current draw, open circuit, or shorts. Adjust carbon pile for specified voltage reading, then record amperage reading.
- 7. A burned solenoid coil, excessively carbonized terminal contacts or contact disc should be replaced (contact disc can be reversed). Also check resistance between solenoid motor terminal stud and "hold-in" winding terminal lug, since oxidation sometimes insulates the terminal lug from the terminal stud (resistance should be no more than 0.2 ohms). Whenever solenoid is removed from the starter motor, pinion clearance must be checked and properly adjusted.




Fig. 9-33: Solenoid Winding Check




Fig. 9-34: Testing Solenoid Winding






Fig. 9-35: Testing Solenoid Pull-In Winding

## 5.6. Disassembly

Normally the starter motor should be disassembled only as far as necessary to repair or replace defective parts.



As a precaution, safety glasses should be worn when disassembling the starter motor.

 Note the relative position of the solenoid, lever housing, nose housing and commutator end for later reassembly. See "Fig. 9-36: Starter Motor Assembly" on page 42.

- 2. Disconnect field coil connector from solenoid motor terminal and ground return lead from solenoid.
- From the insulated/ground terminal, carefully noting orientation for reassembly, remove all parts including the solenoid ground lead. Check the condition of insulators and sealing features and consider replacing them if they are damaged or excessively worn.
- Remove the four (4) CE attaching screws and CE housing. If the armature thrust washer is struck to the CE housing hub, remove it and place it on the armature shaft.
- Remove the remaining insulators from the ground stud, carefully noting orientation for reassembly. Check the condition of insulators and sealing features and consider replacing them if they are damaged or excessively worn.
- 6. Remove attaching screws to separate brush plate assembly from field frame.
- Separate nose housing and field frame from lever housing by removing attaching bolts.
- 8. Remove pinion stop.
- 9. Remove armature and clutch assembly from lever housing.
- 10. Separate solenoid from lever housing by pulling apart.
- 11.It is not necessary to further disassemble starter unless parts require replacement. Refer to 5.6.1. "Inspection, Tests & Repair of Starter" on page 43 in this section for procedure.






Fig. 9-36: Starter Motor Assembly



## 5.6.1. Inspection, Tests & Repair of Starter



The drive assembly, armature and field frame and coils assembly should not be cleaned in any degreasing tank or with grease dissolving solution, Since these would dissolve the lubricant in the drive mechanism and damage the insulation in the armature and field coils.

All parts except the drive should be cleaned with mineral spirits and a brush. The drive should be wiped with a clean cloth.

NEVER use emery cloth to clean commutator.

#### 5.6.2. Brushes & Holders

Refer to 5.4.2. "Brush Inspection" on page 37 in this section for information on brush inspection and replacement.

#### 5.6.3. Armature

If the armature commutator is worn, dirty, out-of-round, or has high insulation, the armature should be put in a lathe and the commutator turned down.

The insulation should then be undercut 1/32" (0.794)mm) wide 1/32" deep and the slots cleaned out to remove any trace of dirt or copper dust. As a final step in this procedure, the commutator should be sanded lightly with No. 00 sandpaper to remove any burrs left as a result of the undercutting procedure. Do not cut deeper than necessary to remove rough spots or out-of-round condition.

Check the armature for open and/or short circuits and grounds as follows:

#### 1. Open circuit test

Open circuits are usually caused by excessively long cranking periods. The most likely place for an open circuit to occur is at the commutator riser bars. Inspect the points where the conductors are joined to the commutator bars for loose connections. Poor connections cause arcing and burning of commutator bars as the cranking motor is used. If the bars are not too badly burned, repair can often be done by soldering (or welding) the leads in the riser bars (using Rosin Flux) and turning down the commutator in a lathe to remove the burnt material. The insulation should then be undercut as noted previously.

#### 2. Short circuit test

Short circuits in the armature are located by the use of a growler. When armature is rotated in the growler with a steel strip such as a hacksaw blade held above it, the blade will vibrate above the area of the armature core in which the short circuit is located. Shorts between bars are sometimes produced by brush dust or copper between the bars. These shorts can be eliminated by cleaning out the slots. See "Fig. 9-37: Checking Armature (shorts)" on page 44.

#### 3. Ground test

Grounds in the armature can be detected with a 110-volt test lamp and test probes. If the lamp lights with one test probe placed on commutator and the other on the core or shaft, the armature is grounded. Grounds occur as a result of insulation failure, which is often brought about by overheating due to excessively long cranking periods, or by accumulation of brush dust between the commutator bars and the steel commutator ring.






Fig. 9-37: Checking Armature (shorts)

#### 5.6.4. Field Coils

Internal wiring circuit is shown. The field coils can be checked for grounds and opens using a test lamp as follows:

#### 1. Grounds

The field coil ground connection must be disconnected during this test. Connect one lead of the 110-volt test lamp to the field frame and the other lead to the field connector terminal stud on the field frame. If

the lamp lights, at least one of the field coils is grounded and must be repaired or replaced.

#### ™NOTE:

This check cannot be made unless the ground connection is disconnected.

#### 2. Opens

Connect one test lamp lead to the terminal stud on field frame and the other in turn to each of the field coil leads which connect to the brush holders; the lamp should light. If lamp fails to light, the field coils are open.

#### 3. Replacement

Remove the eight (8) pole shoe screws and four (4) pole shoes. If sealing on screws are damaged, replace them with new pole shoe screw assemblies.

Remove the field coil assembly, insulation strip, terminal insulator and grommet.

Install the inside terminal insulator, field coil assembly and insulation strip into the frame.

Install the four (4) pole shoes, with notched end toward the Commutator End, and eight (8) pole shoe screws. Torque screws 15 to 50 ft-lb. (20.3 to 67.8 Nm). Consider hitting the coil terminals slightly to ensure they don't touch the insulation paper. This will also help to avoid any rubbing between the armature and terminals.



#### 5.6.5. Commutator End Frame

- Remove Commutator End Housing. Refer to 5.6. "Disassembly" on page 41 in this section for procedure.
- 2. Remove all parts from the CE housing assembly. If reconditioning the CE housing, remove the bushing, cup and wick.
- 3. Soak new wick in SAE 20 weight oil for several hours to allow the oil to penetrate and install into the housing.
- 4. Align the cup with the wick hole, open end down, and tap it into place until it is flush with the housing. It is best to use a deep well socket or similar device about the same size as the outside diameter of the wick cap. Strike it with a hammer until the cup top is flush with the casting.
- Install the CE housing bushing using a large pin punch which has about the same outside diameter as the bushing.
- 6. Install the O-ring onto the frame groove.
- 7. Install the square fiber insulator and fiber washer onto the ground stud.
- Apply bearing type grease onto CE housing's inner diameter where the frame O-ring is seated and apply a small amount of SAE 20 oil into the bushing area.
- Install CE housing over the locator pins and install CE attaching screws, assuring the square fiber washer is properly aligned with the anti-turn feature on the CE housing. Refer to 5.7. "Assembly" on page 48 in this section for complete assembly procedure.

#### 5.6.6. Shift Lever Housing

Inspect oil seal and bushing in shift lever housing for evidence of damage or excessive wear.

Replace bushing, if necessary. New oil seal lip must point inward.

If shift lever appears excessively loose on lever shaft, worn parts can be replaced by removing retaining ring from exposed small end of lever shaft, then driving shaft out of housing. When installing lever and shaft, use new O-rings in grooves in shaft.

#### 5.6.7. Drive Housing

Inspect bushing in nose housing for wear. Replace bushing, if necessary.

#### 5.6.8. Drive Assembly

Drive pinion must rotate freely in overrunning direction and must not slip in cranking direction. The drive assembly can be serviced as follows: See "Fig. 9-38: Drive Clutch Assembly" on page 46.

# 1. Disassembly

Using suitable tools, remove the pinion stop cup and split washer from sleeve.

## ™NOTE:

In removing the pinion stop cup it will probably be damaged. Use new cup at assembly.

Remove pinion, spring retainer outer cup, spring and spring retainer inner cup.

#### 2. Inspection & Repair

Inspect spring and spring retainer cups. If not in good usable condition, replace with new part. Inspect pinion. If teeth are chipped or cracked, replace pinion. Inspect sleeve bushings.

If bushings do not meet specifications listed at end of this group, press old bushings out of sleeve and press new bushings into place. Ream bushings to specifications listed at end of this group.

# 3. Assembly

Install spring retainer inner cup, spring and spring retainer outer cup on sleeve. Install pinion and pinion stop cup on clutch sleeve. Install split-type washers in groove at end of clutch sleeve.

Position clutch sleeve assembly in a vise, then with pinion seated firmly against the pinion stop cup and using suitable tools, bend pinion stop cup lip over split washers, locking pinion stop and split washers together

#### ™NOTE:

DO NOT lubricate the stops (sprags) as they are lubricated for life.






Fig. 9-38: Drive Clutch Assembly

#### 5.6.9. Solenoid

#### 5.6.9.1. Removal

- Loosen 3/4" nut on solenoid motor terminal or loosen E8 Torx Head solenoid motor terminal screw.
- Remove E8 Torx Head screw at field connection on starter frame.
- Remove 3/4" nut from solenoid motor terminal or remove E8 Torx Head solenoid motor terminal screw.
- Remove solenoid to starter field connector strap.
- 5. Remove top 3/8" nut and washer assembly from ground terminal of solenoid.

- 6. Remove flexible ground cable from the solenoid ground terminal.
- Remove access plug and gasket from front of lever housing, ensuring gasket is removed.
- Remove 1/2" plunger nut, carefully as follows:



Proper care must be exercised when completing this step to avoid personal injury and property damage. Also, to avoid overheating and possible damage to the solenoid, power should not be applied in excess of one minute.



Solenoid must be energized for removal of 1/2" plunger nut to prevent plunger from rotating and damaging the rubber boot. Ensure stamped metal connector strap is disconnected to prevent motor from rotating.

- a. Apply power to solenoid between switch "S" (positive lead) and ground (negative lead) terminals. Seat the plunger by simultaneously pushing on 1/2" plunger nut.
- b. Remove 1/2" plunger nut carefully, so it does not drop into motor, and discard.
- Remove power immediately after nut is removed.
- Remove three E8 Torx Head solenoid mounting screws.
- 10.Remove complete solenoid and plunger assembly from lever housing.



#### 5.6.9.2. Installation

- 1. Slide solenoid over lever housing register.
- 2. Orient solenoid so that the flat flange on the solenoid metal case aligns with the flat flange on the housing.
- 3. Verify that the plunger rod is inside the shift lever guide.
- 4. Install three E8 Torx Head solenoid mounting screws and torque 125 to 190 in-lb. (14.1 to 21.5 Nm).
- Install a new 1/2" plunger nut by hand finger tight.



Use of force can rotate the plunger and damage the rubber boot.

- 6. Check and adjust pinion clearance.
- Install access plug and gasket to front of lever housing and tighten to a minimum of 72 in-lb. (8.1 Nm).

- 8. Install solenoid-to-motor field connector strap, using strap, as follows:
  - a. Install E8 Torx Head field terminal screw on starter frame finger tight.
  - b. Install E8 Torx Head screw on solenoid motor terminal finger tight.
  - c. Tighten E8 Torx Head screw at starter frame 75 to 95 in-lb. (8.5 to 10.7 Nm).
  - d. Tighten E8 Torx Head screw at solenoid motor terminal 75 to 95 in-lb. (8.5 to 10.7 Nm).
- Remove top 3/8" nut and washer assembly from solenoid ground terminal and install flexible ground cable.
- Install 3/8" ground terminal nut and washer assembly and tighten to 16 to 38 in-lb. (1.8 to 4.3 Nm).
- 11. Check motor for proper function before installation.



# 5.7. Assembly

- Lubricate splines of armature shaft with SAE 20 oil, then insert drive end of armature shaft through shift lever housing until shaft just extends through housing. Place O-rings and collar over armature shaft and position in counter-bore in housing. Place brake washer over end of shaft.
- Position drive clutch assembly in lever housing with lugs on lever yoke engaging groove in drive clutch shift collar, then push armature shaft through housing and drive clutch.
- Place gasket in counter-bore in shift lever housing, then install drive housing over armature shaft and position at lever housing, with marks made prior to disassembly aligned. Attach drive housing to lever housing with six socket head screws, tighten screws to 13 to 17 ft-lb. (18 to 23 Nm) torque.
- 4. Install new O-ring in groove in field frame side of shift lever housing. Install field frame over armature and position against shift lever housing as noted prior to disassembly. Attach lever housing to field frame with five cap screws and lock washers. Torque 12 to 16 ft-lb. (16 to 22 Nm).
- Position solenoid with plunger rod end inserted into shift lever housing. Fasten solenoid case to shift lever housing with three cap screws and lock washers. Through the opening in opposite end of

- lever housing, make sure plunger rod passes through plunger rod guide in shift lever.
- Place thrust washer over commutator end of armature shaft. Place new O-ring in groove around commutator end frame. Pull the armature out of the field frame just far enough to permit the brush to be placed over the commutator. Connect field coil leads and brush leads to brush holders.

Align commutator end frame and armature with field frame as noted prior to disassembly. Attach end frame to field frame with cap screws and lock washers. Torque cap screws 40 to 60 ft-lb. (4.5 to 6.8 Nm).

## ™NOTE:

Insert the small round fiber insulator and then the rubber bushing over the ground stud into the hole on the CE housing. Installing rubber bushing prior to installing the CE housing can pinch the bushing and destroy its sealing capabilities. Install the large round fiber washer and the remaining hardware in the same order the parts were removed. Torque the large nut on ground stud 20 to 25 ft-lb. (27.0 to 33.8 Nm).

- 7. Connect solenoid ground lead to terminal stud on commutator end frame.
- Saturate all wicks and fill oil reservoirs with SAE 20 oil.



- 9. Adjust pinion clearance as directed below:
  - Connect a battery to the solenoid. See "Fig. 9-39: Starter Motor Pinion Clearance Check" on page 49.



Ensure stamped metal connector strap is disconnected to prevent motor from rotating.



Proper care must be exercised when completing this step to avoid personal injury and property damage. Also, to avoid overheating and possible damage to the solenoid, power should not be applied in excess of one minute.

- b. Solenoid must be energized to prevent plunger from rotating and damaging the rubber boot while tightening plunger nut to adjust pinion clearance. Warning: Ensure stamped metal connector strap is disconnected to prevent motor from rotating. Apply appropriate power to solenoid between switch "S" (positive lead) and ground (negative lead) terminals.
- c. Seat the plunger by simultaneously pushing on 1/2" plunger nut.
- d. Adjust 1/2" plunger nut to obtain correct distance between the pinion face and the inside of the machined surface of the nose housing. This distance must conform to between 0.328" and 0.390" (8.3 to 9.9 mm). While measuring, apply slight pressure against the pinion to take the slack out.
- e. Disconnect power immediately after pinion is properly adjusted.
- 10.Install connector strap on the solenoid "motor" terminal and field frame stud.




Fig. 9-39: Starter Motor Pinion Clearance Check

#### 5.8. Installation

#### ™NOTE:

Before installing starter, perform "no-load" test.

- 1. Use a suitable strap to raise the motor into position.
- Place spacer between starter and engine flywheel housing and install starter using three M12 bolts. Torque bolts to 75 ft-lb. (102 Nm).
- Connect cables and wires to their respective terminals. Torque positive and negative terminal nut 1/2" 13 UNC to 20 to 25 ft-lb. (27 to 34 Nm). Torque solenoid "S" terminal nut #10 32 to 15 to 30 in-lb.
- Set Battery Disconnect switch to the ON position and check operation of starter motor.



# 6. BATTERY SYSTEM

# 6.1. Description

The battery system consists of the vehicle batteries and tray, the battery disconnect switch, and the vehicle fuses. The battery tray is located at the rear curbside of the vehicle behind an access door. It is a stainless steel assembly which houses the batteries and which is equipped with steel rollers and a grab handle to allow ease of access. See "Fig. 9-40: Battery Tray" on page 50. The battery disconnect switch is located on the fusebox, above the battery tray. See "Fig. 9-41: Battery Disconnect Switch & Fuses" on page 51. This switch isolates the batteries from the vehicle elec-

trical system. It must be set to the OFF position whenever electrical maintenance is performed. A cutoff switch access door is provided in the main battery access door to allow disconnection of electrical power without having to open the battery access door. The vehicle fuses are located in the fusebox adjacent to the battery tray. Refer to the PS (Power & Starting) Electrical Schematic for the battery system electrical connections.

# ™NOTE:

ALWAYS set Battery Disconnect switches to the OFF position before disconnecting battery cables. Engine must be OFF before any disconnecting.




Fig. 9-40: Battery Tray






Fig. 9-41: Battery Disconnect Switch & Fuses



# 6.2. Battery Disconnect Switch

# 6.2.1. Description

The Battery Disconnect switch is located inside the battery compartment, on the face of the fusebox cover. This rotary switch serves to disconnect the batteries from the vehicle 12/24V electrical systems. It is accessible through the battery access door. To disconnect the batteries from the electrical system, rotate the battery disconnect switch to the OFF position. Always rotate this switch to the OFF position before disconnecting any battery cables.

## ™NOTE:

Use several wrappings of electrical tape to insulate any disconnected power cable ends or battery terminals that could be accidentally grounded during maintenance activity.

# 6.3. Jumpstart Installation



DO NOT use conventional jumper cables when starting the vehicle. ALWAYS use an approved jumpstart adapter that is designed to be used with the vehicle jumpstart quick-connector.

#### 6.3.1. Description

This vehicle is provided with a jumpstart installation for emergency starts. The installation consists of a quick-connect jumpstart connector which is wired directly to the vehicle 24VDC power supply and ground circuits. The connector is mounted below the battery disconnect switch on the rear equipment box.

Refer to the PS (Power and Starting) Electrical Schematic for the wiring connections for the electrical starting and the battery systems.



Before connecting an external voltage, ensure that the Battery Disconnect switch is ON.



# 6.4. Fusebox Assembly

# 6.4.1. Description

The fusebox assembly is located at the rear curbside of the vehicle. The main components of the fusebox assembly include the Battery Disconnect switch, voltage regulator, fuse panel, circuit breaker panel, and Compartment Light switch. Refer to 6.2. "Battery Disconnect Switch" on page 52 in this section for more information on this component.

# 6.4.2. Fusebox Torque Chart



ALWAYS torque electrical connections to specified torque when replacing any components. Loose connections can result in arcing, component damage, and possibly fire.

FUSEBOX TORQUE CHART				
DEVICE	FASTENER	TORQUE ft-lb. (Nm)		
Battery Disconnect Switch to Power Cables	Lock Nut	14 ft-lb. (19 Nm)		
Circuit Breakers	Lock Nut 1/4" - 20 UNC	3.5 ft-lb. (4.7 Nm)		
Fuse Limiters	Lock Nut 5/16" - 24 UNF	10 ft-lb. (13.5 Nm) see Note 1		
Grid Heater Relay to Power Cables	Lock Nut 5/16" - 24 UNF	4 ft-lb. (5.4 Nm)		
Magnetic Starter Relay Power Cables	Lock Nut 5/16" - 18 UNC	12 ft-lb. (16.3 Nm)		

Note 1: Install fuse and end directly against bus bar without washer in between. Use required number of washers on panel side to level fuse with panel.



## 6.5. Batteries



ALWAYS replace batteries with the same type and size identified in your New Flyer Parts Manual and charge the batteries using the recommended voltage. Over-charging a lead acid battery can produce explosive and hazardous gas. Any change in battery configuration may require modification to the charging system voltage levels and battery service procedures to prevent overcharging and equipment damage. Consult the battery manufacturer's recommendations before installing replacement components.

#### 6.5.1. Description

This vehicle is equipped with two 12 volt, heavy-duty batteries. Electrolyte can be added to these batteries by removing the top caps. Batteries are equipped with positive and negative drop-post terminals.

#### 6.5.2. Batteries Specifications

- ☐ 12 Volt
- □ 8D group size
- □ 1400 cold cranking amperes
- □ 165 AH battery capacity
- ☐ 430 minute reserve capacity

#### 6.5.3. Removal

- 1. Set the Battery Disconnect switch to the OFF position.
- Remove the wing nut and washers and pivot the battery tray retainer bracket downward. Slide the battery tray out to the fully extended position.
- Note the positive and negative terminals on the batteries and tag the cables before

- removing. Refer to Battery Hookup decal on the inside of the fusebox door.
- 4. Disconnect the cables from the negative terminals of the battery.
- Disconnect the cables from the positive terminals of the battery, including the jumper cable.
- Remove the three nuts from the battery holdown retainer. Remove the cable hanger with cables and tie out of the way. Remove the battery holdown retainer.
- Carefully lift and remove the batteries from the tray.

#### 6.5.4. Installation

- Install the batteries into the tray with the positive and negative terminals arranged as originally removed.
- Secure the batteries in place using the holdown retainer and nuts. Position the battery cable hanger and bracket in place and secure.
- Connect the positive cables and jumper cable to their respective terminals as marked on removal. Torque to 10 - 15 ft-lb (14 - 20 Nm).
- Connect the negative cables to the battery negative terminal. Torque to 10 - 15 ft-lb (14 - 20 Nm).
- Ensure exposed battery terminals are protected with a coating of dielectric grease.
   Ensure protective rubber boots are installed over the positive terminal connectors
- Slide the battery tray into the fully retracted position.
- Pivot the battery tray retainer bracket upwards to engage the stud on the battery tray. Install flat washer, lock washer, and wing nut.
- 8. Set the Battery Disconnect switch to the ON position.



## 6.5.5. Inspection

Refer to the Preventive Maintenance Section of this manual for scheduled inspections.

#### 6.5.6. Possible Causes of Battery Failure

- 1. Faulty alternator or regulator.
- Overloads caused by defective starter or excessive use of accessories.
- 3. Dirt and electrolyte on top of batteries causing a constant drain.
- Sulphated battery plates, due to battery being in a low state of charge over a long period of time.
- Physical defects such as shorted cells, loss of active material from plates and so forth.
- 6. Short vehicle operation cycle over an extended time (resulting in a low charge condition).

#### 6.5.7. Filling Battery



When batteries are being charged, an explosive gas mixture forms in each cell, part of this gas escapes through

the holes in the vent plugs and may form an explosive atmosphere around the battery itself if ventilation is poor. This explosive gas may remain in or around the battery for several hours after it has been charged. Sparks or flames can ignite this gas causing an internal explosion which may shatter the battery.

If the electrolyte level is found to be low, water should be added to each cell until the level rises to the bottom of the vent. DO NOT OVERFILL.

# ™NOTE:

Level of electrolyte can be checked by the use of a flashlight and mirror. Hold the mirror over each cell opening and direct flashlight beam so electrolyte level can be seen.

Distilled or demineralized water should be used to eliminate the possibility of harmful impurities being added to the electrolyte. Many common impurities will greatly shorten battery life.



DO NOT add any substance to the electrolyte except water.



## 6.5.8. Charging the Battery

The following are three methods of recharging batteries, the "slow charge" method, the "fast charge" method and "emergency boost charge" method.

These methods differ basically in the length of time the battery is charged and the rate at which charging current is supplied.

#### 6.5.8.1. Slow Charging

The "slow charge" method supplies the battery with a relatively low current flow for a relatively long period of time.

This is the only method that will bring the battery to a fully charged state.

The "slow charge" method consists of charging at approximately a 9-ampere rate for 24 hours or more, if necessary, to bring the battery to full charge.

A fully charged condition is reached when three consecutive specific gravity readings taken at hourly intervals, show no increase.

## 6.5.8.2. Fast Charging

The "fast charge" method supplies current to the battery at a 40 to 50 ampere rate over a 1-1/2 hour time period. If the electrolyte temperature reaches 125°F before the 1-1/2 hour period is completed, the battery must be taken off charge temporarily or the charging rate reduced to avoid damaging the battery. Although a battery cannot be brought to a fully charged condition during "fast charge", it can be substantially recharged or "boosted".

In order to bring the battery to a fully charged condition, the charging cycle must be finished by the "slow charge" method.

## 6.5.8.3. Emergency Boost Charge

In cases where the battery is not sufficiently charged to crank the engine, an emergency boost charge may be applied as a temporary expedient in order to crank the engine.

The "emergency boost charge" method consists of charging at a 40 to 50 ampere rate for a period of one-half hour. It should be particularly noted that the "emergency boost charge" will not necessarily restore the battery to a useful state of charge for continued service. After an "emergency boost charge", failure to charge battery further, either by a long uninterrupted driving period or by the "fast charge" or "slow charge" method, may result in engine cranking failure on the next attempt.

A battery should never be condemned on the basis of engine cranking failure after an "emergency boost charge".

Although an emergency boost charge may put enough energy into the battery to crank the engine once, further charging usually is necessary in order to create a sufficient reserve to crank a second and third time.

The following basic rule applies to any battery charging situation: A battery may be charged at any rate in amperes as long as spewing of electrolyte due to violent gassing does not occur and as long as electrolyte temperature does not exceed 125°F (51°C).

If spewing of electrolyte occurs, or electrolyte temperature exceeds 125°F (51°C), the charging rate in amperes must be reduced or temporarily halted to avoid damage to the battery.

The battery is fully charged when over a two-hour period at a low charging rate in amperes all cells are gassing freely (not spewing liquid electrolyte) and no change in specific gravity occurs.

The full charge specific gravity is 1.260 to 1.280, corrected for electrolyte temperature with the electrolyte level at the split ring, unless electrolyte loss has occurred due to age or over filling in which case the specific gravity reading will be lower.

For the most satisfactory charging, the lower charging rates in amperes are recommended.



#### 6.5.9. Functional Tests

#### 6.5.9.1. Visual Inspection

The first step in testing the battery should be a visual inspection which very often will save time and expense in determining battery condition.

- Check outside of battery for a broken or cracked casing, or broken or cracked cover. If damage is evident, the battery should be replaced.
- Check the electrolyte level. Levels that are too high or too low will cause poor performance.
- Check for loose terminal posts, cable connections, and for evidence of corrosion. Correct as required before proceeding with tests.

## 6.5.9.2. Capacity Test

This test is one means of checking a battery to determine its ability to function as required in the vehicle. A 12 volt battery that will maintain 9.0 volts or better during a capacity test should be considered a good battery.

To make this test, use equipment that will take a heavy electrical load from the battery, such as a carbon pile or other suitable means.

 Connect voltmeter, ammeter, and variable load resistance as illustrated.

## ™NOTE:

Observe polarity of meters and battery when making connections and select correct meter range.

- Apply a load to the battery equal to three times the ampere-hour rating of the battery for 15 seconds (3 x 200 = 600 amperes).
- With ammeter reading specified load, read voltage which should not be less than 9.0 volts for 12 volt battery.
- 4. If voltmeter shows 9.0 volts or more, battery has good output capacity and will readily accept a normal charge. If specific gravity is 1.215 or more, no service is required. If specific gravity is below 1.215, check charging circuit to determine the cause and correct as required. The battery should be slow-charged for city driving. With highway driving and a good charging system, the battery should charge satisfactorily.



## 6.5.10. Specific Gravity (Hydrometer) Test



DO NOT smoke near a battery which is being charged or which has been recently charged.

DO NOT break live circuits at battery terminal as a spark usually occurs at the point where a live circuit is broken. Care should be taken when connecting or disconnecting booster leads or cable clamps on chargers. Poor connections are a common cause of electrical arcs which cause explosions.

The electrical system on these vehicles is negative ground. Installing the battery with the positive terminal grounded or incorrect use of the booster battery and jumper cables will result in serious damage to the generator, battery and battery cables. Any procedure other than the above could result in: personal injury caused by electrolyte squirting out of the battery vents, or personal injury or property damage due to battery explosion.

Treat the booster battery and the discharged battery very carefully when using jumper cables. Follow these instructions being careful not to cause sparks.

Damage to the charging system of the booster vehicle or of the immobilized vehicle. Do not attempt to jump start a vehicle having a frozen battery or the battery may rupture or explode. If a frozen battery is suspected. Examine all filler vents on the battery. If ice is present, or the electrolyte fluid cannot be seen, do not attempt to start the vehicle with jumper cables until the battery is thawed.

# ™NOTE:

New batteries which have become completely discharged over a relatively long period of time, such as during vehicle storage, cannot be accurately tested.


The hydrometer is used to determine degree of battery charge. Measure specific gravity of electrolyte in each cell as follows:

- Hold hydrometer tube vertically at eye level when making a reading. See "Fig. 9-42: Hydrometer Reading Procedure" on page 59.
- Do not draw too much electrolyte into the hydrometer.
- The float should be freely suspended in electrolyte.

# ™NOTE:

If water has recently been added to any of the cells, or the battery charged without removing electrolyte surface charge, the reading will be wrong. Check hydrometer reading as follows: See "Fig. 9-44: Battery Discharge" on page 59.

- a. Specific gravity readings on the hydrometer should be between 1.215 and 1.270 at 80°F (26.7°C). Add 4 points (0.004) to reading for each 10° F (12.2°C) above 80°F (26.7°C). Subtract 4 points (0.004) for each 10°F (12.2°C) below 80°F. See "Fig. 9-43: Temperature Correction" on page 59.
- b. If specific gravity reading is between 1.215 and 1.270 and variance between cells is less than 25 points (0.025), then battery is at least 3/4 charged and presumably in good condition.
- c. If variance between cell readings fluctuates over 50 points (0.050), replace battery.
- d. If specific gravity readings are below 1.215 and the variation between cells is less than 25 gravity points, the battery presumably is in sound condition but needs charging.








Fig. 9-43: Temperature Correction




Fig. 9-44: Battery Discharge



# 6.6. Temperature Indicator

## 6.6.1. Description

A non-reversible temperature indicator strip is installed on top of each battery for ease of temperature monitoring.

# 6.6.2. Temperature Indicator Specifications

Manufacturer	Omega Engineering Inc.
Temp. Indicators	
	140, 150, 160, 170, 180
Accuracy	1.8°F (1°C)

# 6.6.3. Operation

The indicator strip cells turn black as they are exposed to higher temperatures.

#### 6.6.4. Removal

- 1. Lift a corner of the strip and remove.
- 2. Remove any remaining adhesive residue.

#### 6.6.5. Installation

- 1. Ensure the mounting surface is clean and dry.
- 2. Install the strip using the adhesive backing.



# 6.7. Voltage Equalizer

# 6.7.1. Description

The battery voltage equalizer is located in the battery compartment and bracket-mounted to the side structure on the curb-side of the vehicle. The voltage equalizer is a power management system used to obtain a 12 VDC power source from a 24 VDC electrical system and to have the batteries function as if they are in series and parallel at the same time. In addition to providing regulated 12 VDC power, the

system ensures that battery voltages remain equal. See "Fig. 9-45: Battery Voltage Equalizer Installation" on page 61.

#### 6.7.2. Voltage Equalizer Specifications

Manufacturer	Vanner Power Group
Model	70 - 80
Input Voltage 24V	18 to 32 volts
Maximum 24V Input A	mps43 amps
Output Amps 12V	0 to 80 amps




Fig. 9-45: Battery Voltage Equalizer Installation



## 6.7.3. Operation

The voltage equalizer is connected to the battery system at the 12 VDC, 24 VDC, and ground points. The voltage equalizer maintains voltage balance between the batteries and therefore the charge acceptance rate of each battery to within 0.05 volts at light load and 0.1 volts at full rated load.

When the voltage of the battery that is supplying the 12 VDC vehicle load is higher than or equal to the other battery, the equalizer is operating in a standby mode, for example it is not transferring power from its 24 VDC input to its 12 VDC output.

When a 12 VDC load is present and the voltage in the battery supplying the 12 VDC load is less than the voltage in the other battery, then the voltage equalizer activates and transfers sufficient current from the other battery to satisfy the load and maintain an equal voltage and charge in both batteries.

#### 6.7.4. Voltage Equalizer Testing

1. If the battery voltage is below 24V, start the vehicle or apply a 24V battery charger to the batteries.

 With the engine running, turn ON 12V loads up to the equalizer rated capacity. Measure DC amps on the equalizer +12V cable to verify load amperages.

# ™NOTE:

The following readings are all taken at the equalizer.

- Measure and record the voltage between the equalizer +12V and GND terminals. This is referred to as Battery A voltage.
- Measure and record the voltage between the equalizer +24V and +12V terminals. This is referred to as Battery B voltage.
- 5. Subtract Battery A voltage from Battery B voltage and compare readings.

## ™NOTE:

An overload condition exists when the 12 volt loads exceeds the equalizer's rated capacity. The overload condition will not damage the equalizer but may cause damage to the batteries. To correct an overload condition the 12 volt load must be reduced or the equalizer capacity must be increased.

VOLTAGE EQUALIZER TESTING				
VOLTAGE COMPARISON	EQUALIZER STATUS			
Battery A is lower than Battery B but within 0.05 volt	OFF	Stand by mode		
Battery A is lower than Battery B by 0.05 to 0.10 volts	ON	Normal operating mode		
Battery A is lower than Battery B by more than 0.10 volts	ON	Self protection mode due to an overload condition.		
Battery A is lower than Battery B by more than 0.10 volts	OFF	The equalizer is not functioning correctly		
Battery A is higher than Battery B	Abnormal condition - suspect that Battery B is defective or has a 12V load connected to it.			





# 6.7.5. Replacement Procedure



Ensure the wire connections to the equalizer are installed exactly as described. Incorrectly connected wires can damage the unit and possibly cause fires.

- Set the Battery Disconnect switch to the OFF position.
- 2. Obtain access to the equalizer through the curbside panel at the rear of the vehicle interior.

- 3. Remove the two screws and the protective plastic cover from the equalizer.
- 4. Tag and disconnect the three power cables from the terminal studs.
- 5. Remove the bolts and lock washers and remove the equalizer from the vehicle.
- 6. Installation is the reverse of removal.

## ™NOTE:

Torque the nuts on the wire terminals to 120 in-lb. (13.5 Nm) during installation.



# 7. EXTERIOR LIGHTS

See "Fig. 9-46: Exterior Lamps" or page 65.


# 7.1. Headlights

# 7.1.1. Description

The headlight assemblies contain an LED low beam, an LED amber turn light and a high beam bulb. The LED lights have a 10,000 hour service life rating. The high beam has a replaceable bulb. Each headlight assembly is controlled by its own headlight module located behind the wiper motor access door.

# 7.1.2. Operation

The low beam headlights operate at full intensity when the Master Run switch is in either the DAY-RUN or NIGHT-RUN positions. The high beam headlights operate only when the Master run switch is in NIGHT-PARK and the high beam foot switch is activated. The LED headlight module will output a signal to the LCD display on the instrument panel if a headlight or turn signal fails to operate.



- Lamp Assembly, Identification Red LED
- 2. Lamp Assembly, Identification Amber LED
- 3. Headlight Assembly, w/LED Turn Signal Streetside
- 4. Headlight Assembly, w/LED Turn Signal Curbside
- 5. Lamp Assembly, White LED
- 6. Lamp Assembly, Amber LED
- 7. Lamp Assembly, Amber LED
- 8. Lamp Assembly, Amber LED
- 9. Lamp Assembly, Stop Red LED
- 10. Lamp Assembly, Identification Amber LED
- 11. Lamp Assembly, Red LED
- 12. Reflector, Red
- 13. Reflector, Amber
- 14. Lamp Assembly, License Plate LED

s0302338a.svg

Fig. 9-46: Exterior Lamps



#### 7.1.3. Removal

# ™NOTE:

Replacing a faulty low beam or turn signal light requires the replacement of the complete headlight assembly. The high beam bulb can be replaced separately and can be accessed from the interior of the vehicle without removing the complete headlight assembly.

- 1. Set the Battery Disconnect switch to the OFF position.
- Gain access to the headlight assemblies by opening the exterior wiper motor access doors, interior LH lower dash panel access door, and interior RH lower dash panel access door. See "Fig. 9-47: Headlight Removal & Installation" on page 67.
- Access the headlight assembly from the interior of the vehicle and disconnect the wiring harness.
- 4. Remove the nuts and washers that retain the headlight assembly to the front mask and remove the unit from the vehicle.
- 5. Remove the high beam bulb with a 1/4 turn CCW twisting motion.

# ™NOTE:

Determine that the problem is in the headlight and not in the module by plugging the removed headlight into the working headlight module on the opposite side. Replace the headlight assembly if it still does not function.

#### 7.1.4. Installation

- Install a new headlight assembly using the original washers and nuts.
- Install a new high beam bulb with a 1/4 turn CW twisting motion, being careful not to touch the glass surface of the bulb with bare hands or any other object that could leave an oily residue on the bulb.
- Connect the wiring harness to the headlight assembly and secure the harness with cable ties.
- Close and secure all access doors.
- Set the Battery Disconnect switch to the ON position and test operation of the headlight assembly.
- 6. Adjust the headlights if required. Refer to 7.1.5. "Headlight Aiming" on page 68 in this section for aiming procedure.






Fig. 9-47: Headlight Removal & Installation



#### 7.1.5. Headlight Aiming

The LED headlights should be checked at regular intervals to ensure that they are properly aimed in accordance with local vehicle regulations. The headlight assembly is a single unit containing the low beam, high beam, and turn light. A single vertical adjustment screw, accessible from the interior of the vehicle, is provided for aiming the headlight assembly. Proper high beam setting is achieved when the low beam is set correctly.

The preferred method of aiming headlights is with the use of specialized optical headlight aiming equipment and is described in the following procedure. If specialized equipment is not available, headlights can be aimed using prescribed markings on a wall and parking the vehicle a specified distance from the wall. Refer to 7.1.6. "Headlight Aiming (Alternate Procedure)" on page 71 in this section for aiming instructions.

- 1. Move the vehicle to a level surface and set the parking brake.
- Ensure that the tires are properly inflated and that the vehicle ride height is set per specifications. Refer to Section 3 of this manual for ride height adjustment procedures.
- Open the interior LH and RH lower dash panel access doors to gain access to the headlight adjusting screw.

#### ™NOTE:

The following steps assume the use of Canbuilt commercial headlight aiming equipment. Headlight aiming equipment from other manufacturers will require different alignment procedures. Consult the equipment manufacturer's instructions for specific procedures.

- Compensate for floor slope as follows:
  - a. Positioning the aimer at the front of the vehicle.
  - b. Turn on the laser by turning the knob on the laser housing.



DO NOT stare into the aimer's laser beam as damage to the eyes may result. The aimer emits class II laser radiation at a wavelength of 630 to 680 nm with a power output of less than 1 mW.

- c. Measure the center of the laser beam height from the floor at the front wheel and at the back wheels.
- d. The distance from the floor should be the same. If it is not, adjust the floor slope knob on the aimer's base until they are equal.



- 5. Place the aimer in front of one headlamp approximately 10 to 14 in. (25 to 35 cm) from the headlamp assembly.
- 6. Rotate the aimer positioning pointer to the front of the aimer. Adjust the aimer so that the positioning pointer is at the center of the round lens of the low beam then rotate the pointer back into its stored location.
- Square the aimer to the front of the vehicle as follows:
  - a. Choose two symmetrical points on the front of the vehicle, located at the same height. The upper part of the headlight assembly or two points on the defroster/wiper access door may work.
  - b. Looking through the lateral alignment visor, make both chosen points lie on the visor's wire, by slightly rotating the aimer.
  - c. The aimer is now ready to test the headlights.

- Set the Master Run switch to NIGHT-RUN to operate the headlights. Ensure that the high beam is off.
- Observe the pattern displayed on the screen and determine the required direction of adjustment. See "Fig. 9-48: Headlight Aiming" on page 70.
- 10. Use the adjusting screw on the back of the headlight assembly to vertically position the headlight in the desired target area of the aiming equipment.

#### RNOTE:

Use a 5/32" socket to turn the adjusting screw. Rotate the screw CW to raise the beam pattern and CCW to lower the beam pattern.

11. When the adjustment is completed, turn off the headlights, remove the headlight aiming equipment, and close and secure all access doors.






Fig. 9-48: Headlight Aiming



### 7.1.6. Headlight Aiming (Alternate Procedure)

### ™NOTE:

The following procedure describes how to set up headlight aiming marks for the low beam lights. Markings can be made directly on the wall surface if practical, otherwise use a 4' x 8' sheet of plywood, or suitable equivalent, painted white.

- Draw a vertical line C-C on the aiming surface representing centerline of vehicle. Extend this centerline at a right angle along the floor so that it can be used to position the vehicle square to the aiming surface. See "Fig. 9-50: Low Beam Headlight Aiming" on page 72.
- Position vehicle on level floor with low beam headlights 25' (7.62 m) from the aiming surface. Centerline of vehicle must be positioned so that it is at a right angle to the vertical surface.
- Measure height of low beam headlight centers from floor and mark this height on vertical surface. Draw a horizontal line A-A on vertical surface at this height. Extend this line to approximate the width of the vehicle.

#### ™NOTE:

The center of the low beam is marked with a dimple molded into the headlight assembly. If the dimple is not present, measure to the center of the round lens surrounding the low beam elements. See "Fig. 9-49: Low Beam Center Location" on page 71.

- 4. Measure distance between centers of outer (low beam) lights and divide this distance equally on both sides of centerline C-C. Draw a vertical line (D-D and E-E) through each of these points.
- 5. Draw a line on an upward angle to the right from the intersection of lines A-A and D-D. Draw a similar line from the intersection of lines A-A and E-E. These angled lines, approximately 45°, represent the kink where the cutoff line bends upward.

#### ™NOTE:

The upward bend angle of the cutoff line needs to be added to the aiming marks once the first set of low beam lights have been centered and adjusted vertically. Draw a line corresponding to the illuminated upward angle.




Fig. 9-49: Low Beam Center Location






Fig. 9-50: Low Beam Headlight Aiming



#### 8. INTERIOR LIGHTS

#### 8.1. Aisle Lights

#### 8.1.1. Description

The aisle light panels are located above the side windows on either side of the passenger aisle. See "Fig. 9-51: Aisle Lights Layout" on page 73.

Each lighting panel consists of one or more banks of lights, depending on the length of the panel. Each bank of lights consists of a clever board installed in series with several basic boards. The clever board provides the power entry and dimming capability for the entire bank. The power entry and dimming connector installed on each clever board is referred to as a "finger board". See "Fig. 9-52: LED Aisle Lights Assembly" on page 74.

Each LED board contains surfacemounted LEDs arranged in a single row pattern. The dimming level for the light banks is factory preset. Dimmable lighting panel banks can be adjusted using a programming fob. Refer to 8.1.5. "Dimming Adjustments" on page 77 in this section for adjustment procedure.

The LED boards are protected with a plastic translucent lens that runs the entire length of the lighting panels. The lighting panels also include speakers for the vehicle P.A. System as well as duct liners and distribution vents for the heating system.




Fig. 9-51: Aisle Lights Layout






Fig. 9-52: LED Aisle Lights Assembly



#### 8.1.2. Aisle Lights Specifications

#### 8.1.3. Operation

The Aisle Lights switch on the side console provides the operator control of the aisle lights based on the programming configuration for the ON, NORMAL and OFF settings of this switch. Refer to Section 19 of this manual for more information on the operation of the Aisle Lights switch.

#### 8.1.4. Aisle Lights Troubleshooting

#### ™NOTE:

Refer to Electrical Systems Drawings "ES-Electrical Schematics-IL" and the Vansco PLC Program when performing troubleshooting. Troubleshooting the lighting panels should always be performed in the following sequence:

- Confirm lighting program Refer to Section 19 of this manual for definition of which panels illuminate or dim and under what conditions.
- Identify the symptoms and the conditions under which the problem occurs. Example: one bank of lights fail to illuminate during NIGHT-RUN with aisle lights switch in NORMAL position and entrance door closed. Establish the conditions under which the lighting panel should illuminate.
- Confirm that the proper inputs and outputs are present at the VMM modules during the condition identified in the previous step.
- If proper inputs not received at VMM module(s), then trace vehicle wiring circuit for power at switches, connectors, and fuses.
- 5. If proper outputs confirmed at VMM module(s), then check lighting panel connectors for voltage.
- Check finger board connector for power and dimming signals as applicable. Confirm ground circuit from lighting panel to vehicle ground.



#### 8.1.4.1. Troubleshooting Tips

It is important to understand the operating principles of the LED lighting boards in order to properly troubleshoot problems. The following list of operating characteristics and possible problems will help isolate the condition and minimize time spent troubleshooting.

Each lighting bank consists of one clever board and several basic boards. The clever board receives the power and dimming inputs and transmits these signals through the series-connected board-to board connectors on each of the basic boards.

- If the clever board loses a power or dimming signal, then all basic boards in that bank that are connected to the clever board will lose the power or dimming signal.
- If the clever board and one or more downstream basic boards illuminate, but the remainder don't, then the likely problem is with a board-to-board connector at one of the basic boards.

Each lighting board has its own driver that is capable of powering 30 LED's. The LED's are electrically connected in groups.

- ☐ If a lighting board driver fails, then all LED's in that board will fail to illuminate.

  The driver is not repairable and the board must be replaced.
- ☐ If only some LED's in a lighting board fail to illuminate, then an internal connection within the board has failed and the board must be replaced.

The root cause of many electrical problems can be traced to loose or corroded electrical connectors. This is very typical of intermittent problems. Inspect the electrical connections at the following locations:

- ☐ Vehicle harness connection to lighting panel harness.
- Finger board remove IDC connector cover and check for improperly crimped wires.
- □ Board-to-board connectors slide cover back and inspect terminals. Ensure the three screws fastening the lighting board to the panel are secure. Sometimes loosening these screws and repositioning the lighting board will correct the faulty connection.



#### 8.1.5. Dimming Adjustments

The dimmable lighting panels normally operate at 50% lighting intensity and increase to 100% when the entrance door is open. The factory preset dimming level can be adjusted individually on each bank of lights. The following instructions describe the adjustment procedure:

- Remove the lens. Refer to 8.1.6.1. "Lens" on page 78 in this section for procedure.
- Set the Master Run switch to NIGHT-RUN and set the Aisle Light switch to a position that will illuminate all lights. Ensure that the entrance door remains closed during the adjustment procedure.
- 3. Identify the bank of lights that need to be adjusted and located the clever lighting board on that particular bank of lights.

#### ™NOTE:

The clever board provides the power and dimming signal for the downstream basic lighting boards in each bank of lights. The clever board receives power and dimming signals from the finger board and can be easily identified by the three-wire connector on the end of the board.

- Locate the three programming pads on the clever lighting board. The programming pads are labeled "DOWN UP" and "DIM PGM". See "Fig. 9-53: Lighting Board Programming Pads" on page 77.
- 5. Place the pins of the programming fob onto the programming pads. Press the button on the DOWN side of the fob to reduce lighting intensity and press the button on the UP side of the fob to increase lighting intensity. See "Fig. 9-54: Lighting Board Dimming Adjustment" on page 77.

#### ™NOTE:

Each press of the button will change lighting intensity by 5%. The dimming level can be adjusted within the range of 0% to 100% lighting intensity.

- 6. Test the operation of aisle lights and ensure that the dimmable lighting panels increase to 100% lighting intensity when the entrance door is opened.
- 7. Replace the lens once all adjustments have been made.




Fig. 9-53: Lighting Board Programming Pads




Fig. 9-54: Lighting Board Dimming Adjustment



#### 8.1.6. Removal

#### 8.1.6.1. Lens

#### ™NOTE:

The lens is one continuous piece and runs the entire length of the lighting panels. Servicing the LED lighting panels will require removal of the full length of the lens.

- 1. Remove the end cover.
- 2. Starting at one end, compress the upper edge of the lens to release it from the mounting channel. See "Fig. 9-55: Lens Removal" on page 78.

#### ™NOTE:

An additional person will be required to support the lens while the other person is working along the length of the lens to release it from the mounting channel.

 Once the upper edge has been released, carefully work along the length of the lens to release the lower edge. Ensure that the lens is properly supported during removal to avoid excessive bending and possible lens damage.




Fig. 9-55: Lens Removal

#### 8.1.6.2. LED Lighting Board

#### ™NOTE:

The LED boards are not repairable and must be replaced as an assembly if defective

- 1. Remove the lens. Refer to 8.1.6.1. "Lens" on page 78 in this section for procedure.
- Slide the cover back on the board-to-board connectors on each end of the lighting board.
- Remove the three mounting screws that attach the LED lighting board to the lighting panel.
- 4. Remove the lighting board from the lighting panel.

#### 8.1.6.3. Finger Board

- Remove the lens. Refer to 8.1.6.1. "Lens" on page 78 in this section for procedure.
- Locate the finger board which is typically installed at the beginning of a bank of lighting boards. See "Fig. 9-56: Finger Board Assembly" on page 79.
- Use a machinist's scribe or dental pick to pry off the cover on the IDC connector of the finger board.

#### ™NOTE:

Typically there will be one cover for the power (red) and ground (black) wires located at one end of the finger board and another cover at the opposite end for the dimming signal (yellow) wire.

- 4. Note the position of the wires for reassembly and then carefully pull the wires out of the Insulation Displacement Connector (IDC) and clean any residual insulation from the blades of the connector.
- 5. Remove the single mounting screw.
- Remove the finger board by sliding it outward from the lighting board.






Fig. 9-56: Finger Board Assembly

#### 8.1.7. Installation

#### 8.1.7.1. Lens

- Position the length of lens beneath the lighting panels and support on the seat backs.
- 2. Start at one end and insert the lower lip of the lens into the mounting channel, ensuring that the end of the lens is flush with the end of the lighting panel.

#### ™NOTE:

An additional person will be required to support the lens as it is being raised into position.

- Continue to work along the length of the panels, inserting the lower lip of the lens into the mounting channel while another person follows behind, compressing the upper lip on the lens into the mounting channel.
- 4. Reinstall end cover.

#### 8.1.7.2. LED Lighting Board

- Position the lighting board on the panel ensuring that the board is correctly oriented and the male/female board-to-board connectors properly align their mating counterparts.
- Install and tighten the three mounting screws.
- 3. Slide the cover over the board-to-board connectors to ensure the connectors are locked in place.

#### 8.1.7.3. Finger Board

- 1. Place the finger board in position and slide it into the lighting board connector.
- 2. Secure the finger board to extrusion with a single screw.
- 3. Place the red wire into the IDC and press wire into position with the insertion tool tip (commercially available tool).
- 4. Repeat the previous step for the black and yellow wires.
- 5. Snap the IDC connector covers in place.
- 6. Reinstall lens.



#### 9. DOOR MASTER SWITCH

#### 9.1. Description

The Door Master switch is a two-position toggle switch located in the destination sign panel. The switch is labeled ON for normal operation and OFF for emergency operation.

#### 9.2. Operation



The Door Master switch is primarily intended to be used in emergency situations to disable the brake and accelerator interlock system and allow the vehicle to be moved. Positioning the Door Master switch in the OFF position will disable the exit door function and several safety features including:

- ☐ Shift selector can be shifted without foot on brake treadle.
- ☐ Shift selector can be shifted and vehicle moved with wheelchair ramp deployed.
- ☐ Exit doors can be opened with the vehicle in motion by using the emergency release control valve. Brake interlocks will not apply in this situation.

The Door Master toggle switch controls power to the brake interlocks and exit door. When the switch is in the ON position, the entrance and exit doors are fully functional. In this mode, opening the exit door, kneeling the vehicle or operating the wheelchair ramp engages the interlocks. Engaging the interlocks applies the rear brakes and deactivates the accelerator.

Positioning the Door Master switch in the OFF position disables the brake and accelerator interlocks and inhibits operation of the exit door controller. The entrance door, however, remains fully functional. A warning buzzer sounds and the Rear Door Open indicator illuminates on the instrument panel. In this mode, the exit door only opens if the emergency release control valve is activated. The control valve is located behind the breakable window to the left of the exit door.

#### 9.3. Functional Tests



Observe the necessary safety precautions while conducting the following test. Ensure that the wheels are chocked to prevent inadvertent vehicle movement. Advise all personnel to stand clear of the vehicle during testing.

#### 9.3.1. Normal Operation Test

Test normal operation of the Door Master switch and interlock system as follows:

- Start the engine, apply the parking brake, and set the shift selector in neutral [N]. Ensure the Door Master switch is set to the ON (normal) position.
- Move the door controller to position #3, #4, or #5 to enable the exit door. The brake and accelerator interlocks should apply.
- 3. Test application of the brake and accelerator interlocks by releasing the parking brake and slowly applying the accelerator treadle. The engine should remain locked in the idle setting and not respond to accelerator treadle movement. The rear stoplights should remain illuminated even with the parking brake released and no application of the brake treadle.
- 4. Test normal release of the brake and accelerator interlocks by moving the door controller to position #1 to disable the exit door. Set the shift selector in drive [D] and then press on the brake treadle. The combination of having the shift selector in gear and the brake treadle applied will unlatch the interlocks. Return the shift selector to neutral [N].
- Verify that the interlocks are released by lightly applying the accelerator treadle and confirming that the engine responds to accelerator movement and that the rear stop lights are extinguished.



### **Door Master Switch Troubleshooting**

#### 9.3.2. Emergency Operation Test

Test emergency operation of the Door Master switch as follows:

- Apply the accelerator and brake interlocks by re-establishing the conditions defined in steps 1 & 2 of "Normal Operation Test".
- Set the Door Master switch to the OFF (emergency) position. This will release the brake and accelerator interlocks and disable exit door function.
- Verify that the interlocks have been deactivated by releasing the parking brake and lightly applying the accelerator treadle. The engine should respond to accelerator movement and the rear stop lights should extinguish.

## 9.4. Door Master Switch Troubleshooting

- Set the Battery Disconnect switch to the OFF position.
- Disconnect wire leads from Door Master switch and test function of switch.
  - Set the switch to the ON position and test for continuity between the switch terminals using an ohmmeter.

- b. Set the switch to the OFF position and test for an open circuit between the switch terminals using an ohmmeter.
- 3. Replace the switch if it fails to meet either of the preceding test criteria.
- 4. Connect the wire leads to the switch.
- 5. Set the Battery Disconnect switch to the ON position.
- Set the Master Run switch to the DAY-RUN or NIGHT-RUN position and set the Door Master switch to the ON (normal/closed) position.
- 7. Use a voltmeter and connect probes between one of the switch terminals and ground. A reading of approximately 24V should be obtained. Move the positive lead of the voltmeter to the other switch terminal. A reading of approximately 24V should be obtained.
- Set the Door Master switch to the OFF (emergency/open) position. Use a voltmeter and test for 24V at both switch terminals as described in the preceding step. A reading of approximately 24V should be obtained on the input terminal only. Refer to Electrical Schematics for wire lead identification.



# 10. HORNS & WARNING ALARMS

#### 10.1. Electric Horn

#### 10.1.1. Description

- ☐ Two electric horns are mounted on the front bulkhead plate. Each horn is carefully adjusted and inspected during manufacture and should operate indefinitely without attention. If a horn does become inoperative, it must be replaced. See "Fig. 9-57: Horns Installation" on page 82.
- ☐ If a horn fails to operate, the trouble may be in the external circuit. Quick checks may be made with a jumper lead as follows, to isolate trouble:

- Open side console door for access to horn relay. Connect a jumper lead from No. 2 terminal on horn relay to ground. If horns operate, the trouble is in the horn control circuit (between horn button and horn relay). If horns do not operate, remove jumper lead and proceed to next step.
- ☐ Momentarily, connect a jumper lead between No. 1 and 3 terminals on horn relay. If horn operates, the relay is defective.

#### 10.2. Warning Alarms

#### ™NOTE:

Refer to the General Information Section of this manual for information on warning alarms.




Fig. 9-57: Horns Installation



# 11. DRIVER/VEHICLE MONITORING SYSTEM

#### 11.1. Description

The New Flyer Connect™ Driver/Vehicle Monitoring System measures and records vehicle operating parameters and location in real time. See "Fig. 9-58: Driver/Vehicle Monitoring System" on page 83. The system consists of:

- ☐ A Main Board Unit (MBU) located in the electronic equipment enclosure.
- ☐ A GPS/Data Modem Unit mounted on the ceiling of the vehicle, above the driver.
- ☐ A Driver Maneuver Awareness System (DMAS) display mounted on the instrument panel.




Fig. 9-58: Driver/Vehicle Monitoring System



#### 11.2. Operation

The Driver/Vehicle Monitoring System is connected to the vehicle's J1939 and J1587 networks. Information from these networks is monitored and transmitted, in real time, to allow transit authorities to monitor driver performance and vehicle condition.

The Main Board Unit contains a 3-axis accelerometer to monitor hard acceleration and braking and fast turning. The Driver Maneuver Awareness System (DMAS) is an LED bar graph display that provides the driver with feedback on these parameters and warns when accepted values are being exceeded. See "Fig. 9-59: DMAS Display" on page 84.




Fig. 9-59: DMAS Display



### 12. AUTOMATIC VEHICLE ANNOUNCEMENT & AUTOMATIC VEHICLE LOCATOR (AVA/AVL) SYSTEM

The vehicle is equipped with provisions for an AVA/AVL System. See "Fig. 9-60: AVA/

- AVL System" on page 85. The following equipment is installed on the vehicle:
- ☐ 7" Tablet (Samsung) above the driver's area
- ☐ Smart AVA Module in the Electronic Equipment Enclosure
- □ Interior LED sign
- ☐ Smart Hub located above the Tablet




Fig. 9-60: AVA/AVL System



# 13. AUTOMATIC PASSENGER COUNTER (APC) SYSTEM

#### 13.1. Description

The APC system monitors the movement of passengers entering or exiting the vehicle. See "Fig. 9-61: APC System" on page 86. The major components of the APC system include:

- ☐ Smart Sensor Module located in the electronic equipment enclosure.
- □ APC sensors located on wheelchair ramp access door and exit door rear modesty panel.
- ☐ APC reflectors located on the curbside luggage rack and exit door forward modesty panel.




Fig. 9-61: APC System



# 14. VIDEO SURVEILLANCE SYSTEM

The video surveillance system records events as they occur on the vehicle. The System consists of: See "Fig. 9-62: Video Surveillance System" on page 87.

☐ A Gatekeeper Systems 508 Digital Video Recorder (DVR) located in the Electronic Equipment Box

- ☐ Auto Wake Module (AWM) located in the Electronic Equipment Box
- WIFI Radio located in the Electronic Equipment Box
- ☐ Interior Cameras (x5) and Exterior Cameras (x3)
- Driver Alert Box located on the driver's side console




Fig. 9-62: Video Surveillance System



#### 14.1. Power On/Off

The DVR comes equipped with an Auto Wake Module (AWM) that is set up to power on the video surveillance system when the Master Run switch is in the DAY-RUN, NIGHT-RUN, or NIGHT-PARK position. The Shut-down delay is set default to 5 minutes after the Master Run switch is set to the STOP-ENGINE position, but can be customized using the DVR software.

#### 14.2. Driver Alert Box

The DVR comes with the optional Driver Alert Box. On this box are ten status LEDs

and a PANIC button. Pressing the PANIC button marks the current video with an alert flag for quicker video searching and indexing.

## 14.3. WIFI Radio Mobile Network / Direct Connection Network

The WIFI radio allows for connecting to a Mobile Network via a wireless connection. Alternately, a direct DHCP Ethernet connection can be used to access the DVR network. For network configuration and setup, consult your Information Technology (IT) department.





#### 15. VIDEO SYSTEM

The Video System consists of the following components:

- ☐ Luminator Video Controller located in the Electronic Equipment Enclosure
- ☐ Front and rear Display Screens

#### 15.1. Video System Controller

The video controller is a computer-based system with capabilities for interfacing with mass transit vehicle systems and the ODK IV. The controller delivers video display information to the screen displays installed in the vehicle.

Refer to the Preventive Maintenance section of this manual for information on scheduled maintenance intervals and procedures.

#### 15.2. Display Screen

The system is designed to self-start when the Master Run switch is set to the DAY-RUN, NIGHT-RUN, or NIGHT-PARK positions. A sequence of screens should appear on these displays and the boot-up process should take approximately one minute.



# 16. ELECTRICAL SYSTEM SCHEMATICS

#### 16.1. General

These schematics identify the various components of the electrical system, loca-

tions and specific data and are useful to troubleshoot the system. The schematics and related subject matter are disclosed in confidence and must be returned upon request. See "Fig. 9-63: VMM Schematic" on page 90.




Fig. 9-63: VMM Schematic



#### 16.2. Reading Schematics

Three codes are used for locating an I/O device; an address code (for the electronic control system), page code (to locate the device on a schematic), and a location code (the physical location on the vehicle).

Each schematic has a horizontal grid from 1 to 9, and a vertical grid from A to G. A two letter page code which is derived from the function in the vehicle that the schematic page represents is found in the title of each schematic.

A device legend explaining the I/O is included in the upper right corner of the schematic. Within each arrow of the schematic symbol is a location code to assist in finding the device. This location code gives the physical location of the I/O device on the vehicle (for example SC - the side console panel).

The schematic page titled "I/O Assignments" shows the input and output connections to each module. The inputs/outputs are shown in tables with their address code, a brief description, and page code. To locate the input/output on a schematic use the given page code to match the schematic title (for example from schematic "I/O Assignments" input, hazard switch (address code I2-4) is shown with a DS page code, then input can be located on the schematic titled DS (Driver's Signals).

Having located the device on the schematic (by matching address codes), the location code-SC can be found. Therefore the device is located in the side console panel of the vehicle.

#### 16.3. Wire Codes

An abbreviated form of the address is stamped on the wire connected to each I/O device. By simply looking at the wire, you can determine immediately what input or output is connected to any device controlled by the electronic control system.

For example, output O17-3 could be connected to the control module via wire EL80. If this wire runs to a terminal and splits to more devices, the wire at the electronic control system would be labeled EL80A, and the other wires would be labeled EL80B, EL80C and so forth.

Wiring not connected to the electronic control system is stamped with a code derived from the position of the wire on the schematic. The wire code is built up from the schematic code, the grid location, a digit from 1 to 9, and a letter if there are several wires connected to a common terminal.

Every wire running directly from a circuit breaker to a distinct load has a unique number, not a letter suffix.

#### 16.4. Wire Colors

The following wire colors are used throughout the vehicle:

24 VOLT POWERRED
12 VOLT POWERLIGHT BLUE
ELECTRONIC CONTROL INPUT WIRINGYELLOW
GROUNDSWHITE
SWITCHED POWER/GROUNDTAN

The communication network is shown as a double line.



#### 16.5. Page Codes

Each schematic has a horizontal grid from 1 to 9, and a vertical grid from A to G. A two letter page code which is derived from the function in the vehicle that the schematic page represents is found in the title of each schematic.

Here are the page codes for electrical schematics:

PAGE CODES				
PAGE CODE	TITLE			
GI	General Information			
PD	Power Distribution			
Ю	I/O Assignments			
NT	Network Topology			
PN	Primary Networks			
PS Power & Starting				
EN Engine				
TR	Transmission			
CC	Climate Control			
DC	Door Controls			
DS	Driver's Signal			
EL	Exterior Lighting			
IL	Interior Lighting			
LI	LI Lighting			
LK	Kneeling			
CP	Communication Provisions			
AF	Auxiliary Functions			
FS	Fire Suppression			
AB	Anti-Lock Braking			
IP	Instrument Panel			
SP	Spare Wires			

#### 16.6. Device Nomenclature

Where a device is supplied by a third party as part of a system, and is given a code by the vendor, that same code is used on the NFI schematic. For example, connectors supplied by ZF on their harnesses will be labeled BN(X) on the NFI schematic, just as they are in the ZF documentation.

Unique devices require no code for identification purposes, and are labeled on the schematic according to function.

Multiple devices such as circuit breakers and fuses are assigned a code based on the schematic page on which they are found. Thus F4DS is found on page DS, although it may feed loads found on other pages. This is clearly marked on the schematic.





# 17. VENDOR SERVICE INFORMATION

The following supplier manuals contain additional reference information.

#### 17.1. Vansco Manuals

- ☐ VMM 1210/1280/1615 Software User Guide
- □ VMM 1615 Hardware User Guide





# **HVAC System**

1.	SAFET	Ύ	10-1
	1.1. HV	AC System Safety	10-1
		ectrical Hazards	
		frigerant Hazards	
		frigerant Oil Hazards	
		st Aid	
		Refrigerant	
		.5.1.1. Frostbite	
		5.1.2. Eyes	
		5.1.3. Skin	
		.5.1.4. Inhalation	
		Refrigerant Oil	
		.5.2.1. Eyes	
	1	.5.2.2. Ingestion	10-5
2.	HEATII	NG/AIR CONDITIONING SYSTEMS	10-6
	2.1. Des	scription	10-6
		eration	
	2.2.1.		
	2.2.2.		
	2.2.3.		
	2.2.4.		
	2.2.5.	_	
	2.3. HV	AC Unit	
	2.3.1.		
	2.3.2.	·	
	2.3.3.	•	
	2.3.4.	·	
	2.3.5.		
	2.3.6.		
		elligAIRE III Control System	
	2.4.1.		
	2.4.2.		
	2.4.3.		
		2.4.3.1. Power Button	
		2.4.3.2. Set Point Up & Down Buttons	
		2.4.3.3. Zone Select Button	
		2.4.3.4. Alarm Indicators	
		2.4.3.5. Heating & Cooling Indicators	
	2.4.4.	Intelligaire III Control System Diagnostics	10-15

### Table of Contents



2.5.	Com	ıpressor	10-16
	2.5.1.	Description	10-16
	2.5.2.	Compressor Specifications	10-16
	2.5.3.	Operation	10-17
	2.5.4.	Maintenance	10-17
	2.5.5.	Compressor Mounts	10-17
	2.5.6.	Compressor Removal	10-18
	2.5.7.	Compressor Installation	10-18
2.6.	Driv	er's Heater/Defroster	10-19
	2.6.1.	Description	10-19
	2.6.2.	Heater/Defroster Specifications	
	2.6.3.	Operation	
	2.6.4.	Maintenance	
	2.6	.4.1. Blower Assembly Replacement	10-19
	2.6	.4.2. Heater Coil Replacement	
	2.6.5.	3	
		5.1. Vehicle Wiring Check	
		5.5.2. Component Diagnosis	
2.7.	Floo	r Heaters	
	2.7.1.	Description	
	2.7.2.	Floor Heaters Specifications	
	2.7.3.	Operation	10-26
	2.7.4.	Maintenance	
	2.7.5.	Removal	
	2.7.6.	Disassembly	
	2.7.7.	Assembly	
	2.7.8.	Installation	
	2.7.9.	Exit Door Floor Heater Troubleshooting	
		1.9.1. Vehicle Wiring Check	
• •		.9.2. Component Diagnosis	
		ster Pump	
	2.8.1.	Description	
	2.8.2.	Booster Pump Specifications	
	2.8.3.	Operation	
	2.8.4.	Booster Pump Troubleshooting	
	2.8.5.	Functional Tests	
	2.8.6.	Maintenance	
	2.8.7.	Removal	
	2.8.8.	Installation	
	2.8.9.	Pump Removal & Disassembly	
		Connecting Housing Disassembly	
		Pump Cleaning & Inspection	
		Pump Assembly & Installation	
		Connecting Housing Assembly	
		Motor Bearing Replacement	
		3.14.1.Motor Removal	
		: 14.3.Ball Bearing Replacement	
		1.14.4.Shaft & Rotor Assembly	
	2.0		10 07



	3.1. Thermo King Manuals	10-39
3.	VENDOR SERVICE INFORMATION	10-39
	2.8.15.3.Testing	10-38
	2.8.15.2.Installation	
	2.8.15.1.Removal	10-38
	2.8.15. Circuit Board/Heat-Sink Replacement	10-38
	2.8.14.5.Motor Testing & Installation	10-38





#### 1. SAFETY

#### 1.1. HVAC System Safety



DO NOT operate the compressor with the discharge valve closed. This condition causes internal pressure, which can cause an explosion



NEVER apply heat to a sealed refrigeration system or container. Heat increases internal pressure, which might cause an explosion.



Refrigerant in the presence of an open flame, spark or electrical short produces toxic gases that are severe respiratory irritants.



Keep your hands, clothing and tools clear of fans, pulleys, or belts when working on a unit that is running. Loose clothing might entangle moving fans, pulleys, or belts, causing serious injury or possible death.



DO NOT inhale refrigerant. Use caution when working with refrigerant or a refrigeration system in any confined area with a limited air supply, such as a bus or garage. Refrigerant displaces air and can cause oxygen depletion, resulting in suffocation and possible death.



Ensure that your gauge manifold hoses are in good condition before using them. Never let them come in contact with moving belts, motor, engine pulleys or hot surfaces. Defective gauge equipment can damage components or cause serious injury.



ALWAYS wear goggles or safety glasses when working around air conditioning systems or batteries. Refrigerant liquid, oil and battery acid can permanently damage your eyes.



Use extreme caution when drilling holes in the unit. Holes might weaken structural components. Holes drilled into electrical wiring can cause a fire or explosion.



Exposed coil fins can cause lacerations. Service work on the evaporator or condenser coils is best left to a certified Thermo King technician.



Be careful when using ladders or scaffolding to install or service air conditioning systems. A work platform is recommended for servicing rooftop units. Follow the equipment manufacturer's instructions, safety labels and warnings.



### **CAUTION**

Ensure that all mounting bolts are tight and are the correct length for their application. Improper torque and incorrect bolt lengths can result in damage to equipment.



If soldering is required, use dry nitrogen to purge the system during any solder operations. Refer to your Thermo King Maintenance Manual for additional information on using pressurized nitrogen.

#### 1.2. Electrical Hazards



Be careful to not accidentally ground any live circuit when working on the HVAC system. The amount of amperage available from the alternator can cause severe burns if accidentally shorted to ground with metal objects, such as tools.

### **WARNING**

DO NOT wear jewelry, watches, or rings because they increase the risk of shorting out electrical circuits and damaging equipment or causing severe burns.



Use caution when working with electrical circuits that have capacitors. Some capacitors hold a significant charge that might cause burns or shocks if accidentally discharged. Make sure capacitors are discharged before working on electrical circuits.



ALWAYS wear an electrostatic discharge (ESD) wrist strap and connect the opposite end to chassis ground when working on circuits that contain microprocessors. This precaution will prevent electrostatic discharge from damaging circuits.



ALWAYS set the Battery Disconnect switch to the OFF position whenever working on HVAC electrical circuits that are not required to be energized. This will prevent accidental shorting of any live circuits.



#### 1.3. Refrigerant Hazards



DO NOT use a Halide torch when servicing the HVAC system. When a flame comes in contact with refrigerant, toxic gases are produced that might cause suffocation or event death.



Store refrigerant in proper containers, out of direct sunlight and away from intense heat. Heat increases pressure inside storage containers, which can cause them to burst.



DO NOT use oxygen or compressed air for leak testing systems. Oxygen mixed with refrigerant is combustible.



Wear protective garments and goggles or safety glasses when working with refrigerant to prevent frostbite and eye injuries.



ALWAYS wear butyl lined gloves when handling refrigerant to help prevent frostbite.



All charging using the newer refrigerants (Azeotropic blends) must be done in the liquid state. Failure to do this will decrease system operating efficiency. Refer to the charging procedures found in your Thermo King Maintenance Manual.



When recovering or transferring refrigerant, use a process that prevents refrigerant from escaping into the atmosphere. Refrigerant damages the earth's upper ozone layer.



Refrigerant in a liquid state evaporates rapidly when exposed to the atmosphere, freezing anything it contacts. Be careful when handling refrigerant to protect your skin from frostbite.



#### 1.4. Refrigerant Oil Hazards



Protect your eyes from contact with refrigerant oil. The oil can cause serious eye injuries. Avoid prolonged or repeated contact with refrigerant oil. To prevent irritation, wash your hands and clothing thoroughly after handling the oil.



DO NOT mix refrigerant oils because that can cause system damage.



ALWAYS use dedicated equipment to prevent contaminating the system with the wrong type of oil or refrigerant.



ALWAYS use the specified oil listed in your Thermo King Maintenance Manual. Check the ID label on the HVAC equipment to confirm that the correct oil type is being used.



When servicing Thermo King units, DO NOT use equipment that might be contaminated with Polyalkylene Glycol (PAG) oils.



Store refrigerant oil in an approved sealed container to avoid moisture contamination.



DO NOT expose refrigerant oil to the atmosphere any longer than necessary. The oil will absorb moisture, which results in much longer evacuation times and possible system contamination.



ALWAYS wipe up spills immediately. Refrigerant oil can damage paints and rubber materials.



## 1.5. First Aid

#### 1.5.1. Refrigerant

#### 1.5.1.1. Frostbite

Warm the affected skin to body temperature as soon as possible.

#### 1.5.1.2. Eyes

Immediately flush eyes with large amounts of water. CALL A PHYSICIAN.

#### 1.5.1.3. Skin

Flush area with large amounts of warm water. DO NOT apply heat. Remove contaminated clothing and shoes. Wrap burns with dry, sterile, bulky dressing to protect from infection. CALL A PHYSICIAN.

#### ™NOTE:

Wash contaminated clothing before reuse.

#### 1.5.1.4. Inhalation

Move victim to fresh air and apply CPR (cardio-pulmonary resuscitation) or mouth-to-mouth resuscitation to restore breathing, if necessary. Stay with the victim until emergency personnel arrive.

#### 1.5.2. Refrigerant Oil

#### 1.5.2.1. Eyes

Immediately flush eyes with water for at least 15 minutes. CALL A PHYSICIAN. Wash skin with soap and water.

#### 1.5.2.2. Ingestion

DO NOT induce vomiting. Immediately contact local poison control center or physician.



# 2. HEATING/AIR CONDITIONING SYSTEMS



Engine damage may occur if pressurefill and deaeration procedures are not followed. Servicing heating system components may result in air being introduced into the system. It is necessary to completely bleed any air entrapped in the vehicle heating system and the engine cooling system before starting the engine. Refer to Section 6 of this manual for procedure.

## 2.1. Description

#### MOTE:

Refer to the HVAC System Layout when reviewing this information.

The Heating, Ventilation, & Air-Conditioning (HVAC) System is designed to regulate the temperature of the vehicle interior as well as dehumidify and filter the air. The major components of the vehicle HVAC System include:

- ☐ Roof-mounted HVAC unit.
- ☐ HVAC display panel located behind the ceiling-mounted access door.
- ☐ Refrigerant compressor located in the engine compartment.
- Driver's heater/defroster unit located centrally behind the front dash panel.
- Auxiliary floor heaters located on the floor, against the sidewalls.
- ☐ Booster pump located in the engine compartment.

## 2.2. Operation

#### 2.2.1. Air Circulation

The HVAC unit blower assembly draws interior air through the filter panel located in the access door. Air is forced across the heater/evaporator coils and circulated throughout the interior of the vehicle via overhead ducts located above the lighting panels.

The driver's heater/defroster blower assembly draws air through a filter located inside the defroster compartment. The defroster air recirculation control, located on the instrument panel, allows the driver to select interior air, outside air, or a blend of each. The air is circulated through ducts behind the dash panels to defroster outlets below the front windshield and to a heat outlet beneath the instrument panel.

#### 2.2.2. Coolant Circulation

The coolant booster pump draws coolant from the engine and delivers it to the HVAC unit heater coil, interior heater coils, and driver's heater/defroster unit heater coil. Manual shutoff valves are installed in the coolant supply and return lines located in the engine compartment and beneath the driver's platform. A solenoid controlled coolant shutoff valve is located inside the HVAC unit and a cable-operated coolant shutoff valve is located in the defroster compartment. Cooling system drain cocks are provided at the bottom of the radiator and in the driver's heater/defroster return line.



#### 2.2.3. Vehicle Heating System Bypass

A solenoid-operated shutoff valve is installed in the coolant return line and is used to bypass coolant from the vehicle interior heating system and recirculate the coolant directly back to the engine to promote quick engine warmup and maintain an efficient engine operating temperature. The solenoid valve is energized open by the vehicle multiplexing system if the system detects engine coolant temperature below a preset value.

#### 2.2.4. Refrigerant Circulation

Refrigerant flow is maintained by the HVAC compressor located in the engine compartment and driven by the engine crankshaft pulley. Refrigerant vapor from the compressor enters the condenser module.

The expansion valve admits liquid refrigerant from the condenser module to the evaporator coils located in evaporator module. Refrigerant vapor then returns to the compressor.

#### 2.2.5. Theory of Operation

In a typical vehicle unit, interior vehicle air is drawn through the return air grille. This air passes through a filter, evaporator coil and heater coil where it is dehumidified and cooled or heated per mode of system operation.

When the compressor starts operation, the pressure in the suction line and evaporator coil is reduced, causing the refrigerant gas to flow into the compressor. The compressor compresses the refrigerant gas causing an increase in temperature and

pressure. The compressor discharges this high temperature, high pressure refrigerant gas into the condenser. The outside air passing through the condenser coil is cooler than the temperature of the hot refrigerant gas. This temperature difference causes the hot refrigerant gas to give up its heat, thus lowering the temperature of the hot refrigerant gas. When this occurs, the refrigerant changes state from a vapor to a liquid (condenses). The receiver tank stores the refrigerant to meet the varying demands of the expansion valve. The refrigerant leaves the receiver tank through the liquid line and flows through the filter-drier (dehydrator) to the expansion valve. The filter-drier (dehydrator) removes moisture from the system.

The expansion valve meters the liquid into the evaporator coil. As vehicle air flows through the evaporator coil, the refrigerant picks up heat from the air and causes the refrigerant inside the evaporator coil to boil and change to a vapor. The air is cooled and returned to the vehicle. The compressor pumps the heated gas out of the evaporator coil and into the condenser coil causing the cycle to repeat itself. By removing heat from the vehicle faster than it can enter, the unit maintains the desired temperature.

If heat mode is selected, a booster pump circulates warm engine coolant through the heater coil.

The air is then warmed as it passes through the heater coil. Warm air is circulated maintaining thermostat setpoint temperature.



## 2.3. HVAC Unit

#### 2.3.1. Description

The RLF series is a one-piece condenser/ evaporator/heater assembly located on the roof of the vehicle. The HVAC unit is designed to interface with vehicle components such as the compressor, floor heaters and booster pump.

The evaporator, heater coil, and blower motors are housed in the front section of the unit. The condenser coil and fans are housed in the aft section of the unit.

An interior HVAC access door is located in the ceiling of the vehicle. Releasing the quarter-turn latches allows the hinged door to swing downward, providing access to the return air filter.

The receiver/dryer, sight glass, Intelligaire III control module, display module, return air temperature sensor, fuses, and J1939 diagnostic connector can also be accessed from below. All other HVAC components must be accessed from the rooftop. See "Fig. 10-1: Interior HVAC Components" on page 9.






Fig. 10-1: Interior HVAC Components



## 2.3.2. HVAC Unit Specifications

Manufacturer	Thermo King Corp.
Model	RLF2-M11
Condenser Motors	Brushless 24 VDC
Blower Motors	Brushless 24VDC
Refrigerant Type	R-134A

#### 2.3.3. Operation



DO NOT operate the compressor with the discharge valve closed. This conditions increases internal pressure, which can cause an explosion. The vehicle is equipped with a Multiplexing System, which interfaces the RLF unit with the Climate Control switch on the side console. It also allows interface with other HVAC components such as the compressor, floor heater, and boost pump as well as monitor system operation. The Climate Control switch allows the driver to select HVAC system modes of operation.

Depending on the input received from the mode switch, the electronic control system activates the appropriate control circuits to meet system demands, and regulate vehicle temperature. See "Fig. 10-2: HVAC Unit Installation" on page 11.

Refer to the Thermo King Maintenance Manual for specific details of operational mode.






Fig. 10-2: HVAC Unit Installation



#### 2.3.4. Maintenance



ALWAYS follow recommended safety procedures specific to the HVAC System when servicing the system. Refer to 1.1. "HVAC System Safety" on page 1 in this section for safety information.

Refer to the Preventive Maintenance Section of this manual for service intervals and procedures. Refer to 3. "VENDOR SERVICE INFORMATION" on page 39 in this section for further detailed information on service intervals and procedures.

#### 2.3.5. Removal



DO NOT perform any maintenance on roof-mounted components unless equipment is in place to prevent fall hazards. Ensure maintenance personnel use approved lift platforms or scaffolding and wear approved safety harness when working on the roof of the vehicle.

- 1. Set the Battery Disconnect switch to the OFF position.
- Evacuate the refrigerant from the A/C system. Refer to your Thermo King Maintenance Manual for evacuation procedure.
- Disconnect and plug refrigerant lines.
- Drain coolant from the HVAC heater core.
- 5. Disconnect and plug coolant hoses.
- Disconnect HVAC electrical harnesses that interface with vehicle wiring.
- 7. Remove the HVAC unit cover.
- Remove the lock nuts, washers, and spacers that secure the HVAC unit to the roof structure mounting studs. Note the location of washers and spacers for reassembly.
- 9. Attach lifting equipment to the HVAC unit ensuring the load is equally distributed.
- Remove the HVAC unit from the rooftop of the vehicle.



#### 2.3.6. Installation



DO NOT perform any maintenance on roof-mounted components unless equipment is in place to prevent fall hazards. Ensure maintenance personnel use approved lift platforms or scaffolding and wear approved safety harness when working on the roof of the vehicle.

- Prepare the rooftop mounting surfaces and HVAC unit underside surfaces for installation as follows:.
  - a. Scrape clean any existing sealant from the mounting area on the rooftop.
  - b. Apply the self-adhesive gasket to the underside of the HVAC unit. Apply the gasket around the perimeter of the evaporator section and apply a single gasket strip at the aft end of the condenser section.

## ™NOTE:

Position the splice on the evaporator gasket at the aft end of the evaporator and seal joint with Sika 221.

 Apply a generous bead of Sika 221 sealant to the area around each roof mounting stud.

- d. Place a spacer onto mounting stud and press the spacer into the sealant until the sealant is visible around the edges of the spacer.
- e. Apply a second generous bead of Sika 221 around each roof stud and over the spacer.
- Lift the HVAC unit into position and align the holes in the mounting brackets with the rooftop mounting studs.
- 3. Secure the HVAC unit with lock nuts and washers. Torque nuts to 22 ft-lbs. (30 Nm).
- Connect HVAC electrical harnesses to vehicle wiring.
- 5. Connect coolant hoses.
- 6. Connect refrigerant lines.
- Charge the A/C system. Refer to your Thermo King Maintenance Manual for recharging procedure.
- 8. Reinstall the HVAC unit cover.
- Set Battery Disconnect switch to the ON position.
- 10.Top up the cooling system and perform a deaeration procedure. Refer to Section 6 of this manual for deaeration procedure.
- 11. Test the heating and air-conditioning systems for proper operation.



## 2.4. IntelligAIRE III Control System

#### 2.4.1. Controller

The Intelligaire III Controller is a microprocessor equipped unit used to control the vehicle HVAC System. It provides the necessary control logic for all operating modes and has several programmable and diagnostic features such as:

- ☐ Programmable pre-heater function with real time clock activation to activate the system when the vehicle is shut off
- ☐ Technician capable override function for ease of troubleshooting
- Active fault code display
- ☐ Real time alarm and code storage with date and time stamp
- Optional pressure display panel

A single display module is capable of providing all functions. The default setting is "Automatic Control" for damper control, fan speed and operating mode. The controller can be programmed for manual control of the operating modes, fan speed and damper settings when manual switches are preferred. The Display Module can be used for set up parameter limits and has temperature read outs for the discharge air sensor and hybrid battery cooling coil (if equipped). The module has an auto dimming feature. It will illuminate or dim automatically depending on the ambient light conditions. The controller and display panel are accessible through the interior return air grille in the ceiling of the vehicle. See "Fig. 10-3: HVAC Control Panel" on page 14.




Fig. 10-3: HVAC Control Panel



#### 2.4.2. J1939 CAN Interface

The Intelligaire III Controller uses an internal Controller Area Network (CAN) bus to communicate with the HVAC unit, and display module. The main HVAC module also has a second CAN port that can plug directly into the vehicle's J1939 network.

## ™NOTE:

Refer to 3. "VENDOR SERVICE INFOR-MATION" on page 39 in this section for further information on the Intelligaire III Control System.

#### 2.4.3. HVAC Display Module Controls

#### 2.4.3.1. Power Button

The power button is used to turn the system on and off. If the power button is off and power is applied to the display module, the back lighting for the buttons will remain on and the LED indicators and 3-digit display will be turned off. In this mode, the display module will continue communicating with the main module. If the power button is on, the LED indicators and 3-digit display will be lit as determined by the operating mode.

#### 2.4.3.2. Set Point Up & Down Buttons

The temperature set point is adjusted by first selecting the zone to be configured, and then pressing the up or down button once. The set point icon will light and the 3-digit display will show the current temperature set point. Pressing the up or down button again will increment or decrement the set point by 1 degree. If no button is pressed within a 3 second timeout period, the display will return to the inside temperature for the zone selected.

#### 2.4.3.3. Zone Select Button

The temperature set point for the three inside zones and the outside ambient temperature can be displayed. The information displayed on the 3-digit display will coincide with the zone that is selected. Pressing the zone select button will cycle through each enabled zone as well as the outside ambient temperature.

#### 2.4.3.4. Alarm Indicators

The yellow alarm indicator will light to indicate a "check" alarm is currently active. These alarms include sensor readings out of range, open or shorted loads, etc. and may be viewed using the alarm code readout mode on the display module or by using the CAN Diag PC tool. These alarms will clear automatically when the condition is corrected.

The red alarm indicator will light to indicate a "shutdown" alarm has occurred. These alarms include high pressure cut out, low pressure cut out and compressor over temperature conditions. The compressor remains off in this mode and can only be reset by cycling the power button.

#### 2.4.3.5. Heating & Cooling Indicators

The red and blue LED indicators on the right hand side of the 3 digit display will light to indicate the current operating mode of the HVAC unit. The blue indicator will light whenever the compressor is running and the red indicator will light whenever the heat valve is operating.

## 2.4.4. Intelligaire III Control System Diagnostics

## ™NOTE:

Refer to 3. "VENDOR SERVICE INFOR-MATION" on page 39 in this section for information on the Intelligaire III Control System diagnostics.



## 2.5. Compressor

#### 2.5.1. Description

This vehicle is equipped with a Thermo King S391 helical lobed screw compressor. See "Fig. 10-4: Main Features of HVAC Compressor" on page 16. The compressor is belt driven by the engine through a heavy-duty electric clutch. Components of the compressor include:

- Discharge Service Valve used to close off discharge line to condenser when compressor is removed from the system.
- ☐ Suction Service Valve used to close off the compressor from the suction line when the refrigeration system is being serviced.

- Clutch electrically operated clutch to engage and disengage the compressor as commanded by the HVAC electric control system.
- Pressure Switches these cutout switches protect the system from high or low refrigerant pressures.
- Suppression Diode Assembly protects the electrical system from reverse voltage spikes when the clutch field coil is de-energized.

#### 2.5.2. Compressor Specifications

Manufacturer	Thermo King Corp
Model	S391
Туре	Helical Lobed Screw
Displacement(391 cc/rev)	23,86 cu. in./rev
Maximum Speed	3000 rpm




Fig. 10-4: Main Features of HVAC Compressor



#### 2.5.3. Operation



DO NOT operate the compressor with the discharge valve closed. This conditions increases internal pressure, which can cause an explosion.

The function of the compressor is to pump the low pressure gas out of the evaporator so that a rapid and continuous boiling action is maintained in the evaporator coil. The low pressure gas is compressed and forced into the condenser coil where it is cooled by air passing through the coil. The heat removed by the air flowing through the condenser causes it liquefy (condense).

#### 2.5.4. Maintenance



ALWAYS follow recommended safety procedures specific to the HVAC System when servicing the system. Refer to

## 1.1. "HVAC System Safety" on page 1 in this section for safety information.

Refer to the Preventive Maintenance Section of this manual for service intervals and procedures. Refer to 3. "VENDOR SERVICE INFORMATION" on page 39 in this section for further detailed information on service intervals and procedures.

#### 2.5.5. Compressor Mounts

The compressor is bolted to a mounting plate. The mounting plate is bolted to and pivots on a support bracket. The turnbuckle links the mounting plate and the support bracket. The turnbuckle and a slot in the mounting plate permit final tensioning adjustment of the compressor belt. After the turnbuckle is adjusted, a tension clamp (bolt bar) secures the mounting plate to the support bracket and maintains belt tension. An idler roller is mounted on a bracket next to the engine. It dampens belt oscillations during compressor operation. See "Fig. 10-5: A/C Compressor Installation" on page 17.




Fig. 10-5: A/C Compressor Installation



#### 2.5.6. Compressor Removal

- Evacuate the compressor and disconnect from system. Discard the brass washer from the discharge hose. Refer to the Thermo King Maintenance Manual for procedure. Observe all safety precautions and environmental regulations.
- Loosen the 3/4" bolt retaining the compressor mounting plate to the support bracket.
- 3. Loosen the two 5/8" nuts on the bolts clamping the compressor mounting plate to the support bracket.
- 4. Back off turn buckle to relieve belt tension and remove belt.
- Support compressor, remove four 3/8" bolts retaining compressor to mounting plate and remove compressor.

#### 2.5.7. Compressor Installation



The brass washer at both ends of the discharge hose is not reusable. Install new brass washer or washers when reconnecting the discharge hose.

- 1. Position the compressor on the mounting plate and hand-tighten the four 3/8" bolts.
- Use a straightedge to ensure the compressor pulley is aligned with the crankshaft pulley. Slide the compressor forward or aft on the mounting plate slotted holes until the pulleys are visually aligned. Torque the four 3/8" mounting bolts to 35 ft-lb. (47 Nm).
- 3. Install the belt and adjust the turnbuckle to obtain 250 lb. force on the belt.

- Torque the 3/4" pivot bolt that retains the mounting plate to the support plate to 304 ft-lbs. (412 Nm).
- 5. Torque the two 5/8" lock nuts that retain the mounting plate to the support plate to 172 ft-lb. (233 Nm).
- Adjust the position of the roller on the lower run of the belt so that it is centered beneath the belt and that a clearance of 0.06 to 0.12 inch exists.
- 7. Back off the turnbuckle one full turn to relieve tension on the turnbuckle.
- 8. Verify that the compressor pulley is properly aligned with the crankshaft pulley by measuring the angular deviation of the belt at each pulley. The sum of the two angular measurements must not exceed 0.5°. Readjust the fore/aft position of the compressor as required to meet the alignment requirements.



Use a backup wrench on the mating tube fitting nut when tightening the lines to prevent kinking, twisting, or stressing the tube.

- Lubricate seals with refrigerant oil and install new O-ring in suction line and new brass sealing washer in discharge line. Connect lines to compressor and torque fittings to 180 to 190 ft-lb. (244 to 258 Nm)
- 10. Recharge the system. Refer to Thermo King Maintenance Manual for procedure and observe all safety precautions and environmental regulations.
- 11.Operate the A/C compressor and check for proper operation. Check belt tension after run-in and readjust to 200 to 215 lb. force if required.



#### 2.6. Driver's Heater/Defroster

#### 2.6.1. Description

The driver's heater/defroster is located in the driver's area in the front dash panel. The defroster assembly consists of a heater core, blower motor, resistor module, and servo valves to control coolant flow and input and output air flow. This unit is operator controlled by switches located on the instrument panel.

#### 2.6.2. Heater/Defroster Specifications

Heating56880 btu/hr (150° T.D) @3.6 GPM
Airflow 462 CFM @ max speed
Voltage24V
Current (Low Speed)5.4A
Current (Med Speed)7.0A
Current (High Speed)8.5A
Vehicle Interface 21 pin Deutsch connector

#### 2.6.3. Operation

The defroster provides climate control for the driver's area. Heated liquid coolant is delivered to the defroster from the engine and bypassed or circulated through the defroster's heater core depending on the position of the dash controls. Servo actuators in the defroster activate with the dash controls to control the defroster temperature setting by regulating the amount of coolant flowing through the heater core. They also direct the airflow to provide exterior, interior recirculated air or a mix. The foot heat control provides heated airflow to the lower portion of the driver's area. Refer to Section 19 of this manual for more information on the operation of the Climate Controls.

#### 2.6.4. Maintenance

Refer to the Preventive Maintenance Section of this manual for scheduled intervals and service procedures.

#### 2.6.4.1. Blower Assembly Replacement

- 1. Set Battery Disconnect switch to the OFF position.
- Open front defroster access door and remove defroster access plate. See "Fig. 10-6: Heater/Defroster Assembly" on page 20.
- Unplug electrical connectors from blower motor and resistor module.
- Remove fasteners securing blower assembly to unit. Remove motor, blower housing, and resistor module as an assembly from the defroster unit.
- 5. Installation is reverse of removal.






Fig. 10-6: Heater/Defroster Assembly





1.	Heater/Defroster Assembly, 24V
	(Incl. 2-23, 27-50)

- 2. Coil, Heater
- 3. Filter, Air
- 4. Plate

5. Casing, Heater/Defroster

- 6. Plate
- 7. Plate
- 8. Door, Flapper
- 9. Panel, Access
- 10. Support, Hose
- 11. Holder, Door
- 12. Tie, Wrap
- 13. Holder, Blower
- 14. Flapper, Upper Door
- 15. Box, Flapper
- 16. Cover, Front
- 17. Clip
- 18. Rectifier
- 19. Relay, 24V
- 20. Harness, Wiring
- 21. Cable Clamp

- 22. Bushing, w/Set Screw
- 23. Heater Valve Assembly, (Incl. 24-26)
- 24. Bracket, Switch
- 25. Switch, Micro
- 26. Valve, Heater
- 27. Clamp, Gear
- 28. Hose, Drain
- 29. Grommet
- 30. Grommet
- 31. Grommet
- or. Grommor
- 32. Seal, Rubber33. Grommet
- \_ ...
- 34. Bushing
- 35. Plug, 3/8" 36. Receptacle
- 37. Retainer
- 38. Stud, Oval Slotted SST
- 39. Screw, Hex Head #10 - 32 UNF x 3/8" Lg.
- 40. Screw, Hex HD #10 32 x 1/2" Lg.
- 41. Screw, Hex HD #8 32 x 3/8" Lg.
- 42. Screw, Hex HD Tpg. #8 x 3/8" Lg.

- 43. Screw, PH #10 32 x 3/4" Lg.
- 44. Seal, 3/16" x 3"
- 45. Rivet, 3/16"
- 46. Neoprene, 1/16" x 2"
- 47. Nut, Push Flat Plate 3/16"
- 48. Hose, Silicone
- 49. Seal, Foam 103.5" Lg.
- 50. Blower Assembly, 24V (Incl. 51-62)
- 51. Bracket, Resistor
- 52. Clip
- 53. Venturi
- 54. Wheel, Blower
- 55. Housing, Top
- 56. Resistor, Aluminum 4 Speed
- 57. Pad, Motor
- 58. Housing, Blower
- 59. Nut, Lock Nylon #10 32
- 60. Screw, PH #10 32 x 3/4" Lg.
- 61. Pad, Motor
- 62. Motor, 24V

## Heater/Defroster Assembly (parts list)

#### 2.6.4.2. Heater Coil Replacement

- 1. Close coolant supply and return valves located on the streetside of vehicle.
- 2. Open front defroster access door and remove defroster access plate.
- 3. Disconnect coolant hoses from heater coil and drain coolant into a suitable container.
- Remove fasteners from heater coil mounting brackets and remove heater coil from defroster unit.
- 5. Installation is the reverse of removal. Top up coolant at surge tank, run engine, and check for leaks.



## 2.6.5. Heater/Defroster Troubleshooting

## ™NOTE:

Ensure that all electrical connections are clean and making proper contact before conducting troubleshooting procedures. Pay particular attention to the resistor module and motor connections.

This troubleshooting chart provides information to diagnose the various electrical components of the heater/defroster unit including the defroster blower motor, relays, variable fan speed control switch, and heater control valve limit switch. Refer to ES-Defroster Schematic in your New Flyer Vehicle System Drawing Manual.

HEATER/DEFROSTER TROUBLESHOOTING			
SYMPTOM	POSSIBLE CAUSE	RECOMMENDED ACTION	
Defroster motor inoperative.	No Power.	Refer to 2.6.5.1. "Vehicle Wiring Check" on page 23 in this section for procedure.	
	Faulty ground.	Check 21-pin Deutsch connector. Verify that cavity D on the connector is grounded to the vehicle.	
	Motor seized.	Replace motor.	
	Blower wheel obstructed or damaged	Remove obstruction.	
	Motor open circuit.	Replace motor.	
Defroster motor operates at high speed only.	Faulty resistor module (low or medium speed resistor).	Refer to 2.6.5.2. "Component Diagnosis" on page 24 in this section for procedure. Replace resistor module if defective.	
Defroster motor operates at low and medium speed only.	Faulty high speed relay.	Refer to 2.6.5.2. "Component Diagnosis" on page 24 in this section for relay testing procedure. Replace high speed relay if defective.	
	Faulty switch contacts on defroster fan speed control.	Replace defroster fan speed control. Refer to Section 19 of this manual for procedure.	
Defroster motor operates at medium and high speeds only.	Faulty resistor module (low speed resistor open).	Refer to 2.6.5.2. "Component Diagnosis" on page 24 in this section for procedure. Replace resistor block if defective.	
	Faulty contact on defroster fan speed control.	Replace defroster fan speed control. Refer to Section 19 of this manual for procedure.	
Frequent replacement of resistor module required.	Excessive current draw.	Test motor current draw (refer to specifications). Replace motor if defective.	
Defroster motor noisy.	Defroster motor bearings worn.	Replace defroster motor as an assembly.	
	Blower wheel rubbing.	Replace blower wheel if damaged.	



HEATER/DEFROSTER TROUBLESHOOTING		
SYMPTOM	POSSIBLE CAUSE	RECOMMENDED ACTION
Insufficient or no heat	No demand signal from heat control on instrument panel.	Test manual heat control switch. Refer to 2.6.5.2. "Component Diagnosis" on page 24 in this section.
	Heat control valve actuator faulty.	Test heat control valve actuator. Refer to 2.6.5.2. "Component Diagnosis" on page 24 in this section.
No air flow to driver's foot area	No demand signal from foot heat control on instrument panel.	Test foot heat control switch. Refer to 2.6.5.2. "Component Diagnosis" on page 24 in this section.
	Foot heat control valve actuator faulty.	Test foot heat control valve actuator. Refer to 2.6.5.2. "Component Diagnosis" on page 24 in this section.
Fresh air or recirculated air control not functioning properly	No demand signal from fresh/ recirculate control on instrument panel.	Test fresh/recirc control switch. Refer to 2.6.5.2. "Component Diagnosis" on page 24 in this section.
	Fresh/recirculate control valve actuator faulty.	Test fresh/recirc control valve actuator. Refer to 2.6.5.2. "Component Diagnosis" on page 24 in this section.

#### 2.6.5.1. Vehicle Wiring Check

- Set Master Run switch to the DAY-RUN position.
- Open the defroster/wiper access door to gain access to the defroster power harness. See "Fig. 10-7: Defroster Components" on page 24.

The following tests are performed with vehicle power applied to the heater/defroster unit. Use care when making test connections. Connect negative lead of voltmeter to cavity D (ground) on the 21-pin Deutsch connector and the positive lead to the indicated connector and cavity in each of the following test steps. Refer to vehicle Electrical Schematic.

Set Defroster Fan Speed switch to OFF and check for 24V at cavity B and H of the connector.

## ™NOTE:

If no power is indicated at these cavities, check for a tripped circuit breaker or faulty ground circuit. Refer to vehicle electrical schematic.

- Set Defroster Fan Speed switch to LOW and check for 24V at cavity F of the connector.
- Set Defroster Fan Speed switch to MED and check for 24V at cavity A of the connector.
- Set Defroster Fan Speed switch to HIGH and check for 24V at cavity C of the connector.

## ™NOTE:

If power is not indicated at any of the fan speed settings, remove Defroster Fan Speed control switch from instrument panel to confirm switch function.

 Rotate the temperature control counterclockwise from OFF to HOT and observe the voltage output at cavity N of the connector. Voltage should increase proportionately in response to movement towards the HOT position.

## ™NOTE:

If no power is indicated at cavity N check for a faulty control switch on the instrument panel.






Fig. 10-7: Defroster Components

#### 2.6.5.2. Component Diagnosis

#### **Resistor Module**

 Remove the resistor module from the heater/defroster unit and test as follows:

## ™NOTE:

Resistors and thermal cutoff devices are located inside the sealed module. The following diagnostic tests will need to be conducted at the terminal connection points on the module end.

- a. Test the resistance between the Motor terminal and the High Speed terminal. Verify that the value is 0 ohms. See "Fig. 10-8: Resistor Module" on page 25.
- Test the resistance between the Motor terminal and the Low Speed terminal.
   Verify that the value is 1.85 ohms ± 10%.
- c. Test the resistance between the Motor terminal and the Medium Speed terminal. Verify the value is 1 ohms ± 10%.

d. Test the resistance between the Medium Speed terminal and the Low Speed terminal. Verify the value is 0.85 ohms ± 10%.

Resistance readings must conform to these specified values. Measurements that are higher than these specified values will result in improper defroster motor operation. Open circuit readings indicate component failure within the module. In both cases, the module must be replaced.

#### **Electrical Relays**

- Remove the three 24V relays and test as follows:
  - a. Check for continuity between terminals No. 30 and No. 87A using an ohmmeter.
  - b. Check resistance of coil winding by connecting an ohmmeter between terminals No. 85 and No. 86. Resistance should be 360 ohms ± 10%.
  - c. Connect the positive lead from a 24V power supply to terminal No. 86.



- d. Connect the negative lead from the power supply to terminal No. 85.
- e. Turn the power supply ON. The relay should energize. Confirm that contacts are closed by checking for continuity between terminals No. 30 and No. 87, using an ohmmeter.

#### **Electrical Actuators (Servo Motors)**

There are three separate actuators that control the heater control valve, fresh/recirculate flapper valve, and foot heat flapper valve. The following test applies to all actuators.

1. Unplug 6-way connector from actuator.

- 2. Provide 24VDC power supply to pin A of actuator.
- 3. Provide vehicle ground to pin C.
- Use the signal line, pin D, to operate the actuator as follows:
  - a. Provide 24VDC power to pin D. Actuator should drive the operating device fully CCW, viewed from the connector side.
  - Remove power from pin D and provide vehicle ground to pin D. Actuator should drive the operating device fully CW, viewed from the connector side.
  - c. Replace actuator if operation is faulty.




Fig. 10-8: Resistor Module



#### 2.7. Floor Heaters

## 2.7.1. Description

The heaters are located on the streetside and curbside of the vehicle, forward of the exit door. They are floor-mounted. The heaters consist of a stainless steel housing, heater coil, blower, speed control relays and resistors and an air filter.

## 2.7.2. Floor Heaters Specifications

41,000 BTU/F ferential)	H (at 150°F Temperature Dif-
Air Flow	. 350 CFM (at High Speed)
	3.7 A (at 27 V High Speed) 1 A (at 27 V Low Speed)

#### 2.7.3. Operation

Heating

The floor heaters receive heated engine coolant whenever the Climate Control switch is in the HEAT mode. Low speed and high speed blower operation is determined by the rooftop HVAC unit.

#### 2.7.4. Maintenance

Refer to the Preventive Maintenance Section of this manual for scheduled maintenance requirements.

#### 2.7.5. Removal

- 1. Shut off coolant supply and return valves to the heater system.
- 2. From underneath the vehicle, disconnect the coolant supply and return hoses from

the heater taking care to catch any spilled coolant in an appropriate container.

- Tag and disconnect the vehicle wiring harness from the junction block.
- Remove the nuts and washers fastening the heater to the vehicle floor.
- 5. From inside the vehicle, pull the heater up and remove from the vehicle.

### ™NOTE:

The floor holes for the heater hoses are sealed with Butyl tape and Sikaflex. It may be necessary to cut through and remove the sealant before you can remove the heater.

#### 2.7.6. Disassembly

- Remove the filter retainer and slide the filter out. See "Fig. 10-9: Streetside Heater Assembly" on page 27. See "Fig. 10-10: Curbside Heater Assembly" on page 28.
- Remove the top cover fasteners and remove the cover.
- Remove the side cover fasteners and remove the covers.
- 4. Disconnect the electrical connector to the blower motor assembly.
- 5. Remove the blower retainer bracket fasteners and remove the retainers.
- 6. Remove the blower assembly.
- 7. Remove the divider fasteners.
- Pull the divider out of the casing.
- Remove the fasteners retaining the heater coil to the casing and remove the heater coil.




Fig. 10-9: Streetside Heater Assembly






Fig. 10-10: Curbside Heater Assembly



#### 2.7.7. Assembly

- 1. Install the heater coil to the casing and secure in place with mounting fasteners.
- 2. Install the divider to the casing.
- 3. Install the blower assembly and secure in place with retainer brackets and fasteners.
- 4. Connect the electrical connector.
- Attach the side covers with previously removed fasteners.
- 6. Install the top cover.
- Slide the filter into the heater and install the filter retainer.

#### 2.7.8. Installation

- Clean the sealant from the existing heater mounting holes.
- Apply butyl tape around heater inlet and outlet tubes.
- Install the heater into the vehicle from inside.
- 4. From underneath the vehicle, install and tighten mounting fasteners.
- Connect the vehicle wiring harness to the junction block.
- 6. Connect the coolant supply and return hoses and torque clamps to  $4.2 \pm 1.7$  ft-lb  $(5.6 \pm 2.3 \text{ Nm})$
- Apply Sikaflex to seal the heater tube holes.
- 8. Open coolant supply and return valves to the heater system.



## 2.7.9. Exit Door Floor Heater Troubleshooting NOTE:

Ensure that all electrical connections are clean and making proper contact before conducting troubleshooting procedures. Pay particular attention to the drive module and motor connections.

This troubleshooting chart provides information to diagnose the various electrical components of the heater/ unit including the blower motor, speed relays, variable fan speed resistors, and temperature sensor. Refer to the "ES-Curbside Floor Heater" and "ES-Climate Control CC" schematics in the vehicle systems drawing manual.

EXIT DOOR FLOOR HEATER TROUBLESHOOTING		
SYMPTOM	POSSIBLE CAUSE	RECOMMENDED ACTION
Heater motor inoperative	No power	Perform "Vehicle Wiring Check" in this section.
Порегануе	Faulty ground	Check connection to Terminal "D" on vehicle wiring harness interface. Verify that Terminal "D" is properly grounded to the vehicle.
	Motor seized	Replace motor.
	Blower wheel obstructed or damaged	Remove obstruction.
	Motor open circuit	Refer to 2.7.9.2. "Component Diagnosis" on page 31 in this section for procedure. Replace motor as an assembly if defective.
	Faulty fan speed resistor or resistors	Refer to 2.7.9.2. "Component Diagnosis" on page 31 in this section for procedure. Replace wire harness if a resistor is defective.
	Faulty fan speed relay or relays	Refer to 2.7.9.2. "Component Diagnosis" on page 31 in this section for procedure. Replace relay if defective.
Heater motor noisy	Heater motor bearings worn	Replace motor as an assembly.
	Blower wheel rubbing	Replace blower wheel if bent or damaged.



## 2.7.9.1. Vehicle Wiring Check

- Set Master Run switch to the DAY-RUN position but do not start engine.
- 2. Remove the cover of the heater unit to gain access to the heater components.



The following test is performed with vehicle power applied to the heater unit electrical connector. Use care when making connections and taking measurements. Connect negative lead of voltmeter to terminal "D" (ground) and the positive lead to the indicated terminal in each of the following test steps. Refer to "ES-Climate Control CC" electrical schematic.

3. Check for 24VDC at terminal "A".

#### ™NOTE:

If no power is indicated at terminal "A", check for a tripped circuit breaker or faulty ground circuit. Refer to vehicle electrical schematic.

#### 2.7.9.2. Component Diagnosis

- Set the Master Run switch to the STOP-ENGINE position.
- 2. Unplug the relays from their sockets and test as follows:
  - Use an ohmmeter to ensure continuity exists between terminals No. 30 and No. 87A.
  - b. Check the resistance of the relay coil winding by connecting the positive lead of the ohmmeter to terminal No. 85 and the negative lead of the ohmmeter to terminal No. 86. Resistance should be 360 Ohm ± 10%.

- c. Connect the positive lead from a 24VDC power supply to terminal No. 86
- d. Connect the negative lead from the power supply to terminal No. 85. The relay should energize.
- Maintain the test conditions from the previous step and confirm that relay contacts are closed by checking for continuity with an ohmmeter across terminals No. 30 and No. 87.
- 3. Unplug the 3-pin motor connector and test the fan speed resistors as follows:

#### RNOTE:

Refer to the Heater schematic in the Vehicle Systems Drawing Manual.

- Use an ohmmeter to check the resistance between terminal B and C on the motor connector. The value should be 10K Ohms.
- b. Check the resistance between terminal B on the motor connector and 87 on the R1 relay connector. The value should be 56K Ohms.
- c. Check the resistance between terminal B on the motor connector and 87 on the R2 relay connector. The value should be 20K Ohms.

#### ™NOTE:

Replace the wire harness if measurements indicate a resistor is short circuited, open, or deviates greatly from the specified values.

#### ™NOTE:

If the motor still fails to operate, replace the drive motor.



## 2.8. Booster Pump

#### 2.8.1. Description

The booster pump is an integral motor and pump assembly that uses an electronically commutated DC motor and magnetically driven impeller pump. The booster pump is a seal-less design, which allows removal of the motor section from the pump without draining the coolant. The booster pump is mounted to the vehicle frame on the street-side of the engine compartment.

#### 2.8.2. Booster Pump Specifications

Manufacturer	Ametek/Rotron
Operating Voltage	24 Volts DC

Current Draw	4.8 Amps
Flow Rate	18 GPM
Speed	3100 RPM

#### 2.8.3. Operation

The booster pump receives coolant from the engine outlet hose and delivers it to the HVAC unit and also to the driver's heater/defroster unit. The booster pump is operational when the engine is running and the electronic control system receives a heat request signal from either the HVAC unit or driver's heater/defroster unit.

#### 2.8.4. Booster Pump Troubleshooting

BOOSTER PUMP TROUBLESHOOTING			
PROBLEM	POSSIBLE CAUSE	SOLUTION	
Motor inoperative	No electrical power at pump.	Check voltage at motor red (+) lead. Refer to electrical schematic ES - Climate Control and Vansco VMM program to verify output signal.	
	Loose or corroded electrical connections	Tighten and clean connections	
Motor operates but flow insufficient	Restricted lines	Check inlet and discharge lines for blockage. Verify that ball valve in inlet line is fully open.	
	Pump has decoupled from motor	Check current draw. Refer to 2.8.5. "Functional Tests" on page 33 in this section for procedure.	
	Magnetic cup loose on rotor shaft	Tighten setscrews.	



#### 2.8.5. Functional Tests

- With the unit installed in the vehicle, attach an inductive type DC ammeter, with a range of 500 mA to 10 amps, over the red (+) lead on the motor. Attach a voltmeter to the red (+) and black (-) leads of the motor.
- Operate the booster pump and confirm that voltage reading is approximately 27.6 VDC. The following ammeter readings indicate various conditions:
  - a. Reading of 2.5 to 5.5 Amps indicates normal operating condition.
  - b. Reading of 0.5 to 1.0 Amp indicates that the motor has decoupled due to pump seizure. Remove pump assembly and inspect for obstruction.
  - c. Reading of 7.0 Amp or higher indicates excessive torque required to drive the pump assembly Remove pump assembly and inspect for restriction or binding condition.
  - d. Reading of 7.0 Amp or higher indicates possible motor bearing failure. Remove the motor assembly from the pump and test motor current draw. If current for the motor alone exceeds 1.5 amps, then replace the motor bearings.
  - Reading of 100 mA or less indicates improper supply voltage. Verify proper supply voltage.

#### 2.8.6. Maintenance

Refer to the Preventive Maintenance Section of this manual for scheduled intervals and service procedures.

#### 2.8.7. Removal

#### ™NOTE:

The following procedure describes removal of the booster pump and motor as an assembly. If the motor only is being serviced, then it is not necessary to drain coolant or disconnect the coolant hoses. The motor can be separated from the pump and removed for servicing as a separate item.

Set Battery Disconnect switch to the OFF position.

- Disconnect electrical leads from motor. See "Fig. 10-11: Booster Pump Installation" on page 33.
- Close shut-off valves in the coolant supply and return lines.
- Place a drain pan beneath the booster pump.
- Loosen the clamps and disconnect the coolant supply and discharge hoses from the booster pump.
- Remove all fasteners that attach the booster bump baseplate to the vehicle. Note the location of any washers, spacers, or brackets.
- Remove the booster pump assembly from the vehicle.




Fig. 10-11: Booster Pump Installation



#### 2.8.8. Installation

- Align the holes in the booster pump baseplate with the holes in the mounting bracket.
- Install and tighten all fasteners and any washers, spacers, clamps, or brackets in the same position as noted during removal.
- Connect coolant supply and discharge hoses and tighten hose clamps to 70 inlbs. (8 Nm).
- 4. Plug in electrical connector.
- 5. Open coolant shut-off valves.
- 6. Top up coolant to correct level.
- 7. Set the Battery Disconnect switch to the ON position.
- 8. Run engine and check for leaks.

#### 2.8.9. Pump Removal & Disassembly

- Mark the position of the pump housing with respect to the connector ring housing and connecting housing. See "Fig. 10-12: Booster Pump Assembly" on page 36.
- 2. Remove the four socket head screws that attach the baseplate to the motor.
- 3. Remove the pump housing assembly from the connecting housing by removing the four socket head screws and washers.
- 4. Remove and discard the connecting housing gasket.
- 5. Disassemble the pump as follows:
  - Remove four flathead screws and separate housing connector ring from pump housing.
  - b. Remove impeller housing.
  - Remove and discard round gasket.
  - d. Remove the impeller assembly from the impeller shaft.
  - e. Remove the thrust washer from the pump housing.

## 2.8.10. Connecting Housing Disassembly

### ™NOTE:

Remove the connecting housing from the motor if visual inspection indicates that parts require replacement.

- Remove the plastic threaded plug from the connector housing and rotate the drive magnet until a set screw is aligned with the access hole.
- 2. Loosen the setscrew.
- 3. Rotate the drive magnet until the second set screw is aligned with the access hole.
- 4. Loosen the second setscrew and slide the drive magnet off the motor shaft.
- Remove the four flathead screws and remove the connecting housing from the motor assembly.

#### 2.8.11. Pump Cleaning & Inspection

- 1. Inspect the impeller assembly, thrust washer, and pump housing for cracks, dents, worn surfaces, or other damage.
- Replace worn or damaged parts as necessary.
- Clean all parts that will be reused.

#### 2.8.12. Pump Assembly & Installation

- Install the thrust washer in the pump housing.
- Attach the impeller assembly to the impeller shaft.
- Install a new round gasket between the impeller assembly and the impeller housing.
- 4. Slide the impeller housing over the impeller assembly, being careful not to pinch or bend the gasket.
- Align the connector ring housing with the pump housing using the reference marks made during removal.
- Apply Loctite 242 to the screw threads and install four flathead screws to secure connecting ring to pump housing.
- Torque screws to 120 to 130 in-lb. (13.5 to 14.6 Nm).
- 8. Test the pump for leaks.



#### 2.8.13. Connecting Housing Assembly

- Apply Loctite 242 to the threads of the four flathead screws and attach connecting housing to motor.
- Torque screws to 25 to 35 in-lbs. (26 to 28 dNm).
- Insert the drive magnet into the connector housing, aligning the flats on the motor shaft with the setscrew locations on the drive magnet.

#### RNOTE:

Ensure that the inside face of the drive magnet is flush with the end of the motor shaft.

- Apply Loctite 271 or 272 to the first three threads of the setscrews and install the setscrews into the drive magnet. Torque both setscrews to 50 to 55 in-lb. (56 to 62 dNm).
- 5. Insert the plastic threaded plug into the hole on the side of the connecting housing.
- Install pump housing onto connecting housing, ensuring blast direction (outlet) is correctly oriented, as marked during removal.
- Apply Loctite 242 to the threads of the four socket head screws and secure pump housing to connecting housing with screws and flat washers.
- 8. Torque screws to 55 to 60 in-lbs. (62 to 68 dNm).

#### 2.8.14. Motor Bearing Replacement

#### ™NOTE:

The motor may be separated from the booster pump without removing the pump section from the vehicle.

#### ™NOTE:

The following procedure describes the removal of the shaft and rotor assembly to access the motor bearings. Refer to "Circuit Board/Heat Sink Replacement" in this section if further disassembly of the motor is required.

#### 2.8.14.1.Motor Removal

- Set Battery Disconnect switch to the OFF position.
- 2. Disconnect electrical leads from motor.
- Separate the motor from the pump assembly by removing the four socket head screws and washers that attach the connecting housing to the pump housing.
- Remove all fasteners that attach the booster bump baseplate to the vehicle. Note the location of any washers, spacers, or brackets.
- Remove the motor assembly from the vehicle and move to a clean work area.
- Remove the connecting housing from the motor. Refer to 2.8.10. "Connecting Housing Disassembly" on page 34 in this section for procedure.

#### 2.8.14.2.Shaft & Rotor Disassembly

1. Remove the four recessed panhead screws that attach the electronics housing to the motor housing.

## ™NOTE:

Do not remove the circuit board assembly on the end of the electronics housing.

Carefully remove the electronics housing from the motor housing while noting the location of the shim and wave washer on the end of the bearing shaft.

#### ™NOTE:

The wave washer and shim must be reinstalled in the same position during assembly.

3. Remove the shaft and rotor assembly from the motor, being careful not to chip or otherwise damage the encoder magnet located on the end of the shaft.

### ™NOTE:

If the encoder magnet is damaged, the entire shaft and rotor assembly must be replaced.






Fig. 10-12: Booster Pump Assembly



- 1. Booster Pump Assembly, 27V (Incl. 2-9, 18)
- 2. Magnet, Drive
- 3. Housing, Connecting
- 4. Washer, Flat
- 5. Screw. Socket Head
- 6. Gasket, Connecting Bracket
- 7. Plug, Plastic
- 8. Screw, Flat Head
- 9. Housing Assembly, (Incl. 10-17)
- 10. Housing, Pump
- 11. Washer, Thrust
- 12. Shaft, Impeller
- 13. Impeller Assembly
- 14. Gasket
- 15. Housing, Impeller
- 16. Housing, Connector Ring
- 17. Screw, FH
- 18. Motor, 27V (Incl. 19-37)
- 19. Screw, Pan Head #6 32 UNC x .75" Lg.

- 20. Washer, Flat #6
- 21. Electrical Assembly
- 22. Housing, Electronics
- 23. O-Ring
- 24. Stator & Housing Assembly
- 25. Shaft & Rotor Assembly
- 26. Ball Bearing
- 27. Wave Washer
- 28. Shim
- 29. Tubing, Heatsink
- 30. Shell, Female Connector
- 31. Terminal, Male
- 32. Seal, Cable
- 33. Base Plate
- 34. Loom
- 35. Ties. Cable
- 36. Washer, Flat 1/4"
- 37. Screw, Socket Head 1/4" 20 UNC x .50" Lg.

Booster Pump Assembly (parts list)

### 2.8.14.3.Ball Bearing Replacement

 Remove the ball bearings from the shaft/ rotor assembly.



The ball bearings are press fit on the shaft and will need a press to be removed. Support the bearing and apply force to the shoulder of the shaft/ rotor assembly. DO NOT apply force to the encoder magnet.

- 2. Discard the bearings.
- 3. Clean the ball bearing seat using No. 800 emery cloth and lubricate shaft as needed.



DO NOT apply force to the encoder magnet when pressing the new bearings onto the shaft/rotor assembly.

4. Install new bearings on the shaft/rotor using a bearing press fixture. Support the inner race of bearing while pressing the shaft until the bearing is fully seated.

#### 2.8.14.4.Shaft & Rotor Assembly



Use care not to damage the encoder magnet on the end of the shaft/rotor assembly when installing shaft/rotor assembly into stator housing. Ensure that the shaft/rotor assembly does not contact the stator of the stator housing.

- Carefully install the shaft/rotor assembly, with installed bearings, into the stator housing assembly.
- Position the wave washer and shim, as originally positioned, on the end of the shaft/rotor assembly nearest the electronics housing.
- Install new O-ring and assemble electronics housing on stator housing assembly using four panhead screws.
- Torque screws to 18 to 20 in-lb. (20 to 23 dNm).
- Verify that shaft/rotor assembly is assembled correctly by pushing on the end of the shaft. The shaft should spring back if properly installed.



## ™NOTE:

If the shaft does not spring back, remove screws completely, reposition electronics housing on stator housing and retorque screws.

#### 2.8.14.5.Motor Testing & Installation

- Connect the motor lead wires to a 24V power supply, ensuring correct polarity.
- Set the input voltage to 27.6V and energize the motor.
- Verify that the motor is rotating clockwise, as viewed from the motor end with the wire leads.
- Use an ammeter to verify that current draw is approximately 1 amp after one minute of operation.
- Reassemble the motor to the pump. Refer to 2.8.13. "Connecting Housing Assembly" on page 35 in this section for assembly procedure.

## 2.8.15. Circuit Board/Heat-Sink Replacement NOTE:

The following procedure describes the steps required to separate the motor from the pump and replace the circuit board/heat sink assembly.

#### 2.8.15.1.Removal

- Remove the motor from the pump. Refer to 2.8.9. "Pump Removal & Disassembly" on page 34 in this section for removal procedure.
- Note the location where the motor lead wires exit the circuit board/heat-sink assembly with respect to the electronics housing. Scribe a mark on the electronics housing.
- Remove the two panhead screws and washers on the rear of the circuit board/ heat-sink assembly.
- Carefully remove the circuit board/heatsink assembly from the electronics housing.
- Identify and disconnect the stator lead wires from the terminal header on the circuit board/heat-sink assembly.

- Remove and discard the circuit board/ heat-sink assembly.
- Remove all old RTV sealant and clean mating surfaces between circuit board/ heat-sink assembly and electronics housing.

#### 2.8.15.2.Installation

- Attach the stator lead wires to the circuit board/heat-sink assembly as marked during removal.
- Apply a bead of electronics-compatible RTV sealant, such as Dow Corning 3145, around the edge of the electronics housing.



Ensure that the lead wires between the stator housing and circuit board/heat-sink assembly do not rub on the shaft/ rotor assembly.

Position the circuit board/heat-sink assembly in its original position, as marked during disassembly, and secure in position with two panhead screws and washers.

### 2.8.15.3.Testing

- Install an ammeter in the circuit and connect a 24 VDC power supply to the red (+) and black (-) motor lead wires. Record current draw with no load condition.
- 2. Remove the two panhead screws and rotate the PCB/heat-sink assembly 15° in either direction until the lowest current draw is obtained. The current draw should be approximately one amp at rated speed after one minute of run-in without pump attached. The motor should be rotating in a clockwise direction as viewed from the electronics housing end of the motor.
- 3. Install and torque the two panhead screws to 14 to 16 in-lb. (16 to 18 dNm).
- Re-energize the motor and verify clockwise rotation and current draw of approximately 1 amp after one minute of operation.
- Reinstall motor on pump. Refer to 2.8.13.
   "Connecting Housing Assembly" on page 35 in this section for procedure.





# 3. VENDOR SERVICE INFORMATION

The following supplier manuals contain additional reference information.

## 3.1. Thermo King Manuals

- ☐ RLF2-M13 Maintenance Manual
- ☐ IntelligAIRE III Controller Diagnostic Manual





# **Structures & Chassis**

1.	SAFETY	11-1
	1.1. Safety Procedures	11-1
2.	STRUCTURES & CHASSIS	11-2
	2.1. Description	11-2
	2.2. Warranty Limitation	
	2.3. Identification	
	2.4. Welding Procedures	
	2.4.1. Welding Electronic Precautions	
	2.4.2. General Welding Procedures	
	2.4.2.1. Welding Electrode Selection	
	2.4.3. Straightening	
	2.4.4. Cutting	
	2.4.5. Reinforcing	
	2.4.6. General Stainless Steel Welding Procedure	
	2.4.6.1. Cleaning	
	2.4.6.2. Preheating	11-6
	2.4.6.3. Welding	
	2.4.6.4. Post-Heating & Post-Weld Cleaning	
	2.4.6.5. Weld Inspection	
	2.4.7. Austenitic Stainless Steel to Austenitic Stainless Steel Welding Procedure	
	2.4.7.1. Shielded Metal Arc Welding (SMAW)	
	2.4.8. Austenitic or Ferritic Stainless Steel to Carbon Steel Welding Procedure	
	2.4.8.1. Shielded Metal Arc Welding (SMAW)	
	2.4.8.2. Gas Metal Arc Welding (GMAW)	
	2.4.9. Ferritic SS to Ferritic SS or Ferritic SS to Austenitic SS Welding Procedure	
3.	CORROSION PROTECTION	11-9
•-	3.1. Prevention	
	3.2. Corrosion Treatment	
	3.2.1. Introduction	
	0-1-1	
	·	
	3.3. Primer Application	
	3.4. Undercoating Application	
	3.5. Frame Tubing Internal Coating	
	3.6. Corrosion Warranty Inspection	11-15

# Table of Contents



3.6.1.	Frequency of Inspection	11-15
3.6.2.	Inspection Procedure	11-15
	.6.2.1. Under Body Inspection	
3.6.3.	Repairs for Undercoated Areas	11-17
3.6.4.	Repairs for Non-Undercoated Areas	11-17
3.	.6.4.1. Areas of Structure Hidden by Paneling	11-17
	Record Keeping	



# 1. SAFETY

# 1.1. Safety Procedures

This section of the service manual contains procedures which require the mechanics to strictly observe safety procedures in order to ensure personal and equipment safety.

Refer to the General Information Section of this manual for information on types of hoists, hoisting procedures, jackstands and related safety information. Refer to this information and read carefully before lifting, hoisting or jacking the vehicle.

Always ensure that the vehicle is appropriately hoisted and blocked for procedures which require elevating the vehicle. Be aware of the limitations of the blocking equipment, and always ensure that the jarring and shaking created by component removal and installation procedures does not overload the blocks, or cause the vehicle to become unstable.

Certain procedures may require the vehicle be operated in an elevated position in order to accurately troubleshoot and diagnose a problem. If the vehicle must be running while elevated, become familiar with the repair area prior to starting the engine. Take special care in noting areas which will become hot, electrically energized, and areas where moving and rotating components are located. Limit the work in these areas as personal and equipment safety is at risk.

For procedures which involve air lines, ensure the line is safely depressurized prior to disconnecting. Disconnecting pressurized lines will cause solid particles deposited in the line to be uncontrollably propelled, and will also cause the hose end to whip randomly as the air escapes.

During electrical diagnosis procedures an understanding of the vehicle's electric circuits is important to anticipate the results of connecting test equipment. During component removal or installation, ensure the Battery Disconnect switch is in the OFF position.

Failure to follow this procedure may result in personal injury or component failure.

Observe the following procedures involving hydraulic line removal.

- Hydraulic fluid is corrosive and should not be exposed to skin for extensive periods of time.
- Wear eve protection at all times.
- Pressurized lines should not be disconnected until the pressure is safely and controllably released.



# 2. STRUCTURES & CHASSIS

# 2.1. Description

The vehicle structure and chassis is fabricated mainly from steel tubing and reinforcing gussets and consists of the following subassemblies:

Front Chassis
Center Chassis
Rear Chassis
Front Structure
Sidewall Structure
Roof Structure

The vehicle structure and chassis are comprised mainly of carbon steel, but ferritic stainless steel is also used in some areas to aid in corrosion protection. Ferritic stainless steel requires special welding procedures and electrodes when repairing these areas of the vehicle structure. Contact New Flyer Technical Services for additional information on the location of ferritic stainless steel parts and associated welding procedures whenever repairs are necessary.

Structural components can be repaired and replaced by competent craftsmen with proper tools and equipment. Welders repairing the structure and chassis of the New Flyer vehicle shall meet the qualifications for "All Position" welding per Part II of the AWS Standard "Qualifications For Metal Arc Welding".

# 2.2. Warranty Limitation

New Flyer Industries reserves the right to refuse warranty on any section or part of the body structure welded on or in any way modified or repaired by other than New Flyer approved personnel. New Flyer also reserves the right to refuse warranty on any component failure deemed to be the result of any unauthorized modification.

#### 2.3. Identification

Each vehicle structure can be identified by the Chassis Identification Number plate riveted to the engine cradle.





# 2.4. Welding Procedures

#### 2.4.1. Welding Electronic Precautions

Large voltage spikes will occur when striking an arc during arc welding or plasma cutting operations. These voltage spikes can easily damage electronic modules in the vehicle electrical systems. The various modules used in the Multiplexing System share chassis grounds and therefore simply disconnecting the battery cables will not afford the protection required. All electronic module grounds must be isolated from the vehicle chassis ground whenever performing arc welding or plasma cutting operations on the vehicle.

Taking the following precautions will minimize the potential for electronic module damage:

- ☐ Turn off all vehicle electrical loads and set the Master Run switch to the STOP-ENGINE position.
- Set the Battery Disconnect switch to the OFF position.

- ☐ Ensure the welding ground clamp is of adequate size for the welder and that the clamp is as close as possible to the area being welded.
- ☐ Make sure the welding clamp makes a good connection to the ground surface. Remove any paint or coatings so that bare metal is exposed at the ground point.
- ☐ Ensure that the cable ground side of the clamp makes a good ground with the vehicle if using a one-sided ground clamp. Do not rely on the opposite side of the clamp to make the ground connection.
- Do not attach the ground clamp to a vehicle ground terminal bar. The terminal bar may be a ground point for an electronic module.
- □ Do not position the welding ground clamp in a location that would place a vehicle electronic ground point between the repair area and the welding ground clamp.
- ☐ If welding on different vehicle frame rails always relocate the welding ground clamp to the frame rail that is being repaired.
- Do not route welder electrical cables directly across from or near any of the vehicle's electrical wiring harnesses.

"X1".





Adhering to the preceding precautions will minimize the likelihood of damage to any electronic modules, however, to ensure no damage occurs it is recommended that all electronic modules be disconnected including:

- Engine ECM disconnect the vehicle interface harness connector.
   Transmission ECU disconnect the vehicle interface harness connector.
   Anti-Locking Braking System (ABS) ECM disconnect the 18-pin connector
- □ Vansco Multiplexing Modules (VMM) disconnect all VMM1615 modules.
- □ EMP Radiator disconnect positive and negative power cables from radiator. Unplug connector from TMC system controller located on radiator.
- Destination Sign disconnect the vehicle interface harness connector.
- Instrument Panel disconnect all wiring connectors from the backside of the instrument panel.

- HVAC (Intelligaire III Controller) disconnect vehicle interface harness connector.
- ☐ Fire Suppression Display Panel disconnect the vehicle interface harness connector.
- □ Vanner Voltage Equalizer disconnect all ground and ground sensing connectors.
- □ AVA/AVL Systems disconnect the vehicle interface connector from Doublemap module.
- □ Video Surveillance System disconnect the vehicle interface connector from Gatekeeper unit.
- □ Driver/Vehicle Monitoring System disconnect the vehicle interface connectors from the New Flyer Connect™ Main Board Unit.
- □ Vapor Door Control Module disconnect the JII power connector.
- □ APC System disconnect the vehicle interface connector from sensor module.
- □ Video System disconnect the vehicle interface connector from control box.



#### 2.4.2. General Welding Procedures

#### 2.4.2.1. Welding Electrode Selection

Use the following welding electrodes for joining materials:

WELDING ELECTRODE SELECTION		
STRUCTURE TYPE	ELECTRODE	
Carbon Steel to Carbon Steel	ER-49S 3	
Ferritic SST to Carbon Steel	ER-309L Si	
Ferritic SST to 304/304L SST	ER-309L Si	
Ferritic SST to Ferritic SST	ER-309L Si	
304/304L SST to Carbon Steel	ER-309L Si	
304/304L SST to 304/304L SST	ER-308L Si	

## ™NOTE:

Carbon Steel to Carbon Steel can also use ER-309L Si.

All welds are to be made with E7018, low hydrogen, welding rods or ER705-3 wire. Weld gaps should not exceed thickness of material up to a maximum of 1/8".

 Remove all old weld using carbon arc (airarc), grinder, or pneumatic chipper when required.



Faulty welding or improper installation could cause property damage, personal injury or death. Refer to 2.2. "Warranty Limitation" on page 2 in this section limiting New Flyer's liability.

- Oxygen-acetylene torches should not be used. If a carbon arc is used, the area to be rewelded should be ground to remove carbon deposits.
- 3. The area enclosed by the weld zone plus two inches to either side of the weld zone must be cleaned to the base metal by wire brush, removing all grease, oil, rust and scale from surfaces to be joined. The temperature of the steel parts to be welded together must be at or above 10°C before commencing to weld.

#### 2.4.3. Straightening

The use of heat when straightening structural parts of the body is not recommended, since heat affects structural characteristics of certain alloys especially heat-treated parts.

All body structural members should be straightened cold; any part bent or buckled sufficiently to show strains or cracks after straightening, should be replaced or properly reinforced.

#### 2.4.4. **Cutting**



Refer to 2.4.1. "Welding Electronic Precautions" on page 3 in this section if using a plasma cutter.

When cutting a structural member, cut at an angle of 30°. Thus, actual length of cut is twice the width of piece being cut and stress or load is distributed over a longer joint when welded.

Cutting can be done by torch, although use of saw is preferred since cut is cleaner and less material is removed.



#### 2.4.5. Reinforcing



Before reinforcing any part, determine the cause of failure. Reinforcing a point of apparent failure without correcting underlying cause of failure may transfer stress to other parts not engineered for such stress, resulting in development of new failures. Since the body is designed to be flexible, rigid reinforcement in any part of body may nullify the design.

Reinforcing can be made of flat, angle or channel stock, whichever is most suitable for the purpose. Reinforcements should be sufficiently long to distribute load evenly over a considerable area and thickness should not exceed that of member being reinforced. Reinforcements should be welded to broken parts.

# 2.4.6. General Stainless Steel Welding Procedure

#### 2.4.6.1. Cleaning

The surface of the parts to be welded must be free of grease, oil, paint, dirt, etc. Cleaning should be done immediately before welding to prevent the formation of oxides. A clean surface will provide a smoother, stronger joint. Use a stainless steel wire brush to remove burrs and oxides. Gloves should be worn to prevent contamination of the weld surface by hand oil or dirt.

#### 2.4.6.2. Preheating

Preheat is not required for most 300 austenitic grade stainless steels. The base metal should be brought to room temperature, 60 to 75°F. Preheat is necessary when welding thicker ferritic or martensitic grades. It is also needed when joining thick metals or metals containing a high percentage of carbon.

#### 2.4.6.3. Welding

- □ All stainless steel weld joints are to be welded in accordance with American Welding Society code "AWS D1.6 Structural Welding Code - Stainless Steel".
- □ All welds joining austenitic SS to austenitic SS are to be made using 308/308L welding wire; otherwise use 309/309L welding wire when at least one side of the weld joint contains ferritic SS or carbon steel.
- Weld gaps should not exceed the thickness of the material to maximum of 1/8".

#### 2.4.6.4. Post-Heating & Post-Weld Cleaning

Post-heating may be required to relieve internal stresses caused by the concentration of heat in the weld area. Post-heating slows down of the cooling process to minimize cracking. This is a good procedure to use when joining thick metals.

Shielded metal arc and flux cored welding leaves a slag residue on the weld. Remove slag with a chipping hammer or by grinding. Stainless steel is much more sensitive to sharp edges. Any weld toes or weld craters that contain sharp edges must be ground down to a smooth profile.

#### 2.4.6.5. Weld Inspection

When inspection is required, liquid penetrant inspection (LPI) is the specified non-destructive test procedure. Austenitic stainless steels are not magnetic, and will not respond to magnetic particle inspection. Contact New Flyer should details be required for the LPI process.

Once stainless steel is welded, the area does not need any further corrosion protection. Stainless steel is inherently corrosion resistant. If a dissimilar weld was made, or if the weld was a carbon steel weld, corrosion treatment is required to obtain adequate protection.



# 2.4.7. Austenitic Stainless Steel to Austenitic Stainless Steel Welding Procedure

#### 2.4.7.1. Shielded Metal Arc Welding (SMAW)

Use a 308/308L type welding rod, of appropriate thickness for the material being repaired. For most scenarios, an electrode thickness of 1/8" should be adequate. New Flyer does not employ SMAW to fabricate bus frames and the recommended welding rods have not been tested. Follow the power requirements suggested by the electrode manufacturer. Most SMAW electrodes do not permit welding in the vertical down position.

#### 2.4.7.2. Gas Metal Arc Welding (GMAW)

Electrode 308/308L at a diameter of 0.035" is to be used with a shielding gas containing 98% Ar-2% CO2. Shield gas flow rate of 30 cfh is adequate. For material thicknesses up to and including 0.134", set weld machine to 18 volts and a wire feed speed of 310 inches per minute. This should result in amperage of approximately 131 amps. For material thicknesses greater than 0.134", set weld machine to 22.5 volts and a wire feed speed of 400 inches per minute. This should result in amperage of approximately 161 amps. This procedure is valid in all welding positions.

# 2.4.8. Austenitic or Ferritic Stainless Steel to Carbon Steel Welding Procedure

#### 2.4.8.1. Shielded Metal Arc Welding (SMAW)

Use a 309/309L type welding rod, of appropriate thickness for the material to being repaired. Most welds involving dissimilar metals are performed on thick material. An electrode thickness of 3/16" should be adequate. New Flyer does not employ SMAW to fabricate bus frames and the recommended welding rods have not been tested. Follow the power requirements suggested by the electrode manufacturer. Most SMAW electrodes do not permit welding in the vertical down position.

#### 2.4.8.2. Gas Metal Arc Welding (GMAW)

Electrode 309/309L at a diameter of 0.035" is to be used with a shielding gas containing 98% Ar-2% CO2. Shield gas flow rate of 30 cfh is adequate. For all material thicknesses, set weld machine to 24 volts and a wire feed speed of 475 inches per minute. This should result in amperage of approximately 175 amps. This procedure is valid in all welding positions.



# 2.4.9. Ferritic SS to Ferritic SS or Ferritic SS to Austenitic SS Welding Procedure

Electrode 309/309L at a diameter of 0.035" is to be used with a shielding gas containing 98% Ar-2% CO2.

For material thicknesses of 0.188", 0.250 and 0.375" use a shield gas flow rate of 35 cfh. Set the weld machine to 28 volts and a wire feed speed of 600 inches per minute. This should result in a current of approximately 190 amps. This procedure is valid for fillet welds on corner, tee or lap joints, in the flat and horizontal welding positions.

For material thicknesses of 0.060", 0.080", 0.125", 0.188" use a shield gas flow rate of 35 cfh. Set weld machine to 28 volts and a wire feed speed of 550 inches per minute. This should result in amperage of approximately 190 amps. This procedure is valid for fillet welds on corner, tee or lap joints in the flat, horizontal and vertical down welding positions.

For material thicknesses of 0.060" and 0.080" use a shield gas flow rate of 30-35 cfh. Set weld machine to 27 volts and a wire feed speed of 550 inches per minute. This should result in amperage of approximately 180 amps. This procedure is valid for flare or bevel groove welds in the flat and horizontal welding positions.

For material thicknesses of 0.125" and 0.188" use a shield gas flow rate of 30-35 cfh. Set weld machine to 28 volts and a wire feed speed of 600 inches per minute. This should result in amperage of approximately 190 amps. This procedure is valid for flare or bevel groove welds in the flat and horizontal welding positions.

For material thicknesses of 0.060, 0.080, and 0.125" use a shield gas flow rate of 30-35 cfh. Set weld machine to 23 volts and a wire feed speed of 400 inches per minute. This should result in amperage of approximately 160 amps. This procedure is valid for flare or bevel groove welds in overhead positions.



# 3. CORROSION PROTECTION

#### 3.1. Prevention

Periodically clean the under-structure to remove dirt accumulation from flanges, ledges, channels and so forth. These places hold dirt and salt in direct contact with steel and aluminum surfaces. Use of an under-structure spray as part of the regular washing, with an occasional and more thorough cleaning with a high pressure spray is recommended.

## 3.2. Corrosion Treatment

#### 3.2.1. Introduction

The under structure of your New Flyer vehicle has been protected using the following products:

- ☐ Chemkleen CL90 to clean structure.
- ☐ Urethane Zinc Rich Primer consisting of S28079 catalyst and S28080 zinc powder.
- ☐ Corashield<sup>™</sup> 7972 undercoating compound
- ☐ Coratube<sup>™</sup> used as an internal structural tube coating

All of these products are available from PPG Industries.

#### 3.2.2. Surface Preparation

The vehicle frame and chassis must be prepped through several processes to adequately protect the structure and chassis from premature corrosion.



#### 3.2.3. Replacement Structure

- Replacement structural members must be thoroughly washed with a Chemkleen CL90 and water solution using a high pressure wand. This process will remove dirt and oil from the surface to be treated.
- 2. Thoroughly rinse the cleaned structure with water using a high pressure wand.
- 3. Allow the steel members to dry thoroughly.

#### MOTE:

The structure must be dirt and grease free before grit blasting, to prevent dirt and oil from being imbedded into the grit blasted pores.

4. Grit blast the cleaned and dry structure to bare metal. Grit blast all surfaces to an SSPC-SP-6 profile of 1.0 to 2.0 mils. Wheel abrade any spots missed grit blasting which still have rust, millscale or weld spatter still present.

#### ™NOTE:

SSPC-SP-6/NACE No. 3 "Commercial Blast Cleaning" is a standard available from SSPC: The Society for Protective Coatings.

Use compressed air to remove all grit from structure surface. Work down from the top of the blast area.



If available, sandblasting can be used for cleaning bulkheads, brackets and other structural members. However, sand blasting should not be used for cleaning the side paneling of vehicle body. Extreme care should be taken not to sandblast excessively.

# ™NOTE:

This procedure must be followed exactly to produce a properly iron phosphate treated metal surface. This will provide the bonding surface required for adequate primer adhesion for corrosion protection.

- 6. Parts coated with zinc primer and undercoating with a damage area not more than 1/8" in width may be repaired by applying undercoating over the damage area.
- Damaged undercoated areas more than 1/ 8" in width must be cleaned to bare metal. Clean 2" around the damage area in all directions.
- 8. Tube type frame members closed at both ends must be drilled to allow insertion of the spray tip into the tube. The hole should be 1/2" in diameter and approximately midway along the length of the tube to permit complete spray coverage.
- Use caulking sealant (Sika-221) to seal between side panels and frame, between floor and frame and anywhere water could seep into.
- 10. Allow caulking to skin over for a minimum of 15 minutes.
- 11. Mask exposed fittings and hoses.

#### 3.2.4. Existing Structure

For parts coated with previously applied zinc rich primer only, sandblast or wheel abrade the repair area to bare metal, and reapply primer as described. Observe requirements of steps 3. through 8. of "Replacement Structure" to properly treat damaged area before application of primer. See "Fig. 11-1: Untreated Repair Area" on page 11. See "Fig. 11-2: Surface Cleanup" on page 11.




Fig. 11-1: Untreated Repair Area




Fig. 11-2: Surface Cleanup



# 3.3. Primer Application

Primer is applied to all metal parts forming the structure.



Observe all workplace safety standards and procedures. Wear chemical splash protection goggles or a face shield. Use an organic vapor respirator with a dust and mist prefilter as atmospheric conditions require. Wear chemical resistant protective clothing for skin protection such as gloves, apron, coveralls and safety footwear, as required.

- Work in a properly ventilated area with an exhaust and intake system that will safely and efficiently remove fumes and supply fresh air.
- 2. Prepare primer by combining one gallon of S28079 liquid to 29 lb. of S28080 zinc powder as per instructions. Mix thoroughly and use immediately.

# ™NOTE:

DO NOT apply primer if ambient temperature is below 40°F (5°C) or if humidity is less than 12% or above 90%. Primer cannot be applied over undercoating material.

 Apply primer using a brush or appropriate spraying equipment. Wet film thickness should be 6.5 mils. This will result in a dry film of 3.0 to 4.0 mils. Film thickness is important to ensure adhesion and corrosion protection. See "Fig. 11-3: Primer Application" on page 12.

#### ™NOTE:

Air mix spray gun must maintain an air atomization pressure of 60 lb., with a fluid pressure set at 1,000 psi. Airless spray gun operates at a fluid pressure of 2,000 to 4,000 psi. Primer may be mixed with up to 10% thinner when using an air mix sprayer or up to 5% when using an airless sprayer.

4. Ensure all surfaces are properly coated and allow a minimum of 4 hours curing time.




Fig. 11-3: Primer Application



# 3.4. Undercoating Application

Undercoating is factory applied to all the under chassis areas exposed to road spray.

## MOTE:

DO NOT apply undercoat to the following components: axles, bellows, suspension beams, radius rods, steering box, leveling valves, brake valves, safety valves, drain cocks, and the air dryer.

- Mix undercoating compound (Corashield<sup>™</sup> 7972) and thin to required consistency.
- 2. Ensure ambient temperature is between 50 and 90°F (10 and 32°C) and humidity is under 80%. Substrate temperature cannot exceed 212°F (100°C).

- Spray repair areas with a wet film thickness of 20 mils while maintaining a spray distance of 12 to 15" (30 to 38 cm). Dry film thickness to be 10 mils minimum. See "Fig. 11-4: Corashield Application" on page 13.
- 4. If undercoating will not adhere properly, wash area with appropriate solvent and allow to dry for 5 to 10 minutes. Repeat spraying process and allow undercoating to set for a minimum of 10 minutes.

#### ™NOTE:

DO NOT allow freezing of the repaired area for a minimum of 24 hours.

Allow adequate air flow to ensure even drying. Material should be dry to touch in 30 minutes, dry hard in 24 hours and fully cured in 72 hours.




Fig. 11-4: Corashield Application



# 3.5. Frame Tubing Internal Coating

Any tubing that is being replaced must be internally coated with Coratube.

- 1. Insert spray nozzle into tube through 1/2" hole previously drilled and spray sufficient
- compound to fully coat the internal faces of the tubing. See "Fig. 11-5: Coratube Application" on page 14.
- 2. Remove spray nozzle and install sealing plugs.




Fig. 11-5: Coratube Application

# **Corrosion Warranty Inspection**

# 3.6. Corrosion Warranty Inspection

#### ™NOTE:

New Flyer Industries requires that the inspection, maintenance and record keeping requirements covered in this document be performed. Failure to perform these procedures may void the corrosion warranty on affected units.

#### 3.6.1. Frequency of Inspection

The maximum benefit from the corrosion protection of your vehicle can only be achieved with proper care and maintenance. No protection that can be applied to a vehicle can totally protect the vehicle from all the damage to which it may be subjected. Damage from stones, gravel and other vehicles can remove the coatings and leave the metal open to the elements. The most effective method available that can come close to preventing corrosion is an inspection policy and consistent maintenance of the coatings.

The vehicle under body must be fully inspected and cleaned as outlined in this document every three (3) years. Failure to inspect and keep accurate records of these inspections will result in the warranty of the coating system being voided. Please be advised that any curbing or other inci-

dents that may have removed the corrosion protection coating must be repaired within 1 month of incident.

#### 3.6.2. Inspection Procedure

The areas to inspect on a constant basis are areas of high physical wear and high air movement. The area with high impact are areas like behind the wheel wells and structural members that face the front of the vehicle. These areas will face the full impact of road debris, as in stones, and face the most paint erosion.

Areas of high air movement, like intake vents and air conditioning units must be inspected as well. These areas tend to collect dust and dirt that can hold moisture and promote erosion and corrosion in all types of parts.

The following areas are to be inspected. Refer to 3.6.1. "Frequency of Inspection" on page 15 in this section for stated frequency. Prior to the inspection the vehicle should be raised and a preliminary inspection should be given to the under body to find the areas of road debris build-up. These areas should be paid extra attention due to the fact that this debris can hold moisture and promote corrosion.



#### 3.6.2.1. Under Body Inspection

- 1. Perform preliminary inspection for dirt/sand built-up.
- Clean any excess dirt/sand using a stream
  of high pressure water with a weak detergent. Ensure the entire structure is
  cleaned thoroughly including the top surfaces of structural tubes, gusset faces, lap
  joints and interior corners where structural
  members are welded at an angle.
- Start at the front of the vehicle. The area between the front bumper and the front axle will show the minimum amount of erosion/corrosion from water and road debris.
- 4. Front wheel wells should be looked at next. Bare fiberglass at wheel wells means that the vehicle has been in a high erosion area (for example gravel roads).
- 5. The area from the front wheel wells to the rear bumper should be examined for areas of missing primer or undercoating. Structural members that face the direction of travel will experience the worst erosion from road debris being brought up from the tires

- Inspect suspension bunks for paint erosion.
- Inspect the main structural rails above the rear axles. Check at the structural lap joints for loose adhesive. Clean any collected dirt and look for peeling primer and eroded undercoating. Lap joints are areas where crevice and pitting can have the most detrimental affect.
- Inspect the top of the tubes located at the bottom of the side panels for dirt and moisture. Check for corrosion and paint peeling.
- Ensure all drain holes are clean and not plugged.
- 10. Check all lap joints. Any lap joint with missing sealant must be cleaned with high pressure water and sealed with a urethane caulking as per the repair manual.

#### RNOTE:

Any holes, caused by accidents, in side panels, pier panels or roof panels should be filled to prevent water from entering into and sitting behind the paneling. This moisture can be held next to structural tubing and promote high levels of corrosion if allowed to remain.

# **Corrosion Warranty Inspection**

#### 3.6.3. Repairs for Undercoated Areas

- Any scratches, gouges or cracks found in the undercoating that reached the primer or steel underneath must be repaired by first thoroughly grinding the area to remove any contamination and rust. All bare metal surfaces must be primed with Coraprime (available from the New Flyer Parts Division). If the undercoating has been penetrated but the under lying primer is still intact, no repairs are necessary.
- Any adhesive missing from lap joints should be replaced by thoroughly cleaning the area of dirt and grease, and applying the urethane adhesive.
- The Corashield undercoating can then be applied to the required thickness. Corashield is available from the New Flyer Parts Division.

#### 3.6.4. Repairs for Non-Undercoated Areas

- Any area which does not have the undercoating must be repaired by grinding the area and the 1/4" around the damaged area. The bare metal must be primed with Coraprime.
- 2. Corashield must be applied to the determined thickness. This product is available from the New Flyer Parts Division.

#### 3.6.4.1. Areas of Structure Hidden by Paneling

New Flyer does not expect maintenance personnel to inspect the structure underneath paneling, during the above process. Nevertheless, if the customer must replace a panel for any reason they must take the time to inspect the structure for dust or dirt that may have accumulated. Any dirt should be cleaned and the area dried out at this time and the structure examined for corrosion. Any corrosion or loose primer should be repaired before paneling is replaced. Any tubing replaced due to accident damage must have its interior walls under coated with Coratube<sup>TM</sup> available from the New Flyer Parts Division.

#### 3.6.5. Record Keeping

The warranty states that all inspections and repairs must be documented and kept on file for the life of the warranty. The following is the minimum of what should be recorded:

- The Vehicle Serial Number.
- The date of the last repair/inspection.
- 3. The reason for the inspection and/or reason for the vehicle being in the shop.
- 4. What was found and what was done to repair the vehicle. This includes if it was surface corrosion or if there was a perforation of the structure. Include a photograph of the affected area if possible.
- 5. The name of the inspector.
- 6. The name of the worker doing the repair.
- 7. Was a New Flyer service representative called? If so, who?

If you are unsure which products were used on your vehicle order, please contact the New Flyer Customer Services Dept. at:

□ tel: (204) 934-4874 fax: (204) 224-0248





# **Interior Panels & Applied Parts**

1.			
	1.1. Safety P	Procedures	12-1
2.	INTERIOR I	PANELS	12-3
	2.1. Descript	tion	12-3
	-	g	
		Panel Replacement	
		ash Panels	
		cription	
		er RH Dash Panel Replacement	
		er RH Dash Panel Replacement	
		er LH Dash Panel Replacement	
		Kick Panel Replacement	
		Panel Assembly Replacement	
	2.5. Sidewall	l Panels	12-10
		cription	
		n Sidewall Panel Replacement	
		er Kick Panel Replacement	
	2.6. Pier Pan	nels	12-10
		cription	
		Panel Installation	
		Panels	
	_	cription	
		ing Panel Replacement	
		Ikhead Panel	
		cription	
		sing Panels	
		cription	
		noval	
		allation	
		ommended Rivet Drill Sizes	
		ing Procedure	
		allation & Selection	
		noval	
3.	FLOORING		12-16
	3.1. Descript	tion	12-16

# Table of Contents



	3.2. Cor	mposite Flooring	12-17
	3.2.1.	Description	12-17
		or Covering	
		Description	
	3.3.2.	Flooring Specifications	12-17
	3.3.3.	Cleaning	12-17
	3.3.4.	Repair	12-18
	3.	.3.4.1. Flooring Removal	12-18
	3.	3.4.2. Flooring Installation	12-18
4.	SAFET	Y EQUIPMENT	12-20
	4.1. Fire	e Extinguisher	12-20
	4.1.1.	Description	12-20
		Operation	
	4.2. Safe	ety Triangle	12-20
	421	Description	12-20



# 1. SAFETY

# 1.1. Safety Procedures

This section of the service manual contains procedures which require the mechanics to strictly observe safety procedures in order to ensure personal and equipment safety.

Refer to the General Information Section of this manual for information on types of hoists, hoisting procedures, jackstands and related safety information. Refer to this information and read carefully before lifting, hoisting or jacking the vehicle.

Always ensure that the vehicle is appropriately hoisted and blocked for procedures which require elevating the vehicle. Be aware of the limitations of the blocking equipment, and always ensure that the jarring and shaking created by component removal and installation procedures does not overload the blocks, or cause the vehicle to become unstable.

Certain procedures may require the vehicle be operated in an elevated position in order to accurately troubleshoot and diagnose a problem. If the vehicle must be running while elevated, become familiar with the repair area prior to starting the engine. Take special care in noting areas which will become hot, electrically energized, and areas where moving and rotating components are located. Limit the work in these areas as personal and equipment safety is at risk.

For procedures which involve air lines, ensure the line is safely depressurized prior to disconnecting. Disconnecting pressurized lines will cause solid particles deposited in the line to be uncontrollably propelled, and will also cause the hose end to whip randomly as the air escapes.

During electrical diagnosis procedures an understanding of the vehicle's electric circuits is important to anticipate the results of connecting test equipment. During component removal or installation, ensure the Battery Disconnect switch is in the OFF position.

Failure to follow this procedure may result in personal injury or component failure.

Observe the following procedures involving hydraulic line removal.

- Hydraulic fluid is corrosive and should not be exposed to skin for extensive periods of time
- Wear eye protection at all times.
- Pressurized lines should not be disconnected until the pressure is safely and controllably released.



Because fumes are more dangerous in a small space, be sure the vehicle is well ventilated while using any cleaning agent. Follow the manufacturer's advice in using such products. Many cleaners may be poisonous or flammable, and their improper use may cause personal injury or damage to the inside of the vehicle. Therefore, when cleaning the interior, DO NOT use volatile cleaning solvents such as: acetone, lacquer thinners, enamel reducers, nail polish removers; or such cleaning materials as laundry soaps, bleaches, or reducing agents (except as noted in the fabric cleaning advice on stain removal later). **NEVER** use carbon cleaning products.



## PNOTE:

To avoid possible permanent discoloration on light colored trim, DO NOT let materials with unstable dyes come in contact with seat trim materials until totally dry.

Proper cleaning techniques and cleaners must be used on trim materials. Failure to do this on the first cleaning may result in water spots, spot rings, setting of stains, or soilage, all of which make it more difficult to remove in a second cleaning.



Overexposure to adhesives used in this section, specifically Sikaflex-252, may cause breathing difficulties, sensitization, headaches, nausea, vomiting. May aggravate respiratory, skin, eye, lung problems and allergies. If the product is applied according to the manufacturer's

directions, none of these symptoms should be encountered. A person who is allergic to isocyanate may have a reaction with a level of isocyanate well below the T.L.V. Xylene is a central nervous system depressor and in rare cases, may cause a sensitization of the heart muscle causing arrhythmia.

Ensure the user is provided with a full face mask or safety glasses, a rubber apron, sufficient ventilation, and an eyewash station or shower. In case of overexposure, remove contaminated clothing and shoes, wash with plenty of water, wash clothing before rewearing, and consult a physician. If eyes are exposed, rinse immediately for several minutes. See a physician immediately. In case of inhalation, evacuate to fresh air and consult a physician. In case of ingestion, drink plenty of water or milk. DO NOT induce vomiting. See a physician immediately.



# 2. INTERIOR PANELS

# 2.1. Description

Interior panels include the following:

- ☐ Front Dash Panels
- ☐ Sidewall Panels
- □ Pier Panels
- Rear Panels
- Ceiling Panels

# 2.2. Cleaning



DO NOT spray or brush liquid cleaning solutions onto the dash panels or any other areas that may have electrical components behind the surface or nearby. ALWAYS use a cloth dampened with cleaning solution to clean these areas.

The acrylic/PVC panels used in the interior of the vehicle have excellent stain and soilage resistance. If a surface does become stained, the best procedure is to first clean the surface with a household concentration of detergent and water or an ammoniated

type household cleaner. Alcohol solutions such as automobile windshield washer solvents can also be used. The use of a short, fine, stiff-bristled brush and vigorous scrubbing strokes will give the best results in removing most stains.

If the stain cannot be removed using standard cleaning methods, immerse a stiff bristled brush in ethyl cellosolve or perchloroethylene. These solvents are suitable for removing stains such as felt-tip markers, wax crayons and lipstick.

# 2.3. Interior Panel Replacement

The panels used within the interior of the vehicle are assembled with a combination of adhesives, structural tape, screws, rivets, push-in fasteners, and snap-in moldings. Procedures specific to each panel must be followed in order to guarantee a satisfactory installation. Detailed instructions including cleaning, priming, bonding, and attachment procedures are provide in New Flyer engineering installation drawings. Please contact New Flyer Customer Service for detailed installation procedures (engineering installation drawings) and material requirements for the specific panel being replaced. Refer to panel replacement in this section for a basic description of how the panels are attached to the vehicle.



## 2.4. Front Dash Panels

#### 2.4.1. Description

The front dash panels include the upper & lower RH dash panels, upper LH dash

panel, LH kick panel, side console panel assembly, and associated closeout panels. These panels are constructed of 0.118" thick Kydex thermoplastic acrylic/PVC formed sheets. See "Fig. 12-1: Dash Panels Installation" on page 4.




Fig. 12-1: Dash Panels Installation



## 2.4.2. Lower RH Dash Panel Replacement

The lower RH dash panel covers the lower dash area from the entrance door to the driver's platform. The panel is attached to the vehicle structure using double-sided tape and push-in clips. See "Fig. 12-2: Lower RH Dash Panel Installation" on page 5.




Fig. 12-2: Lower RH Dash Panel Installation



# 2.4.3. Upper RH Dash Panel Replacement

The upper RH dash panel is located immediately above the lower RH dash panel and includes the defroster outlet ducts. The

panel is attached to the vehicle structure using Velcro tape. See "Fig. 12-3: Upper RH Dash Panel Installation" on page 6.




Fig. 12-3: Upper RH Dash Panel Installation



# 2.4.4. Upper LH Dash Panel Replacement

The upper LH dash panel is located below the instrument panel and is attached to the

instrument panel frame base with 7 pushin clips. See "Fig. 12-4: Upper LH Dash Panel Installation" on page 7.




Fig. 12-4: Upper LH Dash Panel Installation



# 2.4.5. LH Kick Panel Replacement

The LH kick panel assembly consists of upper and lower kick plate and a driver's foot duct bonded together as a unit. The

kick panel assembly is attached to the instrument panel frame base with push-in clips. See "Fig. 12-5: Side Wall & Kick Panel Assembly" on page 8.




Fig. 12-5: Side Wall & Kick Panel Assembly



## 2.4.6. SC Panel Assembly Replacement

The side console enclosure consists of a side panel, top cover, and end covers bonded together as a unit. The top cover is

fastened to the vehicle structure with 5 screws and the side panel is attached using double-sided tape. See "Fig. 12-6: Side Console Enclosure" on page 9.




Fig. 12-6: Side Console Enclosure



#### 2.5. Sidewall Panels

#### 2.5.1. Description

The sidewall panels include the main sidewall panels, located below the windows, and the lower kick panels (gusset panels), located between the floor and the seat rail. These panels are constructed of 0.090" thick Kydex thermoplastic acrylic/PVC formed sheets. The main sidewall panels are covered with carpet. The vertical seams of the sidewall panels are covered with aluminum moldings.

#### 2.5.2. Main Sidewall Panel Replacement

The main sidewall panels are attached to the vehicle side structure using spacer tape and Sika 221 adhesive. The lower edge of the panel seats within the channel of the seat rail.

#### 2.5.3. Lower Kick Panel Replacement

The upper and lower edges of the kick panels are seated within the channel of the upper and lower seat rails and retained by rivets.

#### 2.6. Pier Panels

#### 2.6.1. Description

The pier panels are located above the sidewall panels and are used to fill the space between the windows. These panels are constructed of 0.090" thick Kydex thermoplastic acrylic/PVC formed sheets.

#### 2.6.2. Pier Panel Installation

#### ™NOTE:

The interior pier panels are installed after the sidewall panels and the speaker panels are installed.

- 1. Dry-fit pier panel onto structure to confirm fit, then remove it.
- Clean structure with Sika 205 cleaner using a lint-free cloth. Allow 30 minutes for air drying.
- 3. Peel off the backing and place two vertical strips of 1/8x 3/8" spacer tape onto structure. Keep the spacer tape 1" away from edges of structural members. See "Fig. 12-7: Pier Panel Installation" on page 11.
- Apply a continuous bead of white Sika 221 adhesive to structure near edge of pier panel.
- Install pier panel to structure within 15 minutes of applying adhesive. Press firmly with up and down motion using a cloth. The perimeter of the pier panel must be completely sealed.
- Remove excessive adhesive with cloth and cleaner.
- 7. Allow 8 hours for curing at room tempera-






Fig. 12-7: Pier Panel Installation



# 2.7. Ceiling Panels

#### 2.7.1. Description

The ceiling panels consist of the driver's area ceiling panel, lower deck ceiling panels, and upper deck ceiling panels. These panels are constructed of 0.150" thick Kydex thermoplastic acrylic/PVC formed sheets. The seam joints are covered by stainless steel moldings.

## 2.7.2. Ceiling Panel Replacement

The ceiling panels are attached to the vehicle roof structure using high strength double-sided acrylic foam bonding tape. The outboard edges of the panels seat within the channel of the stanchion mounting extrusion. The inboard edges of the panels are clamped by a base molding that is riveted to the ceiling structure. A stainless steel cover molding snaps onto the base molding to cover the joint. See "Fig. 12-8: Ceiling Panel Installation" on page 12.




Fig. 12-8: Ceiling Panel Installation



## 2.8. Rear Bulkhead Panel

#### 2.8.1. Description

The rear panel is located above the rear seat and extends to the ceiling and side-wall panels. The rear panel assembly consists of a top panel and two side panels.

Each side panel includes an access door. These panels are of molded fiberglass construction. The panels are attached to the rear vehicle structure using Sika adhesive, spacer tape, and screws. See "Fig. 12-9: Rear Panel Installation" on page 13.




Fig. 12-9: Rear Panel Installation



# 2.9. Advertising Panels

#### 2.9.1. Description

The advertising panels are concave lengths of sheet plastic, installed between the aisle lights and the ceiling of the vehicle. Mounting channels are fastened horizontally to the panels to allow for the insertion of advertising signs.

#### 2.9.2. Removal

 Carefully pull out the flexible joiner strips from each edge of the panel that is being removed.

## ™NOTE:

Depending on the location, it may be necessary to remove transition panels or other closeout panels before the advertising panel can be removed.

- 2. Start at one end of the panel and apply pressure to bow the panel inward while at the same time lifting upward to release the lower edge from the mounting channel.
- Grip the lower edge of the exposed panel and gently twist outward. Continue to work along the length of the panel until the entire panel is released from the channel.
- 4. Pivot the panel upward to the horizontal position so that the lip on the panel can be lifted out of the upper mounting channel.

#### 2.9.3. Installation

Installation is the reverse of removal.



# **2.10. Rivets**

#### 2.10.1. Recommended Rivet Drill Sizes

RECOMMENDED RIVET DRILL SIZE									
RIV	ET	D	RILL SIZE	:e	HOLE SIZE				
DIAM	ETER		NILL SIZE	-3	MINIMUM MAXIMUI		мим		
inches	(mm)	size	inches	(mm)	inches (mm)		inches	(mm)	
3/32	2.38	#40	0.098	2.49	0.097	2.46	0.100	2.54	
1/8	3.18	#30	0.129	3.26	0.129	3.28	0.132	3.35	
5/32	3.97	#20	0.161	4.09	0.160	4.06	0.164	4.17	
3/16	4.76	#10	0.194	4.92	0.192	4.86	0.196	4.96	
1/4	6.35	F	0.257	6.53	0.256	6.50	0.261	6.63	

# 2.10.2. Drilling Procedure

- 1. Use a clean, sharp, properly ground drill.
- Center drill in the chuck so that drill will run true.
- 3. Hold drill perpendicular to the drilling surface.
- 4. To ensure proper hole alignment and to prevent burrs and chips from lodging between the panels, the parts should be tack riveted to prevent "creep" and hole misalignment during the drilling operation.

#### 2.10.3. Installation & Selection

Wherever possible use a solid aluminum rivet.

2. Where it is not possible to get conventional riveting tools in place, a 3/16" stainless steel mono bolt may be used.

#### 2.10.4. Removal

- 1. In thick material, drive out the rivet stem using a tapered steel drift pin. In thin material, drill the tapered portion of the stem away to destroy the lock.
- 2. Drill nearly through the head of the rivet using a drill the same size as the rivet shank. Break off rivet head.
- 3. Drive out remaining rivet shank with a pin having a diameter equal to the rivet shank.



# 3. FLOORING

# 3.1. Description

The flooring used on this vehicle consists of a sectional sub floor base with a rubberized floor covering. See "Fig. 12-10: Flooring Material" on page 16.




Fig. 12-10: Flooring Material



# 3.2. Composite Flooring

# 3.2.1. Description

The subfloor panels are closed cell fiberglass reinforced polyurethane foam boards. These boards are composed of 45% to 88% polyurethane foam and 12% to 55% continuous strand fiberglass and woven roving which creates a reinforced sandwich structure.

# 3.3. Floor Covering

#### 3.3.1. Description

The floor covering is a multi-layer rubberized covering with a wear resistant anti-slip outer surface. The floor covering is installed in multiple pre-cut sections and is bonded to the sub flooring.

#### 3.3.2. Flooring Specifications

Manufacturer/Model	Altro
Adhesive3M Fastbond C	Contact Adhesive 30H
Sealant	Altro Blue No. 73
Weld Thread	Altro WR231, Blue

#### 3.3.3. Cleaning

Do not clean the vehicle interior with pressure spray equipment. This method of cleaning causes excessive soaking of the floor covering, floorboard separation and warping, deterioration of seams or soaking of vinyl or cloth material and possible electrical short circuits.

During the winter months, a certain amount of salt is tracked inside the vehicle by passengers. This can damage the floor covering and flooring. Frequent cleaning and keeping the area as dry as possible will help reduce salt damage. Make immediate repairs when deterioration or damage is detected.

Clean the floor as follows:

- 1. Sweep or vacuum floor.
- Prepare a solution of degreasing detergent and warm water. Use a detergent with a pH level of 10 or less and dilute as recommended by manufacturer.
- Using a mop, liberally apply detergent solution to floor surface.
- Allow solution to work for at least 3 minutes. Do not let solution dry; apply additional detergent if required.
- 5. Scrub the surface to remove soil marks using a medium stiff bristled deck brush or blue or green scrubbing pad.
- Pick up the solution using a mop or wet vacuum.
- Rinse flooring with a mop, using clean cool water to remove detergent. Change water often to ensure it remains clean.

# ™NOTE:

For tough stains apply warm water and an oxygen-based bleach onto stain. Let it stand for 3 minutes. Scrub with scrubbing pad or brush. Rinse with clean cool water and let dry. ALWAYS test a small area first before proceeding.



# 3.3.4. Repair

Damaged floor covering can be repaired by cutting out the localized area of damage and patching with a new piece of floor covering cut to size. Refer to following removal and installation instructions.

# 3.3.4.1. Flooring Removal

- 1. Cut out portion of flooring to be removed.
- 2. Use heat gun and putty knife to remove flooring.
- 3. Clean floor with acetone or xylene.



DO NOT apply cleaning solvent to floor that is not compatible with polyester resins.

DO NOT apply excessive point loading when removing flooring (for example screwdrivers or pry bars).

# 3.3.4.2. Flooring Installation

- Surface must be clean and dry. If flooring is to be installed over plywood, ensure wood humidity does not exceed 75%. Use fans to circulate the air and allow wood to dry for 10 to 12 hours.
- 2. Fill all gaps and irregularities in wood floor with filler and sand flush when dry.
- Carefully measure and cut flooring to fit repair area. Seam gaps should not exceed 1/32" (0.8 mm)
- 4. Place replacement flooring on repair area to ensure it fits correctly.
- 5. Apply adhesive to floor surface repair area and rubber flooring.

# ™NOTE:

Use water-based adhesive to bond flooring to wood surfaces. Use contact adhesive to bond flooring to metal surfaces.

- Allow adhesive to dry to a non-tacky state before installing flooring.
- Carefully position flooring on repair area. Do not allow contact with floor until in correct position as it will adhere immediately.
- 8. Use a metal roller to press flooring down and eliminate any air bubbles.
- 9. Groove out seams to 1/2 to 3/4 of the thickness of the flooring using a hand groover and a straight edge.

# ™NOTE:

DO NOT groove until ready to weld. Avoid accumulation of dirt in the grooves.

- 10. Clean seams and bonding surfaces of dirt and residue.
- 11. Ensure speed welding tip on heat gun is clean. Use a wire brush to remove any
- 12. Pre-heat heat gun to approximately 932°F (500°C) (setting 6 on a variable setting gun). Nozzle should be pointing upwards during this pre-heat period.

# ™NOTE:

Heat gun and nozzle are available from New Flyer Parts.

- 13. Test weld a piece of scrap material with the weld rod to ensure temperature is correct and fusion is taking place.
- 14. Feed weld rod into speed welding tip.
- 15. Starting as close as possible to end of seam, press weld rod down into groove with speed welding tip, ensuring toe of tip is parallel to the vinyl surface. See "Fig. 12-11: Floor Welding Thread Installation" on page 19.
- 16. Pull gun towards you while maintaining a slight downward pressure.
- 17. Any spots which are missed have to be re spot welded.



18. Ensure that heat gun is kept perpendicular to floor. With your spare hand, alternately check that the welded seam is securely bonded, and that the rod is feeding freely.

# ™NOTE:

Maintain a constant rate of welding (weld speed should be 1.3 seconds per inch). A good floor weld is achieved using a combination of suitable heat and correct speed of travel with the heat gun. See "Fig. 12-12: Correct Floor Weld" on page 19.

The weld thread and flooring will burn if the heat setting is too high or the gun is moved too slowly. The weld will not fuse if the heat setting is too low or the gun is moved too quickly.

- 19. Trim the weld bead in two stages using a spatula knife that has been sharpened on one side only. This will make trimming easier and minimize the risk of digging in.
  - a. Place trim plate over weld rod. Insert spatula knife into trim plate. Push knife forward and trim off top portion of weld rod.
  - Allow weld to cool to room temperature and remove excess weld with spatula knife. Keep knife at as shallow an angle to the floor as possible to minimize the risk of digging in.
- 20. Test weld for proper fusion: pull on the weld thread to determine if weld has properly fused to flooring. If weld thread breaks or lifts flooring off floor before letting go, welding procedure was successful.
- 21.Use sealant on seams that cannot be welded with weld thread.




Fig. 12-11: Floor Welding Thread Installation




Fig. 12-12: Correct Floor Weld



# 4. SAFETY EQUIPMENT

# 4.1. Fire Extinguisher

# 4.1.1. Description

The fire extinguisher is a 5 lb. multipurpose dry chemical fire extinguisher. It is installed behind the driver's seat.



The fire extinguisher contains a compressed gas. Avoid breathing dust. FIRST AID - if inhaled, remove victim to fresh air. For eye contact, flush with running water for at least 15 minutes. Call physician. For skin contact, wash with soap and water. Call physician if irritation persists.

# 4.1.2. Operation

1. The fire extinguisher is suitable for use above -65°F (-54°C). Remove safety pin

and squeeze lever as shown on instruction label on fire extinguisher.



DO NOT direct at surface of burning liquid from closer than 10 feet (3 meters).

2. Recharge immediately after use.

# ™NOTE:

Refer to instruction label on fire extinguisher for recharge procedure.

# 4.2. Safety Triangle

# 4.2.1. Description

The safety triangles, located inside the equipment box on the curbside luggage rack, are used to warn oncoming traffic of a potential hazard should the vehicle be out of service on the roadside. See "Fig. 12-13: Safety Equipment Installation" on page 20.




Fig. 12-13: Safety Equipment Installation



# **Exterior Panels & Applied Parts**

1.	SAFE	ETY	13-1
	1.1. S	afety Procedures	13-1
2.	EXTE	RIOR PANELS	13-3
	2.1. D	escription	13-3
		ivets	
	2.2. 2.2.		
	2.2.		
	2.2.		
		ealants, Caulk & Adhesives	
	2.3.	•	
	2.3.	<b>5</b> 1 • • • • • • • • • • • • • • • • • •	
	2.3.		
		2.3.3.1. Description	
		2.3.3.2. Properties	
	2.3.		
		2.3.4.1. Description	
		2.3.4.2. Properties	
		2.3.4.3. Operation	
		2.3.4.4. Component Assembly	
		2.3.4.5. Disassembly	
	2.3.	2.3.4.6. Cleanup	
	2.3.	2.3.5.1. Description	
		2.3.5.1. Description 2.3.5.2. Properties	
		2.3.5.3. Uses	
	2.3.		
	2.0.	2.3.6.1. Description	
		2.3.6.2. Properties	
		2.3.6.3. Uses	
	2.3.		
		2.3.7.1. Description	
		2.3.7.2. Properties	
		2.3.7.3. Uses	
	2.3.	8. Sika-205 Cleaner	13-9
		2.3.8.1. Application Method	13-9
	2.3.		
		2.3.9.1. Description	
		2.3.9.2. Properties	13-9
		2.3.9.3. Application Method	13-9
	2.4. R	emoval	13-10



2.4.1.	Structural Panel Types	
2.4.2.	Panel Removal	13-10
2.4.3.	Frame Repriming	13-11
2.5. Sul	ostrate Preparation & Bonding	13-11
2.5.1.	Introduction	13-11
2.5.2.	Preprimed Aluminum	13-11
2.5.3.	Unprimed Aluminum	13-11
2.5.4.	Steel Primed with PPG Red/Grey Primer	
2.5.5.	Stainless Steel	
2.5.6.	Fiberglass	
	nel Applications	
	General Panel Replacement	
	ewall Panels	
2.7.1.	Description	13-12
2.7.2.	<u>'</u>	
	e Pier Panels	
2.8.1.	Description	
2.8.2.	Pier Panel Installation	
	nt Mask Panels	
2.9.1.		
2.9.2.	·	
	of Panels	
	. Description	
	Roof Panels Installation	
	of Cap Overlay	
	erglass Panels	
	. Fiberglass Panel Repair	
	12.1.1.Using Fiberglass Cloth	
	12.1.2.Using Fiberglass Paste	
	. Gelcoat Finish	
	12.2.1.Gelcoat Surface Repair	
	Larger Fiberglass Panel Damage	
	nting Procedures & Preparation	
	·	
	Substrate Treatment Preparation	
	13.1.1.Stainless Steel	
	13.1.3.Fiberglass	
	13.1.4.Primer	
	13.1.5.Spot Primer	
	13.1.6.Topcoat (Deltron Base Coat/Clearcoat)	
	13.1.7.Clearcoat	
	13.1.8.Topcoat (DCC)	
	13.1.9.Epoxy Primer	
	. Surface Preparation	
2.13.3	. Application Conditions	13-30
2.13.4	. Application Equipment	13-30





	2.13.5. Recommended Drying & Curing Time	
^		
3.	BUMPERS	
	3.1. Description	
	3.2. Removal	
	3.3. Disassembly	
	3.4. Assembly	13-32
	3.5. Installation	13-32
	3.6. Repair	13-33
	3.6.1. Repair Materials	
4.	SPLASH GUARDS	13-35
	4.1. Description	13-35
5.	MIRRORS	13-36
	5.1. Exterior Mirrors	13-36
	5.1.1. Driver's Side Mirror	13-36
	5.1.2. Curbside Mirror	13-38
	5.2. Mirror Servicing	13-40
	5.2.1. Removal	13-40
	5.2.2. Disassembly	
	5.2.3. Installation	
	5.3. Interior Mirrors	
	5.3.1. Description	13-40
6.	WINDSHIELD WIPER & WASHER	
	6.1. Windshield Wiper	13-41
	6.1.1. Description	
	6.1.2. Removal	
	6.1.3. Installation	
	6.2. Windshield Washer	
	6.2.1. Description	
	6.2.2. Removal	
	6.2.3. Inspection	
	6.2.5. Washer System Troubleshooting	
7.	·	
<i>.</i>	7.1. Description	
	7.2. Operation	
	7.2.1. Loading	
	7.2.2. Unloading	
	7.3. Maintenance	
	7.3.1. Bike Rack Servicing	

# Table of Contents



7.3.2.	Latch Mechanism Servicing	13-47
7.3.3.	Support Arm Servicing	13-48
	Support Arm Grip Installation	



# 1. SAFETY

# 1.1. Safety Procedures

This section of the service manual contains procedures which require the mechanics to strictly observe safety procedures in order to ensure personal and equipment safety.

Always ensure that the vehicle is appropriately hoisted and blocked for procedures which require elevating the vehicle. Be aware of the limitations of the blocking equipment, and always ensure that the jarring and shaking created by component removal and installation procedures does not overload the blocks, or cause the vehicle to become unstable.

Certain procedures may require the vehicle be operated in an elevated position in order to accurately troubleshoot and diagnose a problem. If the vehicle must be running while elevated, become familiar with the repair area prior to starting the engine. Take special care in noting areas which will become hot, electrically energized, and areas where moving and rotating components are located. Limit the work in these areas as personal and equipment safety is at risk.

For procedures which involve air lines, ensure the line is safely depressurized prior to disconnecting. Disconnecting pressurized lines will cause solid particles deposited in the line to be uncontrollably propelled, and will also cause the hose end to whip randomly as the air escapes.

During electrical diagnosis procedures an understanding of the vehicle's electric circuits is important to anticipate the results of connecting test equipment. During component removal or installation, ensure the Battery Disconnect switch is in the OFF position.

Failure to follow this procedure may result in personal injury or component failure.

Observe the following procedures involving hydraulic line removal.

- Hydraulic fluid is corrosive and should not be exposed to skin for extensive periods of time
- Wear eye protection at all times.
- Pressurized lines should not be disconnected until the pressure is safely and controllably released.



Follow all proper safety precautions regarding spray painting. Use a filtering mask with the proper filter cartridges for this type of paint. Wear eye protection and proper protective clothing. The paint booth or work area must be properly ventilated, with filtered exhaust fans removing fumes and over spray. Air make-up induction fans should also be used to supply fresh air to the work area. The painting area should be a safe distance from any source of flame, spark or other means of combustion. Atomized paint, thinner, cleaner and solvent fumes are highly volatile with an extremely low flashpoint that can cause explosive combustion. DO NOT smoke or permit anyone else to smoke in or near the painting area.





Overexposure to adhesives used in this section, specifically Sikaflex-252, may cause breathing difficulties, sensitization, headaches, nausea, vomiting. May aggravate respiratory, skin, eye, lung problems and allergies. If the product is applied according to the manufacturer's directions, none of these symptoms should be encountered. A person who is allergic to isocyanate may have a reaction with a level of isocyanate well below the T.I.V. Xylene is a central nervous system depressor and in rare cases, may cause a sensitization of the heart muscle causing arrhythmia.

Ensure the user is provided with a full face mask or safety glasses, a rubber apron, sufficient ventilation, and an eyewash station or shower. In case of overexposure, remove contaminated clothing and shoes, wash with plenty of water, wash clothing before rewearing, and consult a physician. If eyes are exposed, rinse immediately for several minutes. See a physician immediately. In case of inhalation, evacuate to fresh air and consult a physician. In case of ingestion, drink plenty of water or milk. DO NOT induce vomiting. See a physician immediately.



# 2. EXTERIOR PANELS

2.1.	Desc	rin	tion
<b>~</b>	DUSC	יקו וי	

Exterior panels include the following:

- ☐ Sidewall
- ☐ Upper Exterior Side (Pier) Panels
- ☐ Front Mask
- □ Roof

# ™NOTE:

Before any replacement of any exterior panel, an inspection of the structure must be done.

Any damage to the structure or the protective primer must be repaired immediately.

		cords ide.	must	be	kept	tor	every	repair
	Da	te of re	epair.					
	De	scription	on of d	lama	age.			
		Is a re Yes/N	•	o th	e stru	ctur	e nece	ssary?
		Repai	r to the	e pa	nel or	ıly?	Yes/No	
$\neg$	1/18	d						

# 2.2. Rivets

# 2.2.1. Recommended Rivet Drill Size

Name of inspector\_

□ Was New Flyer notified? Yes/No

	RECOMMENDED RIVET DRILL SIZE							
RIVET DRILL SIZES HOLE SIZE								
DIAM	ETER		NILL SIZL	_3	MINIMUM MAXI		IMUM	
inches	(mm)	size	inches	(mm)	inches (mm)		inches	(mm)
3/32	2.38	#40	0.098	2.49	0.097	2.46	0.100	2.54
1/8	3.18	#30	0.129	3.26	0.129	3.28	0.132	3.35
5/32	3.97	#20	0.161	4.09	0.160	4.06	0.164	4.17
3/16	4.76	#10	0.194	4.92	0.192	4.86	0.196	4.96
1/4	6.35	F	0.257	6.53	0.256	6.50	0.261	6.63



# 2.2.2. Drilling Procedure

- 1. Use a clean, sharp, properly ground drill.
- Center drill in the chuck so that drill will run true.
- Hold drill perpendicular to the drilling surface.
- 4. To ensure proper hole alignment and to prevent burrs and chips from lodging between the panels, the parts should be tack riveted to prevent "creep" and hole misalignment during the drilling operation.

#### 2.2.3. Installation & Selection

- 1. Wherever possible use a solid S/S rivet.
- Where it is not possible to get conventional riveting tools in place, a 3/16" stainless steel mono bolt may be used.

#### 2.2.4. Removal

- 1. In thick material, drive out the rivet stem using a tapered steel drift pin. In thin material, drill the tapered portion of the stem away to destroy the lock.
- Drill nearly through the head of the rivet using a drill the same size as the rivet shank. Break off rivet head.
- 3. Drive out remaining rivet shank with a pin having a diameter equal to the rivet shank.


# 2.3. Sealants, Caulk & Adhesives

#### 2.3.1. Description

# ™NOTE:

Application of sealants and caulking is critical to prevent corrosion of vehicles in service. Care is to be taken that all the areas around wheel housing are adequately sealed as these areas are subject to high salt spray concentrations. See "Fig. 13-1: Molding & Trim" on page 5.





- 4. Tape, Butyl .12" x .50" Blk.
- 5. Adhesive, SIKA 221 Black
- 6. Loctite
- 7. Expansion, Drip Rail
- 8. Adhesive, SIKA 221 White
- 9. Molding, Drip Rail Rear Streetside
- 14. Spacer, Foam
- 15. Molding, Trim Joint
- 16. Molding, Trim Joint
- 17. Molding, Trim Joint
- 18. Molding, Trim Joint

- 22. Adhesive, SIKA 221 White
- 23. Molding, Trim Window
- 24. Panel, Roof Cap Overlay
- 25. Adhesive, SIKA 222 Black

s0322389a.svg

Fig. 13-1: Molding & Trim



# 2.3.2. Butyl Tape Sealant (Grey)

□ 0.06 x 1" (1.59 x 25.4 mm)

The butyl tape is to be applied in strips directly from rolls. Locate tape 0.06 to 0.12" (1.59 to 3.18 mm) away from exposed edges to avoid excessive squeeze out of sealant. Do not attempt to clean up butyl material that may have extruded from joints.

Apply as follows:

- 1. Apply continuous strips between wheel housing and body side structure.
- 2. Apply a continuous strip between floor and heater duct retaining flanges.
- 3. Apply continuous strips all around roof vents, between vent frame and roof panel.
- 4. Apply continuous strips around harness entry points.



Use rubber gloves when handling. Apply only in a well ventilated, nonsmoking area. Check labels for warnings.

#### 2.3.3. Sikaflex-221 Elastic Adhesive/Sealant

# 2.3.3.1. Description

Sikaflex-221 is a fast-curing polyurethanebased adhesive sealant. It is a moisturecured non-sag system. It provides a permanent elastic bond to fasten materials with dissimilar coefficients of expansion.

# 2.3.3.2. Properties

Density1.23 kg/l
Tack-free time1 to 2 hours
Cure Rate4 mm/24 hours at 70°F (21°C
Shore A Hardness40 to 45
Elongation at Break 600%
Application Temperature41 to 104°F (5 to 40°C
Service Temperature 
ColorsWhite/Black

# Sealants, Caulk & Adhesives

# 2.3.4. Loctite-567 Pipe Sealant

# 2.3.4.1. Description

Loctite-567 is designed for the locking and sealing of metal tapered threads and fittings.

#### 2.3.4.2. Properties

Material Acrylic
Chemical Type Methacrylate Ester
Appearance (Uncured)Smooth, Creamy, off-white paste
Components Single component
ViscosityHigh
Primary Cure MethodAnaerobic
Secondary Cure Method Activator
ApplicationThread Sealing
StrengthLow

# 2.3.4.3. Operation

The sealant is applied to the threads of metal fittings and cures when confined in the absence of air between close fitting metal surfaces. Cured sealant prevents leakage and component loosening due to shock and vibration.

#### 2.3.4.4. Component Assembly

 For best results, clean all surfaces (external and internal) with a Loctite cleaning solvent and allow to dry.

- 2. If the material is an inactive metal or the cure speed is too slow, spray with Activator 7471 or 7649 and allow to dry.
- 3. Apply a 360° bead of sealant to the leading threads of the male fitting, leaving the first thread free. Force the material into the threads to thoroughly fill the voids.
- 4. Assemble components and tighten fittings.
- 5. Properly tightened fittings will seal instantly to moderate pressures.

# ™NOTE:

For maximum pressure resistance and solvent resistance allow the product to cure a minimum of 24 hours.

# 2.3.4.5. Disassembly

- Disassemble parts with standard hand tools.
- Where hand tools do not work because of excessive engagement length or large diameters (over 1"), apply localized heat to approximately 250°C. Disassemble while hot.

#### 2.3.4.6. Cleanup

Cured product can be removed with a combination of soaking in a Loctite solvent and mechanical abrasion such as a wire brush.



# 2.3.5. Sikaflex-201 Polyurethane Sealant

# 2.3.5.1. Description

Sikaflex-201 is a one component, flexible, polyurethane-based elastomeric sealant. It is a moisture-cured, non-sag system. The chemical reaction is set in motion as soon as the adhesive is extruded or the cartridge is opened. Initially plastic in consistency, it cures to form a high-grade elastomeric adhesive.

#### 2.3.5.2. Properties

Density 1.23 kg/L
Tack-free time 8 to 5 hours
Cure Rate 14 days at 41°F (5°C) 60% rel hum
(1/4" x 1/4" bead) 10 days at 73°F (23°C) 50% rel hum 6 days at 73°F (23°C) 90% rel hum 3 days at 140°F (60°C) 40% rel hum
Shore A Hardness40 to 45
Elongation at Break700%
Application Temperature 5 to $40^{\circ}\text{C}$
Service Temperature 40 to 194°F (-40 to 90°C) (briefly up to 248°F/120°C)
Colors White/Black

# 2.3.5.3. Uses

Use to waterproof rivet seams, and for sealing of exposed and concealed joints of aluminum, steel, coated metals, wood, roof rails, door hinges, as a sealant between all exterior panels, and as a general roof panel adhesive.

#### 2.3.6. Sikaflex-252 Adhesive/Sealant

# 2.3.6.1. Description

Sikaflex-252 is a polyurethane-based material which cures on exposure to air. The chemical reaction is set in motion as soon as the adhesive is extruded or the cartridge is opened. Initially plastic in consistency, it cures to form a high-grade elastomeric adhesive.

#### 2.3.6.2. Properties

Density 1.14 ± 0.03 kg/L
Cure System Moisture Cure
Tack-Free Time*40 min. approx.
Rate of Cure*4 mm approx. per 24 hrs.
Shore A Hardness (DIN 53 505)55 approx.
Elongation at Break (DIN 53 504)>300%
Tensile Strength (DIN 5. 504)4 N/mm <sup>2</sup> approx.
Lap-Shear Strength* 3 N/mm <sup>2</sup>
Tear Propagation Strength (DIN 53 515)9 N/mm approx.
9 N/mm approx.
Shrinkage (DIN 52 451)6% approx.  Application Temperature

#### 2.3.6.3. Uses

Use as an external panel adhesive (except for roof panels) which is applied to the entire perimeter surface of the panel.

# Sealants, Caulk & Adhesives

# 2.3.7. 3M-550 Fast Cure Adhesive/Sealant with Accelerator AC61

# 2.3.7.1. Description

3M-550FC is a polyurethane-based adhesive sealant and it is mixed with AC61 accelerator for faster curing. Mixing is done with special two component dispensing equipment.

# 2.3.7.2. Properties

AppearanceSmooth Paste
Color Accelerator Grey 550FC Gray Mixed at 10:1 ratio
Skin Formation 15 ± 5 minutes
Tensile Strength in 1 hour>70 psi
Tensile Strength after 24 hr cure300 psi
Shore A Hardness (ISO 868 - 3) 40 - 45
Modulus at 100% Elongation1.0 MPa (150 psi)
Elongation at Break>250%
Temperature Resistance22°F to 176°F (-30°C to +80°C)
Ratio Mix: 550FC to AC61

#### 2.3.7.3. Uses

Use as an external panel adhesive, applied to the perimeter surface of the panel.

#### 2.3.8. Sika-205 Cleaner

Sika-205 Cleaner is a special cleaner for the pretreatment of bond faces prior to bonding or sealing with Sikaflex products.

#### 2.3.8.1. Application Method

Apply in a thin film to the bond face. Let dry 10 minutes.

#### 2.3.9. Sika-206G&P Primer

# 2.3.9.1. Description

Sika-206G&P Primer is a black, moisturecuring liquid for the treatment of bond surfaces before bonding with Sikaflex products. It can also be used to touchup scratches and minor paint damage.

#### 2.3.9.2. Properties

Density1.0 kg/L
Flash Point24°F (-4°C)
Drying Time10 min. to 24 hrs. depending on temperature & rel hum
Application Temperature50 to 86°F (10 to 25°C)
Shelf Life9 months

#### 2.3.9.3. Application Method

Ensure substrate is clean and free from all traces of dust and grease. Apply primer in a thin layer using a paintbrush, felt tip, or other suitable application equipment. Allow 10 minutes drying time.



# 2.4. Removal



Follow all proper safety precautions regarding spray painting. Use a filtering mask with the proper filter cartridges for this type of paint. Wear eye protection and proper protective clothing. The paint booth or work area must be properly ventilated, with filtered exhaust fans removing fumes and over spray. Air make-up induction fans should also be used to supply fresh air to the work area. The painting area should be a safe distance from any source of flame, spark or other means of combustion. Atomized paint, thinner, cleaner and solvent fumes are highly volatile with an extremely low flashpoint that can cause explosive combustion. DO NOT smoke or permit anyone else to smoke in or near the painting area.

# 2.4.1. Structural Panel Types

Structural panels are aluminum and fiberglass construction. The aluminum panels are preprimed with a peel-off protective plastic skin. The fiberglass panels have a Gelcoat finish on one side. Rivet holes have to be drilled in the fiberglass panels.

#### 2.4.2. Panel Removal

The structural adhesive/sealant bonding the panels to the frame provides a strong surface bond between the panel and frame. This strong bonding is necessary to make the panel a structural component of the frame. A panel should only be removed if it is damaged beyond a point of external surface repair.

The panel may be salvaged for repair and reinstallation if reasonable care is taken during the panel removing procedure. If care is not exercised, the panel will be irreparably damaged and will have to be replaced. Ultimately, salvaging the panel is dependent upon the degree of initial damage and whether the panel has the structural strength to be removed in one piece.

Tools and supplies required: vice grips putty knife, or utility knife with a sharp blade, lacquer thinner and absorbent shop rags.

 Use the putty knife or utility knife blade soaked in lacquer thinner to cut into the adhesive between the panel and frame at a corner of the panel.

#### ™NOTE:

The lacquer thinner does not dissolve the adhesive, but acts as a releasing agent between the adhesive and primer.

- Pry one corner of the panel up enough to grasp with the vice grips and start to pull on the vice grips. This should start the panel to pull away from the frame.
- Continue to cut or scrape the adhesive where contact is made at the panel and frame, and simultaneously pull the panel away with the vice grips.
- Keep doing this until all of the panel is freed from the bonded adhesive and pulls away from the frame.

#### ™NOTE:

Depending on the initial condition of the panel and care taken during the removal process, the panel may tend to curl up during removal. If this occurs, replace the panel.

Scrape the remaining adhesive from the frame.



All remnants of the adhesive must be removed from the frame. Use the putty knife wet with lacquer thinner to scrape the remnants of adhesive from the frame surface. Scraping may remove some primer from the frame. ALWAYS reprime the entire perimeter area of the frame to maintain corrosion protection.

# **Substrate Preparation & Bonding**

# 2.4.3. Frame Repriming

- Scuff sand the affected frame area using 180 to 220 grit emery paper with a disk sander.
- Wipe the worked area of the frame down with Sika-205 cleaning solvent.
- Use the recommended Sika-206G+P Primer to thoroughly cover the sanded frame areas.

# 2.5. Substrate Preparation & Bonding

#### 2.5.1. Introduction

Refer to the following guidelines before application of adhesive and bonding of new panels.

#### 2.5.2. Preprimed Aluminum

- Clean the bonding surface to remove dirt, grease, and oil, using Sika-205 Cleaner and clean white cloths.
- 2. No priming is required for this material.
- Use a caulking gun to apply Sika-252, 221 or 201 Adhesive.

# 2.5.3. Unprimed Aluminum

- Clean the bonding surface to remove dirt, grease, and oil, using Sika-205 Cleaner and clean white cloths.
- Prime the bonding surface using Sika-206G+P Primer and a brush. Ensure the aluminum surface cannot be seen through the primer.

3. Use a caulking gun to apply Sika-252, 221 or 201 Adhesive.

#### 2.5.4. Steel Primed with PPG Red/Grey Primer

- Clean the bonding surface to remove dirt, grease, and oil, using Sika-205 Cleaner and clean white cloths.
- Brush apply Sika-206G+P black Primer over the red/grey structural primer. Ensure the undercoat primer cannot be seen through the black primer.
- 3. Use a caulking gun to apply Sika-252, 221 or 201 Adhesive.

#### 2.5.5. Stainless Steel

- Clean the bonding surface to remove dirt, grease, and oil, using Sika-205 Cleaner and clean white cloths.
- 2. Priming is not necessary for this material.
- Use a caulking gun to apply Sika-252, 221 or 201 Adhesive.

# 2.5.6. Fiberglass

- 1. Remove mold release paraffin wax on interior surfaces using 36 grit sanding paper.
- Clean the bonding surface to remove dirt, grease, and oil, using Sika-205 Cleaner and clean white cloths.
- 3. No priming is required for this material.
- 4. Use a caulking gun to apply Sika-252, 221 or 201 Adhesive.



# 2.6. Panel Applications

#### 2.6.1. General Panel Replacement

The panels used on the exterior of the vehicle are installed with a combination of adhesives and structural tape. Procedures specific to each panel must be followed in order to guarantee a satisfactory installation. Detailed instructions including cleaning, priming, bonding, and attachment procedures are provide in New Flyer engineering installation drawings. Please contact New Flyer Customer Service for detailed installation procedures (engineering installation drawings) and material requirements for the specific panel being replaced.

# 2.7. Sidewall Panels

#### 2.7.1. Description

Sidewall panels are the exterior fiberglass panels that cover the side structure from the bottom of the window to the bottom of the structure. The panels are installed with a combination of adhesive and structural tape. Procedures specific to each panel must be followed in order to guarantee satisfactory installation. See "Fig. 13-2: Side Panel Application-1" on page 13. See "Fig. 13-3: Side Panel Application-2" on page 15.






Fig. 13-2: Side Panel Application-1

Rev. A - Jul 27 2015



#### 2.7.2. Side Panel Installation

- 1. Install the side panel as follows:
  - a. Dry-fit the side panels onto structure using temporary wood blocking and clamping devices. Place wood blocking onto the window sills and fasten the tabs of the panels to the wood blocking using screws. See Detail A in Figure. If all side panels are replaced start at the rear of the vehicle. Ensure that the top edges of side panels are flush with the structural window openings.
  - If only one panel is replaced push vertical lip of rear panel under vertical lip of front panel. See Detail B in Figure.
  - c. Arrange the panels so that they overlap at the vertical edges with a gap of approximately 1/4" between the adjacent panels. See Detail B in Figure.
  - d. Use clamping devices to secure panels to structure. Remove protective plastic in areas where panels are clamped.
  - e. Remove dry-fitted panels from vehicle.
- 2. Clean structure with Sika 205 cleaner using a lint-free cloth. Allow 30 minutes for air drying.
- Peel off the backing and place two rows of 1/8" thick structural tape along the bottom of the structure. Keep the tape 1" away from the edges of horizontal structural member. See Detail C in Figure.
- Apply two rows of 1/8" thick structural tape on vertical structural members where two panels are joined. Place the tape near the edges of the structure. See Detail C in Figure.
- Place one row of 1/8" thick structural tape on narrow vertical structural members and two rows on wide vertical structural members.
- Place two rows of 1/16" thick structural tape on horizontal structural members below window openings. Keep the tape 1" away from edge of structural members. See Detail D in Figure.

# ™NOTE:

Check that the backing is removed from all structural tape.

- Clean the entire inside surface of the side panels using Sika 205 cleaner and a lintfree cloth. Allow 30 minutes for air drying.
- Apply a continuous bead of white adhesive Sika 221 to horizontal structural members near edges. The beads should 3/8" wide by 7/16" high.

# ™ NOTE:

The adhesive must be applied within one hour of applying the cleaner.

- Apply two rows of adhesive beads between tapes at vertical structural members where two panels are joined. See Detail C in Figure.
- 10. Apply adhesive to structure so that the entire perimeter of the panels are sealed to prevent moisture penetration.
- 11.Apply a small bead of adhesive to joint where two panels are meeting. The adhesive needs to be covered with the overlapping panel. See Detail B in Figure.
- 12. Apply the panels to structure within 15 minutes of applying the adhesive. Secure panels with clamping devices and wood blocking at the window sills.
- 13.Check that all the edges of panels are flush with the structure. Apply even pressure in an up and down motion using a cloth or roller.
- 14. Remove squeeze-out adhesive using soapy-water spray and a putty knife. Window and door openings must be free of adhesive to prevent interference. Remove panel protective film.

#### ™NOTE:

DO NOT use Sika cleaner to remove squeeze-out adhesive from bonded joints. The cleaner could weaken the bonding.

- 15. Allow 8 hours for curing at room temperature.
- 16.Cut the tabs flush with side panels. See Detail A in Figure.






Fig. 13-3: Side Panel Application-2



# 2.8. Side Pier Panels

# 2.8.1. Description

The pier panels are located above the sidewall panels and are used to fill the space between the windows. These panels are constructed of 0.08" thick sheet aluminum.

#### 2.8.2. Pier Panel Installation

# ™NOTE:

DO NOT install pier panels until side panels are installed.

- Wipe panels with a clean dry cloth, then wipe with a clean cloth dipped in Sika-205 Cleaner. Allow to dry for 5 to 10 minutes.
- Dip a clean white cloth in Sika-205 Cleaner and wipe area of structure where adhesive will be applied. Wipe structure dry using a second dry white cloth. Allow to dry for 5 to 10 minutes.
- Install side wall insulation pieces as required.
- 4. Remove backing from 1/8" x 3/8" wide double sided spacer tape and install on structure, approximately 1" from outer edge of vertical structures and approximately 3/4" from top and bottom edges for horizontal structures. This will allow adhesive to squeeze out without contaminating double sided tape.

# ™NOTE:

Refer to the New Flyer Bonding specification (engineering drawing) for proper spacer tape location of pier panels. Contact New Flyer Customer Service for engineering installation drawings.

- 5. Using a V-cut nozzle, apply a continuous and unbroken 0.47" bead of Sika-221 Adhesive to perimeter of structure where edge of panel will contact frame. Apply a thick bead of Sika-221 Adhesive to top edge of side panel where pier panel abuts side panel.
- Remove backing from spacer tape and place pier panel onto structure. Ensure panel is flush with window opening. Manually press panel onto spacer tape to ensure good adhesion.
- Check squeeze out along entire perimeter of panel. Backfill any areas with voids to ensure a watertight seal.
- Remove excess squeeze out along edges of panel and window openings using a water spray bottle and a putty knife. If necessary use abrasive paper to remove cured adhesive. Do not use Sika-205 Cleaner as it will prevent curing of the adhesive.
- 9. Fill all gaps between the structure and panels with adhesive.
- 10. Fill all gaps between filler panels and pier panels with adhesive.
- 11. Fill all gaps between window openings and panels.
- 12. Sand all gaps smooth to ensure window clamp will seal against the panels.

# ™NOTE:

Clean out excess adhesive from the entrance and exit door openings to allow proper door trim installation.



# 2.9. Front Mask Panels

# 2.9.1. Description

The front mask is a molded fiberglass panel that contains the apertures for the windshield and headlights. It is installed on the front of the vehicle using adhesives, monobolt rivets and bolted brackets.

#### 2.9.2. Front Mask Panel Installation



Protective gloves and safety goggles are mandatory when using Sikaflex-252, 201 or 221 Adhesives. They are also mandatory when using Sika-205 Cleaner, or Sika-206G+P Primer; if used in an enclosed area, a respirator with an organic vapor cartridge is also mandatory.

DO NOT wear gloves when operating drills or screw guns.

Ensure proper disposal of controlled products.

- Place front mask panel on structure to ensure correct fit. Mask must fit flush and square at all four corners of structure without distortion. Check to ensure the following:
  - No gaps exist between top corners of mask and roof.
  - ☐ No gaps exist between mask and side console.
  - ☐ No gaps exist between mask surface and windshield cut out.
  - ☐ Defroster opening is centered relative to vertical uprights of structure.

- ☐ Bottom plate structure is not bowed and not preventing mask from sitting flush.
- Remove mask from structure.
- 3. Scuff the front 1 5/8" of the roof panel.
- Remove any dry caulking that may interfere with mask installation.
- Clean panel and structure surfaces to be joined using Sika-205 Cleaner and a clean lint-free cloth. Allow to dry for 10 to 60 minutes. See "Fig. 13-4: Front Mask Panel Application" on page 19.
- Apply Sika-206G+P Primer to joining surfaces on panel and structure. Allow to dry for 10 to 60 minutes.
- Install spacer tape to interior contact surface of front mask (above and below windshield opening) and frame members of front structure.

# ™NOTE:

Adhesive must be applied within one hour of primer application.

- 8. Apply two continuous beads of Sika-252 Adhesive along mating surface of roof panel and mask.
- Apply a continuous bead of Sika-252 Adhesive above spacer tape on center beam.
- 10. Apply one continuous bead of Sika-252 Adhesive along streetside A post.
- 11.Apply two continuous beads of Sika-252 Adhesive along curbside (entrance door insert tube) A post.
- 12. Apply one continuous bead of Sika-252 Adhesive above spacer tape on inside of front mask and along both ends of mask mating surface.



- 13. Apply two continuous beads of Sika-252 Adhesive along front face of lower beam.
- 14. Apply Sikaforce-7780 along the top edge of the front mask to create a flush seal. See "Fig. 13-5: Front Mask Lap Joint" on page 20.

# ™NOTE:

Front mask must be installed within 40 minutes of adhesive application.

- 15.Install front mask over front edge of roof panel and into contact with front structure. Clamp assembly into position. Do not over tighten clamps Allow adhesive to dry for 3 to 4 hours before removing clamps.
- 16. Apply a bead of adhesive along the perimeter of the front mask support bracket and adhere it to the mask.
- 17. Apply sealant along top edge of front mask and along interior top edges of mask at

- bottom closeout and tool into place to create an edge fillet seal.
- 18. Seal gaps between windshield cutout and front structure using Sika-221 Sealant (black).
- 19.Drill nine equally spaced holes (0.191") in lower portion of front mask and install monobolt rivets.
- 20. Apply foam rubber seal to perimeter of defroster door and defroster side plates.
- 21. Position defroster door in front mask.
- 22.Use door as template to mark position of hinge mounting holes.
- Drill four 0.136" holes in structure and attach defroster door to vehicle using rivets.
- 24. Position the mask support bracket and tighten the mounting bolts.






Fig. 13-4: Front Mask Panel Application






Fig. 13-5: Front Mask Lap Joint

#### 2.10. Roof Panels

# 2.10.1. Description

Two roof panels cover the top exterior of the vehicle. They are made from molded fiberglass and contain openings for the roof vents and to allow the structuremounted roof studs to protrude through. The roof panels are attached with adhesive and spacer tape.

#### 2.10.2. Roof Panels Installation

- Ensure that exterior pier panels, roof insulation, and antenna ground planes are installed. Install cork spacers to vehicles with roof top studs. See "Fig. 13-6: Roof Panel Installation" on page 22.
- 2. Test fit roof panel to structure to ensure that all roof bows are parallel to each other within 1/8" before proceeding.
- Measure roof sections to verify correct length and side dimensions. Check for cracks or voids in fiberglass.

- 4. Remove any remaining tape used to hold pier panel joiner strips in place.
- Trim off any dried adhesive squeeze-out that might interfere with roof panel installation.
- Install foam roof channel spacers into the ceiling support channels using Sika-221 to bond the foam spacers against the bottom of the channels. Apply 6" high density spacer tape stitches along one top edge of the foam spacers.
- Install 3/16" x 3/8" wide high density spacer tape along entire length of each roof bow. Extend tape over each end of roof bow and over the edge of each end, being careful to not plug the drain hole on roof bows.
- 8. Apply spacer tape around front roof hatch opening. Remove spacer tape release paper strip around the bonded hatch.
- Wipe bonding surface with Sika-205 Cleaner and lint free cloth to ensure it is dust and residue free. Allow 10 minutes for Sika-205 Cleaner to dry.
- 10. Apply a 3/8" diameter bead of Sika-221 Sealant near the center of all roof bows and on top of each foam spacer.
- 11. Wipe the pre-primed perimeter edge along the bottom, with Sika Activator on the resin side.
- 12. Apply 1/8" x 3/8" spacer tape along full length of vehicle Position tape 1/4" below top edge of pier panel and filler strips. Peel off 8 inches of release paper from the spacer tape at the rear and allow it to hang down.
- 13.Apply one continuous circular bead of Sika-221 Sealant below the tape, along the entire length of the vehicle where the roof panels are to be bonded. Avoid contaminating the spacer tape.

# ™NOTE:

Use caution when applying black Sika-206G+P Primer to white gelcoat roof panels. The primer can cause stains that cannot be removed. Primer application must not exceed the width of the overlapping panel.



- 14. Lower the rear roof panel into place and let it relax with its own weight while holding sides away from structure. All roof studs and cutouts must line up. Press center lap joint down, to ensure panel is sitting on spacer tape.
- 15. Starting at the rear, peel release paper off spacer tape up to center joint.
- 16. Press bottom edge of roof panel into contact with spacer tape and adhesive. If bulging occurs, press down on center of bulge and work outwards using a panel roller.

# ™NOTE:

DO NOT use cinch straps to draw the panel to the mainframe structure.

17. Apply a continuous circular bead of 550FC Adhesive/AC61 Accelerator Sealant near outer edge of center lap joint. Apply a second continuous circular bead near the inner or forward edge. Apply a stitch bead (six inches of adhesive with a 6" gap) to the area between the continuous beads. See "Fig. 13-7: Roof Panel Cross Section" on page 22.

# ™NOTE:

Mixing of the adhesive and accelerator is done with special two component dispensing equipment.

# ™NOTE:

Roof panel must be installed within ten minutes of applying the lap joint beads.

18.Lower the front roof panel into place and let it relax with its own weight. Ensure that all roof studs and cutouts line up and joint overlap is correctly aligned to ensure even distribution of glue load with NO squeeze out.

# ™NOTE:

DO NOT use cinch straps to draw the panel to the mainframe structure.

- 19. Press center lap joint onto rear roof panel and press down front roof panel into contact with spacer tape.
- 20. Peel release paper off spacer tape up to front mask joint. Press bottom edge of roof panel into contact with spacer tape and adhesive. If bulging occurs, press down on center of bulge and work outwards using a panel roller.
- 21. Press down on center lap joint. If necessary, carefully stand on roof with one foot on lap joint and other on top of panel supported by structure plate. There should be no squeeze out.

# ™NOTE:

DO NOT use Sika-205 Cleaner to clean off excess wet adhesive from a bonded joint. The cleaner will taint the Sikaflex and not allow it to harden.

- 22. Ensure all roof stud holes are completely sealed with Sika-201 Adhesive. Smooth off with a putty knife. Ensure threaded ends of studs are free of adhesive.
- 23. Seal gap between roof panel and side console panel with Sika-201 Adhesive after front mask has been installed.
- 24. After painting, apply black Sika-221 into the center lap joint. Do not fill the center gap, but tool a smooth radius edge along the length of the joint.






Fig. 13-6: Roof Panel Installation




Fig. 13-7: Roof Panel Cross Section



# 2.11. Roof Cap Overlay

# 2.11.1. Roof Cap Overlay Installation

- Dry fit the roof cap overlay to the roof panels where the roof panels meet. The overlay must be centered over the roof panel seam and fit flush. See "Fig. 13-8: Roof Cap Overlay Installation" on page 23.
- Place a mark on the overlay near the drip rail where trimming may be necessary. Place lines on the roof panels so that the overlay can be centered over the roof seam.
- Remove the overlap and trim it as required. Remove burrs and rough edges. Scuff the inside radius to improve the sealant adhesion.
- 4. Scuff the roof panels at the vertical seams between the marks inscribed earlier.
- 5. Clean the roof panel and the inside of the overlay with Sika Glass and Surface Cleaner. Allow a minimum of two minutes for drying.

- Apply Sika Aktivator to the bonding area and to the inside of the overlay. Wipe dry with a paper towel and allow to dry for 3 minutes.
- Prime the surface of the roof panel between the marked lines and the underside of the overlay using Sika Primer-206.
- Allow the primer to set for 30 to 60 minutes.
- 9. Apply two triangular beads of Sika-222 to the underside of the overlay.
- 10.Place the overlay over the panel seam between the marked lines. Apply uniform pressure to the overlay to ensure proper bonding.
- 11. Apply a bead of Sika-222 Sealant along the top edge of the overlay to prevent seepage of water.
- 12. Remove excessive sealant immediately using a soft cloth and soapy water.
- 13. Allow the sealant to cure at room temperature for five hours.




Fig. 13-8: Roof Cap Overlay Installation



# 2.12. Fiberglass Panels

# 2.12.1. Fiberglass Panel Repair

Fiberglass parts are repaired by filling the damaged area with fiberglass cloth and resin or strand fiberglass and resin. The repair should be allowed to harden before finishing. Use of the various materials is determined by the type of repair to be made. Large holes, torn sections and separate joints require the adhesive qualities of the resin and the reinforcing qualities of the fiberglass. Small dents, scratches or pits can be repaired using resin and strand fiberglass and filler mixed into paste. Instructions for either mix are explained later under respective headings. For best results, the ambient temperature should be 70 to 75°F for repairs.



Some people experience a skin reaction to resins. When and if this happens, wipe off skin with denatured alcohol or

a good thinner. There are several protective hand creams on the market and use of one of these creams is recommended.

If any disc grinding or sanding is to be done in an enclosed area, a respirator should be used. Goggles should also be worn whenever grinding or sanding is done.

Extreme care must be taken if sander is electrically operated as dust of some resins is combustible when subjected to sparks or open flame.

The proper tool for sanding resin is a low-speed, air driven disc sander with a water attachment or a dry sander having a vacuum bag attachment. Either will eliminate flying glass and resin dust. The following additional tools and materials will assist in making repairs. Hacksaw blade, assorted files, emery paper or cloth (No. 150 grit or finer), scissors or tin snips, wax paper or cellophane sheets, small 3" paint roller, paint brush, putty knife, acetone and one or more heat lamps.



# 2.12.1.1. Using Fiberglass Cloth

 Where necessary, sand paint away around damaged area. On underside of vehicle, scrape away undercoating from damaged area and wipe clean with solvent. Grind or file damaged area to form a "V" at the broken or cracked portion. Sides of "V" should have a shallow pitch for maximum bonding area.

# ™NOTE:

Roughening the surface to be repaired will improve the adhesion of the resin.

- If paneling is warped from original shape, use C-clamps and improvised clamp plates to align surfaces.
- Preheat area to be repaired using one or two heat lamps positioned 12 to 15" from repair.



200°F is the high limit for this material and to go higher will risk material distortion or crystallization.

- Cut fiberglass cloth with scissors or tin snips one to three inches larger than area to be repaired. Build-up area to desired height.
- 5. Mix desired quantity of resin and hardener to one quart of Vibrin 135 resin. Do not use wax cups for mixing and do not allow resin to enter hardener can or vice versa. Mixture which is too thin can be thickened to desired consistency by adding powdered filler. Two tablespoons of filler to 1/2 pint of mix will usually supply desired consistency.
- Saturate layers of fiberglass with mixture, then place laminates over damaged area.
   Smooth out wrinkles and make sure general contour of area is maintained. Bubbles and wrinkles can be rolled out using a roller.



Once the resin and hardener have been mixed, the pot-life (working time) of the mix is approximately 15 minutes. Any accidental contamination to the skin, clothing, tools and so forth must be removed within this period. Use acetone to remove uncured resin.

- 7. Heat resin material again placing lamps 12 to 15" from repaired area. Allow 12 to 15 minutes for repair to cure. After repair is cured, grind, file or sand to contour. Files other than body files may be more suitable. Feather edge and sand.
- 8. After making repair, small pits or irregularities may appear in finished surfaces. Imperfections should be repaired using a liberal amount of chopped strand or filler mixed with resin to form a paste. Refer to 2.12.1.2. "Using Fiberglass Paste" on page 25 in this section for procedure.

#### 2.12.1.2. Using Fiberglass Paste

Fiberglass paste is used for repairing small dents, scratches and pits. Paste is made by mixing resin, hardener and fiberglass strand or filler to the consistency of putty.

Where necessary, sand paint away around damaged area. On underside of vehicle, scrape away undercoating from damaged area and wipe clean with solvent.

Preheat the area to be repaired using heat lamps. Mix desired quantity of resin and hardener (refer to manufacturer's instructions on container). Add powdered fiberglass strand into mixture to thicken it into a putty state. If repair is to be made on a vertical surface several layers of material may be used.

A hacksaw blade held flat to adjacent contour and then pulled, using sawing action across repair when the resin is in the jell stage, will remove excess resin from repair. Finish repair in the same manner as when using fiberglass cloth.



#### 2.12.2. Gelcoat Finish

#### 2.12.2.1.Gelcoat Surface Repair

This first procedure covers any small chips or scratches in the fiberglass panel Gelcoat surface.

 Inspect the panel and mark any chips, pits or small scratches in the Gelcoat surface.

# ™NOTE:

Refer to 2.12.4. "Larger Fiberglass Panel Damage" on page 27 in this section for preliminary repair work that must be done before the gelcoat side is repaired, if the panel has damage greater than superficial chips, scratches or small cracks.

- 2. Use acetone to clean around the area to a radius of 1/2 to 3/4", depending on the size of the chip or scratch.
- Sand rough edges with coarse sandpaper (80 to 90 grit) to roughly feather out to the smooth surface.
- Mask off the area and apply a layer of Gelcoat finishing putty over the prepped area.

#### ™NOTE:

The Gelcoat putty is prepared by mixing colored Gelcoat with powdered fiberglass filler. Add two drops of Cadox catalyst to a teaspoon (tsp.) size lump of Gelcoat mix. Vary this formula proportionally for larger mixes. Depending on ambient temperature and humidity, the average pot life (working time) is approximately 15 minutes.

5. Apply heat to speed hardening. Use a hot air gun or heat lamps. A safe heat range for this process is 150 to 200°F (66 to 93°C). Move the hot air gun continually over the curing surface. Place heat lamps, if used, 12 to 15" from the surface and continually monitor the curing process.



DO NOT overheat, as this will cause yellow discoloring of the white Gelcoat.

- 6. Wet sand the cured filler in increasing grit stages, working from 400, 600, 1200, and 1200 micro-fine wet sanding paper.
- Buff polish the finished area starting with medium-cut cleaner buffing compound and finishing with a fine cleaner buffing compound.

#### 2.12.3. Preprimed Finish

Preprimed Fiberglass Panel Paint Preparation

- 1. Wash down panel with a degreasing and cleaning solution.
- 2. Sand panel with 360 grit sandpaper.
- 3. Buff with 600 grit Scotch sanding pad.
- 4. Air blow dust off panel.
- Wash down with a degreasing and cleaning solution.
- Fill any pits or scratches with fine spot putty.
- 7. Fine sand and blow off residual dust.





## 2.12.4. Larger Fiberglass Panel Damage

Larger fiberglass panel damage can be repaired by applying fiberglass matting to the back of the panel (non-gelcoat side).

- Mark the damaged area, leaving approximately a 2 to 3" overlap. Cut and trim a piece of fiberglass matting to fit within the overlapped area.
- Roughen the marked area with coarse grit emery paper. Wipe the area with acetone to remove any traces of grease or oil. Wipe dry.
- Prepare enough fiberglass resin to thoroughly saturate the fiberglass matting patch.

## ™NOTE:

DO NOT use excess hardener as this will actually hinder the fiberglass and resin compound from curing properly. A properly mixed ratio of resin to hardener compound will have a pot life of approximately 15 to 20 minutes. Air temperature and humidity also affect the curing time of the resin/

hardener compound. The optimum temperature should be 70 to 75°F (21 to 24°C) with relatively low humidity. Lower temperatures and high humidity will cause longer curing time.

- 4. Wet the fiberglass matting completely with resin. Position the resin soaked fiberglass matting within the marked area.
- Thoroughly work into place using a brush or small roller. If the damaged area needs to be built up, apply successive layers of fiberglass matting. The resin can also be thickened by adding filler powder.

#### ™NOTE:

Don't over-thicken, as the matting must still be able to be thoroughly soaked for proper application.

- 6. After the patch has cured, lightly disk sand any exceptionally rough or high spots.
- Turn the panel over and repair the gelcoat side. Refer to 2.12.2.1. "Gelcoat Surface Repair" on page 26 in this section for procedure.



# 2.13. Painting Procedures & Preparation

This information provides guidelines and data for prepping, priming and topcoating of the major substrates used on New Flyer vehicles. Following this information and applying normal paint shop professional application procedures will ensure surface finishes that will meet optimum OEM standards. Always apply all relevant paint shop safety procedures and guidelines for a safe working environment.



These products are intended for Industrial Use and should only be used by professionally trained personnel using proper safety equipment. Follow all proper safety precautions regarding spray painting.

Use a filtering mask with the proper filter cartridges for this type of paint. Wear eye protection, protective gloves and proper protective clothing.

The paint booth or work area must be properly exhausted, using explosion proof ventilation equipment to remove fumes and over spray. Air make-up induction fans should also be used to supply fresh air to the work area.

The painting area should be a safe distance from any source of flame, spark or other means of combustion. Atomized paint, thinner, cleaner and solvent fumes are highly volatile with an extremely low flashpoint that can cause explosive combustion. Do not smoke or permit anyone else to smoke in or near the painting area.

#### 2.13.1. Substrate Treatment Preparation

#### 2.13.1.1.Stainless Steel

- Wash surface with DX-330 wax and grease remover.
- 2. Alternatively, spot blast around rivet heads.
- Scuff surface with 80 grit sandpaper, using dual action sander.
- Clean with DX-330 wax and grease remover.
- 5. Apply primer. Refer to 2.13.1.4. "Primer" on page 29 in this section for procedure.

#### 2.13.1.2.Aluminum

- 1. Wash surface with soap and water.
- 2. Scuff with Scotch Brite 7447 (red).
- Clean with DX-330 wax and grease remover.
- 4. Apply primer. Refer to 2.13.1.4. "Primer" on page 29 in this section for procedure.

#### 2.13.1.3.Fiberglass

- Clean surface with DX-330 wax and grease remover.
- Scuff with Scotch Brite 7447 (red) or sand with 400 grit sandpaper by hand or 320 grit DA.
- Clean with DX-330 wax and grease remover.
- 4. Apply primer. Refer to 2.13.1.4. "Primer" on page 29 in this section for procedure.

# **Painting Procedures & Preparation**

#### 2.13.1.4.Primer

 Blend equal parts of DP Epoxy Primer with equal parts of DP-401 catalyst, allowing for a 30 minute induction period.

## ™NOTE:

If a reducer is desired to enhance the handling characteristics, add up to 25% of the appropriate DT Reducer to the already mixed DP primer.

### ™NOTE:

No induction period required if using DP-402 fast catalyst.

- 2. Apply one full wet coat at 50 psi gun pressure to achieve recommended film build of 0.7 to 1.0 dry film thickness.
- 3. If a second coat is necessary, wait 10 to 15 minutes between coats.
- 4. Air dry primer for one hour at 75°F (24°C) or bake at 150°F (66°C) for 30 minutes.
- Topcoat can be applied up to seven days after which either a fresh coat of DP must be applied or the entire surface must be scuff sanded.

## 2.13.1.5.Spot Primer

#### ™NOTE:

Small imperfections may be filled with DGP 41/42 spot putty.

- 1. Mix 5 parts of K-36 with 1 part K-201 with 1 part DT reducer.
- 2. Apply 2 to 3 full wet coats at 40 to 50 psi at the gun to achieve a recommended dry film thickness of 2 to 4 mils.
- Allow to dry from 1 to 2 hours. Sand with 400 to 600 grit sandpaper. Spot primer may be force dried for 30 minutes at 140°F (60°C).
- Apply topcoat.

## 2.13.1.6.Topcoat (Deltron Base Coat/Clearcoat)

- Mix Deltron Base Coat with the appropriate DRR reducer at a mix rate for solid color at 1 part color and 1 1/2 part DRR reducer. For metallic mix 1 part color and 2 parts DRR reducer.
- Apply medium coats until hiding is achieved. Air pressure should be 40 to 45 psi at the gun. Allow 5 to 10 minutes between coats to allow for complete solvent evaporation and a recommended film build of 0.7 to 1.5 film build.
- Allow final coat to air dry 20 minutes by the clock prior to topcoating with clear or twotoning.

#### 2.13.1.7.Clearcoat

- Clearcoat with CDU 2020 by mixing 2 parts CDU 2020 with 1 part of the appropriate DT reducer and 1 part of the appropriate DU catalyst.
- Apply 1 medium wet coat and then two full wet coats with 40 to 50 psi at the gun to achieve a recommended film thickness of 2 to 3 mils, allowing a 15 to 20 minute flash between each coat. Allow to dry for 6 hours or overnight.
- Force drying may be achieved by baking for 30 minutes at 140°F (60°C). Accelerated drying may also be achieved by adding 1 oz. of DX-84 per gun cup.

## 2.13.1.8.Topcoat (DCC)

- 1. Mix DCC color with 2 parts color with 1 part appropriate DT reducer and 1 part appropriate DU catalyst.
- Apply 2 to 3 wet coats with 40 to 50 psi at the gun to allow a recommended film build of 2 to 3 mils. Allow a 15 to 20 minute flash time between each coat. Allow to dry for 6 hours or overnight.
- Force drying may be achieved by baking for 30 minutes at 140°F (60°C). Accelerated drying may also be achieved by adding 1 oz. of DX-84 per gun cup.



## 2.13.1.9.Epoxy Primer



This product is flammable. Use only with adequate ventilation systems and equipment. Keep away from heat, sparks, and open flame. Refer to and follow the safety data contained on the product labels. Read and follow any other information contained in product safety data sheets.

PPG Moisture Cure Zinc rich primer is designed to provide protection in humid and corrosive environments. It can be top-coated within four hours of application with SUPER-SHIELD®II, epoxy or polyure-thane topcoats.

The specified application required to provide optimum corrosion protection is one 8 mil wet coat drying to 5 mil. This coverage must be attained to maintain corrosion warranty.

The pot life of mixed primer base (part 1) and activator (part 2) is a minimum of 8 hours. The recommended thinner and cleaner is SP05054T0.

#### 2.13.2. Surface Preparation

- 1. Round off rough welds and sharp steel edges. Remove weld splatter.
- 2. Dry-abrasive blasting, chemical treatment or mechanical cleaning, depending on conditions and/or pertinent specifications.

## 2.13.3. Application Conditions

Surface temperature must be at least 5°F (3°C) above the dew point to ensure that moisture condensation does not occur during application and drying period. Apply when air and surface temperatures are between 45°F to 100°F (7°C and 38°C).

## 2.13.4. Application Equipment

- ☐ Electrostatic spray (GRACO pro 4500)
- ☐ Air mix spray Fluid pressure 1,000 psi, air atomization pressure 60 lb. Use 0.013 to 0.017 orifice, 1.57 to 1.97" (40 to 50 mm) fan and 100 mesh filters.
- ☐ Airless spray Fluid pressure 2,000 to 2,400 psi, use 0.013 to 0.019 orifice, 1.57 to 1.97" (40 to 50 mm) fan and 100 mesh filters.

#### ™NOTE:

Finish coat of SUPER-SHIELD®II, polyurethane or epoxy can be applied over this primer from between 1 to 24 hours. This will depend upon the primers original film build, the shop temperature, humidity and air movement conditions.

#### 2.13.5. Recommended Drying & Curing Time

Air dry (20°C (68°F) at 50% rel hum) - dry to touch in 60 to 90 minutes at 4 mils DFT.

#### 2.13.5.1.Force Cured

- 1. Primer only allow 30 minutes flash, then dry at 140 to 176°F (60 to 80°C) for 1 hour.
- Mono cure primer/topcoat, allow the primer to flash for 60 minutes prior to applying topcoat.

Flash topcoat for a minimum of 30 minutes then mono cure at 140°F (60°C) max. for 1 to 2 hours.



# 3. BUMPERS

## 3.1. Description

The front and rear bumpers are constructed of an extruded aluminum channel fitted with three energy-absorbing modules.

## 3.2. Removal

- Support the bumper assembly and remove the four bolts, nuts, and washers securing the bumper assembly to the vehicle structure. See "Fig. 13-9: Front Bumpers Installation & Removal" on page 31. See "Fig. 13-10: Rear Bumpers Installation & Removal" on page 32.
- 2. Remove the bumper assembly from the vehicle, being careful not to lose the two isolator strips that are located between the bumper and the mounting bracket.




Fig. 13-9: Front Bumpers Installation & Removal






Fig. 13-10: Rear Bumpers Installation & Removal

## 3.3. Disassembly

- 1. Remove the three screws that fasten each corner closeout plate to the bumper (front bumper only).
- Pry out the four plastic clips at each end of the bumper that secure the end module to bumper channel.
- 3. Slide out the end modules from the bumper channel and then slide out the center module.

## 3.4. Assembly

1. Insert center module into grooves in bumper channel and slide into place.

- Insert end modules into grooves in bumper channel and slide into place. Lock each end module in place using four plastic clips (Xmas tree style).
- 3. Install each corner closeout plate using three screws (front bumper only).

## 3.5. Installation

- 1. Support bumper and move into place, ensuring rubber isolator strips are placed between the bumper and the vehicle mounting bracket.
- 2. Install and tighten four mounting bolts, nuts, and washers.



## 3.6. Repair

Minor damage to the bumper modules, including scratches and gouges, can be repaired using the following procedure:

- 1. Clean and prepare the surface as follows:
  - a. Clean and scuff the repair area using SEM Scuff and Clean #38338. Follow the manufacturer's instructions for cleaning. If plastic cleaner is not available, use soap and water to clean repair area followed by rinsing with clear water and drying.
  - Prepare the substrate using SEM 3835
     Plastic Prep. Follow the manufacturer's instructions for use.

# ™NOTE:

Lacquer thinner, acetone, alcohol, and similar solvents are not acceptable cleaners and may adversely affect the repair.

- Use 80 grit sandpaper and sand the locally damaged area until all the paint is removed. Proceed to Step 3 for repairs involving minor surface imperfections or scratches. Proceed to Step 4 for repairs involving deep gouges.
- Remove only enough material from the substrate to provide a roughened surface for the repair material to adhere.
- 4. Grind a V-groove in the damaged area using a 24 grit sanding disc.

#### ™NOTE:

Grind or sand using low speed and light pressure to avoid heat buildup that could melt or smear the substrate and adversely affect the repair

- 5. Continue sanding approximately 4 to 5 inches beyond the repair area to remove the paint and provide a roughened surface to feather the repair material.
- Clean surface as described previously in Step 1. Proceed to Step 7 for minor repair or proceed to Step 8 for deep gouge repair.
- Mix equal amounts of 3M Structural Adhesive #8101 and apply per manufacturers instructions using a smooth plastic spatula.

Press firmly into repair area to eliminate air pockets. Apply sufficient buildup of material to allow for sanding and blending to surrounding contours.

- 8. Mix equal amounts of Flexible SEM-Weld (either #39927 or #39928) and apply per manufacturers instructions using a smooth plastic spatula. Apply a sufficient amount of repair material to fill the damaged area and press firmly into repair area to eliminate air pockets. Apply sufficient buildup of material to allow for sanding and blending to surrounding contours.
- Allow repair material to cure in accordance with manufacturer's recommendations. Proceed to Step 10 for minor repair or proceed to Step 11 for deep gouge repair.
- 10. Block-sand the repair area to the surrounding contours using 240 grit sandpaper. Finish sanding using 400 grit sandpaper.

## ™NOTE:

Any low spots or voids can be filled in with additional repair material. Minor pin holes can be repaired using PPG Spot Putty #DFL1 Dark Grey.

11.Block-sand the repair area to the surrounding contours using 80 grit sandpaper. Finish sanding using 180 grit sandpaper.

#### MOTE:

Any imperfections can be filled by applying a skin-coat of additional repair material.

- 12. Top coat paint refinish the repair area as follows:
  - a. Sand 3 to 4 inches around the repaired area using 240 grit followed by 400 grit sandpaper.
  - b. Clean surface as described previously in Step 1.
  - Apply two medium wet coats of SEM Bumper Coater (Black) #399103.

## ™NOTE:

Allow paint to cure 45 minutes to one hour between coats. Lightly sand between coats using 400 grit sandpaper.



## 3.6.1. Repair Materials

The following materials are commonly available from most automotive supply stores or automotive paint finishing suppliers:

- ☐ 3M #8101 Structural Adhesive
- ☐ SEM #3835 Plastic Prep

- ☐ SEM #39927 Flexible SEM-Weld (for large areas)
- ☐ SEM #39928 Flexible SEM-Weld (10 oz. tube for small areas)
- ☐ SEM #39103 Bumper Coater (Black)
- ☐ PPG Spot Putty #DFL1 Dark Grey



## 4. SPLASH GUARDS

## 4.1. Description

Continuous rubber splash guards are mounted to the structure between the front and rear wheel wells. Mud flaps are installed to the rear of each wheel well. Front splash guards are secured with retainers and screws. Rear splash guards are secured to reinforcing brackets with screws. The brackets are bolted to mount-

ing angles which in turn are attached to the vehicle structure. Mud flaps are secured to mounting angles which are attached to the vehicle structure with screws.

Check mounting hardware for condition and security. Replace or tighten as required. Check splash guards and mud flaps for condition. Replace if damaged or unserviceable. See "Fig. 13-11: Splash Guards Installation" on page 35.




Fig. 13-11: Splash Guards Installation



## 5. MIRRORS

## 5.1. Exterior Mirrors

A curbside mirror and a driver's side mirror are provided on this vehicle.

#### 5.1.1. Driver's Side Mirror

The mirror assembly is mounted forward of the lower front edge of the driver's window. It consists of a heated mirror head and support arm assembly. The mirror has upper flat rectangular and lower convex surfaces, and an integral turn signal light. See "Fig. 13-12: Exterior Driver's Side Mirror Assembly" on page 37.

1.	Mirror	Assembly,	Driver's Side	(Incl. 2-	19, 26-28)	
----	--------	-----------	---------------	-----------	------------	--

2. Housing, 8" x 15" with Grommet Hole

3. Plug, Heyco 1/2"

4. Grommet, Rubber

5. Plate and Clamp Assembly

6. Screw, Flat Head #6 - 32 x 5/8"

7. Glass, Flat

8. Plate, Medium Motor

9. Arm, Double Tube

10. Plate, Small Motor

11. Motor, Dual Electric 12V with Heat

12. Glass, Convex Heated

13. Screw, Pan HD #4 x 7/8" Lg.

14. Grommet

15. Plug

16. Harness, Mirror

17. Cable Tie

18. Extrusion, 1" Wire Chase

19. Bracket Assembly, Dovetail (Incl. 20-25)

20. Cap, Plastic

21. Bracket, Double Arm

22. Fitting, Grease 1/4" - 20 Straight

23. Clamp

24. Bolt, 3/8" - 16 x 2.50" SST

25. Bolt, 3/8" - 16 x 1.75" SST

26. Extrusion, 2" Wire Chase

27. Tie Wrap

28. LED Light Assembly, 6" (Incl. 29-31)

29. LED, 12V

30. Post, SST

31. Screw, PH #8 - 32 x 5/8" Pan Head

Exterior Driver's Side Mirror Assembly (parts list)






Fig. 13-12: Exterior Driver's Side Mirror Assembly



#### 5.1.2. Curbside Mirror

This mirror is located above and in front of the entrance door. It consists of a heated mirror assembly attached to a support arm which is connected to a chassis-mounted support housing. The mirror is a remotelyadjusted two-part assembly. It consists of an upper rectangular mirror, a lower convex mirror for wide angle viewing, and an integral turn signal light. See "Fig. 13-13: Exterior Curbside Mirror Assembly" on page 39.

1.	Mirror	Assembly,	Curbside	(Incl.	2-14.	21-28)	
----	--------	-----------	----------	--------	-------	--------	--

2. Grommet

3. Arm. Mirror

4. Harness, Mirror

5. Grommet, Rubber

6. Housing, 8" x 15" with Grommet Hole

7. Plug, Heyco 1/2"

8. Plate and Clamp Assembly

9. Screw, Flat Head #6 - 32 x 5/8"

10. Plate, Medium Motor

11. Glass, Convex Heated

12. Plate, Small Motor

13. Motor, Dual Electric 12V with Heat

14. Bracket Assembly, (Incl. 15-20)

15. Cap, Plastic

16. Bolt, 3/8" - 16 x 1.75" SST

17. Washer, Flat SST 3/8"

18. Clamp

19. Bracket, Double Arm

20. Bolt, 3/8" - 16 x 2.50" SST

21. Plug

22. Tie Wrap

23. Extrusion, 3" Wire Chase

24. Extrusion, 1" Wire Chase

25. Extrusion, 2" Wire Chase

26. Screw, Pan HD #4 x 7/8" Lg.

27. Glass, Flat

28. LED Light Assembly, 6" (Incl. 29-31)

29. LED, 12V

30. Post, SST

31. Screw, PH #8 - 32 x 5/8" Pan Head

Exterior Curbside Mirror Assembly (parts list)






Fig. 13-13: Exterior Curbside Mirror Assembly



## 5.2. Mirror Servicing

#### 5.2.1. Removal

- Disconnect the electrical harness at the bottom of the dove tail bracket.
- Loosen the sets screws on the dove tail bracket.
- 3. Slide the mirror and arm assembly up the dove tail bracket to remove from vehicle.

## 5.2.2. Disassembly

The mirror housing is easily removed from the support arm. However, the wires plugged to the defrost element on the back of the mirror and to the remote control servo must be disconnected first.

- 1. Move the bottom of the mirror face outward and up as far as possible.
- Remove the mirror glass. The glass is held in place by plastic snaps which are located at the bottom and top of the mounting frame.

## ™NOTE:

Be very careful when doing this so as not to chip or break the mirror. For reinstallation, first place the glass in the bottom groove; then push firmly but carefully on the top edge to snap it into the top groove.

- Disconnect the flat two lead plug for the mirror defrost element and the three pin round connector for the remote control servo unit.
- Pry out the housing grommet and pull both cable leads out of the mirror housing. Set the mirror aside.
- Remove the covers from the rear of the mirror and remove the screws on the clamps which retain the arm to the mirror housing to remove the mirror from the arm.

## ™NOTE:

Refer to the illustrations included with this section as a further reference for disassembly and assembly.

#### 5.2.3. Installation

- Install the dove tail on the mirror arm into the dovetail slot on the vehicle- mounted bracket.
- Tighten the set screws on the dove tail mounting bracket to secure the mirror arm in place.
- Connect the electrical harness at the bottom of the dove tail bracket.

#### 5.3. Interior Mirrors

### 5.3.1. Description

The following mirrors are located throughout the vehicle interior:

- ☐ Aisle Mirror The aisle mirror is located under the front destination sign close-out. Its convex glass surface provides a wide view of the entrance door and passenger area.
- ☐ Upper Right Mirror Located to the right of the aisle mirror, the upper right mirror is used to view the rear mirror.
- ☐ Rear Step Area Mirror The rear step area mirror is located on the stanchion at the exit door. This mirror provides a view of the exit door area when looking through the upper right mirror from the driver's seat.





# 6. WINDSHIELD WIPER & WASHER

# 6.1. Windshield Wiper

## 6.1.1. Description

The windshield wipers are two-speed electrically operated units. The wiper motors are mounted to brackets located behind access panels below the windshield. The wiper assemblies are fitted with parallel arms to hold the wiper blades in a vertical position as they sweep across the windshield. Arms are fitted with wet arm adapters and tubes that supply fluid from the washer bottle to the arms.

#### 6.1.2. Removal

 Pull wiper arm away from windshield and insert nail or small pin in wiper arm hole, close to hinge point. Release arm. Arm should be held away from windshield. See "Fig. 13-14: Windshield Wiper & Motor Installation" on page 42.

- Remove acorn nut from operating shaft and mark relationship of arm to shaft for reinstallation.
- 3. Unplug windshield washer hose at front panel.
- 4. Loosen arm-clamping bolt.
- Loosen Allen head set screw retaining cap nut on idler arm pivot and remove cap nut, wiper blade and arm assembly.
- Remove spanner nut from operating shaft, pull out spacer and pivot assembly and disconnect washer hose from assembly.
   Remove spacer and pivot assembly.
- 7. Disconnect electrical connectors at motor.
- Remove four bolts retaining mounting bracket to vehicle and remove wiper motor assembly.






Fig. 13-14: Windshield Wiper & Motor Installation



#### 6.1.3. Installation

- Position motor on vehicle, install mountings bolts and tighten.
- 2. Connect electrical connectors.
- Route windshield washer hose through hole in mask.
- 4. Install gasket on spacer and pivot assembly and connect washer hose to tube fitting. Position pivot assembly on vehicle. Install spanner nut and tighten to 25 to 30 ft-lb. (34 to 41 Nm).
- Install wiper operating arm in originally marked position.
- 6. Tighten arm clamping bolt to 155 to 165 in-lb. (17 to 18 Nm).
- Install idler arm and cap nut on pivot shaft.
   Tighten Allen head set screw to retain cap nut to shaft.
- 8. Install nylon washer and acorn nut on operating arm shaft and tighten securely.
- If wiper blade was removed from wiper arm install wiper blade and retaining screw.
   Tighten screw until blade can no longer pivot then loosen screw 1/4 turn.
- 10. Pull wiper arm away from windshield and remove previously installed nail or small pin from wiper arm pivot. Release arm.
- 11. Operate wipers on wet glass to verify sweep and blade angle. If adjustment is required, proceed as follows:
  - a. Move wiper arm to mid position on windshield.
  - b. Lengthen or shorten idler arm as required to hold wiper blade in vertical position.
  - Operate wipers while observing that the wiper pattern is centered and blades are not touching the windshield seals.
  - d. If sweep is off center, reposition operating arm on wiper shaft and recheck operation.

## 6.2. Windshield Washer

## 6.2.1. Description

The windshield washer is controlled by the wiper/washer control knobs, which are located on the instrument panel. When the control knob is pressed the washer bottle motor operates and causes washer fluid to be sprayed onto the windshield. The motor is externally mounted beside the washer bottle. The motor stops operating when the switch is released.

#### 6.2.2. Removal

- Open side console access panel door below driver's window.
- Disconnect hose between washer bottle and motor at motor. See "Fig. 13-15: Washer Bottle Installation" on page 44.
- Disconnect the hose from the filler cap by removing the attaching clamps.
- 4. Remove the six bolts from the base of the washer bottle support plate.
- 5. Remove washer bottle from vehicle.

## ™NOTE:

To be replaced only as an assembly.


#### 6.2.3. Inspection

Remove the four screws securing the cover plate to the washer bottle. Check for foreign material in reservoir. Remove the filter from the bottom of the inlet hose. Clean if dirty or clogged.

## 6.2.4. Installation

- Secure washer bottle onto the support plate using six hex bolts, washers and lock washers.
- 2. Connect hose to motor.
- Attach hose to filler cap using clamps.
- 4. Close side console access door.
- 5. Start vehicle and test washer operation.





- 1. Hose, Rubber 1 1/8" I.D.
- 2. Bolt, Hex 3/8" 16 UNC x 1" Lg.
- 3. Washer, Flat 3/8"
- 4. Screw, PH Cross Recess SST 1/4" 20 UNC x 3/4" Lg.
- 5. Insert, 1/4" 20 UNC
- 6. Adhesive, SIKA 221 White

- 7. Nut, Lock Nylon 3/8" 16 UNC
- 8. Washer Bottle Assembly
- 9. Filler Cap Assembly
- 10. Clamp, Gear 1.50" 1.75"
- 11. Loctite, 243

s033383a.svg

Fig. 13-15: Washer Bottle Installation



## 6.2.5. Washer System Troubleshooting

WASHER SYSTEM TROUBLESHOOTING				
PROBLEM	CAUSE	SOLUTION		
Fails to Spray Washer Fluid.	Reservoir empty.	Add proper fluid.		
	Improper washer fluid concentration if below 32°F (0°C).	Store vehicle or parts in heated area, then purge fluid system with low temperature solution.		
	Contamination in tubing or nozzles.	Clean with compressed air. Replace if necessary.		
	Tubing damage.	Replace section.		
	Tubing bent or disconnected.	Realign tubing and/or refit. Trim end to ensure proper fit.		
	Clogged inlet filter.	Clean or replace filter.		
Switch Operated, but System Inoperative.	Switch defective.	Replace switch.		
Cyclem moperative.	Motor defective.	Replace motor.		
Inadequate Expulsion of Proper Washer Solution.	Tubing failure.	Replace tubing.		
Troper washer columen.	Motor defective.	Replace motor.		
	Partially restricted inlet filter.	Clean or replace filter.		
Slow Operation.	Motor defective.	Replace motor.		
	Improper solution.	Replace with proper solution.		
Fluid Stream Improperly Directed.	Nozzles adjusted incorrectly.	Reposition nozzles.		



## 7. BIKE RACK SYSTEM

# 7.1. Description

This vehicle is equipped with a bicycle rack system. It is mounted to the front of the

vehicle and allows passengers to load and unload their bicycles without driver assistance. See "Fig. 13-16: Major Components of Bike Rack" on page 46.




Fig. 13-16: Major Components of Bike Rack



## 7.2. Operation



To ensure safe vehicle operation, NEVER load a bike onto the bike rack which will in any way obstruct the head-lamps. ALWAYS verify that the head-lamps are unobstructed whenever a bike has been loaded onto the bike rack.

#### 7.2.1. Loading

- 1. Remove water bottles, pumps or other loose items from bike prior to loading.
- Squeeze bike rack handle UP to release latch.
- Fold down bike rack.
- 4. Lift bike onto rack, fitting wheels into proper wheel slots.
- 5. Raise the support arm over the front tire so that the hook rests at the highest point on the front wheel. Bike is now held firmly in place.

#### 7.2.2. Unloading

- 1. Unload from curb or from front of vehicle.
- 2. Raise support arm off the tire.
- 3. Lift bike out of wheel slots and set down.
- 4. If there are no other bikes on the rack, lift it until the rack swings into the lock position against the vehicle.

### 7.3. Maintenance

## ™NOTE:

Refer to the Preventive Maintenance section of this manual for scheduled maintenance procedures and intervals.

## 7.3.1. Bike Rack Servicing

1. If the bike rack is not raising and lowering with ease, check the two pivot bolt assemblies for incorrect installation or wear. Replace the assemblies if damaged. Check that the pivot tabs are straight and aligned to properly pivot the bike rack. Straighten the tabs as required.

- 2. Check the pivot plate for correct alignment and damage. Remove and straighten the pivot plate if it is not straight.
- If the bike rack magnet does not properly mate with the support arm, check the alignment of the magnet arm (the steel strap securing the magnet to the bike rack). Adjust the magnet arm as required.
- 4. Ensure that the fasteners holding the magnet assemblies to the magnet arm are tight. Examine the magnet and magnet housing for wear. Replace if damaged.
- Examine the structural integrity of the main loops, saddle pieces, and the rectangular tubing of the main frame. Repair or replace the bike rack if damaged.

#### 7.3.2. Latch Mechanism Servicing

- Check release handle and stem for straightness. Correct as required. See "Fig. 13-17: Latch Mechanism Servicing" on page 48.
- Examine plastic insert in tip of latch pin for wear. Replace if worn.
- 3. Ensure latch pin tracks correctly on latch quadrant. Ensure quadrant is attached securely and square to the pivot plate. Replace as required.
- 4. Examine latch housing as follows:
  - a. Remove roll pin attaching latch stem to patch pin.
  - b. Pull on release handle to separate latch stem from latch pin.
  - c. Unscrew latch cap nut and remove components from inside of housing.
  - d. Check spring for wear. Clean and repair or replace as required.
  - e. Check snap ring on latch pin. Replace if damaged.
  - f. Remove any dirt from inside of latch housing.
  - g. Reassemble in reverse order of Steps a to c.

#### ™NOTE:

DO NOT lubricate the latch mechanism.






Fig. 13-17: Latch Mechanism Servicing

## 7.3.3. Support Arm Servicing

- Remove bolts attaching support arm hinge to bike rack. See "Fig. 13-18: Support Arm Servicing" on page 49.
- 2. Remove stop screw at top (washer end) of support arm housing. Remove roll pin from base of housing.
- Carefully slide stainless steel hook arm out from support arm housing. Note how two nylon slider keys and stop plate fit at base of hook arm for reinstallation.
- 4. Remove roll pin on hook arm to free support arm spring. Clean spring and examine for condition. Replace as required.
- 5. Clean inside of support arm housing with a stainless steel brush. Do not use a non-stainless steel brush.
- 6. Examine nylon slider keys at base of hook arm. Replace if damaged or if support tube does not track properly.

- 7. Examine stop plate at base of hook arm. Replace if damaged.
- 8. Assemble support arm in reverse order of steps 1. through 4. Use a wire hook to pull spring into position when inserting roll pin through base of support arm housing and end hook of spring.
- Check operation of reassembled support arm. Hook should pull out smoothly, stop at the stop screw, slide easily into the stored position, and self stow on the magnet when released. Straighten hook as required.
- 10. Examine support arm hinge. Replace housing if excessive side play and warpage exists.
- 11. Examine grip on hook arm. Replace if worn or damaged. Refer to 7.3.4. "Support Arm Grip Installation" on page 49 in this section for procedure.






Fig. 13-18: Support Arm Servicing

## 7.3.4. Support Arm Grip Installation

- 1. Secure hook/support arm assembly.
- 2. Use a dish soap solution of 25% Palmolive (or equivalent) dish soap to water.
- 3. Apply the dish soap solution to hook tube and inside of foam grip.
- 4. Slide grip onto hook; it will be necessary to twist and work the grip past the bend in short, incremental movements.
- Slide the grip until it bottoms out on end of hook tube, being careful not to compromise the end of the grip by stretching it too tightly
- Allow one hour for solution to evaporate and grip to tighten. Always test the grip to ensure proper adhesion before putting bike rack back into service.





# **Windows**

1.	SAFETY	14-1
	1.1. Safety Procedures	14-1
	1.2. Liabilities & Disclaimers	
2.	WINDOWS	14-3
	2.1. Description	14-3
	2.2. Windshield	
	2.2.1. Description	
	2.2.2. Removal	
	2.2.3. Installation	
	2.3. Driver's Window	
	2.3.1. Description	
	2.3.2. Emergency Exit Window Operation	
	2.3.3. Main Frame Assembly	
	2.3.3.1. Subframe Removal	
	2.3.3.2. Main Frame Assembly Removal	
	2.3.3.3. Main Frame Assembly Installation	
	2.3.3.4. Subframe Installation	
	2.3.4. Subframe Spacer	14-10
	2.3.4.1. Subframe Spacer Removal	
	2.3.4.2. Subframe Spacer Installation	
	2.3.5. Subframe Assembly	
	2.3.5.1. Subframe Removal	
	2.3.5.2. Subframe Installation	
	2.3.6. Release Handle	
	2.3.6.1. Subframe Assembly Securement      2.3.6.2. Release Handle Installation	
	2.3.7. Tie Bar Assembly	
	2.3.7.1. Egress Assembly Securement	
	2.3.7.2. Tie Bar Assembly Removal	
	2.3.7.3. Tie Bar Assembly Installation	
	2.3.8. Release Bolt	
	2.3.8.1. Tie Bar Removal	14-13
	2.3.8.2. Damaged Release Bolt Installation	
	2.3.9. Clamp Ring Assembly	
	2.3.9.1. Clamp Ring Removal	
	2.3.9.2. Clamp Ring Installation	
	2.3.10. Sash Assembly	
	2.3.10.1.Sash Assembly Removal	
	2.3.10.2.Sash Assembly Installation	
	2.4. Side Emergency Window	14-15

# Table of Contents



2.4.1. Description	14-15
2.4.2. Emergency Exit Window Operation	14-16
2.4.3. Main Frame Assembly	14-17
2.4.3.1. Subframe Removal	14-17
2.4.3.2. Main Frame Assembly Removal	14-17
2.4.3.4. Subframe Installation	14-18
2.4.4. Subframe Spacer	14-18
2.4.4.1. Subframe Spacer Removal	14-18
2.4.4.2. Subframe Spacer Installation	14-18
2.4.5. Subframe Assembly	14-19
2.4.5.1. Subframe Removal	
2.4.6. Release Handle	
2.4.7. Tie Bar Assembly	
,	
2.4.8. Release Bolt	
2.4.9. Clamp Ring Assembly	
2.5. Side Non-Emergency Window	14-22
2.5.1. Description	14-22
2.5.2. Main Frame Assembly	14-23
2.5.3. Clamp Ring Assembly	
·	
2.6. Side Destination Sign Window	
2.6.1. Description	



## 1. SAFETY

## 1.1. Safety Procedures



Installation of this window system should be done in accordance with the legislation, codes of practice, or instructions found in, the occupational health and safety laws of the jurisdiction in which the work is to be done. Special attention should be paid to the need for personal protective equipment such as safety glasses conforming to the current government safety standard and protective cut resistant work gloves. In addition material safety data sheets should be on hand and understood for any and all chemicals used during the field installation process. The weight of the window system requires a minimum of two people using team lifting techniques during this installation, and in general when handling this window system sound ergonomic practices should be followed.

This section of the service manual contains procedures which require the mechanics to strictly observe safety procedures in order to ensure personal and equipment safety.

Always ensure that the vehicle is appropriately hoisted and blocked for procedures which require elevating the vehicle. Be aware of the limitations of the blocking equipment, and always ensure that the jarring and shaking created by component removal and installation procedures does not overload the blocks, or cause the vehicle to become unstable.

Certain procedures may require the vehicle be operated in an elevated position in order to accurately troubleshoot and diagnose a problem. If the vehicle must be running while elevated, become familiar with the repair area prior to starting the engine. Take special care in noting areas which will become hot, electrically energized, and areas where moving and rotating components are located. Limit the work in these areas as personal and equipment safety is at risk.

For procedures which involve air lines, ensure the line is safely depressurized prior to disconnecting. Disconnecting pressurized lines will cause solid particles deposited in the line to be uncontrollably propelled, and will also cause the hose end to whip randomly as the air escapes.

During electrical diagnosis procedures an understanding of the vehicle's electric circuits is important to anticipate the results of connecting test equipment. During component removal or installation, ensure the Battery Disconnect switch is in the OFF position.

Failure to follow this procedure may result in personal injury or component failure.

Observe the following procedures involving hydraulic line removal.

- ☐ Hydraulic fluid is corrosive and should not be exposed to skin for extensive periods of time.
- Wear eye protection at all times.
- Pressurized lines should not be disconnected until the pressure is safely and controllably released.





Because fumes are more dangerous in a small space, be sure the vehicle is well ventilated while using any cleaning agent. Follow the manufacturer's advice in using such products. Many cleaners may be poisonous or flammable, and their improper use may cause personal injury or damage to the inside of the vehicle. Therefore, when cleaning the interior, DO NOT use volatile cleaning solvents such as acetone, lacquer thinners, enamel reducers, nail polish removers or such cleaning materials as laundry soaps, bleaches or reducing agents (except as noted in the fabric cleaning advice on stain removal later). NEVER use carbon cleaning products.

## ™NOTE:

To avoid possible permanent discoloration on light colored trim, DO NOT let materials with unstable dyes come in contact with seat trim materials until totally dry.

Proper cleaning techniques and cleaners must be used on trim materials. Failure to do this on the first cleaning may result in water spots, spot rings, setting of stains, or soilage, all of which make it more difficult to remove in a second cleaning.

## 1.2. Liabilities & Disclaimers

#### ™NOTE:

The following disclaimer is provided by AROW Global Inc, the manufacturer of the windows installed in this vehicle.

The information provided in this document setting out AROW Global Inc.'s (the "Manufacturer") recommended procedure for Flush Window Glass Replacement is provided at the request of the manufacturer of the bus into which the Manufacturer's flush

glass window system (the "System") is incorporated. The owner/operator/user of such bus assumes the entire risk for any injuries or harm to any persons attempting to perform the removal of glass from or insertion and bonding of glass into the System other than at the Manufacturer's premises. Due to the weight of the System and the individual glass panels installed therein together with the complexity of the Flush Window Glass Replacement procedure described in this section and the inherent danger posed by some of the tools required to perform the said procedure, the Manufacturer expressly recommends that owners/operators/users of buses into which the Manufacturer's Systems are incorporated purchase new Systems from the Manufacturer to replace damaged ones instead of attempting to make field repairs in accordance with the procedure set out in this section.

The Manufacturer shall not be liable under any circumstances or under any legal theory for any injuries or harm to any persons, other than employees of the Manufacturer, attempting to perform the removal of glass from or insertion and bonding of glass into the System or other repairs to the System whether in accordance with or following the procedure outlined in this section. The Manufacturer shall also not be liable under any circumstances or under any legal theory for any direct, indirect, punitive, special, incidental or consequential damages whatsoever that may be suffered by an owner/operator/user of any bus in which the Manufacturer's System is installed and which are suffered as a result of any persons, other than employees of the Manufacturer, attempting to perform the removal of glass from or insertion and bonding of glass into the System or other repairs to the System whether in accordance with or following the procedure set out in this section.



## 2. WINDOWS

# 2.1. Description

This vehicle is equipped with a seal-retained windshield and side windows. See "Fig. 14-1: Windows Installation" on page 3. Side windows consist of a frame, a subframe, a clamp ring and flush-mounted glass.

The following side window assemblies are installed on the vehicle:

- Driver's window
- Destination sign window
- □ Side emergency windows
- □ Side non-emergency windows




Fig. 14-1: Windows Installation



## 2.2. Windshield

## 2.2.1. Description

The windshield consists of streetside, curbside, and upper destination sign glass sections. These three separate glass sections are retained within the front mask by an EPDM molded seal. The perimeter seal

has two sets of channels. One channel is bonded to the front mask fiberglass aperture on the vehicle and the other channel to the windshield glass. A wedge-shaped rubber insert (lace) exerts pressure on the channel in the rubber seal, forcing it tight against the window. See "Fig. 14-2: Windshield" on page 4.




Fig. 14-2: Windshield



#### 2.2.2. Removal



Wear protective gloves and use glass handling equipment when handling glass.

- Pry one end of the lace out of the rubber window seal and pull to remove the entire length from the perimeter of the glass being removed.
- 2. Carefully cut through the sealant adhering the glass to the rubber seal.



DO NOT damage window seal when separating it from glass.

- 3. With help of an assistant, pry the rubber window seal away from the glass and remove the glass from the opening.
- Clean the excess sealant from the rubber window seal.

#### 2.2.3. Installation



This installation is to be performed by qualified personnel only.

 Inspect the window seal for cracks and damage. The seal must be flexible and in good condition at all three glass sections. Inspect seal groove in window seal where windshield section is removed.

#### ™NOTE:

Replace the entire window seal if any section of the window seal is damaged or in poor condition.



DO NOT lubricate the seal or the windshield opening with soapy water, as this may seep in between the windshield layers and cause fogging of the glass.

2. Lubricate the seal groove with an alcohol based glass cleaning foam.



Wear protective gloves and use glass handling equipment when handling glass.

 Wipe the edges of new glass and lubricate them with an alcohol based glass cleaning foam.



- 4. With the help of an assistant, pry open the bottom retaining groove where it meets the vertical seal at center of vehicle, use the installation tool. See "Fig. 14-3: Installation Tool" on page 6. Push the glass corner into seal groove. If installing the destination sign glass, start at the lower streetside or curbside corner.
- 5. Work along the bottom seal then do the vertical seals. Do the top seal at last.
- Check that the windshield is seated properly inside window seal.
- 7. Pry the window seal away from glass and place a continuous bead of black butyl sealant into glass retaining groove. See Details A, B, & C in Windshield illustration. Insert the lace into window seal using lace tool. See "Fig. 14-4: Installing Lace" on page 6. Thread the lace through eye of lace tool and push the lace into lace groove. Work along the bottom seal then do the vertical seals. Do the top seal at last.
- 8. Cut off excessive length of lace and push it into groove.
- 9. Remove the squeeze-out sealant from glass and glass seal using mineral oil.
- 10. Check that the windshield is installed properly and perform a water leakage test.




Fig. 14-3: Installation Tool




Fig. 14-4: Installing Lace



## 2.3. Driver's Window

## 2.3.1. Description

The driver's window is a front slider style with an interior and exterior handle for opening and closing. It can also function

as an emergency exit and is equipped with an emergency release handle. The window assembly consists of a Main Frame, Subframe, Clamp Ring, and flush-mounted glass sections. See "Fig. 14-5: Driver's Window Assembly" on page 7.




Fig. 14-5: Driver's Window Assembly



## 2.3.2. Emergency Exit Window Operation

- 1. Pull the red emergency handle down and hold it in this position. See "Fig. 14-6: Emergency Window Operation" on page 8.
- 2. Push out on the bottom of the window frame. The window will open and rotate outwards on hinges at the top of the frame.
- 3. To close the window, release the emergency handle and allow the window to slam shut.
- 4. Ensure all latches are properly engaged.




Fig. 14-6: Emergency Window Operation



## 2.3.3. Main Frame Assembly

#### 2.3.3.1. Subframe Removal

If only replacing the Main Frame assembly, the Subframe will need to be retained and installed into the Main Frame assembly. The Subframe assembly is removed as follows:

- Remove the hinge retainers located at the top on each side. Each hinge retainer is held in place by (1) #8 screw. Remove each screw along with the hinge retainer and store for reassembly.
- 2. Pull the red release handle located in the interior of the vehicle. Once the tie bar assembly is disengaged the window should swing freely.



DO NOT damage the Subframe assembly since it will be needed to reassemble the window. Store in a safe location until reassembly.

3. At an approximate 45° angle, slide the egress assembly either to the right or left of the assembly until the top hinge rails release the Subframe assembly.

#### 2.3.3.2. Main Frame Assembly Removal

The Main Frame assembly is held in place by the Clamp Ring assembly. To remove the Main Frame assembly:

 Remove the screws that follow the Clamp Ring perimeter from the inside of the vehicle.

## ™NOTE:

This will require two people since these screws are the primary connection to the vehicle frame. One person will need to secure the window from the outside, while the other removes the screws from the interior.

Once the screws are removed, the window should be free from the vehicle frame. Retain the Clamp Ring screws as these will be required to reassemble the window.

## 2.3.3.3. Main Frame Assembly Installation

- 1. Clean the window opening.
- Apply a small bead of Butyl sealant to all exterior joints of the window opening.
- Use two shim spacers consisting of 1" x 3" x 1/8" thick polyethylene under the two contact surfaces of the window.
- Install the window into the vehicle and secure it temporally. There should a vertical gap of 0.25" ± 0.06" between adjacent windows.
- Take the existing Clamp Ring assembly, and align it with the Main Frame assembly. Ensure that the Main Frame assembly is aligned with equal gaps around the vehicle opening.
- 6. Using the Clamp Ring assembly screws reassemble the Clamp Ring assembly.
- 7. Place the first two screws at either side of the splice line but do not tighten.

## ™NOTE:

Make sure the Clamp Ring assembly is aligned side to side.

- Place the next screw in a screw opening 2/3 of the way up the window on the right side. Start the screw but do not tighten.
- 9. Follow the same procedure on the left side.
- 10.Once these are in place, start a screw on each side of the bottom of the Clamp Ring assembly.
- 11. Following the original sequence, torque the screws to 45 in-lb. Starting in a clockwise pattern replace the remaining screws and torque to 45 in-lb.



#### 2.3.3.4. Subframe Installation

- 1. Using two people, tilt the window to an approximate 45° angle.
- 2. With the Subframe assembly to one side, align the upper hinge (on the Main Frame assembly) with the lower hinge (on the Subframe assembly).
- Slide the Subframe assembly into the Main Frame assembly until there is equal spacing on each side.

## ™NOTE:

The Subframe assembly should nest within the Main Frame assembly.

- Using pressure from the outside, force the tie bar assembly over the ramps until the window is closed.
- 5. Reinstall the hinge retainers at the top on each side.

6. Check the function of the egress window to ensure proper installation.

#### 2.3.4. Subframe Spacer

#### 2.3.4.1. Subframe Spacer Removal

If the frame spacer is damaged or broken, remove any broken or damaged sections by drilling the rivet out of the frame.

## 2.3.4.2. Subframe Spacer Installation

- 1. Align the new frame spacer with opening in the Main Frame assembly.
- 2. Using a pop rivet tool, install the provided pop rivet until flush.
- Ensure that the rivet is aligned in the proper location on the Main Frame assembly. See "Fig. 14-7: Rivet Location" on page 10.




Fig. 14-7: Rivet Location



# 2.3.5. Subframe Assembly

#### 2.3.5.1. Subframe Removal

- Remove the hinge retainers located at the top on each side. Each hinge retainer is held in place by (1) #8 screw. Remove each screw along with the hinge retainer and store for reassembly.
- 2. Pull the red release handle located in the interior of the vehicle. Once the tie bar assembly is disengaged the window should swing freely.



DO NOT damage the Subframe assembly since it will be needed to reassemble the window. Store in a safe location until reassembly.

3. At an approximate 45° angle, slide the egress assembly either to the right or left of the assembly until the top hinge rails release the Subframe assembly.

# 2.3.5.2. Subframe Installation

- 1. Using two people, tilt the window to an approximate 45° angle.
- With the Subframe assembly to one side, align the upper hinge (on the Main Frame assembly) with the lower hinge (on the Subframe assembly).
- Slide the Subframe assembly into the Main Frame assembly until there is equal spacing on each side.

# MOTE:

The Subframe assembly should nest within the Main Frame assembly.

- Using pressure from the outside, force the tie bar assembly over the ramps until the window is closed.
- 5. Reinstall the hinge retainers at the top on each side.
- 6. Check the function of the egress window to assure proper installation.

#### 2.3.6. Release Handle

# 2.3.6.1. Subframe Assembly Securement

- 1. Open the Subframe assembly such that the tie bar assembly is visible.
- 2. Support the Subframe assembly open in a secure manner with ample room to work.
- Clamp the tie bar assembly forward (toward the release handle) to reduce the spring pressure. This can be done with C-clamps or vise grips.

#### 2.3.6.2. Release Handle Installation

- 1. Remove the release cable from the release handle assembly.
- 2. Remove the two screws and nuts that hold the release handle assembly in place.
- Align the new release handle assembly with the slot and two holes and insert until flush.
- Reinstall the screws and nuts. See "Fig. 14-8: Release Handle Replacement" on page 12.
- 5. Reinstall the release cable and remove the clamp from the tie bar assembly.
- Cycle the release handle assembly several times to ensure the unit is functioning properly.






Fig. 14-8: Release Handle Replacement

# 2.3.7. Tie Bar Assembly

# 2.3.7.1. Egress Assembly Securement

- 1. Open the Subframe assembly such that the tie bar assembly is visible.
- 2. Support the Subframe assembly open in a secure manner with ample room to work.
- Clamp the tie bar assembly forward (toward the release handle) to reduce the spring pressure. This can be done with C-clamps or vise grips.

#### 2.3.7.2. Tie Bar Assembly Removal

- 1. Remove the release cable from the release handle assembly.
- 2. From the inside of the vehicle remove the filler strip seal.

- 3. Remove the six retaining E-clips and truss head pins with groove.
- 4. Unhook the S-hook from the spring.
- 5. From the outside of the vehicle, remove the clamp. The tie bar should fall free.

#### 2.3.7.3. Tie Bar Assembly Installation

- Align the new tie bar assembly with the channel in the Subframe.
- 2. Attach the S-hook to the spring.
- 3. Hook the cable into the release handle.
- 4. Reinstall the truss head pin with groove through the holes in the frame, and the slot in the retaining bolts.
- 5. Once installed, snap the E-clips onto the truss head pin with groove to secure.
- Cycle the egress handle to ensure proper function.



#### 2.3.8. Release Bolt

#### 2.3.8.1. Tie Bar Removal

- 1. Remove the release cable from the release handle assembly.
- 2. From the inside of the vehicle remove the filler strip seal.
- 3. Remove the six retaining E-clips and truss head pins with groove.
- 4. Unhook the S-hook from the spring.
- 5. From the outside of the vehicle, remove the clamp. The tie bar should fall free.

# 2.3.8.2. Damaged Release Bolt Installation

- Remove the roll pins from each end of the damaged release bolt.
- Replace the damaged release bolt with the new release bolt aligning the slots section into the tie bar. Make sure to note the direction of the release bolt.
- Each release bolt should be facing the same direction, with the slanted ramp section facing inward.
- 4. Replace the pins into the new release bolt.
- 5. Reinstall the tie bar assembly. Refer to 2.3.7.3. "Tie Bar Assembly Installation" on page 12 in this section for procedure.

#### 2.3.9. Clamp Ring Assembly

#### 2.3.9.1. Clamp Ring Removal

 Remove the screws that follow the Clamp Ring perimeter from the inside of the vehicle.

# ™NOTE:

This will require two people since these screws are the primary connection to the vehicle frame. One person will need to secure the window from the outside, while the other removes the screws from the interior.

Once the screws are removed the window should be free from the vehicle frame.

# 2.3.9.2. Clamp Ring Installation

- Align new Clamp Ring assembly with the Main Frame assembly.
- 2. Ensure that the Clamp Ring assembly is aligned with equal gaps around the Main Frame assembly.
- 3. Using the Clamp Ring assembly screws reassemble the Clamp Ring assembly.
- 4. Place the first two screws at either side of the splice line but do not tighten.

### ™NOTE:

Make sure the Clamp Ring assembly is aligned side to side.

- 5. Place the next screw in a screw opening 2/3 of the way up the window on the right side. Start the screw but do not tighten.
- 6. Follow the same procedure on the left side.
- Once these are in place, start a screw on each side of the bottom of the Clamp Ring assembly.
- Following the original sequence torque the screws to 45 in-lb. Starting in a clockwise pattern replace the remaining screws and torque to 45 in-lb.



# 2.3.10. Sash Assembly

# 2.3.10.1.Sash Assembly Removal

- With the Sash Assembly in full closed position, lubricate exposed lower and upper run channel with soapy water.
- 2. Open Sash Assembly to full open position and pull lower run channel out from glass.
- 3. Lower glass in frame slot until it is free of upper frame channel.
- 4. Tilt upper part of glass out approximately 2 inches away from stationary glass and lift Sash Assembly out of lower run channel.

# 2.3.10.2. Sash Assembly Installation

- 1. With lower portion of run channel removed, lower glass in lower frame channel slot at a slight angle.
- Tilt glass inward until it aligns with upper run channel track. Glass will need to be positioned as closely to the full open position as possible.
- 3. Lubricate lower portion of run channel.
- 4. While holding the glass up to its highest position, work the lower run channel back in the track underneath the Sash Assembly. Sash Assembly may need to be moved front to back to assist in threading the run channel back into the track.



# 2.4. Side Emergency Window

# 2.4.1. Description

The side emergency windows function as emergency exits and are equipped with an emergency release handle. The windows cannot be used for ventilating and should only be opened during an emergency. The window assemblies consist of a Main Frame, Subframe, Clamp Ring, and flushmounted glass sections. See "Fig. 14-9: Side Emergency Window Assembly" on page 15.




Fig. 14-9: Side Emergency Window Assembly



# 2.4.2. Emergency Exit Window Operation

- 1. Pull the red emergency handle down and hold it in this position. See "Fig. 14-10: Emergency Window Operation" on page 16.
- 2. Push out on the bottom of the window frame. The window will open and rotate outwards on hinges at the top of the frame.
- 3. To close the window, release the emergency handle and allow the window to slam shut.
- 4. Ensure all latches are properly engaged.




Fig. 14-10: Emergency Window Operation



# 2.4.3. Main Frame Assembly

#### 2.4.3.1. Subframe Removal

If only replacing the Main Frame assembly, the Subframe will need to be retained and installed into the Main Frame assembly. The Subframe assembly is removed as follows:

- Remove the hinge retainers located at the top on each side. Each hinge retainer is held in place by (1) #8 screw. Remove each screw along with the hinge retainer and store for reassembly.
- 2. Pull the red release handle located in the interior of the vehicle. Once the tie bar assembly is disengaged the window should swing freely.



DO NOT damage the Subframe assembly since it will be needed to reassemble the window. Store in a safe location until reassembly.

 At an approximate 45° angle, slide the egress assembly either to the right or left of the assembly until the top hinge rails release the Subframe assembly.

#### 2.4.3.2. Main Frame Assembly Removal

The Main Frame assembly is held in place by the Clamp Ring assembly. To remove the Main Frame assembly:

 Remove the screws that follow the Clamp Ring perimeter from the inside of the vehicle.

# ™NOTE:

This will require two people since these screws are the primary connection to the vehicle frame. One person will need to secure the window from the outside, while the other removes the screws from the interior.

Once the screws are removed, the window should be free from the vehicle frame. Retain the Clamp Ring screws as these will be required to reassemble the window.

#### 2.4.3.3. Main Frame Assembly Installation

- 1. Clean the window opening.
- Apply a small bead of Butyl sealant to all exterior joints of the window opening.
- Use two shim spacers consisting of 1" x 3" x 1/8" thick polyethylene under the two contact surfaces of the window.
- Install the window into the vehicle and secure it temporally. There should a vertical gap of 0.25" ± 0.06" between adjacent windows.
- Take the existing Clamp Ring assembly, and align it with the Main Frame assembly. Ensure that the Main Frame assembly is aligned with equal gaps around the vehicle opening.
- 6. Using the Clamp Ring assembly screws reassemble the Clamp Ring assembly.
- 7. Place the first two screws at either side of the splice line but do not tighten.

# ™NOTE:

Make sure the Clamp Ring assembly is aligned side to side.

- 8. Place the next screw in a screw opening 2/3 of the way up the window on the right side. Start the screw but do not tighten.
- Follow the same procedure on the left side.
- 10.Once these are in place, start a screw on each side of the bottom of the Clamp Ring assembly.
- 11. Following the original sequence, torque the screws to 45 in-lb. Starting in a clockwise pattern replace the remaining screws and torque to 45 in-lb.



#### 2.4.3.4. Subframe Installation

- 1. Using two people, tilt the window to an approximate 45° angle.
- 2. With the Subframe assembly to one side, align the upper hinge (on the Main Frame assembly) with the lower hinge (on the Subframe assembly).
- Slide the Subframe assembly into the Main Frame assembly until there is equal spacing on each side.

# RNOTE:

The Subframe assembly should nest within the Main Frame assembly.

- Using pressure from the outside, force the tie bar assembly over the ramps until the window is closed.
- 5. Reinstall the hinge retainers at the top on each side.

6. Check the function of the egress window to ensure proper installation.

#### 2.4.4. Subframe Spacer

#### 2.4.4.1. Subframe Spacer Removal

If the frame spacer is damaged or broken, remove any broken or damaged sections by drilling the rivet out of the frame.

# 2.4.4.2. Subframe Spacer Installation

- 1. Align the new frame spacer with opening in the Main Frame assembly.
- 2. Using a pop rivet tool, install the provided pop rivet until flush.
- Ensure that the rivet is aligned in the proper location on the Main Frame assembly. See "Fig. 14-11: Rivet Location" on page 18.




Fig. 14-11: Rivet Location

# **Side Emergency Window**

# 2.4.5. Subframe Assembly

# 2.4.5.1. Subframe Removal

- Remove the hinge retainers located at the top on each side. Each hinge retainer is held in place by (1) #8 screw. Remove each screw along with the hinge retainer and store for reassembly.
- 2. Pull the red release handle located in the interior of the vehicle. Once the tie bar assembly is disengaged the window should swing freely.



DO NOT damage the Subframe assembly since it will be needed to reassemble the window. Store in a safe location until reassembly.

3. At an approximate 45° angle, slide the egress assembly either to the right or left of the assembly until the top hinge rails release the Subframe assembly.

# 2.4.5.2. Subframe Installation

- 1. Using two people, tilt the window to an approximate 45° angle.
- With the Subframe assembly to one side, align the upper hinge (on the Main Frame assembly) with the lower hinge (on the Subframe assembly).
- Slide the Subframe assembly into the Main Frame assembly until there is equal spacing on each side.

# ™NOTE:

The Subframe assembly should nest within the Main Frame assembly.

- Using pressure from the outside, force the tie bar assembly over the ramps until the window is closed.
- 5. Reinstall the hinge retainers at the top on each side.
- 6. Check the function of the egress window to assure proper installation.

#### 2.4.6. Release Handle

# 2.4.6.1. Subframe Assembly Securement

- 1. Open the Subframe assembly such that the tie bar assembly is visible.
- 2. Support the Subframe assembly open in a secure manner with ample room to work.
- Clamp the tie bar assembly forward (toward the release handle) to reduce the spring pressure. This can be done with C-clamps or vise grips.

#### 2.4.6.2. Release Handle Installation

- 1. Remove the release cable from the release handle assembly.
- 2. Remove the two screws and nuts that hold the release handle assembly in place.
- Align the new release handle assembly with the slot and two holes and insert until flush.
- Reinstall the screws and nuts. See "Fig. 14-12: Release Handle Replacement" on page 20.
- 5. Reinstall the release cable and remove the clamp from the tie bar assembly.
- Cycle the release handle assembly several times to ensure the unit is functioning properly.






Fig. 14-12: Release Handle Replacement

# 2.4.7. Tie Bar Assembly

# 2.4.7.1. Egress Assembly Securement

- 1. Open the Subframe assembly such that the tie bar assembly is visible.
- 2. Support the Subframe assembly open in a secure manner with ample room to work.
- Clamp the tie bar assembly forward (toward the release handle) to reduce the spring pressure. This can be done with C-clamps or vise grips.

#### 2.4.7.2. Tie Bar Assembly Removal

- 1. Remove the release cable from the release handle assembly.
- 2. From the inside of the vehicle remove the filler strip seal.

- 3. Remove the six retaining E-clips and truss head pins with groove.
- 4. Unhook the S-hook from the spring.
- 5. From the outside of the vehicle, remove the clamp. The tie bar should fall free.

#### 2.4.7.3. Tie Bar Assembly Installation

- Align the new tie bar assembly with the channel in the Subframe.
- 2. Attach the S-hook to the spring.
- 3. Hook the cable into the release handle.
- 4. Reinstall the truss head pin with groove through the holes in the frame, and the slot in the retaining bolts.
- 5. Once installed, snap the E-clips onto the truss head pin with groove to secure.
- Cycle the egress handle to ensure proper function.



#### 2.4.8. Release Bolt

#### 2.4.8.1. Tie Bar Removal

- 1. Remove the release cable from the release handle assembly.
- 2. From the inside of the vehicle remove the filler strip seal.
- 3. Remove the six retaining E-clips and truss head pins with groove.
- 4. Unhook the S-hook from the spring.
- 5. From the outside of the vehicle, remove the clamp. The tie bar should fall free.

# 2.4.8.2. Damaged Release Bolt Installation

- Remove the roll pins from each end of the damaged release bolt.
- Replace the damaged release bolt with the new release bolt aligning the slots section into the tie bar. Make sure to note the direction of the release bolt.
- Each release bolt should be facing the same direction, with the slanted ramp section facing inward.
- 4. Replace the pins into the new release bolt.
- 5. Reinstall the tie bar assembly. Refer to 2.4.7.3. "Tie Bar Assembly Installation" on page 20 in this section for procedure.

#### 2.4.9. Clamp Ring Assembly

# 2.4.9.1. Clamp Ring Removal

 Remove the screws that follow the Clamp Ring perimeter from the inside of the vehicle.

# ™NOTE:

This will require two people since these screws are the primary connection to the vehicle frame. One person will need to secure the window from the outside, while the other removes the screws from the interior.

2. Once the screws are removed the window should be free from the vehicle frame.

# 2.4.9.2. Clamp Ring Installation

- Align new Clamp Ring assembly with the Main Frame assembly.
- 2. Ensure that the Clamp Ring assembly is aligned with equal gaps around the Main Frame assembly.
- 3. Using the Clamp Ring assembly screws reassemble the Clamp Ring assembly.
- 4. Place the first two screws at either side of the splice line but do not tighten.

### ™NOTE:

Make sure the Clamp Ring assembly is aligned side to side.

- 5. Place the next screw in a screw opening 2/3 of the way up the window on the right side. Start the screw but do not tighten.
- 6. Follow the same procedure on the left side.
- Once these are in place, start a screw on each side of the bottom of the Clamp Ring assembly.
- 8. Following the original sequence torque the screws to 45 in-lb. Starting in a clockwise pattern replace the remaining screws and torque to 45 in-lb.



# 2.5. Side Non-Emergency Window

# 2.5.1. Description

The side non-emergency windows are fixed and cannot be opened. The window

assemblies consist of a Main Frame, Clamp Ring, and flush-mounted glass sections. See "Fig. 14-13: Side Non-Emergency Window Assembly" on page 22.




Fig. 14-13: Side Non-Emergency Window Assembly

# **Side Non-Emergency Window**

# 2.5.2. Main Frame Assembly

# 2.5.2.1. Main Frame Assembly Removal

The Main Frame assembly is held in place by the Clamp Ring assembly. To remove the Main Frame assembly:

- Remove the false hinge rail. The false hinge rail is held in place by two screw. Remove the screws and the false hinge rail will fall free. Retain in a secure location to be used for the installation.
- Remove the Clamp Ring assembly by removing the screws that follow the Clamp Ring perimeter from the inside of the vehicle.

#### ™NOTE:

This will require two people since these screws are the primary connection to the vehicle frame. One person will need to secure the window from the outside, while the other removes the screws from the interior.

 Once the screws are removed, the window should be free from the vehicle frame. Retain the Clamp Ring screws as these will be required to reassemble the window.

# 2.5.2.2. Main Frame Assembly Installation

- 1. Clean the window opening.
- Apply a small bead of Butyl sealant to all exterior joints of the window opening.

- 3. Use two shim spacers consisting of 1" x 3" x 1/8" thick polyethylene under the two contact surfaces of the window.
- Install the window into the vehicle and secure it temporally. There should a vertical gap of 0.25" ± 0.06" between adjacent windows.
- Take the existing Clamp Ring assembly, and align it with the Main Frame assembly. Ensure that the Main Frame assembly is aligned with equal gaps around the vehicle opening.
- 6. Using the Clamp Ring assembly screws reassemble the Clamp Ring assembly.
- 7. Place the first two screws at either side of the splice line but do not tighten.

#### ™NOTE:

Make sure the Clamp Ring assembly is aligned side to side.

- 8. Place the next screw in a screw opening 2/3 of the way up the window on the right side. Start the screw but do not tighten.
- 9. Follow the same procedure on the left side.
- 10.Once these are in place, start a screw on each side of the bottom of the Clamp Ring assembly.
- 11. Following the original sequence, torque the screws to 45 in-lb. Starting in a clockwise pattern replace the remaining screws and torque to 45 in-lb.
- 12. Re-install the false hinge.



# 2.5.3. Clamp Ring Assembly

# 2.5.3.1. Clamp Ring Removal

 Remove the screws that follow the Clamp Ring perimeter from the inside of the vehicle.

# ™NOTE:

This will require two people since these screws are the primary connection to the vehicle frame. One person will need to secure the window from the outside, while the other removes the screws from the interior.

2. Once the screws are removed the window should be free from the vehicle frame.

# 2.5.3.2. Clamp Ring Installation

 Align new Clamp Ring assembly with the Main Frame assembly.

- Ensure that the Clamp Ring assembly is aligned with equal gaps around the Main Frame assembly.
- 3. Using the Clamp Ring assembly screws reassemble the Clamp Ring assembly.
- 4. Place the first two screws at either side of the splice line but do not tighten.

# ™NOTE:

Make sure the Clamp Ring assembly is aligned side to side.

- 5. Place the next screw in a screw opening 2/3 of the way up the window on the right side. Start the screw but do not tighten.
- 6. Follow the same procedure on the left side.
- Once these are in place, start a screw on each side of the bottom of the Clamp Ring assembly.
- 8. Following the original sequence torque the screws to 45 in-lb. Starting in a clockwise pattern replace the remaining screws and torque to 45 in-lb.



# 2.6. Side Destination Sign Window

# 2.6.1. Description

The side destination sign window displays the vehicle's destination to the exterior. The window is located on the curbside aft the entrance door. The windows cannot be opened for ventilating. The window assem-

blies consist of a Main Frame, Clamp Ring, and flush mounted glass sections. See "Fig. 14-14: Destination Sign Window Assembly"" on page 25.

# ™NOTE:

Servicing the Side destination sign window is the same as the Side Non-emergency Window.




Fig. 14-14: Destination Sign Window Assembly"





# **Access Doors & Panels**

1.	SAFETY	15-1
	1.1. Safety Procedures	
	1.2. Gas Spring Disposal	
2.	INTERIOR ACCESS DOORS	15-2
	2.1. Maintenance	15-2
	2.2. Front Destination Sign Access	
	2.3. Entrance Mechanism Access	15-2
	2.4. Engine & Transmission Access	15-4
	2.5. Driveshaft Access	15-6
	2.6. Return Air Grille & HVAC Access	15-7
	2.7. HVAC Center Cover Access	15-8
	2.8. Stop Request Sign Access	15-8
	2.9. RH Lower Dash Panel Access	15-8
	2.10. Rear Electronic Equipment Compartment Access	15-8
	2.11. Driver's Locker Access	15-8
	2.12. Rear Panel Access (Streetside & Curbside)	15-9
3.	EXTERIOR ACCESS DOORS	15-10
	3.1. Maintenance	
	3.2. Defroster Access	
	3.3. Side Console Access	
	3.4. Steering Gearbox Access	
	3.5. Battery Access	
	3.6. Radiator Access	
	3.7. Surge Tank Access	
	3.8. Engine Access	
	3.9. Fuel Filler Access	
	3.10. Fuse Box Access	
	3.11. Battery Disconnect Switch Access	
	3.12. Diesel Exhaust Fluid Fill Access	
	3.13. Selective Catalytic Reduction (SCR) Access	
	3.14. Upper Corner Pillar Access	
	3.15. Rear Exterior Access	

# Table of Contents



4. ROOF VENT/HATCHES	15-13	
4.1. Description	15-13	
4.2. Operation		
4.2.1. Ventilation	15-13	
4.2.2. Emergency Exit	15-13	
4.3. Maintenance	15-13	
4.4. Removal	15-13	
4.5. Installation	15-14	



# 1. SAFETY

# 1.1. Safety Procedures

This section of the service manual contains procedures which require the mechanics to strictly observe safety procedures in order to ensure personal and equipment safety.

Always ensure that the vehicle is appropriately hoisted and blocked for procedures which require elevating the vehicle. Be aware of the limitations of the blocking equipment, and always ensure that the jarring and shaking created by component removal and installation procedures does not overload the blocks, or cause the vehicle to become unstable.

Certain procedures may require the vehicle be operated in an elevated position in order to accurately troubleshoot and diagnose a problem. If the vehicle must be running while elevated, become familiar with the repair area prior to starting the engine. Take special care in noting areas which will become hot, electrically energized, and areas where moving and rotating components are located. Limit the work in these areas as personal and equipment safety is at risk.

For procedures which involve air lines, ensure the line is safely depressurized prior to disconnecting. Disconnecting pressurized lines will cause solid particles deposited in the line to be uncontrollably propelled, and will also cause the hose end to whip randomly as the air escapes.

During electrical diagnosis procedures an understanding of the vehicle's electric circuits is important to anticipate the results of connecting test equipment. During component removal or installation, ensure the Battery Disconnect switch is in the OFF position.

Failure to follow this procedure may result in personal injury or component failure.

Observe the following procedures involving hydraulic line removal.

- Hydraulic fluid is corrosive and should not be exposed to skin for extensive periods of time.
- Wear eye protection at all times.
- Pressurized lines should not be disconnected until the pressure is safely and controllably released.

# 1.2. Gas Spring Disposal

Gas springs must be depressurized and drained of any oil before disposal. For safety and environmental reasons, use the following procedure:



Wear a face shield or safety glasses and place a rag over saw blade while cutting.

- 1. Clamp the rod end of the cylinder in a vise.
- 2. Mark the cylinder 30 to 35mm from the base end of the cylinder.
- Cut a crosswise slit in the cylinder in the marked area.
- Stop sawing as soon as a hissing sound is heard. Allow the unit to depressurize completely.

### ™NOTE:

Nitrogen is an inert gas. Consequently, gas release is totally safe.

- 5. Place the cylinder in a drain pan ensuring the cut is facing down. Allow oil to drain completely. Dispose of oil in accordance with environmental regulations.
- 6. Recycle gas spring as a steel component.



# 2. INTERIOR ACCESS DOORS

# 2.1. Maintenance

Refer to the Preventive Maintenance Section of this manual for scheduled maintenance requirements on the interior access doors.

# 2.2. Front Destination Sign Access

The front destination sign access door is located at the front of the vehicle above the windshields. This door allows access to

the destination sign. It is held open by a gas strut and held closed by two wing quad latches. See "Fig. 15-1: Access Door Locations" on page 3.

# 2.3. Entrance Mechanism Access

The entrance mechanism access door is located directly above the entrance door. It allows access to the door mechanism for servicing and maintenance. This door is held open by a gas strut and held closed by two quarter-turn wing latches.






Fig. 15-1: Access Door Locations



# 2.4. Engine & Transmission Access

The engine and transmission access door is located underneath the three rear center seats. To open the door proceed as follows:

- Push the seat lock handles and lift the front of the seat. The assembly will pivot on the piano hinge attached to the upper part of the backrest.
- 2. Continue pivoting the assembly upwards until the gas struts are fully extended.
- Locate the locking gas strut and engage the lock. See "Fig. 15-2: Engine & Transmission Access Doors" on page 5.
- Allow the seat to pivot down slightly until the seats are supported by the locked gas strut.



Ensure the seat assembly is properly secured. Improper securing of the seat assembly could allow it to fall accidentally while accessing the engine or transmission and can cause serious personal injury.

5. Insert a T-handle into the square key latchholes securing the door and turn each of the latches 1/4 turn to release the door.

- Carefully lift the door assembly. It will pivot on the piano hinge attached to the upper part of the access opening.
- Continue pivoting the assembly upwards until the access door back is parallel to the floor.
- 8. Locate the support tube.
- Lift the free end of the tube up and index it with the peg on the bottom of the access door assembly.
- 10. Allow the access door to pivot down slightly so the peg engages into the open end of the support tube.
- 11.Install the safety pin through the crossdrilled hole in the tube and peg to safely secure the access door assembly in the raised position.



Ensure the access door assembly is properly secured with the support tube and safety pin is installed to prevent the access door assembly from being lifted further from the raised position. Improper securing of the access door assembly could allow it to fall accidentally while accessing the engine or transmission and can cause serious personal injury.






Fig. 15-2: Engine & Transmission Access Doors



# 2.5. Driveshaft Access

A driveshaft access door and access plate are located in the floor at the rear of the vehicle. See "Fig. 15-3: Driveshaft Access" on page 6.

To access the driveshaft from inside the vehicle:

- 1. Use a square key to turn the 1/4 turn latches on the interior access door.
- 2. Remove the 4 bolts from the driveshaft shield beneath the access door and carefully remove it.

# ™NOTE:

The four 1/2" bolts retaining the driveshaft shield are fastened into nuts that have been welded in place. The plate and mounting hardware can be removed and installed from inside the vehicle.

To install the driveshaft shield:

- Install the driveshaft shield onto the subfloor angle supports using the four 1/2" bolts.
- Insert the driveshaft access door into the floor opening and use a square key to turn the 1/4 turn latches to secure the door in place.




Fig. 15-3: Driveshaft Access



# 2.6. Return Air Grille & HVAC Access

The interior A/C access door is located in the ceiling of the vehicle. It is secured with square-key quarter-turn latches on the streetside and a concealed hinge on the curbside. See "Fig. 15-4: HVAC Interior Access" on page 7.

The door swings downward to access the HVAC unit return air filter. A detachable lanyard prevents the access door from falling open uncontrollably.




Fig. 15-4: HVAC Interior Access



# 2.7. HVAC Center Cover Access

The interior A/C center cover access door is located in the ceiling of the vehicle, forward of the return air grille. It is secured with square-key quarter-turn latches on the rearward edge of the access door and a hinge on the forward edge. The door opens downward and provides access to the HVAC refrigerant lines and coolant lines. A detachable lanyard prevents the access door from falling open uncontrollably.

# 2.8. Stop Request Sign Access

The Stop Request Sign access door is located between the Return Air Grille and the HVAC center cover access doors. It is secured with square-key quarter-turn latches on the rearward edge and a hinge on the forward edge. The door swings downward and provides access to the stop request sign.

# 2.9. RH Lower Dash Panel Access

The RH lower dash panel access door is located in the lower dash, near the entrance door. It is secured with square key latches and hinges outward to allow access to the curbside headlight assembly.

# 2.10. Rear Electronic Equipment Compartment Access

The rear electronic equipment access door is located directly above the rear bench. It allows access to the electrical components for servicing and maintenance. This door is secured by two square-key quarter-turn latches and pivots open rearward on a hinge.

# 2.11. Driver's Locker Access

The driver's locker access door is located directly above the driver's side window. This door is held open by a gas strut and held closed by a guarter-turn wing latch.



# 2.12. Rear Panel Access (Streetside & Curbside)

The rear panel access doors are part of the rear panel located behind the rear bench seat. The curbside door allows access to the voltage equalizer and the streetside door allows access to various electrical harnesses. The doors are held in place with two square-key latches. See "Fig. 15-5: Rear Panel Access" on page 9.




Fig. 15-5: Rear Panel Access



# 3. EXTERIOR ACCESS DOORS

#### 3.1. Maintenance

Refer to the Preventive Maintenance Section of this manual for scheduled maintenance requirements on the exterior access doors.

#### 3.2. Defroster Access

The defroster access cover allows exterior access to the defroster. It is fitted with two hinges on its upper edge and is closed using two quarter-turn latches.

# 3.3. Side Console Access

The side console access door is located under the driver's window. This door allows access to the front electrical panel, circuit breakers and fuses that protect operator controlled circuits of vehicle electrical systems. It is held open by two gas struts and closed by two square-key quarter-turn latches.

# 3.4. Steering Gearbox Access

Two exterior access doors are located beneath the vehicle and provide access to the steering gearbox and miter box. The access doors are retained with square-key latches and are hinged to open downward. A closeout panel, located near the access doors, can be removed if additional access is required in this area. Remove the three bolts that attach the panel to vehicle structure.

# 3.5. Battery Access

The battery access door is located behind the rear wheel on the curbside and allows access to the batteries, primary fuel filter. It is secured with two square-key quarterturn latches and held open by one gas strut.

# 3.6. Radiator Access

The radiator access door is located on the streetside, at the rear of the vehicle. It enables access to the radiator, charge air cooler and hydraulic oil cooler for cleaning and servicing. This grilled door is held open by two gas struts and secured closed with two square-key quarter-turn latches.

# 3.7. Surge Tank Access

The surge tank access door is located above the radiator access door. This door allows for easy filling and checking of the engine cooling system. It is spring loaded to remain either open or closed.

# 3.8. Engine Access

The engine access door is located at the back of vehicle. It serves to provide access to the hydraulic reservoir, alternator, engine assembly and engine switch panel. This door is equipped with a fixed handle to raise, and two gas struts to support the door. The door is held closed by two square-key quarter-turn latches.

#### 3.9. Fuel Filler Access

The fuel filler access door is located on the curbside near the center of the vehicle. This door allows access to the fuel tank for filling and maintenance inspection. The door is spring-loaded to remain either open or closed.

#### 3.10. Fuse Box Access

The fuse box access door is located on the curbside, at the rear of the vehicle. It enables access to the battery disconnect switch, jumpstart assembly and fuses for servicing. This door is held open by two gas struts and secured closed with two square-key quarter-turn latches.



# 3.11. Battery Disconnect Switch Access

The battery disconnect switch access door is a small hinged door mounted in the front of the fuse box access door. This door allows access to the battery disconnect switch, compartment light switch, and jumpstart connection without opening the fuse box access door. It is held open and closed by a gas strut.

#### 3.12. Diesel Exhaust Fluid Fill Access

Two diesel exhaust fluid fill doors are located on the curbside rear of the vehicle. The pressure fill access door is a small hinged door mounted in the rear of the fuse box access door. The manual fill access door is mounted in the center of the curbside upper corner pillar access door. They are both held open and closed by a gas strut.

# 3.13. Selective Catalytic Reduction (SCR) Access

The SCR access is a roof mounted perforated panel at the rear of the vehicle. Removing this panel allows access to the exhaust system components and plumbing. It is held in place with bolts at the rearward edge and nuts at the forward edge. Remove the screws and bolts, retaining all fasteners for reassembly, and lift the access panel to clear the threaded studs on the vehicle structure at the forward edge.

# ™NOTE:

The SCR access incorporates a directional contoured "Air Scoop" to provide air flow to the SCR components.

# 3.14. Upper Corner Pillar Access

The upper corner pillar access doors are located on the streetside and curbside at the rear of the vehicle. See "Fig. 15-6: Streetside Corner Pillar" on page 11. See "Fig. 15-7: Curbside Corner Pillar" on page 11. These access doors are secured with square-key quarter-turn latches at the rear of the vehicle. They are hinged and pivot 90° outward to allow access to the exhaust system and air intake components.




Fig. 15-6: Streetside Corner Pillar




Fig. 15-7: Curbside Corner Pillar



# 3.15. Rear Exterior Access

The rear exterior access door is located at the rear of the vehicle above the engine compartment. It is equipped with two gas cylinders and a handle for opening. The access door is held closed with two square key latches. This door provides access to the rear shelf area.



# 4. ROOF VENT/HATCHES

# 4.1. Description

Two multi-position glass hatches are located on the roof. These hatches can be opened to allow fresh air into the vehicle and in an emergency the vents can be used as escape exits.

# 4.2. Operation

#### 4.2.1. Ventilation

Without touching the emergency handle, grasp the handholds and push up to obtain any of the three venting positions:

- Open front end for air intake.
- Open rear end for air exhaust.
- ☐ Full open venting position.

To close, grasp the handles and pull the hatch downward into the closed position. Do not touch the emergency handle.

#### 4.2.2. Emergency Exit

The roof hatch functions as an emergency exit and is identified by decals on the hatch panel. Proceed as follows to operate the emergency exit:

 Pull the red handle at the rear of the hatch to release the locking mechanism. The handle is attached to a cable which will release the retaining pins from the rear hinge. See "Fig. 15-8: Roof Vent/Hatches" on page 14. Push upward on the rear section of the hatch, allowing it to swing fully open on the front hinges.

#### ™NOTE:

If the emergency handle was activated, reinstall the retaining pins into the release hinges.

#### 4.3. Maintenance

Refer to the Preventive Maintenance Section of this manual for scheduled maintenance requirements.

# 4.4. Removal



DO NOT perform any maintenance on roof-mounted components unless equipment is in place to prevent fall hazards. Ensure maintenance personnel use approved lift platforms or scaffolding and wear approved safety harness when working on the roof of the vehicle.

- Remove the interior trim ring by pulling one side in and down. Remove the screws and washers retaining the emergency release handle to its mounting bracket.
- Use a utility knife to carefully cut through the adhesive around the perimeter of the hatch. Ensure the knife blade is parallel to the roof and extends under the mounting flange to completely break the seal.
- Carefully pry the hatch up from the opening and remove.






Fig. 15-8: Roof Vent/Hatches

# 4.5. Installation



DO NOT perform any maintenance on roof-mounted components unless equipment is in place to prevent fall hazards. Ensure maintenance personnel use approved lift platforms or scaffolding and wear approved safety harness when working on the roof of the vehicle.

- 1. Clean the rooftop opening. Remove any excess sealant or other contaminants.
- 2. Apply Sika 221 Adhesive to the perimeter of the hatch mounting flange and press the hatch into the opening.

- Mount the release handle to the mounting bracket.
- 4. Install the interior trim by clipping one side in and pushing the opposite side until it also clips into place.

# **™**NOTE

This installation requires an assistant, if sealant has not been allowed to cure. Press the hatch down from the roof side while the interior trim is being installed.

5. Allow the Sika adhesive to cure for 12 hours before placing the vehicle into service or exposing it to the elements.



# **Entrance & Exit Doors**

2.1. Description       16-3         2.2. Door Safety Features       16-5         2.2.1. Service Brake Interlock       16-5         2.2.2. Throttle Interlock       16-5         2.3. Operation       16-6         2.3.1. Door Power Up Operation       16-6         2.3.2. Door Closed       16-6         2.3.3. Door Not Closed       16-6         2.3.4. Front Door Close Obstruction       16-6         2.3.5. Front Door Open Obstruction       16-6         2.5. Door Controller       16-6         2.5. Door Controller       16-7         2.5.1. Description       16-7         2.5.2. Door Controller Specifications       16-7         2.5.3. Operation       16-8         2.5.4. Controller Inputs       16-8         2.5.4. Speed Interlock Input       16-8         2.5.4. Poor Command Input       16-8         2.5.4. Door Construction Input       16-8         2.5.4. Seed Interlock Input       16-8         2.5.4. Seed Input       16-8         2.5.4. Seed Input       16-8         2.5.4. Seed Input       16-8         2.5. Soor Fully Open Output       16-8         2.5. Soor Fully Open Output       16-10         2.5. Soor Fully Closed Output	1.	SAFET	Ύ	16-1
2.1. Description       16-3         2.2. Door Safety Features       16-5         2.2.1. Service Brake Interlock       16-5         2.2.2. Throttle Interlock       16-5         2.3. Operation       16-6         2.3.1. Door Power Up Operation       16-6         2.3.2. Door Closed       16-6         2.3.3. Door Not Closed       16-6         2.3.4. Front Door Close Obstruction       16-6         2.3.5. Front Door Open Obstruction       16-6         2.4. Maintenance       16-6         2.5. Door Controller       16-7         2.5.1. Description       16-7         2.5.2. Door Controller Specifications       16-7         2.5.3. Operation       16-8         2.5.4. Controller Inputs       16-8         2.5.4. Speed Interlock Input       16-8         2.5.4. Speed Interlock Input       16-8         2.5.4. Speed Interlock Input       16-8         2.5.4. Door Construction Input       16-8         2.5.4. Speed Interlock Input       16-8         2.5.4. Speed Interlock Input       16-8         2.5.4. Door Construction Input       16-8         2.5.4. Speed Interlock Input       16-8         2.5.4. Speed Interlock Input       16-8         2.5.		1.1. Saf	ety Procedures	16-1
2.1. Description       16-3         2.2. Door Safety Features       16-5         2.2.1. Service Brake Interlock       16-5         2.2.2. Throttle Interlock       16-5         2.3. Operation       16-6         2.3.1. Door Power Up Operation       16-6         2.3.2. Door Closed       16-6         2.3.3. Door Not Closed       16-6         2.3.4. Front Door Close Obstruction       16-6         2.3.5. Front Door Open Obstruction       16-6         2.4. Maintenance       16-6         2.5. Door Controller       16-7         2.5.1. Description       16-7         2.5.2. Door Controller Specifications       16-7         2.5.3. Operation       16-8         2.5.4. Controller Inputs       16-8         2.5.4. Speed Interlock Input       16-8         2.5.4. Speed Interlock Input       16-8         2.5.4. Speed Interlock Input       16-8         2.5.4. Door Construction Input       16-8         2.5.4. Speed Interlock Input       16-8         2.5.4. Speed Interlock Input       16-8         2.5.4. Door Construction Input       16-8         2.5.4. Speed Interlock Input       16-8         2.5.4. Speed Interlock Input       16-8         2.5.	2.	VAPOF	R/NFI SLIDE GLIDE ENTRANCE DOOR	16-3
2.2. Door Safety Features       16-5         2.2.1. Service Brake Interlock       16-5         2.2.2. Throttle Interlock       16-5         2.3. Operation       16-6         2.3.1. Door Power Up Operation       16-6         2.3.2. Door Closed       16-6         2.3.3. Door Not Closed       16-6         2.3.4. Front Door Close Obstruction       16-6         2.3.5. Front Door Open Obstruction       16-6         2.4. Maintenance       16-6         2.5. Door Controller       16-7         2.5.1. Description       16-7         2.5.2. Door Controller Specifications       16-7         2.5.3. Operation       16-8         2.5.4. Controller Inputs       16-8         2.5.4. Speed Interlock Input       16-8         2.5.4. Speed Interlock Input       16-8         2.5.4. Speed Interlock Input       16-8         2.5.4. Door Consend Input       16-8         2.5.4. Speed Interlock Input       16-8         2.5.4. Door Consend Input       16-8         2.5.4. Speed Interlock Input       16-8         2.5.4. Door Consend Input       16-8         2.5.4. Speed Interlock Input       16-8         2.5.4. Door Consend Input       16-8         2.5.5. C				
2.2.1. Service Brake Interlock       16-5         2.2.2. Throttle Interlock       16-5         2.3. Operation       16-6         2.3.1. Door Power Up Operation       16-6         2.3.2. Door Closed       16-6         2.3.3. Door Not Closed       16-6         2.3.4. Front Door Close Obstruction       16-6         2.3.5. Front Door Open Obstruction       16-6         2.4. Maintenance       16-6         2.5. Door Controller       16-7         2.5.1. Description       16-7         2.5.2. Door Controller Specifications       16-7         2.5.3. Operation       16-8         2.5.4. Controller Inputs       16-8         2.5.4. Controller Inputs       16-8         2.5.4.1. Speed Interlock Input       16-8         2.5.4.2. Air Dump Pressure Switch Input       16-8         2.5.4.3. Door Closed Input       16-8         2.5.4.4. Door Command Input       16-8         2.5.4.5. Emergency Release Input       16-8         2.5.4.5. Emergency Release Output       16-8         2.5.5. Controller Outputs       16-10         2.5.5.2. Door Fully Closed Output       16-10         2.5.5.3. Door Fully Closed Output       16-10         2.5.5.4. Door Obstruction Signal Output				
2.2.2. Throttle Interlock       16-5         2.3. Operation       16-6         2.3.1. Door Power Up Operation       16-6         2.3.2. Door Closed       16-6         2.3.3. Door Not Closed       16-6         2.3.4. Front Door Close Obstruction       16-6         2.3.5. Front Door Open Obstruction       16-6         2.4. Maintenance       16-6         2.5. Door Controller       16-7         2.5.1. Description       16-7         2.5.2. Door Controller Specifications       16-7         2.5.3. Operation       16-8         2.5.4. Controller Inputs       16-8         2.5.4. Speed Interlock Input       16-8         2.5.4.1. Speed Input Inputs       16-8         2.5.4.2. Door Closed Input       16-8         2.5.4.3. Door Closed Input       16-8         2.5.4.4. Door Command Input       16-8         2.5.4.5. Emergency Release Input       16-8         2.5.4.6. Sensitive Edge Input       16-8         2.5.5. Controller Outputs       16-10         2.5.5.1. Emergency Release Output       16-10         2.5.5.2. Door Fully Closed Output       16-10         2.5.5.5. Emergency Release Solenoid Output       16-10         2.5.5.5. Motor Brake Output       16-10				
2.3.1. Door Power Up Operation       16-6         2.3.2. Door Closed       16-6         2.3.3. Door Not Closed       16-6         2.3.4. Front Door Close Obstruction       16-6         2.3.5. Front Door Open Obstruction       16-6         2.4. Maintenance       16-6         2.5. Door Controller       16-7         2.5.1. Description       16-7         2.5.2. Door Controller Specifications       16-7         2.5.3. Operation       16-8         2.5.4. Controller Inputs       16-8         2.5.4.1. Speed Interlock Input       16-8         2.5.4.2 Air Dump Pressure Switch Input       16-8         2.5.4.3. Door Closed Input       16-8         2.5.4.4. Door Command Input       16-8         2.5.4.5. Emergency Release Input       16-8         2.5.4.6. Sensitive Edge Input       16-8         2.5.5. Controller Outputs       16-10         2.5.5.1. Emergency Release Output       16-10         2.5.5.2. Door Fully Open Output       16-10         2.5.5.5. Emergency Release Solenoid Output       16-10         2.5.5.6. Motor Brake Output       16-10         2.5.5.8. Motor Brake Output       16-10         2.5.5.8. Control Connectors       16-10         2.5.8. J. J. Voice Annun				
2.3.1.       Door Power Up Operation       16-6         2.3.2.       Door Closed       16-6         2.3.3.       Door Not Closed       16-6         2.3.4.       Front Door Close Obstruction       16-6         2.3.5.       Front Door Open Obstruction       16-6         2.4.       Maintenance       16-6         2.5.       Door Controller       16-7         2.5.1.       Description       16-7         2.5.2.       Door Controller Specifications       16-7         2.5.3.       Operation       16-8         2.5.4.       Controller Inputs       16-8         2.5.4.       Controller Inputs       16-8         2.5.4.       Air Dump Pressure Switch Input       16-8         2.5.4.2.       Air Dump Pressure Switch Input       16-8         2.5.4.3.       Door Closed Input       16-8         2.5.4.4.       Door Command Input       16-8         2.5.4.5.       Emergency Release Input       16-8         2.5.4.6.       Sensitive Edge Input       16-8         2.5.4.7.       Logic Power Input       16-8         2.5.5.1.       Emergency Release Output       16-10         2.5.5.2.       Door Fully Open Output.       16-10 <td></td> <td></td> <td></td> <td></td>				
2.3.2. Door Closed       16-6         2.3.3. Front Door Close Obstruction       16-6         2.3.5. Front Door Open Obstruction       16-6         2.4. Maintenance       16-6         2.5. Door Controller       16-7         2.5.1. Description       16-7         2.5.2. Door Controller Specifications       16-7         2.5.3. Operation       16-8         2.5.4. Controller Inputs       16-8         2.5.4.1. Speed Interlock Input       16-8         2.5.4.2 Air Dump Pressure Switch Input       16-8         2.5.4.3. Door Closed Input       16-8         2.5.4.5. Emergency Release Input       16-8         2.5.4.5. Emergency Release Input       16-8         2.5.4.7. Logic Power Input       16-8         2.5.5. Controller Outputs       16-10         2.5.5.1. Emergency Release Output       16-10         2.5.5.2. Door Fully Open Output       16-10         2.5.5.3. Door Fully Open Output       16-10         2.5.5.5. Emergency Release Solenoid Output       16-10         2.5.5.6. LeD indicators       16-10         2.5.5.7. J1939 J7 Connector (door position)       16-10         2.5.8. Control Connectors       16-10         2.5.8.1. J1 Voice Annunciator (Vapor)       16-10		-		
2.3.3.       Door Not Closed       16-6         2.3.4.       Front Door Close Obstruction       16-6         2.3.5.       Front Door Open Obstruction       16-6         2.4.       Maintenance       16-6         2.5.       Door Controller       16-7         2.5.       Door Controller Specifications       16-7         2.5.       Door Controller Specifications       16-7         2.5.       Operation       16-8         2.5.       Controller Inputs       16-8         2.5.       4.0 Controller Inputs       16-8         2.5.       2.5.       1.0 Controller Input       16-8         2.5.       2.5.       2.5 Controller Outputs       16-10         2.5.       2.5.       2.5 Controller Outputs       16-10         2.5.				
2.3.4. Front Door Close Obstruction       16-6         2.3.5. Front Door Open Obstruction       16-6         2.4. Maintenance       16-6         2.5. Door Controller       16-7         2.5.1. Description       16-7         2.5.2. Door Controller Specifications       16-7         2.5.3. Operation       16-8         2.5.4. Controller Inputs       16-8         2.5.4.1 Speed Interlock Input       16-8         2.5.4.2 Air Dump Pressure Switch Input       16-8         2.5.4.3. Door Closed Input       16-8         2.5.4.5 Emergency Release Input       16-8         2.5.4.5 Emergency Release Input       16-8         2.5.4.7 Logic Power Input       16-8         2.5.5.1 Emergency Release Output       16-10         2.5.5.2 Door Fully Open Output       16-10         2.5.5.3. Door Fully Closed Output       16-10         2.5.5.5. Emergency Release Output       16-10         2.5.5.5. Emergency Release Solenoid Output       16-10         2.5.5.6. Motor Brake Ou				
2.3.5. Front Door Open Obstruction       16-6         2.4. Maintenance       16-6         2.5. Door Controller       16-7         2.5.1. Description       16-7         2.5.2. Door Controller Specifications       16-7         2.5.3. Operation       16-8         2.5.4. Controller Inputs       16-8         2.5.4.1. Speed Interlock Input       16-8         2.5.4.2. Air Dump Pressure Switch Input       16-8         2.5.4.3. Door Closed Input       16-8         2.5.4.5. Emergency Release Input       16-8         2.5.4.5. Emergency Release Input       16-8         2.5.4.7. Logic Power Input       16-8         2.5.5.7. Controller Outputs       16-10         2.5.5.1. Emergency Release Output       16-10         2.5.5.2. Door Fully Open Output       16-10         2.5.5.3. Door Fully Closed Output       16-10         2.5.5.5. Emergency Release Solenoid Output       16-10         2.5.5.6. Motor				
2.4. Maintenance       16-6         2.5. Door Controller       16-7         2.5.1. Description       16-7         2.5.2. Door Controller Specifications       16-7         2.5.3. Operation       16-8         2.5.4. Controller Inputs       16-8         2.5.4.1. Speed Interlock Input       16-8         2.5.4.2. Air Dump Pressure Switch Input       16-8         2.5.4.3. Door Closed Input       16-8         2.5.4.5. Emergency Release Input       16-8         2.5.4.5. Emergency Release Input       16-8         2.5.4.7. Logic Power Input       16-8         2.5.5. Controller Outputs       16-10         2.5.5.1. Emergency Release Output       16-10         2.5.5.2. Door Fully Open Output       16-10         2.5.5.5. Emergency Release Solenoid Output       16-10         2.5.5. LED indicators       16-10         2.5.8. Control Connector (door position)       16-10         2.5.8. J1 Voice Annun		_		
2.5. Door Controller       16-7         2.5.1. Description       16-7         2.5.2. Door Controller Specifications       16-7         2.5.3. Operation       16-8         2.5.4. Controller Inputs       16-8         2.5.4.1. Speed Interlock Input       16-8         2.5.4.2. Air Dump Pressure Switch Input       16-8         2.5.4.3. Door Closed Input       16-8         2.5.4.4. Door Command Input       16-8         2.5.4.5. Emergency Release Input       16-8         2.5.4.6. Sensitive Edge Input       16-8         2.5.4.7. Logic Power Input       16-8         2.5.5. Controller Outputs       16-10         2.5.5.1. Emergency Release Output       16-10         2.5.5.2. Door Fully Open Output       16-10         2.5.5.3. Door Fully Closed Output       16-10         2.5.5.4. Door Obstruction Signal Output       16-10         2.5.5.5. Emergency Release Solenoid Output       16-10         2.5.5.6. Motor Brake Output       16-10         2.5.5.7. J1939 J7 Connector (door position)       16-10         2.5.8.1. J1 Voice Annunciator (Vapor)       16-10         2.5.8.2. J12 Quadrature Encoder (Vapor)       16-10         2.5.8.3. J5 Bus Interface (Grey) (OEM Supplied)       16-10			•	
2.5.1. Description       16-7         2.5.2. Door Controller Specifications       16-7         2.5.3. Operation       16-8         2.5.4. Controller Inputs       16-8         2.5.4.1. Speed Interlock Input       16-8         2.5.4.2. Air Dump Pressure Switch Input       16-8         2.5.4.3. Door Closed Input       16-8         2.5.4.4. Door Command Input       16-8         2.5.4.5. Emergency Release Input       16-8         2.5.4.5. Emergency Release Input       16-8         2.5.4.7. Logic Power Input       16-8         2.5.5. Controller Outputs       16-10         2.5.5.1. Emergency Release Output       16-10         2.5.5.2. Door Fully Open Output       16-10         2.5.5.3. Door Fully Closed Output       16-10         2.5.5.4. Door Obstruction Signal Output       16-10         2.5.5.5. Emergency Release Solenoid Output       16-10         2.5.5.6. Motor Brake Output       16-10         2.5.7. J1939 J7 Connector (door position)       16-10         2.5.8. Control Connectors       16-10         2.5.8. Control Connectors       16-10         2.5.8. J1 Voice Annunciator (Vapor)       16-10         2.5.8. J5 Bus Interface (Grey) (OEM Supplied)       16-10				
2.5.2. Door Controller Specifications.       16-7         2.5.3. Operation       16-8         2.5.4. Controller Inputs.       16-8         2.5.4.1. Speed Interlock Input.       16-8         2.5.4.2. Air Dump Pressure Switch Input.       16-8         2.5.4.3. Door Closed Input.       16-8         2.5.4.4. Door Command Input       16-8         2.5.4.5. Emergency Release Input       16-8         2.5.4.6. Sensitive Edge Input       16-8         2.5.4.7. Logic Power Input       16-8         2.5.5. Controller Outputs       16-10         2.5.5.1. Emergency Release Output       16-10         2.5.5.2. Door Fully Open Output       16-10         2.5.5.3. Door Fully Closed Output       16-10         2.5.5.4. Door Obstruction Signal Output       16-10         2.5.5.5. Emergency Release Solenoid Output       16-10         2.5.5.6. Motor Brake Output       16-10         2.5.7. J1939 J7 Connector (door position)       16-10         2.5.8. Control Connectors       16-10         2.5.8. Control Connectors       16-10         2.5.8.2. J12 Quadrature Encoder (Vapor)       16-10         2.5.8.3. J5 Bus Interface (Grey) (OEM Supplied)       16-10				
2.5.3. Operation       16-8         2.5.4. Controller Inputs       16-8         2.5.4.1. Speed Interlock Input       16-8         2.5.4.2. Air Dump Pressure Switch Input       16-8         2.5.4.3. Door Closed Input       16-8         2.5.4.4. Door Command Input       16-8         2.5.4.5. Emergency Release Input       16-8         2.5.4.5. Emergency Release Input       16-8         2.5.4.7. Logic Power Input       16-8         2.5.5.7. Controller Outputs       16-10         2.5.5.1. Emergency Release Output       16-10         2.5.5.2. Door Fully Open Output       16-10         2.5.5.3. Door Fully Closed Output       16-10         2.5.5.4. Door Obstruction Signal Output       16-10         2.5.5.5. Emergency Release Solenoid Output       16-10         2.5.5.6. Motor Brake Output       16-10         2.5.5.7. J1939 J7 Connector (door position)       16-10         2.5.8.1. J1 Voice Annunciator (Vapor)       16-10         2.5.8.2. J12 Quadrature Encoder (Vapor)       16-10         2.5.8.3. J5 Bus Interface (Grey) (OEM Supplied)       16-10				
2.5.4. Controller Inputs       16-8         2.5.4.1. Speed Interlock Input       16-8         2.5.4.2. Air Dump Pressure Switch Input       16-8         2.5.4.3. Door Closed Input       16-8         2.5.4.4. Door Command Input       16-8         2.5.4.5. Emergency Release Input       16-8         2.5.4.6. Sensitive Edge Input       16-8         2.5.4.7. Logic Power Input       16-8         2.5.5. Controller Outputs       16-10         2.5.5.1. Emergency Release Output       16-10         2.5.5.2. Door Fully Open Output       16-10         2.5.5.3. Door Fully Closed Output       16-10         2.5.5.4. Door Obstruction Signal Output       16-10         2.5.5.5. Emergency Release Solenoid Output       16-10         2.5.5.6. Motor Brake Output       16-10         2.5.7. J1939 J7 Connector (door position)       16-10         2.5.8. Control Connectors       16-10         2.5.8.1. J1 Voice Annunciator (Vapor)       16-10         2.5.8.2. J12 Quadrature Encoder (Vapor)       16-10         2.5.8.3. J5 Bus Interface (Grey) (OEM Supplied)       16-10		2.5.3.	•	
2.5.4.1. Speed Interlock Input       16-8         2.5.4.2. Air Dump Pressure Switch Input       16-8         2.5.4.3. Door Closed Input       16-8         2.5.4.4. Door Command Input       16-8         2.5.4.5. Emergency Release Input       16-8         2.5.4.6. Sensitive Edge Input       16-8         2.5.4.7. Logic Power Input       16-8         2.5.5. Controller Outputs       16-10         2.5.5.1. Emergency Release Output       16-10         2.5.5.2. Door Fully Open Output       16-10         2.5.5.3. Door Fully Closed Output       16-10         2.5.5.4. Door Obstruction Signal Output       16-10         2.5.5.5. Emergency Release Solenoid Output       16-10         2.5.5.6. Motor Brake Output       16-10         2.5.6. LED indicators       16-10         2.5.7. J1939 J7 Connector (door position)       16-10         2.5.8. Control Connectors       16-10         2.5.8.1. J1 Voice Annunciator (Vapor)       16-10         2.5.8.2. J12 Quadrature Encoder (Vapor)       16-10         2.5.8.3. J5 Bus Interface (Grey) (OEM Supplied)       16-10		2.5.4.	·	
2.5.4.3. Door Closed Input       16-8         2.5.4.4. Door Command Input       16-8         2.5.4.5. Emergency Release Input       16-8         2.5.4.6. Sensitive Edge Input       16-8         2.5.4.7. Logic Power Input       16-8         2.5.5. Controller Outputs       16-10         2.5.5.1. Emergency Release Output       16-10         2.5.5.2. Door Fully Open Output       16-10         2.5.5.3. Door Fully Closed Output       16-10         2.5.5.4. Door Obstruction Signal Output       16-10         2.5.5.5. Emergency Release Solenoid Output       16-10         2.5.5.6. Motor Brake Output       16-10         2.5.6. LED indicators       16-10         2.5.7. J1939 J7 Connector (door position)       16-10         2.5.8. Control Connectors       16-10         2.5.8.1. J1 Voice Annunciator (Vapor)       16-10         2.5.8.2. J12 Quadrature Encoder (Vapor)       16-10         2.5.8.3. J5 Bus Interface (Grey) (OEM Supplied)       16-10		2.		
2.5.4.4. Door Command Input       16-8         2.5.4.5. Emergency Release Input       16-8         2.5.4.6. Sensitive Edge Input       16-8         2.5.4.7. Logic Power Input       16-8         2.5.5. Controller Outputs       16-10         2.5.5.1. Emergency Release Output       16-10         2.5.5.2. Door Fully Open Output       16-10         2.5.5.3. Door Fully Closed Output       16-10         2.5.5.4. Door Obstruction Signal Output       16-10         2.5.5.5. Emergency Release Solenoid Output       16-10         2.5.6. Motor Brake Output       16-10         2.5.6. LED indicators       16-10         2.5.7. J1939 J7 Connector (door position)       16-10         2.5.8. Control Connectors       16-10         2.5.8.1. J1 Voice Annunciator (Vapor)       16-10         2.5.8.2. J12 Quadrature Encoder (Vapor)       16-10         2.5.8.3. J5 Bus Interface (Grey) (OEM Supplied)       16-10		2.	.5.4.2. Air Dump Pressure Switch Input	16-8
2.5.4.5. Emergency Release Input       16-8         2.5.4.6. Sensitive Edge Input       16-8         2.5.4.7. Logic Power Input       16-8         2.5.5. Controller Outputs       16-10         2.5.5.1. Emergency Release Output       16-10         2.5.5.2. Door Fully Open Output       16-10         2.5.5.3. Door Fully Closed Output       16-10         2.5.5.4. Door Obstruction Signal Output       16-10         2.5.5.5. Emergency Release Solenoid Output       16-10         2.5.6. Motor Brake Output       16-10         2.5.6. LED indicators       16-10         2.5.7. J1939 J7 Connector (door position)       16-10         2.5.8. Control Connectors       16-10         2.5.8.1. J1 Voice Annunciator (Vapor)       16-10         2.5.8.2. J12 Quadrature Encoder (Vapor)       16-10         2.5.8.3. J5 Bus Interface (Grey) (OEM Supplied)       16-10				
2.5.4.6. Sensitive Edge Input       16-8         2.5.4.7. Logic Power Input       16-8         2.5.5. Controller Outputs       16-10         2.5.5.1. Emergency Release Output       16-10         2.5.5.2. Door Fully Open Output       16-10         2.5.5.3. Door Fully Closed Output       16-10         2.5.5.4. Door Obstruction Signal Output       16-10         2.5.5.5. Emergency Release Solenoid Output       16-10         2.5.6. Motor Brake Output       16-10         2.5.6. LED indicators       16-10         2.5.7. J1939 J7 Connector (door position)       16-10         2.5.8. Control Connectors       16-10         2.5.8.1. J1 Voice Annunciator (Vapor)       16-10         2.5.8.2. J12 Quadrature Encoder (Vapor)       16-10         2.5.8.3. J5 Bus Interface (Grey) (OEM Supplied)       16-10				
2.5.4.7. Logic Power Input       16-8         2.5.5. Controller Outputs       16-10         2.5.5.1. Emergency Release Output       16-10         2.5.5.2. Door Fully Open Output       16-10         2.5.5.3. Door Fully Closed Output       16-10         2.5.5.4. Door Obstruction Signal Output       16-10         2.5.5.5. Emergency Release Solenoid Output       16-10         2.5.6. Motor Brake Output       16-10         2.5.6. LED indicators       16-10         2.5.7. J1939 J7 Connector (door position)       16-10         2.5.8. Control Connectors       16-10         2.5.8.1. J1 Voice Annunciator (Vapor)       16-10         2.5.8.2. J12 Quadrature Encoder (Vapor)       16-10         2.5.8.3. J5 Bus Interface (Grey) (OEM Supplied)       16-10				
2.5.5. Controller Outputs       16-10         2.5.5.1. Emergency Release Output       16-10         2.5.5.2. Door Fully Open Output       16-10         2.5.5.3. Door Fully Closed Output       16-10         2.5.5.4. Door Obstruction Signal Output       16-10         2.5.5.5. Emergency Release Solenoid Output       16-10         2.5.5.6. Motor Brake Output       16-10         2.5.6. LED indicators       16-10         2.5.7. J1939 J7 Connector (door position)       16-10         2.5.8. Control Connectors       16-10         2.5.8.1. J1 Voice Annunciator (Vapor)       16-10         2.5.8.2. J12 Quadrature Encoder (Vapor)       16-10         2.5.8.3. J5 Bus Interface (Grey) (OEM Supplied)       16-10				
2.5.5.1. Emergency Release Output       16-10         2.5.5.2. Door Fully Open Output       16-10         2.5.5.3. Door Fully Closed Output       16-10         2.5.5.4. Door Obstruction Signal Output       16-10         2.5.5.5. Emergency Release Solenoid Output       16-10         2.5.6. Motor Brake Output       16-10         2.5.6. LED indicators       16-10         2.5.7. J1939 J7 Connector (door position)       16-10         2.5.8. Control Connectors       16-10         2.5.8.1. J1 Voice Annunciator (Vapor)       16-10         2.5.8.2. J12 Quadrature Encoder (Vapor)       16-10         2.5.8.3. J5 Bus Interface (Grey) (OEM Supplied)       16-10				
2.5.5.2. Door Fully Open Output       16-10         2.5.5.3. Door Fully Closed Output       16-10         2.5.5.4. Door Obstruction Signal Output       16-10         2.5.5.5. Emergency Release Solenoid Output       16-10         2.5.6. Motor Brake Output       16-10         2.5.6. LED indicators       16-10         2.5.7. J1939 J7 Connector (door position)       16-10         2.5.8. Control Connectors       16-10         2.5.8.1. J1 Voice Annunciator (Vapor)       16-10         2.5.8.2. J12 Quadrature Encoder (Vapor)       16-10         2.5.8.3. J5 Bus Interface (Grey) (OEM Supplied)       16-10				
2.5.5.3. Door Fully Closed Output       16-10         2.5.5.4. Door Obstruction Signal Output       16-10         2.5.5.5. Emergency Release Solenoid Output       16-10         2.5.5.6. Motor Brake Output       16-10         2.5.6. LED indicators       16-10         2.5.7. J1939 J7 Connector (door position)       16-10         2.5.8. Control Connectors       16-10         2.5.8.1. J1 Voice Annunciator (Vapor)       16-10         2.5.8.2. J12 Quadrature Encoder (Vapor)       16-10         2.5.8.3. J5 Bus Interface (Grey) (OEM Supplied)       16-10			·	
2.5.5.4. Door Obstruction Signal Output       16-10         2.5.5.5. Emergency Release Solenoid Output       16-10         2.5.5.6. Motor Brake Output       16-10         2.5.6. LED indicators       16-10         2.5.7. J1939 J7 Connector (door position)       16-10         2.5.8. Control Connectors       16-10         2.5.8.1. J1 Voice Annunciator (Vapor)       16-10         2.5.8.2. J12 Quadrature Encoder (Vapor)       16-10         2.5.8.3. J5 Bus Interface (Grey) (OEM Supplied)       16-10				
2.5.5.5. Emergency Release Solenoid Output       16-10         2.5.5.6. Motor Brake Output       16-10         2.5.6. LED indicators       16-10         2.5.7. J1939 J7 Connector (door position)       16-10         2.5.8. Control Connectors       16-10         2.5.8.1. J1 Voice Annunciator (Vapor)       16-10         2.5.8.2. J12 Quadrature Encoder (Vapor)       16-10         2.5.8.3. J5 Bus Interface (Grey) (OEM Supplied)       16-10				
2.5.5.6. Motor Brake Output       16-10         2.5.6. LED indicators       16-10         2.5.7. J1939 J7 Connector (door position)       16-10         2.5.8. Control Connectors       16-10         2.5.8.1. J1 Voice Annunciator (Vapor)       16-10         2.5.8.2. J12 Quadrature Encoder (Vapor)       16-10         2.5.8.3. J5 Bus Interface (Grey) (OEM Supplied)       16-10				
2.5.6. LED indicators       16-10         2.5.7. J1939 J7 Connector (door position)       16-10         2.5.8. Control Connectors       16-10         2.5.8.1. J1 Voice Annunciator (Vapor)       16-10         2.5.8.2. J12 Quadrature Encoder (Vapor)       16-10         2.5.8.3. J5 Bus Interface (Grey) (OEM Supplied)       16-10				
2.5.7. J1939 J7 Connector (door position)       16-10         2.5.8. Control Connectors       16-10         2.5.8.1. J1 Voice Annunciator (Vapor)       16-10         2.5.8.2. J12 Quadrature Encoder (Vapor)       16-10         2.5.8.3. J5 Bus Interface (Grey) (OEM Supplied)       16-10			•	
2.5.8. Control Connectors       16-10         2.5.8.1. J1 Voice Annunciator (Vapor)       16-10         2.5.8.2. J12 Quadrature Encoder (Vapor)       16-10         2.5.8.3. J5 Bus Interface (Grey) (OEM Supplied)       16-10				
2.5.8.1. J1 Voice Annunciator (Vapor)       16-10         2.5.8.2. J12 Quadrature Encoder (Vapor)       16-10         2.5.8.3. J5 Bus Interface (Grey) (OEM Supplied)       16-10				
2.5.8.2. J12 Quadrature Encoder (Vapor)       16-10         2.5.8.3. J5 Bus Interface (Grey) (OEM Supplied)       16-10				
2.5.8.3. J5 Bus Interface (Grey) (OEM Supplied)				
2.3.3.4. 07 01303 interface (Diack) (OLIVI Supplied)			.5.8.4. J7 J1939 Interface (Black) (OEM Supplied)	



	2.5.8.5. J9 Baseplate Interface (Green) (Vapor)	
	2.5.8.6. J11Power and Motor (Vapor)	16-11
	2.5.8.7. J13 USB Port	. 16-11
	2.5.9. Diagnostic Program	16-11
	2.5.10. Setup & Basic Parameters	16-11
	2.5.10.1.Parameter Settings	
	2.5.10.2.Controller Inputs & Output Status	16-11
	2.5.10.3.Controller Testing	16-11
	2.5.10.4.Controller Status	16-11
	2.5.10.5.Serial Port Setup	16-12
	2.5.10.6.Product ID	. 16-12
	2.5.11. Advanced Parameters	16-13
	2.5.11.1.Open Cushion Start (20-50% of teeter lever rotation)	. 16-14
	2.5.11.2.Open Cushion Length (20-50% of teeter lever rotation)	16-15
	2.5.11.3.Close Cushion Start (20-50% of teeter lever rotation)	
	2.5.11.4.Close Cushion Length (20-50% of teeter lever rotation)	16-16
	2.5.11.5.Open Speed	16-16
	2.5.11.6.Close Speed	16-16
	2.5.11.7.Reset Controller	16-16
	2.5.11.8.QS Home	16-16
	2.5.11.9.QS Preload	16-16
	2.5.11.10.QS Encoder	16-16
	2.5.11.11.Save to Flash	16-16
	2.5.11.12.Load from File	16-16
	2.5.11.13.Verify from File	16-16
	2.5.11.14.Save to File	16-16
	2.5.11.15.Output Configuration	16-16
	2.5.11.16.Operator Orientation	16-16
	2.5.12. Door Cycling Window	16-17
	2.5.12.1.Door State	. 16-17
	2.5.12.2.Open Door	16-17
	2.5.12.3.Close Door	16-17
	2.5.12.4.Start Door Cycle	16-17
	2.5.12.5.Stop Door Cycle	16-17
	2.5.12.6.Clear Times	16-17
	2.5.12.7.Dump Log Files	16-17
	2.5.12.8.Dump System Files	16-17
	2.5.12.9.Dump Count Data	. 16-17
	2.5.12.10.Clear System Data	. 16-17
	2.5.12.11.Clear Count Data	. 16-17
	2.5.13. Inputs/Outputs Window	16-17
2.6	. Entrance Door Adjustment Procedure1	6-19
	2.6.1. Door Panel Alignment	
	2.6.2. Door Panel Height Adjustment	
	2.6.3. Aft Panel Closed Position Stop Adjustment	
	· · ·	
	2.6.4. Fore & Aft Panel Open Stop Adjustments	
	2.6.5. Connecting Rod Adjustment	
	2.6.5.1. Quick Door Linkage Adjustment	
	2.6.5.2. Step 1 (home position)	
	2.6.5.3. Step 2 (door close preload)	
	2.6.5.4. Step 3 (encoder calibration)	
	2.6.5.5. Door Test Box	16-23



	2.6.6.	Door Pocket Seals	16-24
		Door Panel Lower Brush & Upper Portal Splash Guard Adjustment	
	2.7. Doc	or Speed Adjustments	16-24
	2.7.1.	Description	
	2.7.2.	Adjustment Procedure	16-24
	2.8. Em	ergency Release	16-25
	2.8.1.		
	2.8.2.	Entrance Door Émergency Release	
	2.9. Dod	or Manual Control Valve	16-25
	2.9.1.	Description	16-25
	2.10. Dod	or Shaft/Arm Assemblies & Bearings	16-26
		Description	
		Removal/Installation	
	2.11. Cor	necting Rod Assemblies	16-27
		Description	
	2.11.2.	Removal	16-27
	2.11.3	Installation	16-27
	2.12. Dod	or Panels	16-28
	2.12.1.	Description	16-28
	2.13. Dod	or Glass	16-28
	2.13.1.	Description	16-28
	2.13.2.	Removal	16-28
	2.13.3.	Installation	16-28
2	VADOR	MELCLINE CLINE EVIT DOOD	16.20
3.		/NFI SLIDE GLIDE EXIT DOOR	
3.	3.1. Des	cription	16-29
3.	3.1. Des		16-29
3.	3.1. Des	eration  Door Power Up Operation	
3.	3.1. Des 3.2. Ope 3.2.1. 3.2.2.	Pration  Door Power Up Operation	
3.	3.1. Des 3.2. Ope 3.2.1. 3.2.2. 3.2.3.	Door Power Up Operation	
3.	3.1. Des 3.2. Ope 3.2.1. 3.2.2. 3.2.3. 3.2.4.	Pration Door Power Up Operation Door Closed Door Not Closed Rear Door Close Obstruction	
3.	3.1. Des 3.2. Ope 3.2.1. 3.2.2. 3.2.3. 3.2.4. 3.3. Mai	Pration Door Power Up Operation Door Closed Door Not Closed Rear Door Close Obstruction ntenance	
3.	3.1. Des 3.2. Ope 3.2.1. 3.2.2. 3.2.3. 3.2.4. 3.3. Mai 3.4. Exit	Door Power Up Operation	16-2916-3116-3116-3116-3316-33
3.	3.1. Des 3.2. Ope 3.2.1. 3.2.2. 3.2.3. 3.2.4. 3.3. Mai 3.4. Exit	Pration Door Power Up Operation Door Closed Door Not Closed Rear Door Close Obstruction Intenance Door Adjustment Procedure Door Panel Adjustments	
3.	3.1. Des 3.2. Ope 3.2.1. 3.2.2. 3.2.3. 3.2.4. 3.3. Mai 3.4. Exit 3.4.1. 3.4.2.	Door Power Up Operation	
3.	3.1. Des 3.2. Ope 3.2.1. 3.2.2. 3.2.3. 3.2.4. 3.3. Mai 3.4. Exit 3.4.1. 3.4.2. 3.	Door Power Up Operation	16-2916-3116-3116-3116-3316-3316-33
3.	3.1. Des 3.2. Ope 3.2.1. 3.2.2. 3.2.3. 3.2.4. 3.3. Mai 3.4. Exit 3.4.1. 3.4.2. 3.3.	Door Power Up Operation Door Closed Door Not Closed Rear Door Close Obstruction  ntenance Door Adjustment Procedure Door Panel Adjustments Connecting Rod Adjustment 4.2.1. Step 1 (home position) 4.2.2. Step 2 (door close pre-load)	16-29
3.	3.1. Des 3.2. Ope 3.2.1. 3.2.2. 3.2.3. 3.2.4. 3.3. Mai 3.4. Exit 3.4.1. 3.4.2. 3. 3.	Paration  Door Power Up Operation  Door Closed  Door Not Closed  Rear Door Close Obstruction  Intenance  Door Adjustment Procedure  Door Panel Adjustments  Connecting Rod Adjustment  4.2.1. Step 1 (home position)  4.2.2. Step 2 (door close pre-load)  4.2.3. Step 3 (encoder calibration)	16-2916-3116-3116-3316-3316-3316-3516-3516-35
3.	3.1. Des 3.2. Ope 3.2.1. 3.2.2. 3.2.3. 3.2.4. 3.3. Mai 3.4. Exit 3.4.1. 3.4.2. 3. 3. 3. 3.3.	Pration  Door Power Up Operation  Door Closed  Door Not Closed  Rear Door Close Obstruction  Intenance  Door Adjustment Procedure  Door Panel Adjustments  Connecting Rod Adjustment  4.2.1. Step 1 (home position)  4.2.2. Step 2 (door close pre-load)  4.2.3. Step 3 (encoder calibration)  Door Test Box	16-2916-3116-3116-3316-3316-3516-3516-3516-35
3.	3.1. Des 3.2. Ope 3.2.1. 3.2.2. 3.2.3. 3.2.4. 3.3. Mai 3.4. Exit 3.4.1. 3.4.2. 3.3. 3.4.3. 3.4.3.	Door Power Up Operation Door Closed Door Not Closed Rear Door Close Obstruction  ntenance Door Adjustment Procedure Door Panel Adjustments Connecting Rod Adjustment 4.2.1. Step 1 (home position) 4.2.2. Step 2 (door close pre-load) 4.2.3. Step 3 (encoder calibration) Door Test Box  or Speed Adjustments  To Speed Adjustments  Door Test Box  To Speed Adjustments  Door Speed Adjustments	16-29
3.	3.1. Des 3.2. Ope 3.2.1. 3.2.2. 3.2.3. 3.2.4. 3.3. Mai 3.4.1. 3.4.2. 3.3. 3.4.3. 3.5. Doo 3.5.1.	Pration  Door Power Up Operation  Door Closed  Door Not Closed  Rear Door Close Obstruction  Internance  Door Adjustment Procedure  Door Panel Adjustments  Connecting Rod Adjustment  4.2.1. Step 1 (home position)  4.2.2. Step 2 (door close pre-load)  4.2.3. Step 3 (encoder calibration)  Door Test Box  Pr Speed Adjustments  Description	16-29
3.	3.1. Des 3.2. Ope 3.2.1. 3.2.2. 3.2.3. 3.2.4. 3.3. Mai 3.4.1. 3.4.2. 3. 3. 3. 3. 3. 3. 3. 3. 3. 3. 3. 3. 3.	Pration  Door Power Up Operation  Door Closed  Door Not Closed  Rear Door Close Obstruction  Intenance  Door Adjustment Procedure  Door Panel Adjustments  Connecting Rod Adjustment  4.2.1. Step 1 (home position)  4.2.2. Step 2 (door close pre-load)  4.2.3. Step 3 (encoder calibration)  Door Test Box  Or Speed Adjustments  Description  Adjustment Procedure	16-29
3.	3.1. Des 3.2. Ope 3.2.1. 3.2.2. 3.2.3. 3.2.4. 3.3. Mai 3.4. Exit 3.4.1. 3.4.2. 3.3. 3.4.3. 3.5. Doo 3.5.1. 3.5.2. 3.6. Eme	Pration  Door Power Up Operation  Door Closed  Door Not Closed  Rear Door Close Obstruction  Intenance  Door Adjustment Procedure  Door Panel Adjustments  Connecting Rod Adjustment  4.2.1. Step 1 (home position)  4.2.2. Step 2 (door close pre-load)  4.2.3. Step 3 (encoder calibration)  Door Test Box  In Speed Adjustments  Description  Adjustment Procedure  Pergency Air Release Valve	16-2916-3116-3116-3316-3316-3516-3516-3516-3516-3516-35
3.	3.1. Des 3.2. Ope 3.2.1. 3.2.2. 3.2.3. 3.2.4. 3.3. Mai 3.4.1. 3.4.2. 3. 3. 3. 3. 3. 3. 3. 3. 3. 3. 3. 3. 3.	Pration  Door Power Up Operation  Door Closed  Door Not Closed  Rear Door Close Obstruction  Intenance  Door Adjustment Procedure  Door Panel Adjustments  Connecting Rod Adjustment  4.2.1. Step 1 (home position)  4.2.2. Step 2 (door close pre-load)  4.2.3. Step 3 (encoder calibration)  Door Test Box  In Speed Adjustments  Description  Adjustment Procedure  Pergency Air Release Valve  Description	16-29
3.	3.1. Des 3.2. Ope 3.2.1. 3.2.2. 3.2.3. 3.2.4. 3.3. Mai 3.4.1. 3.4.2. 3.3. 3.4.3. 3.5. Doo 3.5.1. 3.5.2. 3.6.1.	Pration  Door Power Up Operation  Door Closed  Door Not Closed  Rear Door Close Obstruction  Intenance  Door Adjustment Procedure  Door Panel Adjustments  Connecting Rod Adjustment  4.2.1. Step 1 (home position)  4.2.2. Step 2 (door close pre-load)  4.2.3. Step 3 (encoder calibration)  Door Test Box  In Speed Adjustments  Description  Adjustment Procedure  Pergency Air Release Valve	16-2916-3116-3116-3316-3316-3516-3516-3516-3516-3516-3516-3516-3516-35

# Table of Contents



	3.6.4.	Installation	16-36
	3.6.5.	Maintenance	16-36
	3.7. Sen	nsitive Edges	16-37
		Description	
		Functional Test	
	3.7.3.	Maintenance	16-40
	3.7.4.	Installation	16-40
4.	DRIVE	R'S DOOR CONTROL	16-41
	4.1. Des	scription	16-41
	4.2. Ins	pection	16-41
		erhauling	
		Disassembly	
		.3.1.1. Cleaning	
		Reassembly	
	4.3.3.	Testing after Reassembly	16-45
	4.	.3.3.1. Test Equipment Required	
	4.	.3.3.2. Testing - Mechanical	
	4.	.3.3.3. Testing - Electrical	
	4.3.4.	Storing	16-45





## 1. SAFETY

## 1.1. Safety Procedures

This section of the service manual contains procedures which require the mechanics to strictly observe safety procedures in order to ensure personal and equipment safety.

Always ensure that the vehicle is appropriately hoisted and blocked for procedures which require elevating the vehicle. Be aware of the limitations of the blocking equipment, and always ensure that the jarring and shaking created by component removal and installation procedures does not overload the blocks, or cause the vehicle to become unstable.

Certain procedures may require the vehicle be operated in an elevated position in order to accurately troubleshoot and diagnose a problem. If the vehicle must be running while elevated, become familiar with the repair area prior to starting the engine. Take special care in noting areas which will become hot, electrically energized, and areas where moving and rotating components are located. Limit the work in these areas as personal and equipment safety is at risk.

For procedures which involve air lines, ensure the line is safely depressurized prior to disconnecting. Disconnecting pressurized lines will cause solid particles deposited in the line to be uncontrollably propelled, and will also cause the hose end to whip randomly as the air escapes.

During electrical diagnosis procedures an understanding of the vehicle's electric circuits is important to anticipate the results of connecting test equipment. During component removal or installation, ensure the Battery Disconnect switch is in the OFF position.

Failure to follow this procedure may result in personal injury or component failure.

Observe the following procedures involving hydraulic line removal.

- Hydraulic fluid is corrosive and should not be exposed to skin for extensive periods of time.
- Wear eye protection at all times.
- Pressurized lines should not be disconnected until the pressure is safely and controllably released.






Fig. 16-1: Entrance Door



# 2. VAPOR/NFI SLIDE GLIDE ENTRANCE DOOR

## 2.1. Description

The Vapor/NFI slide glide entrance door is electrically operated. The door system consists of a door controller and operator mounted horizontally on a shelf plate above the door panels. See "Fig. 16-2: Entrance Door Base Plate" on page 4. The operator, when operated, causes the rod actuating assembly to apply torque to the two hinge posts, and arm assemblies, which are mounted vertically from the base of the door portal up through the shelf plate, one on each side of the door opening. The slide glide door panels are affixed to the post and arm assemblies by upper and lower arm rod ends. See "Fig. 16-1: Entrance Door" on page 2.

The door panels are sealed into the door portal by means of weather seals that abut the door frame on the outboard side of each panel. The door panel leading edges are sealed by means of an overlapping seal, the rearward (aft) panel with the backing seal and the forward (fore) panel with the over seal. Each door panel is also equipped with a lower brush that closes the space between the bottom of the door panel and the top of the floor. Another brush is fastened to the upper door portal blocking the space between the shelf plate. The slide glide door operates in such a manner as to offer optimum height and width of opening by sliding the door panels open at 90° to the vehicle body while using very little space for movement for the opening mechanism.

- 1. Entrance Door Assembly, Fore
- 2. Entrance Door Assembly, Aft
- 3. Wedge, w/Thread
- 4. Wedge, w/o Thread
- Screw, PH Cross Recess SST 1/4" - 20 UNC x 1/2" Lg. Black
- 6. Screw, FH 1/4" 20 x 3/4" Lg. Black
- 7. Screw, PH Cross Recess Tpg. Type F #10 24 UNC x 3/4" Lg. Black
- 8. Adhesive, SIKA 221 Black
- 9. Bolt, Hex Lock Flanged 5/16" Black
- 10. Screw, 12 PT 3/8" 24 UNC x 1 1/4" Lg.
- 11. Washer, Flat SST 1/4"
- 12. Rivet, Low Profile Blind Breakstem Alum. 3/16" x .500/.781 Black

- 13. Seal, Pocket Entrance
- 14. Coupler, Shaft Fore
- Drive Shaft Assembly, Entrance Door Fore
- 16. Door Shaft & Arm Assembly, Fore
- 17. Bracket, Door Shaft Mount
- 18. Pivot Assembly, Fore
- 19. Door Shaft & Arm Assembly, Aft
- 20. Pivot Assembly, Aft
- 21. Brush, Entrance Door Upper
- 22. Seal, Entrance Door Header
- 23. Retainer, Jamb Seal Fore
- 24. Retainer, Jamb Seal Aft
- 25. Seal, Bottom Corner
- 26. Ring, Retaining 1.00" Ext

- 27. Washer, Special 1.50" x 1.00"
- 28. Washer, Thrust 1.50" x 1.00"
- 29. Bearing, Door Shaft Fore
- 30. Key, Square 1/4" SST
- 31. Spacer, Entrance Door Pivot
- 32. Seal, Door Jamb Fore (Incl. 33)
- 33. Bracket, Jamb Seal
- 34. Seal, Door Jamb Aft (Incl. 35)
- 35. Bracket, Jamb Seal
- 36. Insert, Steel 5/16" 18 UNC x .027" .150"
- 37. Insert, Steel 5/16" 18 UNC x .150" .312"
- 38. Screw, FH 1/4"- 20 x 1.00" Black
- 39. Loctite, 24

Entrance Door (parts list)






Fig. 16-2: Entrance Door Base Plate





- 1. Base Plate Assembly, Entrance Door (Incl. 2-26, 30, 34-59)
- 2. Base Plate, Welded
- 3. Cable, Encoder
- 4. Bracket, Rotary Valve
- 5. Plate, Door Operator
- 6. Bushing, 3/8" I.D. x 1/2" O.D.
- 7. Bearing, Ball
- 8. Bearing, Block
- 9. Nut, Hex Locking 3/8" 16
- 10. Nut, Hex Locking 5/16" 18 UNC
- 11. Screw, Hex HD Cap 3/8"
- 12. Nut, Hex 3/8" 16 UNC
- 13. Cap, Neoprene
- 14. Air Cock Assembly
- 15. Screw, Flt HD Rec #8 - 32 UNC x .31" Lg.
- Elbow, Nylon Tube Fitting Brass 3/ 8"
- 17. Clip, Tie Holder
- 18. Door Operator Assembly
- 19. Teeter Assembly
- 20. Target, Door Open Sensor
- 21. Washer, Plain #8 - .375" O.D. x .032" Thk.

- 22. Screw, PH Rec Sem Ex #8 32 x .38" Lg.
- 23. Washer, Lock 5/16"
- 24. Washer, Lock Special 5/16" .125" W x .078" Thk.
- 25. Screw, Hex HD Cap 5/16" 18 x .50
- 26. Lever Assembly, Door Shaft (Incl. 27-29)
- 27. Screw, Locking Torque Patch
- 28. Washer, Lock 1/4"
- 29. Washer, 1/4" - .562 O.D. X .049 Thk.
- 30. Lever Assembly, Door Shaft (Incl. 31-33)
- 31. Screw, Locking Torque Patch
- 32. Washer, Lock 1/4"
- 33. Washer, 1/4" - .562 O.D. X .049 Thk.
- 34. Nut, Hex Keps #8 32 UNC
- 35. Washer, Plain 3/8" .813" O.D. x .065" Thk.
- 36. Washer, Lock Special 3/8" .141" W x .094" Thk.
- 37. Screw, Locking Torque Patch
- 38. Connecting Rod Assembly
- 39. Connecting Rod Assembly

- 40. Spacer
- 41. Washer, Lock 1/4"
- 42. Screw, Hex HD Cap SC
- 43. Harness, Wiring
- 44. Label, Identification
- 45. Proximity & Connector Assembly
- 46. Switch, Pressure
- 47. Hose Assembly
- 48. Sealant, Teflon
- 49. Tee, Pipe Fitting Brass 1/4"
- 50. Fitting, Pipe w/Brass Bushing 1/4"
- 51. Bracket, Mag Valve
- 52. Valve, Solenoid
- 53. Washer, Plain #10 - .438" O.D. x .032" Thk.
- 54. Washer, Lock #10
- 55. Screw, Hex Head TRM #10
- 56. Washer, Lock Int. #10
- 57. Tubing, Nylon
- 58. Fitting, Tube
- 59. Conduit, Convoluted 12.25" Lg.

Entrance Door Base Plate (parts list)

## 2.2. Door Safety Features



Any malfunction or deviation of adjustment of the doors or safety systems, should receive immediate corrective action. No vehicle should be operated in transit service with door safety systems disconnected.

#### 2.2.1. Service Brake Interlock

Your New Flyer vehicles are equipped with a service brake interlock. The interlock is activated by opening or authorizing the rear exit door, or by opening the entrance door.

#### 2.2.2. Throttle Interlock

The throttle (accelerator) interlock is activated by opening or authorizing a door or by initiating the operation of a kneeling system or wheelchair ramp. The power to the throttle treadle is cut off, preventing the inadvertent increase of engine RPM by the driver.



## 2.3. Operation

### 2.3.1. Door Power Up Operation

The control will monitor the door closed sensor at power up to determine the door position. The control also uses an encoder to determine door position but does not retain this information after the power is removed. The door will synchronize the encoder each time the door is in the closed position. The encoder is tested at power by jogging the motor to confirm that the encoder is functioning.

#### 2.3.2. Door Closed

If the door closed sensor is detected at power-up, the controller will perform a test to determine if the door is closed. When the test has passed the control is placed in the door fully closed state.

#### 2.3.3. Door Not Closed

If the door closed sensor is not detected at power-up, the controller will be placed in the door fault state. At this point the control does not know if the door is open or closed. The door open signal is sent to the vehicle. When a door command signal change from open to close is detected, the door will move slowly to the closed position. When the door stops moving, the position encoder will be synchronized with the door.

#### 2.3.4. Front Door Close Obstruction

The front doors do not have a sensitive edge to detect obstructions when closing. The control can detect an obstruction as the door is closing. It cannot detect an obstruction during the last few inches of the door closing movement. A front door closing obstruction is determined by the control monitoring the front door movement. If an obstruction is detected during the closing, the door will stop and recycle to the open position. There will be a one second delay once the door has reached the door fully open position. After the delay the controller will then respond to the door command signal. If the signal indicates a door close command, the door will start to close. If the command is in the door open command, the door will remain in the open position.

## 2.3.5. Front Door Open Obstruction

The door will stop when an obstruction is detected as the door is opening. After a 1 second delay, the door will continue to move in the opening direction. If an obstruction is detected again, the door will stop for one second and then resume opening. After three attempts to open, the door will stop and enter the fault state. Commanding the door to close will clear the fault and return to normal operation.

#### 2.4. Maintenance

Refer to the Preventive Maintenance section of this manual for scheduled maintenance requirements.



## 2.5. Door Controller

## 2.5.1. Description

The door controller is an electronic module that controls the function of the electric door motor. It consists of an electronic module with seven connectors for interfacing to the vehicle electrical system and diagnostic computers. The door controller also contains four LED indicator lights. The door controller is bracket mounted above the door baseplate and is accessible through the mechanism access door. See "Fig. 16-3: Door Controller" on page 7.

## 2.5.2. Door Controller Specifications

Supply Voltage	
Nominal	24 to 28 VDC
Range	20 to 36 VDC
Supply Current (typical)	
2 to 10 Amps durin	g door movement

## ™NOTE:

The current can reach 20 Amps during a door obstruction event. The preload current at end of door cycle is 16 Amps for 500 milliseconds.

# Motor Drive Max Current (short-circuit shutdown) ......30A




Fig. 16-3: Door Controller



## 2.5.3. Operation

The Door Controller receives inputs from the multiplexing system and the door base-plate sensors and switches. It uses these inputs to determine door state (open or closed) and the intended state (driver's control) and supplies the appropriate control signals for door motor operation. See "Fig. 16-4: System Schematic" on page 9.

## 2.5.4. Controller Inputs

The controller has been designed with optically coupled input circuitry. Each input can be configured for an active high or active low signal. The standard configuration is active high.

#### 2.5.4.1. Speed Interlock Input

This input provides a speed interlock that disables the controller from driving the motor while the signal is low. The signal applied to this input will be low when the vehicle is moving and high when the vehicle is stopped.

## 2.5.4.2. Air Dump Pressure Switch Input

This input is wired to a pressure switch that is used monitor the air pressure supplied to the emergency release cylinder. The state of the pressure switch is used to automatically reengage the mechanical operator.

## 2.5.4.3. Door Closed Input

This signal comes from the proximity sensor located on the gearbox. It senses a metal bracket attached to the teeter lever. When the sensor detects the bracket, the door is in the closed position.

### 2.5.4.4. Door Command Input

This input commands the controller to open and close the door. A high signal will command the door to open. The door will close when the signal goes low.

#### 2.5.4.5. Emergency Release Input

This signal comes from a proximity sensor located on the gearbox. This sensor monitors the emergency release mechanism. During normal operation this input is high from the sensor. If the emergency release mechanism is activated this signal will be low.

#### 2.5.4.6. Sensitive Edge Input

This input is wired to a sensitive edge pressure switch. When the pressure switch has sensed an obstruction, this signal to this input goes high. This will stop the doors from closing and then re-open them.

#### 2.5.4.7. Logic Power Input

This input powers the controller on and off. A low current (less than 1 amp) 24 VDC signal will turn on the controller allowing the controller to be powered down when the Master Run Switch is turned off.






Fig. 16-4: System Schematic



## 2.5.5. Controller Outputs

The controller outputs are high side switches rated at 1 Amp. When active these drivers will supply a signal at the vehicle supply voltage. The logic for the vehicle interface is configurable to the requirements of the OEM.

#### 2.5.5.1. Emergency Release Output

When the controller is in the emergency release state, this output will be on. During normal operation this output is off.

## 2.5.5.2. Door Fully Open Output

The output will be on when the controller is in the door fully open position.

#### 2.5.5.3. Door Fully Closed Output

This output will be on when the controller is in the door fully closed position.

#### 2.5.5.4. Door Obstruction Signal Output

This output will pulse on for a short duration when the controller has detected an obstruction.

## 2.5.5.5. Emergency Release Solenoid Output

This output is connected to the release reset solenoid. This output is turned on to activate the solenoid to allow the emergency release to reset.

## 2.5.5.6. Motor Brake Output

This output is connected to the motor brake solenoid. When turned on, the motor brake will disengage to allow the electric operator to move the doors.

#### 2.5.6. LED indicators

#### **Setup LED**

The setup LED is active during the Quick Setup door linkage adjustment procedure.

#### **Maintenance LED**

The maintenance LED does not have a function. It will momentary indicate the controller is saving data to the file system.

#### **Fault LED**

The fault LED indicates when the controller has entered a fault state. To exit the fault state, command the door to the close position.

#### **Power LED**

The power LED indicates when the controller is powered.

#### 2.5.7. J1939 J7 Connector (door position)

The controller has the ability to function on a J1939 network. Connector J7 contains the connection points for the J1939 network as well as inputs which can be used for door position information. The connector that contains the door position jumpers are attached to the door baseplate harness. The front door is always position 0 and does not require a connector with jumper wires. This allows a single controller part number to be placed in any door position on the vehicle.

## 2.5.8. Control Connectors

## ™NOTE:

Refer to the ES-DC Door Control System Schematic in the Vehicle System Drawing manual for information on which connectors and signals are used.

#### 2.5.8.1. J1 Voice Annunciator (Vapor)

The plug for this connector is supplied on the Vapor Voice Annunciator.

#### 2.5.8.2. J12 Quadrature Encoder (Vapor)

The plug for this connector is supplied on the Vapor encoder cable.

## 2.5.8.3. J5 Bus Interface (Grey) (OEM Supplied)

Deutsch Grey with a 12 pin Connector-Plug with Wedge Lock

## 2.5.8.4. J7 J1939 Interface (Black) (OEM Supplied)

Deutsch Black with a 12 pin Connector-Plug with Wedge Lock





## 2.5.8.5. J9 Baseplate Interface (Green) (Vapor)

The plug for this harness is supplied on the Vapor Baseplate Harness.

### 2.5.8.6. J11Power and Motor (Vapor)

The plug for this connector is supplied on the Vapor Power/Motor Cable

#### 2.5.8.7. J13 USB Port

This port is for programming and diagnostics.

## 2.5.9. Diagnostic Program

Vapor provides a diagnostic application that runs on a Windows PC. It is used for parameter setting and controller diagnostics.

## 2.5.10. Setup & Basic Parameters

## 2.5.10.1.Parameter Settings

There are several parameters that can be adjusted to configure the door performance.

- Open cushioning start
- Open cushioning length

☐ Close cushioning sta	ırt
------------------------	-----

- Close cushioning length
- Open speed
- □ Close speed

## 2.5.10.2.Controller Inputs & Output Status

The status of all the signal inputs and outputs can be monitored. The state of each output can be changed for testing.

## 2.5.10.3. Controller Testing

The operation of the door can be controlled using the diagnostic application. The door can be manually opened, closed or automatically cycle.

#### 2.5.10.4. Controller Status

The following status information from the door can be monitored.

- Door controller state
- Door fault status
- Door opening time
- Door closing time



## 2.5.10.5. Serial Port Setup

The screen is used for setting up the serial port configuration The baud rate must be set to 57600, the stop bits is set to 1, the data bits is set to 8, the Interface can be set to COM1 - COM4. The Set button will allow the program to attempt to reconnect to the controller. When a connection is established, the product ID window will be displayed See "Fig. 16-5: Serial Port Setup" on page 12.




Fig. 16-5: Serial Port Setup

#### 2.5.10.6.Product ID

The product ID window will show the firmware version information when the PC is communicating. Do not use the RS232 Mode or the USB mode buttons. See "Fig. 16-6: Product ID" on page 12.



Fig. 16-6: Product ID



## 2.5.11. Advanced Parameters

This window is used for adjusting controller parameters. See "Fig. 16-7: Advanced Parameters" on page 13.




Fig. 16-7: Advanced Parameters



## 2.5.11.1.Open Cushion Start (20-50% of teeter lever rotation)

This parameter controls the point in the door travel where the cushion starts. The

value refers to the last 20-50 percent of the teeter lever rotation before the door is open. See "Fig. 16-8: Open Cushion Start" on page 14.




Fig. 16-8: Open Cushion Start



## 2.5.11.2.Open Cushion Length (20-50% of teeter lever rotation)

This parameter controls the duration of the cushion speed deceleration. See "Fig. 16-9: Open Cushion Length" on page 15.




Fig. 16-9: Open Cushion Length



## 2.5.11.3.Close Cushion Start (20-50% of teeter lever rotation)

This parameter controls the point in the door travel where the cushion starts. The value refers to the last 20-50 percent of the teeter lever rotation before the door is closed.

## 2.5.11.4.Close Cushion Length (20-50% of teeter lever rotation)

This parameter controls the duration of the cushion speed deceleration.

## 2.5.11.5.Open Speed

This parameter adjusts the door speed from 25 to 100 percent of maximum motor speed.

## 2.5.11.6.Close Speed

This parameter adjusts the door speed from 25 to 100 percent of maximum motor speed.

#### 2.5.11.7.Reset Controller

This button will reset the controller.

#### 2.5.11.8.QS Home

This button is part of the quick setup procedure. The operator will open and then return to the door home position. This is the position that the door adjustments are performed.

#### 2.5.11.9.QS Preload

This button is part of the quick setup procedure. The operator will be driven to the predetermined pre-load closed force.

#### 2.5.11.10.QS Encoder

This button is part of the quick setup procedure. The operator will rotate to the door fully open position and then back to the fully closed position to calibrate the encoder.

#### 2.5.11.11.Save to Flash

This button will send the parameters to controller and then store them in the file system.

#### 2.5.11.12.Load from File

This button is used to retrieve the parameters setting from a file on the computer.

#### 2.5.11.13. Verify from File

This button is used to verify the controller settings are programmed.

#### 2.5.11.14.Save to File

This button will save the parameters to a file on the computer.

## 2.5.11.15.Output Configuration

This selection box is for configuring the electric controller for the vehicle logic.

Always set the output configuration to "New Flyer". See "Fig. 16-10: Output Configuration" on page 17.

#### 2.5.11.16.Operator Orientation

This selection button is used to configure the orientation of the electric operator gearbox. There are two versions of operator gearbox, the difference is in which side the operator the emergency release pull cable is located. The motor direction changes depending on the operator model.






Fig. 16-10: Output Configuration

## 2.5.12. Door Cycling Window

This screen allows the user to manually control the door and view system data. See "Fig. 16-11: Door Cycling Window" on page 18.

#### 2.5.12.1.Door State

This box will display the current state of the controller.

### 2.5.12.2.Open Door

This button will command the door to open. Using this method of opening the door will disable the Door Command Electrical Input. Reset the controller to re-enable the Door Command Electrical Input.

#### 2.5.12.3.Close Door

This button will command the door to close. Using this method of closing the door will disable the Door Command Electrical Input. Reset the controller to reenable the Door Command Electrical Input.

## 2.5.12.4.Start Door Cycle

This button will enable the auto door cycling mode. This feature causes the door to cycle at an 8 second rate. Press the door open or closed button to start.

#### 2.5.12.5.Stop Door Cycle

This button will stop the auto door cycling mode.

#### 2.5.12.6.Clear Times

This button clears the door open and closed timing data.

## 2.5.12.7. Dump Log Files

Pressing the Dump Log Files button will display a log of events.

#### 2.5.12.8.Dump System Files

Pressing the Dump System Files button will display the system data.

## 2.5.12.9.Dump Count Data

Pressing the Dump Count Files button will display the count data.

#### 2.5.12.10.Clear System Data

Pressing the Clear System Data button will clear the system data.

## 2.5.12.11.Clear Count Data

Pressing the Clear Count Data button will clear the count data.

#### 2.5.13. Inputs/Outputs Window

This windows show the status on the inputs and outputs. The override section is used to force the status See "Fig. 16-12: Inputs/Outputs Window" on page 18.






Fig. 16-11: Door Cycling Window




Fig. 16-12: Inputs/Outputs Window

## **Entrance Door Adjustment Procedure**

## 2.6. Entrance Door Adjustment Procedure

Adjustment of the entrance door assembly is performed in the following four stages and in the following sequence.:

- Door panel alignment
- □ Door stop adjustment (initial)
- Connecting rod adjustment
- Door panel lower brush and upper portal splash guard adjustment

Adjustment slots for door alignment are provided in the baseplate, the forward shaft support bracket, the forward shaft bottom bracket, the aft shaft bottom bracket and the door panel bottom seals. See "Fig. 16-13: Entrance Door Adjustment Points" on page 20.

## 2.6.1. Door Panel Alignment

Before making any adjustments to the doors, ensure that the door panels seat into their proper positions when closed.

## ™NOTE:

These adjustments must be made prior to installation of jamb seals.

- Set the Battery Disconnect Switch to the OFF position.
- Remove fore panel lower pocket seal. Retain seal and mounting hardware for reinstallation.

- Loosen closed position stop jamb nut on aft panel and rotate stop screw counter clockwise to allow for maximum aft shaft rotation in the closed position.
- Disconnect connecting rods from door shaft levers to allow for individual manual operation of each door panel.
- Manually rotate both door panels to the "ideal" fully closed position. Ensure forward panel leading edge seal is overlapping the aft panel seal.
- Verify metal to metal gap between door panels is 4.00" to 4.25" from top to bottom. Gap between door panel trailing edge and pillar trim for both fore and aft panels should be approximately 3/4".
- If required, loosen baseplate mounting bolts and adjust the fore/aft position of base plate to achieve the require 3/4" gap. Tighten baseplate mounting bolts after adjustment.
- Rotate door panels to fully closed position. Verify that lower edge of each panel is collinear and that lower brush seals are directly over edge of the vehicle floor.
- Ensure door panel leading edge seals (near the bottom of the doors) are making adequate contact to form a water resistant seal. If required, adjust the inboard/outboard position of the fore and aft door panel lower pivots to attain an adequate seal.






Fig. 16-13: Entrance Door Adjustment Points



## **Entrance Door Adjustment Procedure**

## 2.6.2. Door Panel Height Adjustment

The height of each panel must be adjusted to allow light contact (approximately 1/16") between the top edge of each panel and the upper brush seal. If there is a gap, the doors panels must be raised by adding shims between each respective door shaft lever and pillow block bearing collar.

- 1. Measure gap between the edge of each panel and bristles of the upper brush. To determine required shim pack for each panel, add 1/16" to measured gap.
- 2. Remove door shaft operating lever and loosen bearing collar set screws to allow for vertical movement of each shaft. Retain all hardware for reinstallation of levers.
- Install spacer washers as required (1.00" ID) onto each stub shaft. Ensure spacer washers rest flush against pillow block bearing collars.
- 4. Reinstall door shaft levers ensuring timing marks on shaft and lever are aligned. Tighten pillow block bearing collar set screws and torque operating lever lock bolts to 42 ft-lb. (57 Nm). See "Fig. 16-14: Timing Marks" on page 21.

- Adjust vertical position of fore shaft upper bearing bracket (mounted to "A" pillar) to center lower shaft arm in door panel pocket when door is closed.
- 6. Reinstall fore panel lower pocket seal.




Fig. 16-14: Timing Marks



## 2.6.3. Aft Panel Closed Position Stop Adjustment

- Manually rotate both door panels to the "ideal" fully closed position. Ensure fore panel leading edge seal is overlapping the aft panel seal.
- 2. With the doors in this position the metal-tometal door panel leading edge gap should be a minimum of 4.00". See "Fig. 16-15: Door Closure Adjustment" on page 22.
- 3. While holding the door in the "ideal" closed position, turn the stop screw clockwise until the bumper tip just contacts the adjacent surface of the upper arm.
- 4. Secure this adjustment by tightening the stop screw jam nut.




Fig. 16-15: Door Closure Adjustment

## 2.6.4. Fore & Aft Panel Open Stop Adjustments

- Manually rotate both panels to the "ideal" open position. The panels should be parallel to each other and perpendicular to the door threshold.
- Adjust door open stop screws in base plate guide tracks to achieve the required door open position. Secure adjustment by tightening stop screw jam nuts.

## **Entrance Door Adjustment Procedure**

## 2.6.5. Connecting Rod Adjustment

## 2.6.5.1. Quick Door Linkage Adjustment

The door controller has a setup button that will assist in the door linkage adjustment. The yellow button is located next to the Setup LED indicator on the front of the control. Press this button for 5 seconds to start the quick setup mode. The setup LED indicator will be lit when in quick setup mode. If the emergency release was activated, pressing the quick setup button will re-engage the door operator.



The electric door operator, door panels and door linkage will be in motion during this adjustment and caution should be taken to prevent bodily harm.

## 2.6.5.2. Step 1 (home position)

## MOTE:

This step is normally performed with the door linkage removed.

During the home position location process, the teeter lever may rotate more than 360 degrees when searching for the home position. When the motor stops, the teeter is in the home position. Note that the keyway on the teeter shaft is almost vertical. Connect and adjust the door linkage rods

so that the doors are closed. Do not over tighten the door panels (excessive door close preload).

#### 2.6.5.3. Step 2 (door close preload)

Press and release the setup button again and the controller will apply the programmed door closed pre-load force. Test the door for a tight closure. The setup LED will still be on and the controller still in setup mode.

### 2.6.5.4. Step 3 (encoder calibration)

Pressing and releasing the setup button again will run the encoder calibrate process. The door will open fully and then close at a slow speed allowing the encoder position to be calibrated. When complete, the setup LED will turn off and the door can be operated normally.

#### 2.6.5.5. Door Test Box

The door test box can be used to assist in door setup when the vehicle is not electrically fully functional. See "Fig. 16-16: Door Test Box" on page 23. This test box is connected to a 24VDC 15 Amp supply. There are cables that are connected to the electric operator control to provide power and control signals. The Power On switch will turn on the electric operator. The door open and close switch will command the door.




Fig. 16-16: Door Test Box



#### 2.6.6. Door Pocket Seals

Door pocket seals are located on the fore and aft panel lower pockets.

Verify that sealant is correctly applied to prevent water ingress. Apply sealant to both corners of each pocket seal as required.

## 2.6.7. Door Panel Lower Brush & Upper Portal Splash Guard Adjustment

- Operate the door controller to the closed position.
- Loosen retaining hardware and slide the brush assembly upwards or downwards in the slots until the brush just makes contact with the floor. Maximum 1/16" compression is acceptable.
- 3. Tighten the retaining hardware to secure the seal in place.
- 4. Operate the door controller to the open position.
- Adjust upper portal splash guard height to allow splash guard to clear door panel by a minimum of 1/16".
- Cycle door from closed to open position several times to ensure that brush does not drag excessively and splash guard clears the door panels.

## 2.7. Door Speed Adjustments

## 2.7.1. Description

Opening and closing speeds and door cushioning are software adjustable through a computer connected to the electronic door controller.

## ™NOTE:

Perform all other mechanical adjustment procedures before adjusting the door opening and closing speeds.

### **Specifications**



Closing speed should be adjusted to ensure the specified amount of time between initiation of closure and full door closed position.

#### 2.7.2. Adjustment Procedure

- Adjust door closing speed to specification as measured between initiation of closing and the door fully closed position. Refer to 2.5.9. "Diagnostic Program" on page 11 in this section for information on connecting to the door controller and setting door operating parameters.
- 2. Adjust door opening speed to specification as measured between initiation of opening and the door fully opened position.



## 2.8. Emergency Release

### 2.8.1. Door Emergency Release

In the case of an emergency, the door gearbox can be disengaged allowing the door to be freely pushed open. The release mechanism has a rotary dump valve located behind a breakable cover. When turned, the valve allows air to escape and activates the spring loaded cable release cylinder. The cylinder moves a cable that disengages an interval clutch, allowing the teeter lever to rotate freely. A proximity sensor detects that the emergency release mechanism has been activated.

## 2.8.2. Entrance Door Emergency Release

Before exiting the vehicle, the driver rotates the Master Run switch to OFF which removes power from the magnetic dump valve solenoid. Air exhausts from the emergency release device, disengaging the clutch on the electric operator. The doors enter a neutral state and can be operated manually by hand. Rotating the Master Run switch to ON will apply power to the Command State dump valve. Once adequate air pressure is achieved the

emergency release device will initiate the homing sequence by engaging the clutch on the electric operator. The door will slowly move to the fully closed position, regardless of the door's commanded state. Obstruction detection is active during the homing sequence. Once the door reaches the fully closed (home) position, the door will return to the normal operating state and respond to commands via the driver's door controller. For example: If the driver's door controller is in the open position during the homing sequence, the door will move to the full open position *after* reaching the fully closed (home) position.

#### 2.9. Door Manual Control Valve

## 2.9.1. Description

The door panels may be manually opened by exhausting the air from the cable release cylinder. The door manual control valve is located on the front vertical face of the side console.

To manually open the doors rotate the handle 90°, wait for the air pressure to exhaust and push open the door panels.



## 2.10. Door Shaft/Arm Assemblies & Bearings

## 2.10.1. Description

The shaft and arm assemblies are attached to the door panels and held in place by upper and lower bearings. The upper bearings are seated in the door mechanisms base plate assembly and hold the weight of the shafts and doors. The lower bearings are attached to the floor to control lateral movement. These components function together as part of the door assembly to open and close the doors.

#### 2.10.2. Removal/Installation

- Set Battery Disconnect switch to OFF position.
- 2. Remove the door panel from the door shaft and arm assembly as follows:
  - Support the door panel and remove the three screws from each location where the door panel is attached to the door shaft arm.
  - b. Carefully disengage the door panel from the door shaft arms and from the baseplate roller guide.
  - c. Set the panel aside, being careful to protect the glass and finish.
- Remove the door shaft and arm assemblies as follows:
  - a. Open the entrance mechanism access door.

- b. Disconnect the connecting rod ends from the door shaft lever.
- c. Note the alignment marks on the door shaft/lever and remove screw and wedge that fasten the lever to the shaft. Remove the lever from the shaft.
- d. Remove the two nuts that attach the upper bearing assembly to the baseplate and lift the bearing assembly from the door shaft.
- e. Mark the position of the lower mounting brackets (fore & aft door shafts) and the forward shaft support bracket (fore door shaft only). Remove the bolts from the mounting brackets and carefully slide out the door shaft and arm assemblies from the baseplate.
- 4. Installation is the reverse of removal with the following steps to be noted:
  - Install door shaft and arm assembly mounting brackets in the positions originally marked; otherwise position the brackets in the mid-point of the adjustment slots.
  - Ensure door shaft lever and U-joint splines are correctly indexed to the door shaft splines per the alignment marks.
  - c. Ensure that the dowel pins are engaged before tightening the three screws that fasten the door shaft arms to the door panel.
  - d. Refer to 2.6. "Entrance Door Adjustment Procedure" on page 19 in this section for final adjustments.

## **Connecting Rod Assemblies**

## 2.11. Connecting Rod Assemblies

## 2.11.1. Description

The connecting rod assemblies direct the action of the door operator to the door levers. The connecting rods also act as turnbuckle for door adjustment and as such are threaded right-hand at the teeter plate end (operator) and left-hand at the rod end (lever). The rod ends are secured to the motor teeter lever by a stud, nut and washer. The rod ends are secured to the door levers by a stud, nut and washer.

#### 2.11.2. Removal

## ™NOTE:

It is recommended that connecting rod ends be replaced, when necessary, with exactly the same thread protrusion as the old part. This practice will eliminate the need to adjust the door panels. One end should be removed at a time.

 Access the connecting rods by opening the hinged panel over the door.



While hinged panel above door is open, it protrudes into the stepwell area becoming a hazard for anyone entering the vehicle. Remove the panel to alleviate problem.

- Remove the nut and lockwasher from the teeter plate end and the nut and lockwasher from the rod end.
- Place the connecting rod in a vice with the ends protruding as if they were still mounted in the vehicle.
- Loosen the jam nut at the rod end (lefthand thread) or at the rod end (right-hand thread) while holding the end in position.
- 5. Count the number of revolutions necessary to remove the end.

#### 2.11.3. Installation

- 1. Replace the jam nut on the new end.
- Insert the end into the connecting rod and turn it the same number of revolutions as were required to remove the end.
- 3. Lock the jam nut in place.
- Lightly coat the friction surfaces with SAE #20 oil.
- Repeat the procedure as required for additional end replacements.
- Reverse the steps to complete the installation.



## 2.12. Door Panels

## 2.12.1. Description

The door panels consist of several extruded aluminum pieces. Two vertical sides are joined at the top and bottom of the door panel by extruded inserts. The extruded center sections are secured by screws from the outside vertical sides forming a rigid frame work. The entire assembly is bonded into one piece.

Minor damage to the door sections may be repaired with the use of body filler. Major damage may require replacement of the entire door sub-assembly.

#### 2.13. Door Glass

## 2.13.1. Description

Your slide glide entrance and exit doors are fitted with glass inserts. The windows are made of laminated safety glass to allow translucence and protection against glass fragments in the event of breakage.

Keep windows clean for vision purposes. Rubber moldings should be cleaned of road grime and salt.

#### 2.13.2. Removal



Windows in this vehicle are laminated safety glass and should be handled with care while wearing gloves and approved eye protection.

## ™NOTE:

The door windows are locked in place by a single formed seal with a locking lip.

- 1. Have an assistant inside the vehicle to keep the glass from falling.
- 2. Be sure the door is securely closed.
- Using an appropriate tool, lift up a corner of the locking lip and insert tool under the lip and over the door panel.
- Smoothly pull the tool around the window until the locking lip has been forced inside the door panel.
- 5. Gently push the window to the assistant inside the vehicle.
- Clean the window frame area of dirt, rubber and old sealant.
- Discard the old window and it is recommended that a new seal be used in place of the old one.

#### 2.13.3. Installation

- Position the new seal around the new door glass.
- Lubricate the seal with a soap and water solution or a commercial seal lubricant.
- Have the assistant place the window in the frame and gently push on it while the locking lip is positioned.
- 4. Insert the seal tool over the panel and under the lip.
- Pull the tool smoothly around the window frame while the assistant simultaneously pushes lightly on the glass until lip is fully in position.



# 3. VAPOR/NFI SLIDE GLIDE EXIT DOOR

## 3.1. Description

The Vapor/NFI exit door of this vehicle is a slide glide door. The door functions the same as the entrance door. See "Fig. 16-

17: Exit Door" on page 30. The base plate assembly above the door contains the door controller, the door operator lever assembly, door shaft levers, proximity switches and pressure switch connected to the door sensitive edges. See "Fig. 16-18: Exit Door Base Plate" on page 32. Refer to 3.7. "Sensitive Edges" on page 37 in this section for information on that system.

16 - 30






Fig. 16-17: Exit Door



## 3.2. Operation

### 3.2.1. Door Power Up Operation

The control will monitor the door closed sensor at power up to determine the door position. The control also uses an encoder to determine door position but does not retain this information after the power is removed. The door will synchronize the encoder each time the door is in the closed position. The encoder is tested at power by jogging the motor to confirm that the encoder is functioning.

#### 3.2.2. Door Closed

If the door closed sensor is detected at power-up, the controller will perform a test to determine if the door is closed. When the test has passed the control is placed in the door fully closed state.

#### 3.2.3. Door Not Closed

If the door closed sensor is not detected at power-up, the controller will be placed in the door fault state. At this point the control does not know if the door is open or closed. The door open signal is sent to the vehicle. When a door command signal change from open to close is detected, the door will move slowly to the closed position. When the door stops moving, the position encoder will be synchronized with the door.

#### 3.2.4. Rear Door Close Obstruction

The rear doors use sensitive door edge sensors to detect an obstruction while closing. The sensitive edge signals will wire into the electric operator control. The electric operator will monitor and react to the sensitive edge signal during the entire time that the door is closing until the door is fully closed. If a sensitive edge is detected during a door closing movement, the door will stop and then recycle open. There will be a one second delay once the door has reached the door fully open position. After the one second delay the controller will then respond to the door command signal. If the signal indicates a door close command, the door will start to close. If the command is in the door open command, the door will remain in the open position. The electric operator control can also detect a closing obstruction by monitoring the door movement.

- 1. Exit Door Assembly, Fore
- 2. Exit Door Assembly, Aft
- 3. Washer, Special
- 4. Nut, Crown 3/8" 16 UNC Black
- 5. Washer, Flat 3/8" Black
- 6. Nut, Lock Nylon #10 32
- 7. Nut, Hex Acorn #10 32 UNC
- 8. Washer, Plain #10 - .438" O.D. x .032" Thk.
- 9. Nut, Hex Locking 3/8" 16
- 10. Screw, PH Cross Recess SST #10 - 32 UNF x 3/8" Black
- 11. Screw, HD #10 32
- 12. Nut, Hex #10 32
- 13. Washer

- 14. Bolt, Carriage 316 SST 1/4" 20 UNC x 2" Lg.
- 15. Wedge, w/Thread
- 16. Wedge, w/o Thread
- 17. Rivet, Blind Black Painted 3/16" x .187/.437
- 18. Screw, PH Cross Recess Tpg. Type F #10 24 UNC x 3/4" Lg. Black
- 19. Nut, Hex SST 1/4" 20 UNC
- 20. Washer, Flat SST 1/4"
- 21. Screw, 12 PT 3/8" - 24 UNC x 1 1/4" Lg.
- 22. Washer, Flat SST #10 Black
- 23. Door Shaft & Arm Assembly, Fore
- 24. Pivot Assembly, Fore

- 25. Seal, Bottom Corner
- 26. Strip, Retaining
- 27. Seal, Rubber
- 28. Pocket Seal Assembly
- 29. Extrusion
- 30. Door Shaft & Arm Assembly, Aft
- 31. Seal, Jamb
- 32. Retainer, Jamb Seal
- 33. Seal, Upper Wide Xcelsior®
- 34. Pivot Assembly, Aft
- 35. Brush Assembly, Upper
- 36. Brush Assembly, Lower Aft
- 37. Brush Assembly, Lower Fore
- 38. Adhesive, SIKA 221 Black

Exit Door (parts list)






Fig. 16-18: Exit Door Base Plate



#### 3.3. Maintenance

Refer to the Preventive Maintenance Section of this manual for scheduled maintenance requirements.

## 3.4. Exit Door Adjustment Procedure

This section covers the adjustment of rear door panels and linkage.

## 3.4.1. Door Panel Adjustments

- Before attempting to make any adjustments make sure connecting rods have been removed from the door shaft levers. Each panel can now be moved independently of each other. Also check that all door bracket mounting studs are centered within their respective slots, including the upper roller assembly and lower pivot assembly mounting hardware. This will establish a starting point for all panel alignment adjustments.
- 2. Measure the door shaft center to the center distance at the top of the opening. If

- necessary, adjust the lower pivot in the forward or aft direction to obtain the same door shaft spacing at the bottom of the opening. Make sure the door shafts are square with the vehicle floor. Tighten mounting hardware to secure the adjustment.
- 3. Manually close the doors. Check for approximately a 7/8" gap between the door trailing edge seal and the jamb seal retainer along the entire door length. If adjustment is required, loosen the four acorn nuts securing the door to the door mounting brackets and move the panel forward or aft as required. Tighten all mounting hardware after making adjustments.
- 4. With the doors in the fully closed position, check that the top brush forms a tight seal with the top of the doors. If gaps exist, install additional spacers between the door shaft lever and bearing to raise the door enough to form a tight seal. See "Fig. 16-19: Door Shaft Lever Shim Adjustment" on page 34.
- 1. Base Plate Assembly, Exit Door (Incl. 2-34, 38, 41-51)
- 2. Base Plate. Welded
- 3. Bearing, Ball
- 4. Clip, Harness
- 5. Washer, Flat #6 .312" O.D. x .028" Thk.
- 6. Nut, Hex Keps #6 32 UNC
- 7. Plate, Engine Mounting
- 8. Washer, Plain 3/8" 1" O.D. x .072"
- 9. Washer, Lock Special 3/8" .141" W x .094" Thk.
- 10. Nut, Hex 3/8" 16 UNC
- 11. Door Operator Assembly
- 12. Washer, Flat 3/8" .813" O.D. x .065" Thk.
- 13. Screw, Locking Torque Patch
- 14. Proximity & Connector Assembly
- 15. Screw, PH Cross Recess SEM Ex #8 32 x .38
- 16. Target, Door Open Sensor
- 17. Switch. Pressure Wave
- 18. Washer, Flat #8 .375" O.D. x .032" Thk.
- 19. Screw, PH Cross Recess #8 32 UNC x .375"
- 20. Conduit, Convoluted 8.25" Lg.
- 21. Screw, Hex Head Cap 5/16" 18 x .88"
- 22. Washer, Teeter
- 23. Teeter Assembly
- 24. Screw, Locking Torque Patch
- 25. Washer, Lock Special 1/4" -.109 W x .062" Thk.
- 26. Washer, Flat 1/4" .625" O.D. x .065" Thk.

- 27. Tie, Harness White
- 28. Harness, Door Position
- 29. Harness, Wiring
- 30. Washer, Lock 5/16"
- 31. Connecting Rod Assembly
- 32. Clip, Tie Holder
- 33. Spacer, Lever
- 34. Lever Assembly, Door Shaft RH (Incl. 35-37)
- 35. Washer, Lock Special 5/16" .125" W x .078" Thk.
- 36. Nut, Hex 5/16" .125" W x .078" Thk.
- 37. Shaft Lever
- 38. Lever Assembly, Door Shaft LH (Incl. 39-40)
- 39. Washer, Lock Special 5/16" .125" W x .078" Thk.
- 40. Nut, Hex 5/16" .125" W x .078" Thk.
- 41. Elbow, Nylon Tube Fitting Brass 3/8"
- 42. Tee, Pipe Fitting Brass 1/4"
- 43. Sealant, Teflon
- 44. Connector, Bulkhead Female 1/4" NPTF
- 45. Fitting, Pipe w/Brass Bushing 1/4"
- 46. Switch, Pressure
- 47. Bracket, Mounting
- 48. Nut, Hex 1/4" 20 Steel
- 49. Label, Identification
- 50. Hose Assembly, 8.5" Lg.
- 51. Cable, Encoder

Exit Door Base Plate (parts list)



- 5. Loosen the front and rear door top seal retainer and adjust the height of the top rubber seal so that it overlaps the top edge of the doors by approximately 1/16" when the doors are in the fully closed position. The top edge of the doors should wipe across the seal as they open. Tighten the retaining strip mounting hardware to secure the adjustment.
- 6. Adjust the front and rear door lower brush seals by first loosening the 10 - 32 acorn nuts securing the brush to the lower brush holder. Move the brush down until the bristles fill the step tread grooves. Secure the adjustment by tightening the 10 - 32 acorn nuts
- 7. Manually push the doors to their full open position. Verify that the doors open to a 90° angle with respect to the step edge. If necessary, loosen the four 5/16" 18 roller bracket assembly mounting screws and adjust roller bracket to obtain a 90° door open position. Tighten screws to secure the adjustment.
- 8. Reattach the connecting rods to the door shaft levers using hardware removed.
- Manually open and close the doors. Verify that the leading panel overlaps the trailing panel during closing. If the edges bind during closing, lengthen the leading panel connecting rod and shorten the trailing panel connecting rod enough to eliminate the interference.
- 10. With the doors in the closed position, verify that the leading door edge metal to metal distance is 4.15" across the entire door length. See "Fig. 16-20: Door Closure Adjustment" on page 34. If adjustment is necessary, loosen the 3/18" 16 acorn nuts securing the door panel to the door mounting brackets and move the panel forward or aft as required. Tighten mounting hardware to secure the adjustment.




Fig. 16-19: Door Shaft Lever Shim Adjustment




Fig. 16-20: Door Closure Adjustment



## 3.4.2. Connecting Rod Adjustment

The door controller has a setup button that will assist in the door linkage adjustment. The button is located next to the Setup LED indicator on the front of the control. Press this button for 5 seconds to start the quick setup mode.



The electric door operator, door panels and door linkage will be in motion during this adjustment and caution should be taken to prevent bodily harm.

#### **3.4.2.1. Step 1 (home position)**

During the home position location process, the teeter lever may rotate more than 360 degrees when searching for the home position. When the motor stops, connect and adjust the door linkage rods so that the doors are closed. Do not over tighten the door panels (excessive door close preload).

#### 3.4.2.2. Step 2 (door close pre-load)

Press the setup button again and the controller will apply the programmed door closed pre-load force. Test the door for a tight closure.

#### 3.4.2.3. Step 3 (encoder calibration)

Pressing the setup button again will run the encoder calibrate process. The door will open and then close at a slow speed allowing the encoder position to be calibrated. When complete, the door can be run normally.

#### 3.4.3. Door Test Box

The door test box can be used to assist in door setup when the vehicle is not electrically fully functional. This test box is connected to a 24VDC 15 Amp supply. There are cables that are connected to the electric operator control to provide power and control signals. The Power On switch will turn on the electric operator. The door open and close switch will command the door.

## 3.5. Door Speed Adjustments

## 3.5.1. Description

Opening and closing speeds and door cushioning are software adjustable through a computer connected to the electronic door controller.

## ™NOTE:

Perform all other mechanical adjustment procedures before adjusting the door opening and closing speeds.

### **Specifications**



Closing speed should be adjusted to ensure the specified amount of time between initiation of closure and full door closed position.

#### 3.5.2. Adjustment Procedure

- Adjust door closing speed to specification as measured between initiation of closing and the door fully closed position. Refer to 2.5.9. "Diagnostic Program" on page 11 in this section for information on connecting to the door controller and setting door operating parameters.
- 2. Adjust door opening speed to specification as measured between initiation of opening and the door fully opened position.



## 3.6. Emergency Air Release Valve

## 3.6.1. Description

A red handled rotary emergency release valve is used to pressurize and vent the air supply from the lines and the spring loaded release cylinder of the door system. The valve can be used to quickly exhaust the air from the cylinder, should an emergency arise, or during service procedures. The emergency release valve is located beside the door behind a frangible cover.

### 3.6.2. Operation

If the emergency release valve is activated, the air is exhausted from the emergency cylinder causing the cylinder to extend. The spring loaded cylinder moves the release lever on the gearbox disengaging the internal clutch allowing the teeter lever to rotate freely. This allows the door to be pushed open.

When the emergency release valve is in the deactivated position, the cylinder is pressurized causing the clutch to reengage and closing the door.

#### 3.6.3. Removal

- 1. Open accessory tank drain valve, to vent air to atmosphere.
- 2. Access emergency valve; mark, loosen and remove the supply lines from valve.

- Loosen and remove the two mounting screws and nuts.
- 4. Lift valve away from bracket.
- Remove fittings from supply ports to be used on replacement valve.

#### 3.6.4. Installation

- 1. Position valve in place on top of bracket and secure with mounting hardware. Ensure proper orientation.
- Connect the air line from accessory tank to Port No. 1 and air line from throttle valve to Port No. 2.
- Ensure valve handle is in the exhaust position.
- 4. Close accessory tank drain valve and charge the air system.
- When tank is fully charged, place emergency valve to the normal position; this will energize the door motor circuit.
- 6. Check all valve fittings for air leaks using a soap and water solution.

#### 3.6.5. Maintenance

The emergency release valve is considered non-serviceable and cannot be adjusted. Valve must be checked regularly for proper operation and leakage. Any defect requires that the valve be replaced as a unit.



## 3.7. Sensitive Edges

#### 3.7.1. Description

The sensitive door edge system consists of a soft rubber edge with a sealed chamber, a PVC transfer tube, a pressure airwave switch and a set of door operator cam switches which signal door position, and interface with the electrical control system. See "Fig. 16-21: Door Edge to Panel Interface" on page 37.

When the sealed chamber (door edge) is momentarily deflected, (for example by an obstruction), a pressure wave is created which is transmitted via the PVC tubing to the pressure switch.

The pressure wave deflects the diaphragm of the switch, closing its contacts only momentarily since the built-up pressure is quickly equalized through the switch pressure compensating orifice. See "Fig. 16-22: Switch Contacts" on page 38.

The switch is supplied with the sensitivity properly factory preset for the sensitive edge arrangement being utilized. See "Fig. 16-23: Air Wave Switch" on page 38.

Upon closure of the pressure wave switch contacts, the door control system is signaled to reverse (reopen). The door system will reopen until the 85° limit switch is actuated. Refer to the DC (Door Controls) Electrical Schematic in Section 9 of this manual. The system will then reinitiate the closing cycle. Upon reaching a closed position, the 5° limit switch will actuate. This switch indicates the doors are in a closed position and the sensitive edge circuit may then be deactivated.




Fig. 16-21: Door Edge to Panel Interface






Fig. 16-22: Switch Contacts




Fig. 16-23: Air Wave Switch



#### 3.7.2. Functional Test

#### ™NOTE:

The following test is used to verify that the sensitive edges deactivate when the door is 5° from being fully closed. All door linkage adjustments must be completed before switch adjustments are made.

- Ensure that the system is at full air pressure, the vehicle is parked and the parking brake is set.
- 2. Open the doors to be checked.
- 3. Set the doors to close.
- 4. Standing outside the vehicle and while the doors are closing, firmly pinch the sensitive edge seal on the left hand door panel. The doors should reopen. See "Fig. 16-24: Pinch Test" on page 39.
- 5. Repeat steps 3 and 4 for the right hand door panel.
- 6. Standing outside the vehicle with the door closing, hold a 1 inch diameter rod (hardwood or metal approx. 18 in. (45.72 cm) long) perpendicular to the side of the vehicle at the vertical centerline of the door opening, 12 inches above the bottom of the door panels. See "Fig. 16-25: Rod Test" on page 39.
- The doors should reopen when the door edges contact the rod.
- 8. Repeat steps 6 and 7 two more times. First with the rod held at the mid point of the door opening and again with the rod held at a point 12 inches below the top of the door panels.
- If the doors open when tested according to steps 4 through 8, the sensitive edge system is working properly.

10. If the doors fail to open at any testing step, this may indicate a problem with a component of the sensitive edge system (sensitive edge seals, pressure wave switches, tubing or connection point). Verify proper operation of these components and then repeat this test procedure.




Fig. 16-24: Pinch Test




Fig. 16-25: Rod Test



#### 3.7.3. Maintenance

Sensitive edge systems should be periodically checked following limit switch adjustments.

Many times a simple visual inspection for cuts, tears and disconnected tubing will indicate a need for service.



When performing body work on a transit vehicle, be sure to thoroughly mask edges before repainting. Several types of vehicular finishes contain chemicals which attack the neoprene rubber (such as polisocyanates used in polyurethane enamel activator).

#### 3.7.4. Installation

Most edges have a "T" or a box-shaped cross-section on one side which matches a T-slot or C-channel on the leading edge of the door.

To install the edge on the door: lubricate the back side of the edge with a liquid soap (this is preferable to silicone or oil lubricants since the soap may be rinsed off with water after installation). Start the bottom of the edge into the top of the door by aligning the retaining section of the edge with the matching slot or channel.

Proceed to pull the edge into the slot or channel along the length of the door. The last (top) six inches of the edge (the area where a short section of PVC tubing protrudes) should be held away from the door. Connect this tubing to a length of PVC tubing sufficient to reach the pressure wave switch. Route the PVC tubing through the access hole in the door panel. The remaining six inches of edge may now be squeezed sideways into the slot using a dull putty knife on the box or "T" area. The PVC tubing should be routed up to the pressure wave switch. Allow excess tubing at all moving joints and cover exposed sections with spiral wire wrap or equivalent. Be sure that the tubing is not kinked anywhere. Connect the end of the tubing to the open port on the pressure wave switch.



## 4. DRIVER'S DOOR CONTROL

## 4.1. Description

The door controller consists of two normally open momentary microswitches, which are operated by a mechanical plunger and handle.

The Vapor type door controller consists of two single pole, double throw electrical switches, both of which are cam actuated. The cam is fixed to a rotating adapter assembly and has two raised surfaces that come in contact with the switch push buttons. The adapter assembly permits a secure interface between the door controller and the customer's control system.

Four possible combinations can be obtained for front and rear door operation. A predetermined number of these combinations can be obtained by adding stops to

limit the movement of the selector handle. This feature affords the option of having a #2, #3, #4, or #5 position controller. See "Fig. 16-26: Door Controller Positions" on page 42.


## 4.2. Inspection

Periodic inspection of the controller should be made to ensure that the controller is mounted securely and that all its components are tightly fastened. Any accumulation of dirt on the controller should be removed by brushing and vacuuming; this will protect the electrical contacts of the switches. Check controller functions through all positions.

## 4.3. Overhauling

In the event of a malfunction, remove the controller from the vehicle and replace with a spare.





s034523a.svg

Fig. 16-26: Door Controller Positions



#### 4.3.1. Disassembly

- Remove the adapter assembly by loosening the 10 32 hex head machine screws and lock washers and lift the assembly from the controller collar. See "Fig. 16-27: Door Controller Assembly" on page 44.
- Detach the wiring harness by removing the pan head screws and flat washers from both switches.
- 3. Remove the front door snap action switch by unscrewing the two 8 32 socket head cap screws and removing the 8 32 hex nuts, lock washers and spacers.
- 4. The rear door snap action switch and switch insulator may be removed by loosening and removing the two 6 32 round head machine screws, lock washers, flat washers and tapping pad.
- 5. Remove any controller stops that may be present. Unscrew and remove any 10 32 socket head machine screw(s), acorn

- nut(s) and No. 10 split lock washer(s). Mark their location(s) for proper positioning during reassemble.
- Detach the bullet catch bracket from the bracket assembly. Unscrew and remove the two 1/4" - 20 socket head cap screws, lock washers and flat washers.

#### ™NOTE:


As the bullet catch bracket is removed, the index plunger and index plunger spring will fall from it.

7. Slide the actuator cam out of the sleeve in the bracket assembly.

#### 4.3.1.1. Cleaning

All disassembled parts should be cleaned with Chlorothene NU. Use a brush dipped in the solvent when cleaning the switches and the actuator cam and wipe dry (do not soak).





- 4. Washer, Plain #6 - .312" O.D. x .028" Thk.
- 5. Screw, PHD Rec. Sem #6 - 32 UNC x 1 1/4" Lg.
- 6. Insulator, Switch
- 7. Switch, Snap Action
- 8. Pad, Tapping
- 9. Cam, Actuator

- #8 32 UNC x .31" Lg.
- 14. Switch, Snap Action
- 15. Screw, 1/4" 20 UNC x 3/4" Lg.
- 16. Screw, #8 32 UNC x 1" Lg.
- 17. Nut, Hex #8 32 UNC
- 18. Washer, Lock #8
- 19. Bracket, Bullet Catch

- 24. Washer, Lock External 1/4"
- 25. Handle Assembly, Door Controller (Incl. 26)
- 26. Bushing
- 27. Washer, Flat SST 1/4"
- 28. Screw, PH Cross Recess SST 1/4" - 20 UNC x 1/2" Lg.

s034423c.svg

Fig. 16-27: Door Controller Assembly



#### 4.3.2. Reassembly

Before reassembly, all bearing surfaces should be lightly coated with Lubriplate No. 110. Reassemble the controller as follows:

- Position the actuator cam with its drive end through the hole in the bracket assembly.
- Insert the index plunger spring and the index plunger into the bullet catch bracket.
   Mount the bullet catch bracket to the bracket assembly with the two socket head cap screws, lock washers and flat washers.
   Torque the screws to 46 in-lb.
- Replace any controller stops that have been removed. Insert socket head machine screws in the holes marked during disassembly. Secure with acorn nuts and split lock washers. Socket head machine screw heads should be on the same side of the bracket assembly as the actuator cam.
- Mount the rear door switch and switch insulator to the bracket assembly. Use the round head machine screws, lock washers, flat washers and tapping pad.
- Mount the front door switch using the two spacers. Secure with two socket head cap screws, hex nuts and lock washers.
- Attach the harness assembly to both switches. Secure with pan head screws and flat washers.
- Attach the adapter assembly to the bracket assembly and secure it with hex head machine screw and split lock washer. Torque the screw to 30 in-lb.

#### 4.3.3. Testing after Reassembly

#### 4.3.3.1. Test Equipment Required

- ☐ Ohmmeter (Simpson 261 or similar)
- Gauges, Feeler Type

#### 4.3.3.2. Testing - Mechanical

 Actuate the rear door switch. The clearance between the switch button and the

- cam rise surface must be a minimum of 0.015" to have positive switch actuation and to prevent the bottoming out of the switch button causing damage to the switch. Check switch in deactuated position for minimum gap of 0.005" between switch button and flat cam surface.
- Actuate the front door switch. The clearance between switch button and cam surface can be from 0.030" to 0.005" This will make positive actuation and prevent switch button from bottoming, causing damage to switch.



## DO NOT force the gauge. This could damage the switch when it is forced to bottom.

If these clearances are not within specified limits, loosen the mounting hardware of the switch being tested and adjust accordingly.

Operate the controller through all positions. There must be no binding and operation should be smooth.

#### 4.3.3.3. Testing - Electrical

- Connect the leads of an ohmmeter to the N.C. "A" contact terminals. The ohmmeter should indicate infinity with the switch actuated. Zero ohms should be indicated when the switch is deactuated.
- Connect the leads of the ohmmeter to the N.O. "B" contact terminals. The ohmmeter should indicate infinity with the switch deactuated. Zero ohms should be indicated when the switch is actuated.

#### 4.3.4. Storing

If the controller is not going to be put back into use immediately after servicing, store controllers in a glassine bag in a clean dry area.





# **Seating & Stanchions**

1.	SAFETY	17-1
	1.1. Safety Procedures	17-1
2.	DRIVER'S SEAT (USSC Evolution G2A)	17-2
	2.1. Description	
	2.2. Operation	
	2.2.1. Seat Height Adjustment	
	2.2.2. Back Tilt Adjustment	
	2.2.3. Air Lumbar Adjustments	
	2.2.4. Slide Adjustment	
	2.2.5. Back Recline Adjustment	
	2.3. Maintenance	17-4
	2.3.1. Removing Seat from Riser	
	2.3.2. Installing Seat on Riser	
	2.3.3. Slides & Slide Handle Replacement	
	2.3.4. Air Tilt Bag Replacement	
	2.3.5. Air Switch Replacement	
	2.3.6. Air Lumbar Bag Replacement	
	2.3.7. Seat Cushion Replacement	
	2.3.8. Seat Back Cover Replacement	
	2.4. Driver's Seat (USSC Evolution G2A) Troubleshoot	ing 17-6
3.	PASSENGER SEATING	17-8
	3.1. Mounting Passenger Seats	17-8
	3.2. Inspection	
	3.3. Upholstery Maintenance	
	3.3.1. Cleaning Vinyl	
	3.3.1.1. Spot & Stain Removal	
	3.3.2. Cleaning Woven Fabric	
	3.3.2.1. Spot & Stain Removal	
4.	STANCHIONS & GRABRAILS	17-11
	4.1. Description	17-11
	4.2. Removal	
	4.3. Installation	
5.		
	5.1. Description	17-13

## Table of Contents



5.2. Ope	17-13	
5.2.1.	Positioning the Wheelchair	17-13
5.2.2.	Rear Wheelchair Restraints	17-13
5.2.3.	Front Wheelchair Restraints	17-13
5.2.4.	Passenger Securement	17-13
5.3. Mai	intenance	17-13





## 1. SAFETY

## 1.1. Safety Procedures

For procedures which involve air lines, ensure the line is safely depressurized prior to disconnecting. Disconnecting pressurized lines will cause solid particles deposited in the line to be uncontrollably propelled, and will also cause the hose end to whip randomly as the air escapes.

Always follow manufacturer's directions when working with cleaning solvents. Wear a filter mask and protective gloves to prevent inhalation of noxious vapors and damage to skin.



# 2. DRIVER'S SEAT (USSC Evolution G2A)

## 2.1. Description



DO NOT adjust the seat during vehicle operation.

The Evolution G2A driver's seat is an adjustable air suspension seat consisting of a steel frame base and back panel and molded foam cushions. The seat-belt retracts to holders beside the seat cushion. Six controls adjust the positioning of the seat and seat cushions to suit the needs of the individual. Make position adjustments to provide for the best driving visibility and control. See "Fig. 17-1: Driver's Seat" on page 2.




Fig. 17-1: Driver's Seat



## 2.2. Operation

#### 2.2.1. Seat Height Adjustment

Pull the seat height adjustment toggle switch up to raise the seat height. Push this switch down to lower the seat height.

#### 2.2.2. Back Tilt Adjustment

Adjust the backrest to the desired position by pulling the tilt rocker switch up to raise the tilt pan. Push down on this switch to lower the tilt pan.

#### 2.2.3. Air Lumbar Adjustments

Three rocker switches control each of three air lumbar support cells. Push these switches at the top to inflate and push the switches at the bottom to deflate.

#### RNOTE:

The three air lumbar support cells can be individually adjusted.

#### 2.2.4. Slide Adjustment

Press the red button to release the slides, move the seat to the desired location and release the button. Slides will automatically lock in place.

Raising the slide handle, located at the seat front below the rubber bellow, releases the lock and lets the seat move forward/backward. Release the bar once you have reached the desired position. Then move forward and rearward on the seat to be sure that the seat adjusters have latched.

#### 2.2.5. Back Recline Adjustment

Adjust the backrest to the desired recline position by turning the control knobs located on either side at the bottom of the backrest.



#### 2.3. Maintenance

#### 2.3.1. Removing Seat from Riser

- 1. Disconnect air hose.
- 2. Remove nuts on four bolts that run through the seat slide rack and the top base plate.
- Remove seat.

#### 2.3.2. Installing Seat on Riser

Installation is the reverse of removal.

#### 2.3.3. Slides & Slide Handle Replacement

- Remove the screws retaining the slide tracks to the bottom of the seat, at each end of the slides.
- 2. Remove the slide tracks.
- 3. Install new slide tracks.
- 4. Install the retaining screws on each end of the slide tracks and tighten.
- 5. Insert slide handle by fitting each side onto the two tabs on the slide tracks



Replacing the slides should be performed by a qualified technician using only approved parts. Incorrect installation can severely decrease the safety performance of the seat in the event of a vehicle crash.



Seats supplied with C-brackets connecting the seat to the riser must have these brackets installed correctly. Removal or incorrect installation can severely decrease the safety performance of the seat in the event of a vehicle crash.

#### 2.3.4. Air Tilt Bag Replacement

- 1. Move seat to the maximum height.
- Remove seat cushion.
- 3. Remove the right hand switchbox.

#### ™NOTE:

You do not need to disconnect the air lines.

- 4. Manually raise the tilt pan as much as possible.
- 5. Disengage the air line quick connect that hooks up to the tilt bag.
- Locate and loosen the two panel screws, on the underside of the tilt bag, securing the tilt bag to the top pan
- Replace bag, tighten panel screws and reconnect air line.
- 8. Reinstall switchboxes and replace seat cushion.

#### 2.3.5. Air Switch Replacement

- 1. Disconnect the air supply to the seat.
- Remove the seat cushion assembly.
- 3. Remove the three switch box mounting bolts on top of seat pan.
- Remove switchbox from seat pan and disconnect air lines.
- 5. Replace any faulty switches.
- 6. Reconnect the air lines.
- 7. Reinstall switchbox and fasten in place with mounting bolts.
- 8. Replace seat cushion assembly.



#### 2.3.6. Air Lumbar Bag Replacement

- 1. Disconnect the air supply to the seat.
- Disconnect the air connectors from seat base to the seat back.
- 3. Remove back shell and zipper ring.
- 4. Un-zip back cover upholstery panel.
- Remove two rivets holding plastic lumbar panel in front of Dymetrol.
- 6. Slide lumbar panel down and remove from back assembly.
- Remove defective lumbar bag from lumbar panel.
- 8. Install new bag onto lumbar panel.
- Reinstall lumbar panel by sliding it between seat foam and Dymetrol.
- Replace rivets securing lumbar panel in place.
- 11. Reinstall back cover panel, upholstery panel and backshell.
- 12. Reconnect air lines.

#### 2.3.7. Seat Cushion Replacement

#### ™NOTE:

The driver's seat is supplied with a quick release cushion assembly.

 To remove and replace the cushion simply lift up on the cushion firmly to detach the Velcro attachments.

## ™NOTE:

The back of the seat cushion should be slightly underneath the back cushion, and the cushion contour should be aligned with

- the contour of the seat pan trim and switchbox assemblies.
- 2. Locate the cushion correctly on the seat pan before locking in the Velcro attach

#### 2.3.8. Seat Back Cover Replacement

- 1. Remove armrest.
- Remove backshell.
- 3. Remove zipper ring and unzip both back zippers.
- 4. Remove headrest.

#### MOTE:

A screwdriver will be required to pry the spring pin from the detent.

- Loosen headrest caps and pull cover from left to right to remove. The center section will require a small amount of force to pop loose from the back foam but no additional tools are required.
- 6. Install center foam into new cover by placing it between the cover and the plastic locking trim.
- Secure plastic trim/cover assembly into back center panel.
- 8. Secure headrest plugs into headrest tubes.
- 9. Use zipper to secure the entire cover in place and replace zipper rings.
- 10. Replace headrest, backshell and armrests. Air bags decreases the space between the bolsters to allow for smaller drivers. Deflating the bolsters provides more room for larger drivers.



## 2.4. Driver's Seat (USSC Evolution G2A) Troubleshooting

DRIVER'S SEAT (USSC EVOLUTION G2A) TROUBLESHOOTING				
PROBLEM	POSSIBLE CAUSE	CORRECTIVE ACTION		
Seat does not travel fore/aft.	Side release handle not engaging.	Inspect for function repair or replace if required.		
	Air slide button disconnected or not working properly.	Inspect air line and connection at air slide button.		
	Debris in slide mechanism.	Clean slide tracks and lightly grease.		
	Vehicle air pressure is low or off.	Ensure vehicle air system is pressurized.		
Seat does not travel up/down.	Air spring torn or leaking.	Inspect air spring for damage and replace if necessary.		
	Height adjust switch disconnected or not working properly.	Inspect height adjust switch and air line connection.		
	Vehicle air pressure low or off.	Ensure vehicle air system is pressurized.		
	Suspension scissors obstructed.	Inspect scissors, shoulder bolts, and bushings for damage.		
Air tilt does not function properly.	Air tilt bag torn or leaking.	Inspect air tilt bag for damage and replace if necessary.		
	Air tilt switch disconnected or not working properly.	Inspect air tilt switch and air line connection.		
	Vehicle air pressure low or off.	Ensure vehicle air system is pressurized.		
	Air tilt pan obstructed.	Inspect underneath tilt pan and remove any obstructions.		
Lumbar bag does not remain inflated or inflates without switch activation.	Air bag torn or leaking.	Inspect air bag for damage and replace if necessary.		
	Lumbar switch disconnected or not working properly.	Inspect lumbar switch for damage and replace if necessary.		
	Vehicle air pressure low or off.	Ensure vehicle air system is pressurized.		
	Air supply line kinked or obstructed.	Inspect air lines for damage and repair if necessary.		



DRIVER'S SEAT (USSC EVOLUTION G2A) TROUBLESHOOTING					
PROBLEM	POSSIBLE CAUSE	CORRECTIVE ACTION			
Seat belt difficult to release from retractor.	Operator attempting to put on seat belt to quickly.	Slowly pull belt from housing to desired length, then buckle.			
	Shoulder belt installed at incorrect angle.	Make sure shoulder belt is oriented correctly.			
	Seat belt is restricted by seat back.	Make sure shoulder belt is spaced off to frame with bracket.			
	Damaged or faulty seat belt.	Replace immediately. Do not operate vehicle without seat belt.			
Seat back does not recline properly.	Recline knob loose or stripped.	Replace or tighten recline knob.			
	Recline gear damaged.	Replace back frame or back assembly.			
	Obstruction behind seat.	Remove obstruction.			
	Obstruction between recline stop and back.	Make sure are between the recline stop and back frame is clear.			



## 3. PASSENGER SEATING

## 3.1. Mounting Passenger Seats

The vehicle is equipped with a combination of two, three and five-passenger transverse and longitudinal sets. The seats located in the wheelchair area are of a flip-

up and lock design. The center section of the five-passenger rear seat is designed to flip up to allow access to the engine and transmission compartments. All other seats are fixed and are supported by pedestals and the side wall seat rail. See "Fig. 17-2: Seating Layout" on page 8.




Fig. 17-2: Seating Layout



## 3.2. Inspection

Check the mounting hardware for tightness and security. Tighten or replace as required. Inspect seats for rips or tears. Repair, patch or replace as required.

## 3.3. Upholstery Maintenance

Vinyl or woven fabric upholstered seating must be kept clean to retain a neat appearance and ensure a lengthy service life.

In both appearance and wearability, best results are obtained if upholstery is cleaned at regular intervals before dirt, dust and grit have been ground into the vinyl or woven fabric.

Vacuuming is the only daily maintenance required. Periodically wash the upholstery, either with a mild household detergent or a foam upholstery cleaner.

If covers may be removed for cleaning, only dry cleaning is recommended since improper washing can cause shrinkage, thereby preventing the covers from being reapplied to the seats without damage.

## ™NOTE:

Refer to your New Flyer Parts Manual for breakdown lists of parts and assemblies if any seats are damaged and need to be repaired or replaced.

#### 3.3.1. Cleaning Vinyl

#### ™NOTE:

DO NOT use strong solvents as they will attack vinyl and plastic compositions.

- 1. Use household detergents with warm water and applied with a sponge or cloth. A soft bristle brush may be used after the soap has been applied to the surface.
- Stubborn or embedded dirt, use a nonabrasive cleaner.
- 3. Before the surface dries, wipe with a clean dry cloth to remove residue.
- After using a cleaning solvent, rinse the cleaned area with clear water and wipe with a clean dry cloth.



The fumes of cleaning fluids are flammable and harmful if inhaled. Ensure adequate ventilation is provided when using.

#### 3.3.1.1. Spot & Stain Removal

- Ink Can be removed sometimes by the use of alcohol.
- Paint, Shoe Polish & Tar Can be best removed by using Naphtha or Kerosene on a clean white cloth.
- ☐ Chewing Gum May be removed by first carefully scraping the surface and then the remaining gum should be removed by the use of Naphtha or Kerosene.



#### 3.3.2. Cleaning Woven Fabric

#### ™NOTE:

For spots and stains to avoid a ring formation, ALWAYS start outside of the stained area and work towards the center of the stained area with slow circular motion.

- Remove all dust and loose dirt from the fabric with a vacuum cleaner or a whisk broom.
- 2. Use household detergent worked into a thick foam or a foam upholstery cleaner and apply only the foam with a brush, sponge or Turkish towel.
- Cover a small area of the fabric with the cleaning foam, avoid soaking and rub vigorously.
- 4. Remove the cleaning foam with a clean brush, sponge or dampened cloth.
- 5. Allow the upholstery to dry, before returning the vehicle to service.

#### 3.3.2.1. Spot & Stain Removal

- ☐ Chewing Gum & Tar Moisten the gum or tar with kerosene or turpentine and work it off with a dull knife. Saturate a clean cloth with solvent and rub lightly to remove the remaining spot. If kerosene is used, wash stained area with warm soapy water afterwards.
- ☐ Lipstick, Grease, Oil & Shoe Polish Apply a small quantity of a commercial spot remover by means of a cloth and immediately press a blotter firmly on the spot. Repeat this process using a clean portion of the blotter, until blotter no longer shows stains.
- Candy, Ice Cream, Fruit Stains, Liquor & Wine, Soft Drinks - Use clear lukewarm

water and a clean cloth to soften. Scrape off loose material with a dull knife. If stain remains, rub with cloth or sponge soaked in a lukewarm foam cleaner. Remove foam with dampened cloth. After spot has dried, sponge soiled area with a cleaning solvent and rub with a clean dry cloth.

☐ Blood - Rub out spot with a clean cloth soaked in cool water. If spot remains, repeat the process using household ammonia and rinse with clean wet cloth.

## ™NOTE:

DO NOT use hot water or soapsuds on a blood stain. This will only set the stain.

- □ Vomit Stains Sponge the stained area with cleaning foam until the stain is removed. Remove cleaning foam with a clean damp cloth.
- ☐ Urine Stains Sponge stain with lukewarm cleaning foam applied with a clean cloth and rinse with cold water. Next, use a cloth to apply a mixture of one (1) part of household ammonia water and five (5) parts of water. Allow to remain for a minute, then rinse by rubbing with a clean, wet cloth.
- □ Ink Because inks differ in composition, it is impossible to find removers that are equally effective for all types of ink spots. For most ink spots it is necessary to try several methods. Sponge stain repeatedly with alcohol, benzene, acetone or amyl acetate. Then rub glycerin (use glycerin only with alcohol) into the stain and finally rinse out with solvent. If this does not remove the stain, let the stain dry, then wet with water and rub in a synthetic detergent to help soften the stain or soak in warm suds containing four (4) tablespoons of ammonia to a quart of water. Rinse with clean water and let dry.



## 4. STANCHIONS & GRABRAILS

## 4.1. Description

Vertical stanchions and horizontal grab rails are located along both sides of the aisle and provide support to standing passengers. Horizontal grab rails are also mounted transversely between the vertical stanchions and vehicle structure to provide additional support. The stanchions and

grabrails are constructed of tubular stainless steel and are attached to one another using cross fittings, tee fittings, and cup fittings.

The upper end of the vertical stanchion is fitted with a mounting plate that is bolted to an overhead support extrusion. The lower end of the vertical stanchion is bolted to the passenger seat frame or grab bar using a stanchion cup fitting. See "Fig. 17-3: Stanchions & Grabrails" on page 11.




Fig. 17-3: Stanchions & Grabrails



#### 4.2. Removal

#### ™NOTE:

Depending on the location of the vertical stanchion or horizontal grab rail, it may be necessary to remove the adjacent stanchion mounting hardware to allow enough movement when separating the components.

- 1. Remove the snap-in cover from around the top of the vertical stanchion.
- Remove the fasteners from the mounting plate that attaches the upper end of the stanchion to the overhead support extrusion. See "Fig. 17-4: Stanchion Upper Mounting" on page 12.
- Loosen the attaching hardware on the tee fitting or cross fitting that attaches the vertical stanchion to the horizontal grabrail. See "Fig. 17-5: Tee & Cross Fitting Connection" on page 12.
- 4. Remove the vertical stanchion and grabrail.

#### 4.3. Installation

- Dry fit all stanchion components together. Trim or make any adjustments necessary until proper stanchion and grab rail fit is achieved.
- Install the stanchions into their lower cups and install the fasteners to secure the top of the stanchion to the mounting plate in the support extrusion, but do not tighten at this time.
- 3. Join the stanchion to the grab rail, ensuring the parts are fully seated together.
- 4. Apply 1 to 2 drops of Loctite 242 and final tighten the upper mounting fasteners. Torque screws 60 to 72 in-lb.
- Reinstall snap-in cover trim around the top of the vertical stanchion.




Fig. 17-4: Stanchion Upper Mounting




Fig. 17-5: Tee & Cross Fitting Connection



## 5. WHEELCHAIR RESTRAINT SYSTEM

## 5.1. Description

The forward seat positions are equipped with a Wheelchair Restraint System for security of handicapped passengers. For optimum passenger safety be sure to follow the operating procedures to complete all the necessary restraint system connections. See "Fig. 17-6: Wheelchair Restraint System" on page 14.

## 5.2. Operation

#### 5.2.1. Positioning the Wheelchair

Position the wheelchair in the restraint area as follows:

- 1. Move the flip-up seat cushions up to the lock position.
- 2. Back the wheelchair into the restraint area, facing forward (facing driver's seat).
- 3. Set the wheelchair brakes.

#### 5.2.2. Rear Wheelchair Restraints

Attach the rear wheelchair restraint belts as follows:

- Pull the belt release handle and pull the belts to extend.
- 2. Attach the belt hooks around a solid rear frame member of the wheelchair.
- 3. Pull the belt release handle to take up belt slack.

#### 5.2.3. Front Wheelchair Restraints

Attach front wheelchair restraint belts as follows:

- Deploy the restraint arm assembly by pulling on the release knob and folding the arms down. Ensure that arms are locked into their respective detents.
- Press the retractor release button and pull the belts to extend.
- Attach the belt hooks around solid front frame members of the wheelchair.
- 4. Press the retractor release button again to take up the belt slack.
- 5. Turn the belt retractor knobs until tight.

#### 5.2.4. Passenger Securement



Restraints should not be held away from body by wheelchair components.

Secure wheelchair occupant as follows:

- Extend both ends of lap belt and connect together at occupant's hip area on aisle side. Do not place belt over armrest.
- Extend window-side shoulder belt and connect to stud on lap belt.
- 3. Ensure that belt clips and buckle are securely engaged.

#### 5.3. Maintenance

Refer to the Preventive Maintenance Section of this manual for scheduled inspections of the wheelchair restraint system.






Fig. 17-6: Wheelchair Restraint System



## **Destination Signs**

. DESTIN	IATION SIGNS	18-2
	scription	
	ntrol Console	
2.2.1.	Description	
2.2.2.	Operation	
	2.2.1. Reypad Switches	
2.2.3.	Removal	
2.2.4.	Installation	
2.2.5.	Testing	
_	nt Destination Sign	
2.3.1.	Description	
2.3.2.	Operation	
2.3.3.	Cleaning	
2.3.4.	Removal	
2.3.5.	Disassembly	
2.3.6.	Assembly	
2.3.7.	Installation	
2.4. Sid	e Destination Sign	
2.4.1.	Description	
2.4.2.	Operation	
2.4.3.	Removal	
2.4.4.	Installation	
2.4.5.	Testing	
	ır Route Sign	
2.5.1.	Description	
2.5.2.	Operation	
2.5.2. 2.5.3.	Removal	
2.5.4.	Installation	
2.5.5.	Testing	
. VENDO	R SERVICE INFORMATION	18-10
3.1 Twi	nVision Manual	







## 1. SAFETY

## 1.1. Safety Procedures

This section of the service manual contains procedures which require the mechanics to strictly observe safety procedures in order to ensure personal and equipment safety.

Certain procedures may require the vehicle be operated in an elevated position in order to accurately troubleshoot and diagnose a problem. If the vehicle must be running while elevated, become familiar with the repair area prior to starting the engine. Take special care in noting areas which will

become hot, electrically energized, and areas where moving and rotating components are located. Limit the work in these areas as personal and equipment safety is at risk.

During electrical diagnosis procedures an understanding of the vehicle's electric circuits is important to anticipate the results of connecting test equipment. During component removal or installation, ensure the Battery Disconnect switch is in the OFF position.

Failure to follow this procedure may result in personal injury or component failure.



## 2. DESTINATION SIGNS

## 2.1. Description

The Destination Sign System consists of:

- ☐ electronic front and side destination signs
- rear route sign
- control console and associated wiring harnesses and connectors.

#### ™NOTE:

New Flyer has included the Vendor Service Manual to aid in repair and trouble-shooting of the electronic sign. Refer to 3. "VENDOR SERVICE INFORMATION" on page 10 in this section for applicable references.

We have included the installation drawings and general system layout to aid the mechanic. Refer to your New Flyer Parts Manual for further part or assembly breakdown assistance.

## 2.2. Control Console

#### 2.2.1. Description

This control console is easily mastered and is used as a central unit to control all automatic signs. It is located on the driver's overhead panel.

## ™NOTE:

The following information provides basic introductory information on primary control console and TwinVision destination sign programming and functioning.

Your transit company management establishes policies about programming destination sign information messages and their required codes.

Manuals are available for the TwinVision

Destination Sign System providing more detailed operating information. Discuss any further information needs with your Supervisory/Management group.

The control console controls and verifies the destination sign message/route display. The console is located in the driver's overhead panel.

Destination sign message codes are entered into the system data processor using the keypad switches on the front panel of the control console. The code is translated into message writing data stored in memory by the console and used to display information on the destination and route signs.

This message writing data from the system data processor is stored in memory until updated from the system data processor or the system is powered down. Powering-down occurs when the Master Run switch is switched off from the DAY-RUN, NIGHT-RUN or NIGHT-PARK position.

#### 2.2.2. Operation

Basic operation of the sign system involves presetting transit authority message codes into the sign system using the controller unit keypad switches. The message codes correlate to pre-programmed destination names, public relations messages, and route numbers unique to each transit authority. If required, multiple sets of message codes may be entered to allow for a quick and complete sign change while in route.



#### 2.2.2.1. Keypad Switches

The control unit contains 28 Keypad switches. Certain Keypad switches, or groups, may not function if they are not needed for coded entry procedures. Switches that are not enabled either have no effect when pressed, or indicate that particular function is not available. Keypad switch functions are as follows: See "Fig. 18-1: Control Console" on page 3.

- P/R press to enable public relations message code entry.
- □ ROUTE press to enable route number entry. Route number entry may be either coded or be the actual route number for display.
- □ DEST A, DEST B press the appropriate key (A or B) to enable destination message code entry and/or message display change.

- 0-9 Group these keys are used to select a specific listing in the Transit Authority destination listing.
- ☐ A-F Group key switches are for sequential entering of message codes that contain letters and numbers.
- ☐ ENTER press to activate the selected message during code entry and during operation.
- MENU this is used as part of a sequence to upload destination/public relations information to the sign system.

#### ™NOTE:

Code entry sequences must be followed to set-up destination sign messages. A "beep" sounds and a visual read-out appears on the display when pressing any enabled key switch.




Fig. 18-1: Control Console



#### 2.2.2.2. Code Entry

When powering-up the sign system it will display the messages entered previously. If continuing on the same route, re-entering new codes may not be required.

To enter a new set of message codes:

- 1. Consult the transit authority code list for the code that corresponds to your route.
- 2. Press the switch DEST A, DEST B, P/R, or ROUTE for the message code you are about to enter.
- For each code press the corresponding switches in the 0 though 9 and/or A through F groupings one at a time and in proper sequence.
- Press the ENTER key switch and allow the controller unit to display the actual message.
- Repeat steps 1 to 4 for each code required for the route.

To change from one preset message to another for a turn-around or while in route press the appropriate DEST A or DEST B switch.

#### 2.2.3. Removal

 Set the Battery Disconnect switch to the OFF position.

- Using a Phillips screwdriver, loosen the two front bezel screws. As each screw turns, the threaded cam latch behind the panel will turn to release its grip.
- When both screws are loose, remove the control console from the panel and disconnect the wiring at the rear.

#### ™NOTE:

Ensure the wiring is secured and does not fall out of reach behind the panel.

#### 2.2.4. Installation

- Set the Battery Disconnect switch to the OFF position.
- Connect the wires to the rear of the control console.
- 3. Attach the control console to the access panel using the two retaining screws.
- Close and secure the panel and set the Battery Disconnect switch to the ON position.

#### 2.2.5. Testing

Test the system. Refer to the TwinVision Service Manual for procedure.

#### ™NOTE:

Refer to 3. "VENDOR SERVICE INFOR-MATION" on page 10 in this section for further maintenance information.



## 2.3. Front Destination Sign

#### 2.3.1. Description

The front destination sign is located in front of the vehicle above the windshield. It is driver controlled from the control unit located in the driver's overhead panel. The front destination sign compartment can be accessed from the interior of the vehicle through a hinged access door.

#### 2.3.2. Operation

Refer to 2.2. "Control Console" on page 2 in this section for information on front destination sign operation.



Disconnect power to the sign system before performing any maintenance or repair. Discharge and ground the circuit before working on it. Follow electrostatic charge prevention practices by using a wrist ground strap or anti-static grounded floor mat while handling any printed wiring assembly (PWA).

#### 2.3.3. Cleaning

1. Set Battery Disconnect switch to the OFF position.

- 2. Open front destination sign access door.
- Loosen the clamps on the shock pad pivots and rotate the sign assembly 90° towards you.



DO NOT use cleansers, solvents, rags, or brushes that may scratch or damage plastic surfaces and seals.

- 4. Clean sign assembly using compressed air, vacuum, or a clean soft cloth.
- Rotate sign assembly to vertical position and lock in place by tightening clamps on shock pad pivots.

#### 2.3.4. Removal

- 1. Set Battery Disconnect switch to the OFF position.
- 2. Open front destination sign access door.
- 3. Disconnect vehicle wiring harness from sign.
- Remove two nuts and washers from either end of the mounting support bar. See "Fig. 18-2: Front Destination Sign Installation" on page 6.
- 5. Lift sign assembly off mounting studs and remove through access door.






Fig. 18-2: Front Destination Sign Installation

#### 2.3.5. Disassembly

- 1. Unplug the two wiring connectors from the power supply/data controller board.
- 2. Disconnect the power/data cable from the four display boards.
- Remove each display board or power supply/data controller board by removing the two retaining nuts. Remove board assembly from support bar.
- 4. Disassemble the support bar assembly as follows:
  - Loosen the clamps on the shock pad pivot and remove the shock pads from either end of the support bar.
  - b. Remove the three screws and remove the end pivot from either end of the support bar.
  - c. Slide the T-bolt bars out from the support bar.





#### 2.3.6. Assembly

- Assemble the support bar assembly as follows:
  - Insert the T-bolt bars into the support bar. The short T-bolt bar is located at the power supply end of the support bar.
  - Install the end pivots at either end of the support bar and secure with three screws.
  - Assemble the shock pad pivot and pivot mount onto each end of the support bar assembly.
  - d. Tighten shock pad pivot clamps, ensuring head of bolt is facing towards the rear of the vehicle.
- 2. Install the four display boards and the power supply/data controller board using two retaining nuts for each board.

## MOTE:

If necessary, loosen the clamps on the end of the support bar assembly and adjust the sign display boards to the vertical position. Tighten clamps.

- 3. Connect power/data cable to the four display boards.
- 4. Plug the two wire connectors into the power supply/data controller board.

#### 2.3.7. Installation

- Align sign assembly mounts over the studs in the destination sign compartment. Secure with nuts and washers.
- 2. Connect vehicle wiring harness to sign.
- Set Battery Disconnect switch to ON position.
- 4. Test destination sign operation.



## 2.4. Side Destination Sign

#### 2.4.1. Description

The side destination sign is located on the curbside, of the vehicle, in the upper portion of the first window of the vehicle. It is an LED type of sign, making the sign easily visible, even in bright sunshine. The sign is operator controlled from an operator display keyboard located on the destination sign access door.

## 2.4.2. Operation

Refer to 2.2. "Control Console" on page 2 in this section for the side destination sign operation.

#### 2.4.3. Removal

 Set the Battery Disconnect switch to the OFF position.

- 2. Disconnect the electrical connections to the sign, and tag for reinstallation. See "Fig. 18-3: Side Destination Sign Installation" on page 8.
- 3. Remove the retaining screws holding the sign in place and remove the sign.

#### 2.4.4. Installation

- 1. Secure the sign in place, using the retaining screws.
- 2. Reconnect the electrical connection.
- 3. Set the Battery Disconnect switch to the ON position.

#### **2.4.5.** Testing

Test the sign. Refer to the Twinvision Service Manual for procedure.




Fig. 18-3: Side Destination Sign Installation



## 2.5. Rear Route Sign

#### 2.5.1. Description

The rear route sign is installed in the curbside rear crown grille panel. It is an LED sign. See "Fig. 18-4: Rear Route Sign Installation" on page 9.

## 2.5.2. Operation

Refer to 2.2. "Control Console" on page 2 in this section for the rear route sign operation.

#### 2.5.3. Removal

- 1. Set the Battery Disconnect switch to the OFF position.
- Open the HVAC access door and disconnect the electrical connector from the sign.

- 3. Remove the mounting screws which retain the sign.
- 4. Remove the sign from the vehicle.

#### 2.5.4. Installation

- 1. Set the Battery Disconnect switch to the OFF position.
- 2. Apply Loctite 242 to screw threads and secure the sign with the mounting screws.
- 3. Attach the electrical connector.
- 4. Set the Battery Disconnect switch to the ON position

## 2.5.5. **Testing**

Test the sign. Refer to 3. "VENDOR SER-VICE INFORMATION" on page 10 in this section for sign testing information.




Fig. 18-4: Rear Route Sign Installation



# 3. VENDOR SERVICE INFORMATION

The following supplier manuals contain additional reference information.

## 3.1. TwinVision Manual

☐ Operation & Maintenance Manual



## **Driver's Controls**

1.	SAFETY	<i>/</i>	19-1
	1.1. Safe	ty Procedures	19-1
2.	INSTRU	MENTATION & CONTROLS	19-2
		rument Panel	
	2.1.1.	Turn Indicators (Green)	
	2.1.2.	Stop Request Indicator (Red)	
	2.1.3.	W/C Stop Request Indicator (Amber)	
	2.1.4.	Rear Door Open Indicator (Red)	
	2.1.5.	Low Fuel Indicator (Amber)	
	2.1.6.	A/C Fail Indicator (Red)	
	2.1.7.	Diesel Exhaust Fluid (DEF) Indicator (Amber)	
	2.1.8.	Hot Engine Indicator (Red)	
	2.1.9.	Stop Engine Indicator (Red)	
	2.1.10.	Check Engine Indicator (Amber)	
		ABS Fail Indicator (Amber)	
		Parking Brake Indicator (Red)	
		Exhaust Regen Needed Indicator (Amber)	
		High Exhaust Temp Indicator (Amber)	
		Exhaust Malfunction Indicator (Amber)	
	2.1.16.	Engine Fan Fault (Amber)	19-6
	2.1.17.	Stop Lights Indicator (Red)	19-6
	2.1.18.	Retarder Off Indicator (Red)	19-6
	2.1.19.	Low Oil Indicator (Red)	19-6
	2.1.20.	No Gen Indicator (Red)	19-7
	2.1.21.	Low Coolant Indicator (Amber)	19-7
	2.1.22.	Exclamation Symbol (Red or Amber)	19-7
	2.1.23.	Kneel Indicator (Amber)	19-7
	2.1.24.	W/C Ramp Indicator (Red)	19-7
	2.1.25.	Wait to Start Indicator (Amber)	19-7
	2.1.26.	High Beam Indicator (Blue)	19-7
	2.1.27.	Mode Button	19-7
	2.1.28.	Enter Button	19-8
		Air Pressure Gauges	
	2.1.30.	Speedometer	19-8
		Message Display Screen	
		.31.1.Function Readout Display	
		.31.2.Text Messages	
		Odometer/Hourmeter Display Screen	
		DMAS Display	
	2.1.34.	Shift Selector Operation	19-13



	312	Removal	
	3.1.1.	Description	
3.1	. Inst	ument Panel	19-27
IN	ISTRU	MENT REPAIRS	19-27
		Entrance Door Manual Control Valve	
		Exhaust Filter Switch	
		ABS Switch	
	2.5.1.	Door Master Switch	
0	2.5.1.	Retarder Switch	
2.5		cellaneous Controls	
	2.4.5.	<u> </u>	
	2.4.4.	Turn Signal Switches	
	2.4.3.	Headlight Dimmer Switch	
	2.4.1.	Accelerator Treadle	
•	2.4.1.	Brake Treadle	
2.4		Operated Controls	
		Climate Control Switch	
		Silent Alarm Switch	
		Dash Fan Speed Switch	
		Driver's Light Switch	
		Stop Engine Override Switch	
		Start Push Button	
		Four-Way Hazard Lights Switch	
		Parking Brake Control Valve  Emergency Brake Release Control Valve	
		Mirror Heater Button	
	2.3.9.	Remote Mirror Control Switches	
	2.3.8.	Door Controller	
	2.3.7.	Master Run Switch	
	2.3.6.	Hazard Lights Switch Indicator	
	2.3.5.	Speaker Select Switch	
	2.3.4.	Idle Speed Switch	
	2.3.3.	Aisle Lights Switch	
	2.3.2.	Camera Event Marker	
	2.3.1.	Public Address Switch	
2.3	. Side	Console Switch Panel	
	2.2.5.	Driver's Floor Heat	
	2.2.4.	Driver's Vent	
	2.2.3.	Defroster Temperature Control	
	2.2.2.	Defroster Air Recirculation Control	19-15
	2.2.1.	Defroster Fan Control	19-15
2.2	. Driv	er's Climate Controls	19-15
	2.1.38.	Panel Lights Dimmer Switch	19-14
	2.1.37.	Wiper/Washer Controls	19-14
		Kneel Switch	
	2.1.35.	Hamp Switch	19-13

3.



	3.1.3.	Disassembly	19-28
	3.1.4.	Disassembly	19-28
	3.1.5.	Installation	19-28
	3.2. Side	e Console	19-29
		Description	
		Operation	
	3.2.3.	Maintenance	19-30
	3.	.2.3.1. Toggle Switch Replacement	19-30
	3.	.2.3.2. Dial Switch Removal	19-3
4.	ACCEL	ERATOR CONTROL	19-32
	4.1. Des	scription	19-32
		eaning & Lubrication	
		tentiometer Replacement	
5.	STEER	ING & HORN	19-34
	51 Des	scrintion	19-3/





## 1. SAFETY

## 1.1. Safety Procedures

This section of the service manual contains procedures which require the mechanics to strictly observe safety procedures in order to ensure personal and equipment safety.

Always ensure that the vehicle is appropriately hoisted and blocked for procedures which require elevating the vehicle. Be aware of the limitations of the blocking equipment, and always ensure that the jarring and shaking created by component removal and installation procedures does not overload the blocks, or cause the vehicle to become unstable.

Certain procedures may require the vehicle be operated in an elevated position in order to accurately troubleshoot and diagnose a problem. If the vehicle must be running while elevated, become familiar with the repair area prior to starting the engine. Take special care in noting areas which will become hot, electrically energized, and areas where moving and rotating components are located. Limit the work in these areas as personal and equipment safety is at risk.

For procedures which involve air lines, ensure the line is safely depressurized prior to disconnecting. Disconnecting pressurized lines will cause solid particles deposited in the line to be uncontrollably propelled, and will also cause the hose end to whip randomly as the air escapes.

During electrical diagnosis procedures an understanding of the vehicle's electric circuits is important to anticipate the results of connecting test equipment. During component removal or installation, ensure the Battery Disconnect switch is in the OFF position.

Failure to follow this procedure may result in personal injury or component failure.

Observe the following procedures involving hydraulic line removal.

- Hydraulic fluid is corrosive and should not be exposed to skin for extensive periods of time.
- Wear eye protection at all times.
- Pressurized lines should not be disconnected until the pressure is safely and controllably released.



# 2. INSTRUMENTATION & CONTROLS

## 2.1. Instrument Panel

The instrument panel is located directly in front of the driver and provides a visual display of the vehicle operating systems as well as providing controls for the various systems. The instrument panel cluster is a programmable electronic unit with diagnostic capabilities. See "Fig. 19-1: Instrument Panel" on page 3.



#### 2.1.1.Turn Indicators (Green)



If turn signal indicators do not operate as described, DO NOT OPERATE THE VEHICLE.

The turn indicators, symbolized by directional arrows, flash on either side of the instrument panel when the right-hand or left-hand floor-mounted turn signal switch is pressed.

When the Hazard switch is activated, both turn indicators flash together. Failure of these lights to flash normally indicates that the flasher module is not functioning.



#### 2.1.2.Stop Request Indicator (Red)

The Stop Request indicator illuminates when the passenger signal system has been activated.



## 2.1.3.W/C Stop Request Indicator (Amber)

The Wheelchair Stop Request indicator illuminates when the wheelchair passenger signal system has been activated.



## 2.1.4.Rear Door Open Indicator (Red)

The Rear Door Open indicator illuminates when the door controller is turned to position #3, #4 or #5 and the exit door opens.



## 2.1.5.Low Fuel Indicator (Amber)

The Low Fuel indicator illuminates when the natural gas pressure in the tanks drops to 500 psi and is no longer sufficient for continued reliable vehicle operation.



## 2.1.6.A/C Fail Indicator (Red)

The A/C Fail indicator illuminates if the heating, ventilating and air conditioning (HVAC) unit malfunctions.



## 2.1.7.Diesel Exhaust Fluid (DEF) Indicator (Amber)

The DEF symbol will illuminate to indicate that the fluid level in the tank is low and needs to be refilled.



## 2.1.8.Hot Engine Indicator (Red)

The Hot Engine indicator will illuminate if the engine exceeds its normal operating temperature and overheats. The Hot Engine indicator is accompanied by a warning buzzer.

#### ™NOTE:

If this indicator remains illuminated, the Engine Protection System engages, initiating an automatic engine shutdown sequence.






Fig. 19-1: Instrument Panel





## 2.1.9.Stop Engine Indicator (Red)

The Stop Engine indicator illuminates if an engine operating condition occurs that will result in damage to the engine. The indicator is controlled by the vehicle's Multiplexing System which monitors engine sensor output. If the Multiplexing System illuminates the indicator it also initiates an engine shut-down sequence.

As an operation check, the Stop Engine indicator should remain illuminated momentarily when the engine is started.

## ™NOTE:

If this indicator remains illuminated, the engine will continue running for 30 seconds. Use the time to drive out of traffic to a safe area.



## 2.1.10.Check Engine Indicator (Amber)



If after engine start-up the Check Engine indicator remains illuminated, advise service personnel. Avoid extended periods of operation with this indicator illuminated. The Check Engine indicator illuminates if the engine requires service. The indicator is controlled by the vehicle's Multiplexing System which monitors engine sensor output. The Multiplexing System will illuminate the indicator if sensor output signals fall outside of a predetermined range.



### 2.1.11.ABS Fail Indicator (Amber)

The ABS Fail indicator illuminates if the ABS System requires service. Engine start-up illuminates the indicator momentarily as part of a system check. It is also used during diagnostics to display the blink code.



## 2.1.12.Parking Brake Indicator (Red)

The parking brake indicator, symbolized by a circled letter "P" illuminates when the parking brake control valve is applied. Activating the parking brake illuminates the stop lights indicator and all red stop lamps.





## 2.1.13.Exhaust Regen Needed Indicator (Amber)

This indicator will either illuminate steady or flash and may illuminate in combination with the Check Engine

indicator to indicate the various stages of soot buildup in the muffler particulate filter. Refer to the following chart for a description of various conditions and actions required when this indicator illuminates.

EXHAUST REGEN NEEDED INDICATOR FUNCTION						
DPF Soot Level	Exhaust Regen Needed Indicator	Check Engine Indicator	Stop Engine Indicator	Engine Derate	Procedure	
Low to Medium	On	Off	Off	None	Increase vehicle duty cycle to allow mobile active regeneration.	
Medium to High	Flashing	Off	Off	None	Increase vehicle duty cycle to allow mobile active regeneration.	
High	Flashing	On	Off	Derate (Note 1)	Perform stationary regeneration (Note 3)	
Severe	Off	Off	On	Severe Derate (Note 2)	Stop engine at earliest opportunity. (Note 3)	

Note 1: Moderate derate of engine torque. Note 2: Severe derate or engine speed.

Note 3: Stationary regeneration will be disabled.





## 2.1.14.High Exhaust Temp Indicator (Amber)



If the High Exhaust Temp indicator on the instrument panel illuminates, ensure the exhaust outlet is not located where it could cause damage to persons or any materials which could melt or explode, and that nothing is within 2 feet of the outlet. Ensure no combustible materials are within 5 feet of the outlet. Exhaust outlet temperatures can reach 1500°F (800°C) when this indicator illuminates.

The High Exhaust Temp indicator illuminates during the regeneration process when exhaust temperatures are high.

### ™NOTE:

Illumination of this indicator does not signify the need for any kind of vehicle or engine service.



## 2.1.15.Exhaust Malfunction Indicator (Amber)

The Exhaust Malfunction indicator will illuminate when a malfunction related to the Emissions Control System is detected.



#### 2.1.16.Engine Fan Fault (Amber)

The Engine Fan Fault indicator will illuminate if a fault is detected with the electronically-controlled radiator cooling fans.



#### 2.1.17.Stop Lights Indicator (Red)



If the stop lights indicator does not operate as described, DO NOT OPER-ATE THE VEHICLE.

The stop lights indicator, symbolized by a circled letter S, illuminates each time the service brake or parking brake control valve is applied. If under these circumstances the indicator does not illuminate, then any or all rear stop lights are malfunctioning.



#### 2.1.18.Retarder Off Indicator (Red)

The Retarder Off indicator illuminates to indicate that the Retarder switch is in the OFF position disconnecting power from the transmission retarder.



### 2.1.19.Low Oil Indicator (Red)



If the Low Oil alarm continues and the indicator lamp remains illuminated, DO NOT OPERATE THE VEHICLE.

The Low Oil indicator illuminates if the engine oil pressure is too low for proper engine lubrication. The Low Oil indicator is accompanied by a warning buzzer.

Before starting the engine, positioning the Master Run switch to DAY-RUN or NIGHT-RUN illuminates the Low Oil indicator and sounds its alarm. This occurs momentarily and is a normal electrical system test.

## ™NOTE:

If this indicator remains illuminated, the Engine Protection System engages to initiate an automatic engine shutdown sequence.





#### 2.1.20.No Gen Indicator (Red)



If the no gen indicator remains illuminated while the engine is operating, DO NOT OPERATE THE VEHICLE.

The no gen indicator, symbolized by a battery, illuminates when the alternator is not charging. The no gen indicator illuminates when the Master Run switch is in the DAY-RUN or NIGHT-RUN position and the engine is not operating. The no gen indicator turns off once the engine is operating.



## 2.1.21.Low Coolant Indicator (Amber)

The Low Coolant indicator illuminates if too little coolant is in the engine to maintain normal engine operating temperature.

## ™NOTE:

If this indicator remains illuminated, the Engine Protection System engages to initiate an automatic engine shutdown sequence.



## 2.1.22.Exclamation Symbol (Red or Amber)

The Exclamation Symbol will illuminate when a text message tell tale appears in the Message Display Screen. The color of the exclamation symbol will change to match the message currently being displayed on the screen.



#### 2.1.23.Kneel Indicator (Amber)

The Kneel indicator illuminates when the front suspension is in the kneeling mode and is lowering the vehicle to the curb.

## ™NOTE:

The Kneel toggle switch is located on the instrument panel.



## 2.1.24.W/C Ramp Indicator (Red)

The Wheelchair Ramp indicator illuminates to indicate operation of the wheelchair ramp.

### ™NOTE:

The Ramp toggle switch is on the instrument panel.



## 2.1.25.Wait to Start Indicator (Amber)

The Wait to Start indicator illuminates before engine start-up with the Master Run switch in the DAY-RUN or NIGHT-RUN position. The indicator will remain illuminated for up to 45 seconds while the intake air heater system operates.

## ™NOTE:

The Wait to Start indicator and the intake air heater system will only operate in temperatures below 66°F (19°C).



## 2.1.26. High Beam Indicator (Blue)

The high beam indicator, symbolized by a lit headlight, illuminates when the vehicle headlights are in the high beam mode of operation. Pressing the dimmer switch returns the headlights to normal low beam operation.



#### 2.1.27.Mode Button

The Mode button is used primarily to navigate between the Message Display Screen and the Odometer/Hourmeter Display Screen and to navigate through the menus and select various options available on the selected screen. The button function is dependent on the length of time it is pressed. Refer to 2.1.31. "Message Display Screen" on page 8 and Refer to 2.1.32. "Odometer/Hourmeter Display Screen" on page 11 in this section for information on the operation of this button.





#### 2.1.28.Enter Button

The Enter button is used to navigate through the menus on the Message Display Screen and to switch screen formats on the Functional Readout Screen, The Enter button can also be used to reset the tripmeters on the Odometer Display Screen. The button function is dependent on the length of time it is pressed. Refer to 2.1.31. "Message Display Screen" on page 8 and Refer to 2.1.32. "Odometer/Hourmeter Display Screen" on page 11 in this section for information on the operation of this button.



## 2.1.29.Air Pressure Gauges

Individual analog air pressure gauges are used to monitor the vehicle's front and rear air brake systems. An LED indicator at the bot-

tom of the gauge illuminates and a warning buzzer sounds if air pressure drops below 75 psi (517 kPa). If air pressure exceeds the normal operating range, the LED indicator will flash. Normal operating pressure range is 117 to 131 psi (807 to 903 kPa).



### 2.1.30.Speedometer

This gauge indicates the vehicle's forward speed. The speedometer will initialize as soon as the Master Run switch is set to the DAY-RUN or NIGHT-RUN position.

During this self-test process the gauge will sweep full scale and then return to the zero point.

## ™NOTE:

Refer to 2.1.32. "Odometer/Hourmeter Display Screen" on page 11 in this section for information on the odometer.

## 2.1.31. Message Display Screen

The larger of the two LCD screens is located between the air pressure gauges and is used to display text messages to warn the driver of potential problems. The screen will change color, from blue to amber to red, depending on the severity of the warning message.

The message display screen has four separate menus. Navigate through the menus by performing a long press (over 3 seconds) on the ENTER button.

- ☐ Function Readout (default screen) change the readout between bar graph and digital using a short press (1 to 3 seconds) on the ENTER button.
- Active LCD Tell Tale Overview this screen displays a list of the active tell tale messages.
- ☐ IP Software Version this screen displays the IP software version, configuration file label, and routing table label.
- VMM Query this screen displays the application and ladder logic version of the VMM multiplexing modules on the vehicle.

#### ™NOTE:

There are no operator navigable or resettable features in the IP Software Version or VMM Query screens.

Perform a long press (greater than 3 seconds) on the MODE button to navigate between the Message Display Screen and the Odometer/Hourmeter Display Screen. If the Odometer/Hourmeter Display Screen has been selected, then an arrow pointing to it will appear in the lower right-hand corner of the Message Display Screen.



## 2.1.31.1.Function Readout Display

- Diesel Exhaust Fluid Level displayed on a bar graph as percentage of fluid remaining in the tank. See "Fig. 19-2: Function Readout" on page 9.
- □ Voltmeter (12V) the voltmeter indicates the voltage levels in the vehicle's 12 volt
- electrical system. The normal operating range is between 11 and 14 volts.
- □ Voltmeter (24V) the voltmeter indicates the voltage levels in the vehicle's 24 volt electrical system. The normal operating range is between 24 and 28.5 volts.




Fig. 19-2: Function Readout



## 2.1.31.2.Text Messages

- □ RH Headlight Fault (Amber) The RH Headlight Fault message will appear on the LCD screen to indicate a fault with a low beam headlight.
- RH Turn Fault (Amber) The RH Turn Fault message will appear on the LCD screen to indicate a fault with the right-hand turn light.
- ☐ LH Headlight Fault (Amber) The LH Headlight Fault message will appear on the LCD screen to indicate a fault with the low beam headlight.
- ☐ LH Turn Fault (Amber) The LH Turn Fault message will appear on the LCD screen to indicate a fault with the left-hand turn light.
- □ Hot Trans (Red) The Hot Trans message will advise that the oil in the transmission exceeds the maximum rated operating temperature. Immediately move the vehicle to a safe area and shut down the system.
- □ Starter Lockout (Amber) This message will appear if an attempt is made to reengage the starter within four seconds of a previous starter engagement. Allow four seconds to elapse before attempting to reengage the starter.
- Kneel Snsr Fault (Amber) This message will appear if the kneeling sensors malfunction during the kneeling process.

- Stop Lamp Fault (Red) This message will appear on the LCD screen and the buzzer will sound to indicate a fault with a stop lamp circuit.
- ☐ Tail Lamp Fault (Amber) This message will appear on the LCD screen to indicate a fault with a tail lamp circuit.
- Ext Lamp Fault (Amber) This message will appear on the LCD screen to indicate a fault with an exterior lamp circuit.
- Interlock (Red) The interlock message appears when the interlock system applies the brake interlocks. The message disappears when the interlock system releases.

## ™NOTE:

Refer to 2.4. "Foot Operated Controls" on page 24 in this section for information on the brake treadle and interlock operation.

- ☐ CLNT Fill Mode (Red) This message will appear on the LCD screen to indicate that the coolant fill mode is active.
- ☐ Check Trans (Amber) The Check Trans message will appear if the transmission electronics has detected a potentially serious problem in the transmission. If this message appears, DO NOT OPERATE THE VEHICLE.
- □ Seat Belt (Red) This message appears on the LCD screen and a buzzer sounds when the driver's seat belt is not buckled and the engine is running.



## 2.1.32. Odometer/Hourmeter Display Screen

The smaller of the two LCD screens is located directly below the speedometer and contains the odometer, two trip odometers and an engine hour meter. The display screen has four separate menus. Navigate through the menus by performing a quick press (less than 1/2 second) on the MODE button. See "Fig. 19-3: Odometer/Hourmeter Display Screen Options" on page 11.

## ™NOTE:

The trip odometers can be reset by navigating to the appropriate screen with the MODE button, and then performing a short press (1 to 3 seconds) on the ENTER button.

Perform a long press (greater than 3 seconds) on the MODE button to navigate between the Message Display Screen and the Odometer/Hourmeter Display Screen.




Fig. 19-3: Odometer/Hourmeter Display Screen Options



## 2.1.33. DMAS Display

The Driver Maneuver Awareness System (DMAS) provides the driver with visual feedback as to whether he/she is operating the vehicle within acceptable driving limits. The display consists of five LED indicators that will illuminate in response to the severity of the driving parameter being exceeded. These driving parameters include acceleration, braking, and turning. See "Fig. 19-4: DMAS Display" on page 12.

The function of the LED indicators is as follows:

- ☐ The small round white indicator at the base of the display indicates that a problem exists with the system.
- ☐ The blue LED indicates that power is on and the system is functioning properly.
- ☐ The green LED indicates vehicle operation within normal limits.
- ☐ The amber, orange, and red LED's indicate the degree to which the vehicle is being operated outside acceptable limits.




Fig. 19-4: DMAS Display



## 2.1.34. Shift Selector Operation



If you leave the vehicle and the engine is running, the vehicle can move suddenly and you or others could be injured. If you must leave the engine running, do not leave the vehicle until you put the transmission in NEUTRAL, and ensure that the engine is at low idle, and apply the park brake and emergency brakes and make sure they are properly engaged, and chock the wheels and take any other steps necessary to keep the vehicle from moving.

The vehicle service brakes, park brake, or emergency brake must be applied whenever NEUTRAL is selected to prevent unexpected vehicle movement. Selecting NEUTRAL does not apply the vehicle brakes.

- ☐ [R] REVERSE selects Reverse gear.
- □ [N] NEUTRAL selects Neutral. The area around the [N] button is a raised ridge so the driver can identify the pushbuttons by touch, without looking at the display. It is not necessary to press this button prior to starting the vehicle.
- D DRIVE selects the highest available forward range. The transmission shifts to the starting gear and will automatically upshift through the gears, as operating conditions permit, until the highest available gear is attained.
- □ UPSHIFT and DOWNSHIFT Arrow Buttons these buttons are used to change the range selected to a higher or lower forward range:
  - One press of the DOWNSHIFT button sets range SELECT to the same range as the current range attained, shown in the MONITOR position on the display. This is referred to as Express Preselect.
  - ☐ Each subsequent press of the DOWN-SHIFT button decreases the range selected by one range.
  - One press of the UPSHIFT button increases the range selected by one range.

- ☐ If the UPSHIFT or DOWNSHIFT button is held continuously, the selected range will continue to change up or down until the button is released or until the highest or lowest possible range of gears is selected.
- MODE Button pressing the MODE button invokes a secondary shift schedule or a special operating function. Pressing the MODE button also toggles to the next Diagnostic Trouble Code (DTC) while in the DTC display mode. And it clears active and inactive DTCs from the ECU memory.
- □ Select & Monitor during normal operation with [D] Drive selected, the SELECT section of the display shows the highest attainable forward range for the shift schedule in use. The MONITOR section displays the gear range that has been commanded in the transmission. Reverse [R] and Neutral [N] are likewise displayed when appropriately selected and in use. The display of any other character in the SELECT or MONITOR section denotes a nonstandard operating condition.

#### 2.1.35. Ramp Switch



The Ramp toggle switch is a momentary type. If pressure is removed, the switch returns to the center FLOAT position and operation ceases.

This is a three-position switch that controls the wheelchair ramp.

#### **DEPLOY**

This position activates the ramp from the closed position to the open position.

#### **FLOAT**

This position shuts off power to the pump, allowing the ramp to free-fall to either the open or the closed position. Upon cycle completion this becomes an off position.

#### **STOW**

This position is used to move the ramp from the open to the closed position.



#### 2.1.36. Kneel Switch



When placed in the RAISE position, the Kneel toggle switch will latch and continue to raise the vehicle until full ride height is reached at which point the raising action will automatically stop. In order to interrupt the raising operation during its cycle, the toggle switch must be set to the HOLD position.

This three-position momentary switch is used to operate the vehicle's kneeling system. The kneeling system lowers the front of the vehicle approximately 3 to 4 inches by exhausting air from both front suspension air springs. Boarding the vehicle becomes easier, particularly for small children and the handicapped.

#### LOWER

This position lowers the vehicle, activating the interlocks, the audible alarm and the exterior warning light. The instrument panel Kneel indicator also illuminates.

#### ™NOTE:

The Kneel toggle switch is a momentary spring loaded switch that will operate in the LOWER position only as long as pressure on the switch is maintained.

### **RAISE**

This position raises the vehicle automatically to its full ride height. Once the vehicle has reached normal ride height, the interlocks will release (with doors closed), the alarm will silence and the exterior warning light and Kneel indicator will both extinguish.

## ™NOTE:

Closing the switch guard locks the switch in the RAISE position.

#### HOLD

During the kneeling cycle, this position stops kneeling operations, silences the alarms and extinguishes the exterior warning light. The Kneel indicator and the interlocks remain activated.

## 2.1.37. Wiper/Washer Controls

The wiper control switch operates the lefthand and right-hand wiper motors. Rotating the control knob through the intermittent range will vary the delay of the wiper sweep for differing rain conditions. In the low or high position the wipers operate at fixed speeds. Pushing down on the knob operates the windshield washer pump to spray fluid onto the windshield.

## RNOTE:

The windshield washer bottle filler is located near the side console.

#### 2.1.38. Panel Lights Dimmer Switch

The Panel Lights Dimmer switch controls the brightness of the instrument panel lighting. Rotating the dimmer knob clockwise increases the brightness and counterclockwise decreases the brightness of the panel lights.



## 2.2. Driver's Climate Controls

See "Fig. 19-5: Driver's Area Climate Controls" on page 15.

#### 2.2.1. Defroster Fan Control

The defroster Fan knob on the instrument panel controls the speed of the driver's heater/defroster fan. Turning the knob from the extreme left (OFF position) to the right provides variable fan speed settings.

#### 2.2.2. Defroster Air Recirculation Control

The Air knob on the instrument panel controls the amount of fresh air circulated through the driver's heater/defroster system. This knob can be set to recirculate all or a portion of air entering the heater compartment and admit a corresponding amount of fresh air.

## 2.2.3. Defroster Temperature Control

The Temp knob on the instrument panel controls the temperature of the air blowing from the defroster. Turn the knob from left to right to decrease temperature and from right to left to increase temperature.

#### 2.2.4. Driver's Vent

The vehicle is equipped with a lower vent that allows outside air to enter the vehicle interior during forward motion. The lower vent inlet is located on the left front corner below the windshield. The vent control is located below the instrument panel. Turn the knob clockwise to increase air flow.

#### 2.2.5. Driver's Floor Heat

The driver's floor heat control on the instrument panel controls the defroster/heater outlet to the floor area of the driver's platform. Turn the knob counter-clockwise to increase the foot heat setting.

## ™NOTE:

Use the Temperature control knob to set the floor heat air temperature.




Fig. 19-5: Driver's Area Climate Controls



## 2.3. Side Console Switch Panel

See "Fig. 19-7: Side Console Panel" on page 18.

#### 2.3.1. Public Address Switch

The Public Address Switch energizes the P.A. system. The switch operates in conjunction with the Speaker Select Switch and the Foot-Operated Microphone Switch.

#### 2.3.2. Camera Event Marker

This device is used to event mark incidents on the video surveillance system for storage and subsequent playback. Pressing the push-button saves incidents to the DVR hard drive.

## 2.3.3. Aisle Lights Switch

The following table displays the lights that will be illuminated based on the positions of the Aisle Lights switch and Master Run switch. See "Fig. 19-6: Aisle Lights" on page 17.

AISLE LIGHTS SWITCH OPERATION						
AISLE LIGHTS SWITCH POSITION	MASTER RUN SWITCH POSITION	ILLUMINATED LIGHTS				
ON	DAY-RUN	Streetside (1,2,3,4) Curbside (1,2,3,4)				
ON	NIGHT-RUN	Streetside (1,2,3,4) Curbside (1,2,3,4)				
ON	NIGHT-PARK <sup>1</sup>	Streetside (1) Curbside (1)				
NORMAL	DAY-RUN <sup>2</sup>	Streetside (1,2,3,4) Curbside (1,2,3,4)				
NORMAL	NIGHT-RUN <sup>3</sup>	Streetside (1,2,3,4) Curbside (1,2,3,4)				
NORMAL	NIGHT-PARK <sup>1</sup>	Streetside (1) Curbside (1)				
OFF	ANY POSITION	Streetside (None) Curbside (None)				

<sup>1</sup> Multiplexing System must be active

<sup>2</sup> Engine must be running

<sup>3</sup> Light bank 1 on the streetside and curbside will only illuminate when the front entrance door is open






Fig. 19-6: Aisle Lights

#### 2.3.4. Idle Speed Switch



Excessive engine idling is not recommended by the engine manufacturer. Operate engine at fast idle speed if idling for periods longer than 10 minutes. Consult your local transit authority for operating policy.

The Idle Speed toggle switch activates the preset fast idle to increase the engine RPM to maintain optimum engine operating temperature during periods of extended idling. Activating the fast idle following a cold engine start also allows quicker engine warm-up.

## ™NOTE:

The FAST position on the Idle Speed switch only operates if the engine is running, the transmission shift selector is in the neutral [N] position and the parking brake is applied.

#### 2.3.5. Speaker Select Switch

The Speaker Select toggle switch controls the interior and exterior speakers of the public address (P.A.) system. Position this toggle switch to INTERIOR, EXTERIOR or BOTH to direct the P.A. announcement to the desired audience. This switch operates in conjunction with the Public Address Switch.

#### 2.3.6. Hazard Lights Switch Indicator

The Hazard Lights Switch indicator illuminates when the Master Run switch is in the NIGHT-RUN or NIGHT-PARK position. It serves only to highlight the position of the Four-Way Hazard Lights switch.






Fig. 19-7: Side Console Panel



#### 2.3.7. Master Run Switch

The Master Run switch is a 4-position rotary switch. The DAY-RUN, NIGHT-RUN, and NIGHT-PARK positions are used to activate the vehicle Multiplexing System and energize various 12/24V electrical circuits. The STOP-ENGINE position is used to shutdown the engine and de-energize the Multiplexing System and most 12/24V electrical circuits except those associated with safety functions. The Battery Disconnect switch must be set to the OFF posi-

tion in order to disconnect the remaining 12/24V circuits from the vehicle batteries. The following table provides a list of circuits energized by the various Master Run switch positions:

## ™NOTE:

The Multiplexing System is programmed to remain active for 30 minutes after the Master Run switch is set to the STOP-ENGINE position.

MASTER RUN SWITCH OPERATION					
CIRCUIT OR SYSTEM	STOP- ENGINE	DAY- RUN	NIGHT- RUN	NIGHT- PARK	
Headlights (low beam)		х	х		
Headlights (high beam)			х		
Four-way hazard lights	х	х	х	х	
Turn lights (Note 3)	х	х	х	х	
Stop lights		х	х		
Clearance/marker lights			х	х	
Tail lights			х	х	
License plate light			х	х	
Backup lights & alarm		х	х		
Aisle lights (normal) (Note 3)	х	х	х	х	
Aisle lights (on) (Note 3)	х	х	х	х	
Instrument panel illumination			х	х	
Instrument panel dimmer			х	х	
Driver's lamp (Note 3)	х	х	х	х	
Service compartment lights (Note 3)	х	х	х	х	
Entrance & exit door lights with door open (Note 2)		х	х	х	
Instrument panel warning indicators		х	х		
Shift selector		х	х		
Brake & accelerator interlocks		Х	х		



MASTER RUN SWITCH OPERATION				
CIRCUIT OR SYSTEM	STOP- ENGINE	DAY- RUN	NIGHT- RUN	NIGHT- PARK
Destination sign operation		х	х	х
Door controller		х	х	х
Horns	х	х	х	х
Retarder (Note 1)		х	х	
Driver's alarm		х	х	
Fire suppression & alarm	х	х	х	х
Parking brake alarm (Note 3)	х			х
Silent alarm	х	х	х	х
Kneeling operation & alarm		х	х	
Wheelchair ramp & alarm		х	х	х
Passenger signal system		х	х	
Public address system		х	х	
HVAC system (Note 1)		х	х	
Wiper control		х	х	
Mirror heat		х	х	х
Remote mirror		х	х	

Note 1: Engine must be running

Note 2: DAY-RUN also requires W/C ramp deployed

Note 3: Multiplexing System must be active



## 2.3.8. Door Controller



Positioning the Door Master switch to OFF disables the brake interlocks and the exit door controller.

The door controller opens and closes the entrance and exit doors. See "Fig. 19-8: Door Controller" on page 21. The five positions of the controller and the related door functions are as follows:

- Position #1 (CLOSED): Entrance door closed, exit door disabled.
- Position #2 (FRONT): Entrance door open, exit door disabled.

- ☐ Position #3 (FRONT REAR): Entrance door open, exit door enabled.
- Position #4 (REAR): Entrance door closed, exit door enabled.
- Position #5 (REAR FRONT): Entrance door open, exit door enabled.

When the exit door is open, the brake and accelerator interlocks apply automatically and the stop lights indicator illuminates.

#### 2.3.9. Remote Mirror Control Switches

The Remote Mirror Control switches allow the operator to adjust the curbside and streetside mirrors from the driver's seat.




Fig. 19-8: Door Controller



#### 2.3.10. Mirror Heater Button

This push button powers the heater elements behind the right and left exterior mirrors. The button illuminates to confirm heater element operation.

#### 2.3.11. Parking Brake Control Valve



If the air pressure is below 40 psi (276 kPa), the parking brake valve will return to the applied position.

The parking brake control valve controls the application or the release of the parking brake. Pulling up on the control knob applies the parking brake. Pushing down on the knob releases the parking brake.

## 2.3.12. Emergency Brake Release Control Valve

This valve supplies the air pressure to release the rear brakes if the air system pressure drops below 40 psi (276 kPa) and the rear brakes apply automatically. Pushing down and holding the valve allows the air pressure to release the rear brakes. Releasing the valve knob shuts off the air pressure supply, allowing the rear brakes to re-engage.

## ™NOTE:

The emergency brake release is for emergency use only. It allows the operator to move the vehicle away from a potentially dangerous location when the air system has failed. The rear brakes remain released as long as the valve is pressed. The brakes will drag at about 65 psi (448 kPa) even though the parking brake is in the released position.

## 2.3.13. Four-Way Hazard Lights Switch

The Hazard Lights toggle switch has an ON and OFF position. When the switch is ON, the instrument panel turn indicators and the exterior signal lights flash.

When the switch is OFF, the exterior signal lights function only as turn signals. The exterior signal lights and instrument panel turn indicators flash when the left or right turn signal foot-switch is pushed and held.

Activate the four-way hazard lights when the vehicle is stopped or parked and may block traffic or present a possible hazard to following or approaching vehicles. Also use the four-way hazard lights when the vehicle is being towed.

#### 2.3.14. Start Push Button



Put the shift selector in neutral [N] and apply the parking brake before starting the engine. If the parking brake indicator does not illuminate, DO NOT OPERATE THE VEHICLE.

This momentary Push Button on the side console allows the operator to start the engine without leaving the driver's seat.

## ™NOTE:

The Multiplexing System limits continuous starter operation to 14 seconds; the starter circuit is then disconnected for 60 seconds to allow the starter to cool down.



## 2.3.15. Stop Engine Override Switch



Apply the Stop Engine Override switch only for emergencies, such as moving the vehicle from traffic to a safe stopping area. The override interval is 30 seconds. Repeat the switch cycle to activate a repeat override sequence as necessary.

The Stop Engine Override toggle switch is used to override the engine shutdown system in an emergency.

## 2.3.16. Driver's Light Switch

The Driver's Light toggle switch is a twoposition switch that controls the light above the driver.

#### 2.3.17. Dash Fan Speed Switch

The Dash Fan Speed toggle switch controls the center dash fan. To run the fan, reposition switch from OFF to either HIGH or LOW for desired speed.

#### 2.3.18. Silent Alarm Switch

Activating the silent alarm switch will prompt the destination signs to display a distress message.

#### 2.3.19. Climate Control Switch

The Climate Control switch is a five-position switch that controls the HVAC System. In the VENT Low or the VENT High position the system circulates unheated fresh air through the interior of the vehicle. In the HEAT position the system delivers heated air into the interior of the vehicle and maintains the temperature at a preset value. In the COOL position, the system delivers cooled air into the interior of the vehicle and maintains the temperature at a preset value. The OFF position deactivates the system.



## 2.4. Foot Operated Controls

See "Fig. 19-9: Driver's Foot Controls" on page 24.

#### 2.4.1. Brake Treadle

The brake treadle, located to the left of the accelerator treadle, controls the application and release of the service brakes. The brake treadle also controls the retarder function.

Brake application is proportional to the amount of treadle movement applied. Pressing the brake treadle illuminates the stop lights and the stop lights indicator.

## ™NOTE:

The brake treadle drops slightly when the Interlock System applies. To release the brake interlock system, apply sufficient pressure to the brake treadle to "push through" the interlock application. The interlock message will disappear from the instrument panel LCD screen and the treadle will return with the operator's foot to its normal position.

#### 2.4.2. Accelerator Treadle

The accelerator treadle, located to the right of the brake treadle, controls the engine throttle. Acceleration of the engine is proportional to the amount of treadle movement applied.

#### 2.4.3. Headlight Dimmer Switch

The Headlight Dimmer switch is a heelactivated click-in switch located adjacent to the side console. Pressing the switch changes the headlight operating mode between either high beam or low beam. The blue high beam indicator on the instrument panel indicates the high beam mode.

### 2.4.4. Turn Signal Switches

Two bracket-mounted, momentary-on switches control the right and left turn signal lights when held depressed. Left or right turn signal indicators on the instrument panel illuminate when respective floor switch is activated.

### 2.4.5. P.A. Microphone Switch

The P.A. microphone switch is located between the turn signal switches and is for activating the P.A. System. Push and hold this switch while speaking. A hands-free microphone is mounted to the steering column.




Fig. 19-9: Driver's Foot Controls



## 2.5. Miscellaneous Controls

See "Fig. 19-10: Miscellaneous Switches" on page 25.

#### 2.5.1. Retarder Switch

The Retarder toggle switch controls power to the transmission retarder. Positioning the switch to ON enables the retarder. The OFF position disables the retarder and illuminates the Retarder Off indicator on the instrument panel.

## ™NOTE:

Consult your transit authority for specific operating conditions during which the Retarder switch should be used.

#### 2.5.2. Door Master Switch



Greater attention to passenger safety must be given whenever operating the vehicle with the Door Master switch in the OFF position, as this position disables several safety features and will allow the following conditions to occur:

 Vehicle can be moved with entrance and/or exit door open (brake interlocks disabled).

- ☐ Transmission can be shifted without foot on brake treadle.
- ☐ Transmission can be shifted and vehicle moved with wheelchair ramp deployed.
- ☐ Exit doors can be opened at any speed by using the emergency release control valve.

The Door Master toggle switch controls power to the brake interlocks and exit door. When the switch is in the ON position, the entrance and exit doors are fully functional. In this mode, opening the exit door, kneeling the vehicle or operating the wheelchair ramp engages the interlocks. Engaging the interlocks applies the rear brakes and deactivates the accelerator.

When the switch is In the OFF position, the brake interlocks are released (interlocks will not engage). The entrance door remains fully functional and the exit door does not function. A warning buzzer sounds and the Rear Door Open indicator illuminates on the instrument panel. In this mode, the exit door only opens if the emergency release control valve is activated. The control valve is located behind the breakable window to the left of the exit door.




Fig. 19-10: Miscellaneous Switches



#### 2.5.3. ABS Switch

The ABS switch is used by service personnel to troubleshoot the ABS System. Pulling the switch to BLINK CODE and releasing activates the blink code diagnostic capabilities. The blink code sequence displays on the instrument panel ABS Fail indicator.

#### 2.5.4. Exhaust Filter Switch

The Exhaust Filter switch is a 3-way toggle switch with NORMAL, INHIBIT and REGEN positions. This switch is used by service personnel as required to regenerate or burn soot off of the muffler filter. The function of the switch settings is as follows:

NORMAL - this position is used for everyday vehicle operation. Regeneration will occur as needed while the vehicle is being driven.

- □ INHIBIT this position is used when the vehicle is parked inside for servicing or any other situations where the regeneration process must be disabled for safety reasons.
- REGEN this position is used by service personnel to initiate a forced regeneration when the vehicle is parked in a safe location. The engine speed and exhaust temperature will increase as the muffler filter regenerates.

#### 2.5.5. Entrance Door Manual Control Valve

This air control valve is located beside the driver, just below the side console. Turning it to the OFF position releases the air controlling the entrance door. This allows manual operation of the door for initial vehicle entry. For normal entrance door operation, position the door manual control valve to ON.



## 3. INSTRUMENT REPAIRS

## 3.1. Instrument Panel

## 3.1.1. Description

The instrument panel houses the electronic instrument cluster. The instrument cluster includes gauges, LCD display screen and odometer, telltale indicators, and control buttons. The LCD screen is a programmable unit with diagnostic capabilities. A USB port is located below the instrument panel which is intended for configuring the instrument cluster using a PC.

The instrument panel is also fitted with controls and switches for operating electrical and mechanical devices.

#### 3.1.2. Removal

- Set the Battery Disconnect switch to the OFF position.
- 2. Drain the vehicle air tanks.

- 3. Tilt the steering wheel away from the instrument panel.
- Remove the bezel by prying it away from the instrument panel. See "Fig. 19-11: Instrument Panel Repair & Installation" on page 27.
- Remove the two machine screws at the top of the instrument panel.
- Disconnect the USB port below the instrument panel.
- Pull the instrument panel away to access the connectors on the back side of the panel.

## ™NOTE:

The lower corners of the instrument panel are secured with Velcro tape.

- Disconnect all electrical plugs and connectors from the instrument panel. Tag all wire connectors.
- Disconnect all cables from defroster controls
- 10.Remove the instrument panel from the dash.




Fig. 19-11: Instrument Panel Repair & Installation



## 3.1.3. Disassembly

 Remove the self-tapping screws holding the instrument cluster and remove it from the instrument panel.

### ™NOTE:

The electronic instrument cluster is not repairable and must be replaced as an assembly.

- Remove the pushbutton shift selector by removing two nuts from retaining bracket and remove pushbutton shift selector from front side of panel.
- 3. Remove toggle switches as follows:
  - Tag and disconnect electrical leads from switch.
  - b. Remove the retaining nut on the face of the panel and remove the switch from the back of the panel.
- 4. Remove mechanical controls as follows:
  - Remove the control knob from the device by loosening the setscrew on the knob.
  - b. Remove the retaining nut from the face of the panel and remove the control switch from the back of the panel.

- 5. Remove electrical controls as follows:
  - Remove the control knob from the device by loosening the setscrew on the knob.
  - b. Remove the retaining nut from the face of the panel and remove the control switch from the back of the panel.

### 3.1.4. Assembly

Assemble the instrument panel by reversing the disassembly procedure.

#### 3.1.5. Installation

- Remove the existing Velcro tape and clean the contact areas. Apply new Velcro tape to the left and right side on dash panel.
- Place the instrument panel in front of the dash and reconnect all electrical and mechanical connections.
- Reconnect the USB port below the dash panel.
- 4. Attach the instrument panel to the dash using the machine screws.
- 5. Set the Battery Disconnect switch to the ON position.
- 6. Start the engine and check operation of instrumentation and controls.



## 3.2. Side Console

## 3.2.1. Description

The driver's side console is located to the left of the driver's seat, below the driver's side window. The aluminum panel and frame are mounted on a set of slider rails for ease of access to the electrical and pneumatic connections mounted to the interior of the drawer-like mechanism. Two 50 pound spring cylinders support the assembly in the raised position and retain it in the stowed position. A side console access door. located on the exterior streetside of the vehicle, also gives access to its lower electrical components, and pressure switches. The console is electrically attached to the vehicle using wire harnesses and cables that run up from under the vehicle. The toggle switches, and

Pull-Off Dial switches are attached to its face using nuts and spiral lock washers. The Door Control Handle, a five tier switch, is attached from the underside of the console.

## 3.2.2. Operation

The side console houses the Vehicle Start, Lighting, HVAC, Parking Brake and Door Opening Controls. All control signals are sent from the side console to the Multiplexing System, using the two I/O modules located in the console. The Multiplexing System will allow system operation once it confirms that all preprogrammed parameters are met to activate the system. Current limiters which prevent damage to electrical components are described separately in this section.



#### 3.2.3. Maintenance

## 3.2.3.1. Toggle Switch Replacement

- 1. Set the Battery Disconnect switch to the OFF position.
- Loosen the captive screws at either end of the side console. Pull on the access handle and raise the console. See "Fig. 19-12: Side Console Repair" on page 30.
- 3. Remove the switch securing nut from the face of the panel.

- 4. Carefully push the switch down through the top of the console.
- 5. Disconnect all wires from the rear of the switch, and tag them for reinstallation.
- 6. Insert the new switch into the hole and attach the securing nut to the face of the panel.
- 7. Connect all wires to the switch.
- 8. Lower the side console panel and tighten the captive securing screws at either end.
- 9. Set the Battery Disconnect switch to the ON position.




Fig. 19-12: Side Console Repair



## 3.2.3.2. Dial Switch Removal

- 1. Set the Battery Disconnect switch to the OFF position.
- Loosen the captive screws at either end of the side console. Pull on the access handle and raise the console.
- 3. Remove the pull-off dial from the front of the switch, by loosening the securing screw from the side of the switch.
- 4. Remove the switch securing nut from the face of the panel.
- Carefully remove the switch from the bottom of the console.

- Remove the attaching electrical connection.
- Insert the new switch into the hole and attach the securing nut to the face of the panel.
- Reattach the electrical connection to the switch.
- Reattach the securing nut the bottom of the switch and attach the dial using the securing screw on the dial's side.
- 10.Lower the side console panel and tighten the captive screws at either end.
- 11.Set the Battery Disconnect switch to the ON position.



## 4. ACCELERATOR CONTROL

## 4.1. Description

The accelerator position sensor is used in vehicles equipped with electronically controlled engines. A signal is provided to the engine fuel control system in proportion to the degree of pedal actuation. A solid state potentiometer delivers the signal to the engine. This treadle incorporates hardened pin and replace able bushings at all pivot points. The rubber pedal cover is replaceable. The potentiometer and wire harness are replaceable as an assembly. Other than routine inspection and cleaning, very little maintenance is required.

## 4.2. Cleaning & Lubrication

- Clean all the metal parts in a petroleum base cleaning solvent, such as mineral spirits (Stoddard solvent) or kerosene and air dry.
- Check for excessively worn, damaged, or corroded parts. Replace bushings and shaft as required. See "Fig. 19-13: Accelerator" on page 33.
- Lubricate pivot pins and roller with a thin layer of dry lubricant (Molykote 321 or equivalent).

## ™NOTE:

DO NOT use grease or oils, they will attract and retain contaminants.

4. Reinstall the nylon roller. Install bushings in pedal pivot holes (if applicable) and put pedal back on treadle base, taking care to install spring coils with the pivot pin.

## 4.3. Potentiometer Replacement

- Set the Battery Disconnect switch to the OFF position.
- Remove two screws which retain potentiometer in base of pedal. Disconnect wiring harness. Discard harness and potentiometer.
- Install replacement potentiometer by aligning slot on potentiometer with tang on pinion in base of pedal. Rotate potentiometer 10 to 15° clockwise to align screw holes on potentiometer with holes in base of pedal. Install screws and torque 15 to 20 in-lb. Do not over tighten screws.
- 4. Connect wiring harness to vehicle wiring.
- 5. Set the Battery Disconnect switch to the ON position. Test drive vehicle and confirm correct operation of treadle.






Fig. 19-13: Accelerator



## 5. STEERING & HORN

## 5.1. Description

## ™NOTE:

Refer to Section 3 of this manual for further discussion or breakdown of steering components.

The tilt/telescopic wheel turns front wheels with aid of the steering hydraulic system (while engine is running).



DO NOT turn steering wheel if engine is not operating except in emergency situations. DO NOT OPERATE VEHICLE if any of the following conditions exist:

- ☐ Binding or resistance in steering wheel operation (with vehicle in motion).
- ☐ Unusual noises related to steering.
- Steering wheel vibration.
- □ Looseness of steering.
- □ Looseness, binding or resistance in tilt/ telescopic mechanism.

The horn button is located in center of steering wheel. To sound horn, press down on button. Horn will sound until button is released.



# **Wheelchair Ramp**

1.	SAFETY	20-1
	1.1. Safety Procedures	20-1
2.	WHEELCHAIR RAMP	20-2
	2.1. Description	
	2.2. Operation	
	2.2.1. Hydraulic Operation	
	2.2.2. Mechanical Operation	
	2.2.3. Proximity Switch Operation	
	2.2.4. Manual Operation	
	2.3. Maintenance	
	2.4. Wheelchair Ramp Troubleshooting	
	2.4.1. Hydraulic System Diagnosis	
	2.4.2. Hydraulic System Flushing	
	2.4.3. Solenoid Testing	
	2.4.3.1. S1 Solenoid	
	2.4.3.2. S2 Solenoid	
	2.4.4. Proximity Switch Testing	
	2.5. Removal	
	2.6. Installation	
	2.7. Ramp Operating Mechanism	
	2.7.1. Description	
	2.7.2. Disassembly	
	2.7.2.1. Ramp Plate Removal	
	2.7.2.2. Hinge & Cover Removal	
	2.7.2.3. Drive Sprockets, Chain, & Pivot Plate Removal	20-16
	2.7.2.4. Operating Mechanism Removal	
	2.7.2.5. Ramp Power Pack Removal	
	2.7.2.6. Operating Mechanism Disassembly	
	2.7.3. Assembly	
	•	
	2.7.3.1. Ramp Plate Installation	20-19
	2.7.3.1. Ramp Plate Installation	20-19 20-19
	2.7.3.1. Ramp Plate Installation	
	2.7.3.1. Ramp Plate Installation	
	2.7.3.1. Ramp Plate Installation	20-19 20-19 20-20 20-22 20-25
	2.7.3.1. Ramp Plate Installation	20-19 20-19 20-20 20-22 20-25 20-25
	2.7.3.1. Ramp Plate Installation	20-19 20-19 20-20 20-22 20-25 20-25 20-25
	2.7.3.1. Ramp Plate Installation	20-19 20-19 20-20 20-22 20-25 20-25 20-25

# Table of Contents



2.8.2.	Hydraulic Power Pack & Cylinder Specifications	20-27
	Operation	
	Maintenance	
2.8.5.	Hydraulic Power Pack & Cylinder Troubleshooting	20-27
	Removal	
287	Installation	20-27





## 1. SAFETY

## 1.1. Safety Procedures

This section of the service manual contains procedures which require the mechanics to strictly observe safety procedures in order to ensure personal and equipment safety.

Always ensure that the vehicle is appropriately hoisted and blocked for procedures which require elevating the vehicle. Be aware of the limitations of the blocking equipment, and always ensure that the jarring and shaking created by component removal and installation procedures does not overload the blocks, or cause the vehicle to become unstable.

Certain procedures may require the vehicle be operated in an elevated position in order to accurately troubleshoot and diagnose a problem. If the vehicle must be running while elevated, become familiar with the repair area prior to starting the engine. Take special care in noting areas which will become hot, electrically energized, and areas where moving and rotating components are located. Limit the work in these areas as personal and equipment safety is at risk.

For procedures which involve air lines, ensure the line is safely depressurized prior to disconnecting. Disconnecting pressurized lines will cause solid particles deposited in the line to be uncontrollably propelled, and will also cause the hose end to whip randomly as the air escapes.

During electrical diagnosis procedures an understanding of the vehicle's electric circuits is important to anticipate the results of connecting test equipment. During component removal or installation, ensure the Battery Disconnect switch is in the OFF position.

Failure to follow this procedure may result in personal injury or component failure.

Observe the following procedures involving hydraulic line removal.

- Hydraulic fluid is corrosive and should not be exposed to skin for extensive periods of time.
- Wear eye protection at all times.
- Pressurized lines should not be disconnected until the pressure is safely and controllably released.



## 2. WHEELCHAIR RAMP

## 2.1. Description

The wheelchair ramp assembly is located at the entrance door and consists of the following major components:

- ☐ Pivoting, fold-out aluminum ramp
- ☐ Recessed stainless steel ramp enclosure

- ☐ Hydraulically operated, chain-driven operating mechanism
- Power pack assembly consisting of electric motor, hydraulic pump, and manifold with control solenoids.
- ☐ Proximity switch, warning beeper, and electrical harnesses.

See "Fig. 20-1: Ramp Assembly Major Components" on page 2.




Fig. 20-1: Ramp Assembly Major Components



## 2.2. Operation

The wheelchair ramp is a hydraulically operated, chain-driven, fold-out ramp assembly. Refer to 2.2.1. "Hydraulic Operation" on page 3 in this section for a description of the hydraulic system operation and Refer to 2.2.2. "Mechanical Operation" on page 3 in this section for a description of the mechanical components operation. Also refer to Section 19 of this manual for information on the operation of the Ramp switch

#### 2.2.1. Hydraulic Operation

## ™NOTE:

Refer to the Entrance Door Wheelchair Ramp Hydraulic Schematic when reviewing this information.

The wheelchair ramp is controlled by the three-position Ramp switch located on the instrument panel. Switch positions and hydraulic functions are as follows:

- □ DEPLOY This position activates the pump and the S2 solenoid in the valve block. The oil from the pump flows out of the manifold block and applies pressure to the base end of the ramp operating cylinder. The ramp then moves from the stowed position and starts through its arc until fully deployed. Oil from the rod end of the cylinder returns to the pump and reservoir through the S1 solenoid in the manifold block. A restrictor in the return oil circuit prevents the ramp from travelling faster than the pump oil supply as the ramp passes the vertical position.
- □ STOW This position activates the pump and the S1 solenoid in the valve block. The oil from the pump flows out of the manifold block and applies pressure to the rod end of the ramp operating cylinder. The ramp then moves from the deployed position and

starts through its arc until fully stowed. Oil from the base end of the cylinder returns to the pump and reservoir through the S2 solenoid in the manifold block. A restrictor in the return oil circuit prevents the ramp from travelling faster than the pump oil supply as the ramp passes the vertical position.

□ FLOAT - This is the normal position of the switch. In this position the hydraulic pump and both solenoids (S1 & S2) are deactivated and the ramp will float to either DEPLOYED or STOWED position. When the solenoids are deactivated, the base and rod ends of the cylinder and the reservoir are hydraulically interconnected. This allows the weight of the ramp to operate the cylinder. The restrictors in the solenoid block prevent rapid oil flow and limit ramp travel speed. Manual operation is possible in this position.

#### 2.2.2. Mechanical Operation

- □ DEPLOY The hydraulic cylinder piston rod extends and acts on the push channel which is connected to a drive and idler sprocket by a chain spacer block and drive chain. The drive sprocket rotates the main drive shaft and the secondary drive sprockets located at either end of the shaft. A drive chain connects each of the secondary drive sprockets to a sprocket and pivot plate assembly which is fastened to the ramp. Actuation of the chain drive mechanism causes the ramp to pivot and swing outward until fully deployed.
- ☐ STOW Operation of the ramp mechanism in the STOW mode is basically reverse of the DEPLOY operation. The hydraulic cylinder piston rod retracts and pulls on the push channel which in turn, through the drive sprockets, chains, and drive shaft, returns the ramp to the stowed position.



#### 2.2.3. Proximity Switch Operation

An inductive normally-closed (N.C.) proximity switch is threaded into the RH (forward) support plate and senses movement of the push channel. There is no target (push channel) in front of proximity switch when the ramp is in the stowed position. The proximity switch is closed and sends a signal to the multiplexing system that the ramp is stowed.

As the ramp is deployed, the target (push channel) will move in front of the proximity switch at approximately 15° from the fully stowed position. The proximity switch will sense the target and become open (no signal to the multiplexing system). This signal is used to activate the brake and accelerator interlocks during ramp deployment and also illuminate the W/C Ramp indicator on the instrument panel.

#### 2.2.4. Manual Operation



Exercise caution when operating the ramp in manual mode. The hydraulic system will not provide dampening after the first deploy cycle and will fall freely. Ensure that you do not position yourself in the way of the ramp when it is falling to either the deployed or stowed positions.

The wheelchair ramp can be operated manually in the case of an emergency or failure of the hydraulic/electric system. Operate the ramp manually as follows:

1. Pull up on the lift strap, located on the edge of the ramp, and then grip the ramp with both hands and carefully raise the ramp to the vertical position.



Ensure no one else is in the immediate area of the ramp, inside or outside of the vehicle.

Allow the ramp to free fall from the vertical position to the fully extended deploy position.

#### ™NOTE:

On the first manual deploy cycle, the hydraulic system will provide a dampening action to slow the ramp descent. Dampening will not be provided on subsequent cycles.

3. Stow the ramp manually by grasping the ramp plate with both hands and lifting to the vertical position.



Ensure no one else is in the immediate area of the ramp inside the vehicle.

4. Allow the ramp to free fall from the vertical position to the stowed position.

#### ™NOTE:

When operating the ramp in the manual mode, oil will flow very slowly to fill the opposing side of the piston, taking approximately one minute. If the ramp is allowed to rest in the deployed position for at least one minute before stowing, then dampening action will be provided. However, if the ramp is returned from the deploy position to the stow position in less than one minute, then little or no dampening will be provided.

## 2.3. Maintenance

Refer to the Preventive Maintenance Section of this manual for regularly scheduled maintenance intervals and procedures.



## 2.4. Wheelchair Ramp Troubleshooting

WHEELCHAIR RAMP TROUBLESHOOTING				
SYMPTOM	POSSIBLE CAUSE	SOLUTION		
Excessive resistance, binding, or jerking when deploying or stowing ramp	Problem in hydraulic system	Inspect hydraulic system. Refer to 2.4.1. "Hydraulic System Diagnosis" on page 7 in this section for procedure.		
	Misaligned drive shaft	Align drive shaft. Refer to 2.7.3.7. "Ramp Mechanism Initial Adjustments" on page 25 in this section for procedure.		
	Improperly adjusted drive chain(s)	Align drive chains. Refer to 2.7.3.7. "Ramp Mechanism Initial Adjustments" on page 25 in this section for procedure.		
	Damaged or binding ramp pivot assemblies	Inspect LH & RH pivot assemblies. Clean debris and any buildup of dirt or grease from the pivot area. Apply lubricant to the pivot assembly bushing. Refer to the Preventive Maintenance Section of this manual for lubricant specification and procedure.		
Ramp does not function in STOW or DEPLOY positions	Faulty ramp toggle switch	Replace ramp toggle switch		
OTOW OF BETTER POSITIONS	No power to electric motor	Refer to electrical schematic and check fuse, ramp pump relay, ramp switch, and electrical connector at motor. Repair or replace defective component		
	Entrance door not fully open	Check and adjust mechanical door stop Check and adjust door open limit switch		
Ramp motor operates but ramp will not stow	Faulty S1 solenoid valve	Perform solenoid electrical test. Refer to 2.4.3. "Solenoid Testing" on page 8 in this section for procedure. Replace faulty solenoid.		
Ramp motor operates but ramp will not deploy	Faulty S2 solenoid valve	Perform solenoid electrical test. Refer to 2.4.3. "Solenoid Testing" on page 8 in this section for procedure. Replace faulty solenoid.		



WHEELCHAIR RAMP TROUBLESHOOTING				
SYMPTOM	POSSIBLE CAUSE	SOLUTION		
Ramp functions opposite of the ramp switch STOW and DEPLOY positions	Incorrect hydraulic hose connections	Refer to 2.4.1. "Hydraulic System Diagnosis" on page 7 in this section to determine proper hose connections		
	Solenoids incorrectly wired	Confirm wires on connector between solenoids and vehicle harness are correctly installed		
Ramp slams when deploying	S1 solenoid not fully closing	Replace S1 solenoid		
Ramp slams when stowing	S2 solenoid not fully closing	Replace S2 solenoid		
Ramp slams when stowing or deploying	Internal leakage in actuating cylinder or manifold block	Replace manifold block. If problem still exists, replace actuating cylinder		
Ramp is stowed but interlocks remain on, W/C indicator on instrument panel remains illuminated, and ramp motor/pump continues to run	Faulty proximity switch (open circuit)	Test operation of proximity switch. Refer to 2.4.4. "Proximity Switch Testing" on page 8 in this section for procedure. Adjust or replace switch as necessary.		
	Faulty wiring	Refer to electrical schematic and check fused power supply to proximity switch. Check ground circuit. Confirm output to multiplexing system with switch in normally-closed position. Repair wiring as required		
Ramp deploys but W/C Ramp indicator on instrument panel does not illuminate	Multiplexing system is receiving a STOWED signal from the proximity sensor instead of a DEPLOY signal	Test operation of proximity switch. Refer to 2.4.4. "Proximity Switch Testing" on page 8 in this section for procedure. Adjust or replace switch as necessary. Refer to electrical schematic and check wiring connections at proximity switch for possibility of power wire being short-circuited to signal wire.		

# **Wheelchair Ramp Troubleshooting**

#### 2.4.1. Hydraulic System Diagnosis

The following checks and test procedures will help diagnose and isolate problems in the hydraulic system.

- Confirm that the hydraulic hoses are properly connected between the hydraulic block and the actuating cylinder. The hose from the S1 port of the hydraulic block should be connected to the rod end of the cylinder. The hose from the S2 port should be connected to the base end of the cylinder.
- 2. Isolate the hydraulic system to determine whether the excessive resistance or binding is a mechanical or hydraulic problem. Remove the hoses from the manifold block. Install clean, extended length Teflon hoses into the manifold S1 and S2 ports and place the ends of the hoses into a glass jar. Manually move the ramp from the stowed to the deploy position. If there is resistance to movement then the problem is mechanical.

## ™NOTE:

If dirty or contaminated fluid is evident in the glass jar then the system will need to be flushed. Refer to 2.4.2. "Hydraulic System Flushing" on page 7 in this section for procedure.

 Maintain the test hoses in the glass jar as described in the previous step. Briefly operate the ramp switch in both the DEPLOY and STOW positions. Fluid should flow freely from the S1 hose when in the DEPLOY position and from the S2 hose when in the STOW position.

- 4. If only one of the hoses allowed fluid to flow then check to see whether;
  - a. the solenoid is functioning for the hose without flow. Replace solenoid if defective.
  - the restrictor orifice is blocked in the line for the hose without flow. Replace the manifold block if orifice is blocked.
- If little or no flow is evident during test, then inspect for a faulty pressure relief valve. Replace the manifold block if pressure relief valve is stuck open.

#### 2.4.2. Hydraulic System Flushing

If dirty or contaminated fluid is noted in the system then the following flushing procedure will need to be performed:

- Remove the plug from the reservoir and drain all fluid.
- Manually operate the ramp through several cycles while draining the fluid, so as to force fluid back to the reservoir.
- Disassemble reservoir from manifold and replace inlet filter and O-ring.
- 4. Reassemble reservoir and manifold.
- Reinstall plug and fill reservoir with clean fluid. Manually operate ramp through several cycles to force fluid through the system.
- 6. Repeat steps 2 and 5 until fluid is clean.



#### 2.4.3. Solenoid Testing

## ™NOTE:

Refer to Electrical Schematic "ES-Kneeling LK" when performing solenoid tests.

Manually deploy the ramp, remove the access cover plate, and disconnect the wring harness to the solenoids.

#### 2.4.3.1. S1 Solenoid

Test the S1 stow solenoid as follows:

- Set the ramp switch to the STOW position and check for 24 VDC between pins "C" and "D". If reading is OK, proceed to step 4.
- Check for 24 VDC output from multiplexing module. Refer to electrical schematic for module address.
- 3. Check that pin "D" on connector is providing a good ground.
- Use an Ohmmeter to measure resistance between pins "C" and "D" of the connector on the solenoids.



DO NOT measure resistance on the vehicle supply side of the wiring connector.

5. Replace solenoid if resistance value does not fall within 27.9 ± 2.0 Ohms.

#### 2.4.3.2. S2 Solenoid

Test the S2 deploy solenoid as follows:

- Set the ramp switch to the DEPLOY position and check for 24 VDC between pins "A" and "B". If reading is OK, proceed to step 4.
- Check for 24 VDC output from multiplexing module. Refer to electrical schematic for module address.

- Check that pin "B" on connector is providing a good ground.
- Use an Ohmmeter to measure resistance between pins "A" and "B" of the connector on the solenoids.



DO NOT measure resistance on the vehicle supply side of the wiring connector.

5. Replace solenoid if resistance value does not fall within 27.9 ± 2.0 Ohms.

#### 2.4.4. Proximity Switch Testing

The proximity switch is a normally-closed (N.C.) inductive switch. The switch is powered when the vehicle is either in DAY-RUN or NIGHT-RUN. A signal is sent to the multiplexing system when there is no target in proximity to the switch (STOW position). When the switch is in proximity to the target, the switch becomes "open" and no signal is sent to the multiplexing system (DEPLOY position).

Test the proximity switch as follows:

- 1. Remove the access cover from the ramp and confirm that the proximity switch is uncovered by the push channel when in the stowed position.
- Turn the Master Run switch to DAY-RUN and then place a metal object over the face of the proximity switch. The interlocks should apply and the W/C Ramp indicator on the instrument panel should illuminate.
- 3. Remove the metal object and confirm that the interlocks release and the W/C Ramp indicator extinguishes.
- Manually deploy ramp and confirm that the interlocks apply and the W/C Ramp indicator illuminates as soon as the target (push channel) comes within close proximity to the switch.



#### 2.5. Removal

## ™NOTE:

The following procedure describes the removal of the entire ramp assembly as a unit from the vehicle, including operating mechanism and hydraulic power pack. Refer to 2.7. "Ramp Operating Mechanism" on page 12 in this section for detailed servicing procedures on this assembly.

- Set the Battery Disconnect switch to the OFF position.
- 2. Manually deploy the ramp.
- Remove the interior dash access cover and disconnect the electrical cables to the wheelchair ramp. See "Fig. 20-2: Ramp Installation" on page 10.
- Remove the nut from the conduit connector and release the two clamps attaching the conduit to the vehicle structure.
- 5. Remove the floor closeout plates from around the wheel chair ramp.
- Remove the ramp access cover to expose the hydraulic pump and chain drive mechanism. See "Fig. 20-3: Ramp Assembly" on page 11.
- Remove the two 5/16" bolts that secure the operating mechanism to the vehicle structure.

## ™NOTE:

The ramp operating mechanism mounting bracket has four slotted holes. The front (outboard) holes are used to secure the operating mechanism to the weld-nuts in the vehicle structure. These two bolts need to be removed in order to separate the ramp operating mechanism from the ramp enclosure.

- Remove the two screws that secure the inboard corners of the ramp to the structure angle brackets.
- Remove the four 1/4" bolts that secure the outboard corners of the ramp to the structure angle brackets.

#### ™NOTE:

Spacer plates are used at the outboard corners. Note the position and retain these spacers for reinstallation.

- 10. Manually stow the ramp.
- 11.Using appropriate lifting equipment, remove the ramp from the vehicle, taking care to avoid damaging the electrical cables and conduit.

## ™NOTE:

The ramp has been sealed to the floor using flooring sealant. It may be necessary to cut the sealant to complete the ramp removal.







Fig. 20-2: Ramp Installation





- Wheelchair Ramp Assembly, Entrance (Incl. 2-53)
- 2. Box Assembly, SST
- 3. Fitting, #4 ORB Adapter
- 4. Fitting, #4 ORB 90° Elbow
- 5. Loctite
- 6. Screw, FH Cross Recess SST 1/4" 28 UNF x 3/8" Lg.
- 7. Screw, PH Cross Recess SST #10 24 UNC x 1/2" Lg.
- 8. Screw, PH Cross Recess SST #10 24 UNC x 3/4" Lg.
- 9. Screw, PH Cross Recess SST #8 32 UNC x 5/8" Lg.
- 10. Bolt, Hex 1/4" 20 UNC x 3/4" Lg.
- 11. Bolt, Hex 5/16" 18 UNC x 1" Lg.
- 12. Bolt, Hex 5/16" 18 UNC x 2 3/4" Lg.
- 13. Bolt, Hex 3/8" 16 UNC x 3/4" Lg.
- 14. Clamp, "P" .562" SST/HT
- 15. Base, Cable Mount
- 16. Decal, Fill Line

- 17. Receptacle, Clip-On
- 18. Nut, Hex SST 1/4" 20 UNC
- 19. Screw, SST 5/8" X 1" Lg.
- 20. Key, SQ 3/16" x 3/4" Lg.
- 21. Pump Assembly, Ramp
- 22. Screw, Set #10 32 UNF x 1/8" Lg.
- 23. Pivot Ramp Assembly, LH
- 24. Pivot Ramp Assembly, RH
- 25. Sprocket
- 26. Switch, Proximity
- 27. Washer, Thrust 5/8" x 1" x 1/16"
- 28. Bearing Sleeve, 5/8" x 7/8" x 3/4"
- 29. Bracket
- 30. Chain, Roller # 41 x 36 Lg.
- 31. Link, Connecting #41
- 32. Link, Offset #41 AC
- 33. Cover, Pivot Mount Channel
- 34. Harness
- 35. Spacer, Wheelchair Ramp
- 36. Plate, Rubber Closeout
- 37. Nut, Hex SST 5/16" 18 UNC

- 38. Washer, Flat SST #10
- 39. Washer, Flat SST 1/4"
- 40. Washer, Flat SST 5/16"
- 41. Washer, Flat SST 3/8"
- 42. Ramp Assembly, 32"
- 43. Insert, SST #10 24 UNC
- 44. Wheelchair Ramp Chain Cover Assembly
- 45. Wheelchair Ramp Chain Cover Assembly
- 46. Hose Assembly, FC510-04 13.06 FL
- 47. Hose Assembly, FC510-04 10.13 FL
- 48. Nut, Hex SST #10-32 UNF
- 49. Rivet, Mono Blind SST 1/4" x .080/.375
- 50. Mechanism Assembly, 32"
- 51. Cable Tie, 4" Lg. Black
- 52. Seal, Rubatex 0.5" W x 0.06" Thk.
- 53. Loom, Convoluted Split .38"

s0364112a.svg

Fig. 20-3: Ramp Assembly



## 2.6. Installation

- Using appropriate lifting equipment, position the ramp into the flooring cutout, taking care to avoid pinching the electrical wires and conduit.
- Apply downward pressure on the perimeter flange facing the driver's platform and manually open the ramp into the deployed position.
- Align the open slots on the operating mechanism with the weld-nuts in the vehicle structure.
- 4. Install the 5/16" bolts but do not tighten.
- 5. Install the screws at the inboard corners of the wheel chair ramp ensuring ramp flanges are snug to the top of the flooring.
- Align the outboard end of the ramp to the structure angles and install spacer plates, washers and the four 1/4" bolts. Torque all bolts to 18 ft-lb ± 1 ft-lb (24 Nm ± 1 Nm).
- Install the floor close-out plates and apply sealant to any gaps between the ramp and the floor.
- 8. Install the cover. Ensure the perimeter gap between the cover plate and the ramp outer channel does not exceed a maximum of 5/8" (16mm) and that the ramp is able to move into the stowed position without contacting the cover.



The maximum gap of 5/8" (16mm) is an American Disabilities Association (ADA) specification. This gap dimension MUST NOT be exceeded around the perimeter of the cover plate.


- Route the conduit to the hole in the front mask and secure the connector in place with the threaded nut. Secure the conduit in place with two clamps. Reconnect the cables and install the interior dash access cover.
- 10. Install the floor closeout plates.
- 11.Set the Battery Disconnect switch to the ON position.
- 12. Test the function of the ramp.

## 2.7. Ramp Operating Mechanism

#### 2.7.1. Description

The ramp operating mechanism includes the mechanical, hydraulic, and electrical components that drive the hydraulic cylinder, drive shafts, sprockets, chains, and pivot plates. Refer to 2.8. "Hydraulic Power Pack & Cylinder" on page 27 in this section for descriptive information and servicing procedures on the hydraulic operating components. See "Fig. 20-4: Ramp Mechanism Assembly" on page 13.





- 1. Mechanism Assembly, 32" (Incl. 2-33)
- 2. Bolt, Hex SST 1/4" 20 UNC x 3" Lg.
- 3. Bolt, Hex SST 1/2" 13 UNC x 2 1/4" Lg.
- 4. Spacer, Bushing
- 5. Shaft, Clevis
- 6. Spring Disk
- 7. Push Channel Assembly
- 8. Pin, Spring
- 9. Cylinder Assembly, 1503.5
- 10. Shaft, Push
- 11. Pin, Dowel

- 12. Shaft, 1" Diameter
- 13. Washer, Thrust 5/8" I.D.
- 14. Sleeve Bearing, Bronze .625 x 0.75 x 1.5" Lg.
- 15. Sprocket Assembly
- 16. Retainer
- 17. Block Tensioner 1"
- 18. Sprocket
- 19. Sleeve Bearing, 1" x 1.25" x 1" Lg.
- 20. Pin, Dowel
- 21. Bushing, Spherical 1" I.D.
- 22. Bracket, Wheelchair Mechanism LH

- 23. Bracket, Wheelchair Mechanism RH
- 24. Standoff, #8 32 x 2.0" Lg.
- 25. Washer, #10 x 3/8" x 0.05 Thk
- 26. Screw, Hex Socket SST #10 32 UNF x 3/4" Lg.
- 27. Nut, Lock Nylon 1/4" 20 UNC SST
- 28. Nut, Lock Nylon SST 1/2" UNC
- 29. Collar, Wheelchair Ramp
- 30. Chain, Roller
- 31. Chain Spacer, Block
- 32. Spacer, Wheelchair Ramp
- 33. Loctite, 243

s0364116a.svg

20 - 13

Fig. 20-4: Ramp Mechanism Assembly



#### 2.7.2. Disassembly

#### 2.7.2.1. Ramp Plate Removal

## ™NOTE:

Ramp plate removal can be performed with ramp mechanism installed in the vehicle.

- 1. With the ramp plate in the stowed position remove the nine 10-32 screws and rubber flap and trim pieces from each side of the ramp plate.
- 2. Remove the seven 10-24 screws and closeout plate that attach the rubber cover to the bottom of the ramp box. See "Fig. 20-5: Rubber Hinge Cover" on page 14.
- 3. Manually deploy ramp plate.
- 4. Remove the eleven 10-24 screws that attach the cover to the ramp box. Remove the cover by lifting the inner edge and pulling inward to disengage the cover slot from the hinge arm.
- 5. Support the ramp plate in a horizontal position and remove the five Phillips flat head screws on each side of the ramp plate that secure the pivot plate and sprocket to the ramp plate. See "Fig. 20-6: Ramp Plate Removal" on page 14.
- 6. Carefully slide the ramp plate complete with piano hinge, rubber cover, and hinge arm out of ramp box and move the assembly to a work area for further disassembly as required. Refer to 2.7.2.2. "Hinge & Cover Removal" on page 15 in this section for disassembly procedures.




Fig. 20-5: Rubber Hinge Cover




Fig. 20-6: Ramp Plate Removal



#### 2.7.2.2. Hinge & Cover Removal

## ™NOTE:

The following procedure describes the replacement of the piano hinge and rubber cover on the ramp plate with the ramp plate removed from the vehicle.

- Remove the eleven 10-32 screws that attach the trip deflector plate and hinge assembly to the ramp plate. See "Fig. 20-7: Hinge & Cover Assembly" on page 15.
- 2. Remove the ten 10-24 socket head screws that attach the front closing bar to the hinge and closeout block. Separate the front closing bar, hinge assembly, rubber cover, and closeout block.
- Remove the hinge arm and roller assembly from the closeout block by removing the two 10-24 socket head screws. Separate the spacer and hinge arm assembly from the closeout block.
- 4. Inspect the roller on the hinge arm and replace if required by removing the 8-32 socket head screw that fastens the roller to the hinge arm.




Fig. 20-7: Hinge & Cover Assembly



# 2.7.2.3. Drive Sprockets, Chain, & Pivot Plate Removal

## ™NOTE:

The removal of these components can be performed while installed in the vehicle or with the ramp box removed from the vehicle. The following procedure describes component removal while installed in the vehicle.

- 1. Remove the ramp box top cover.
- 2. Relieve chain tension by loosening the lock nuts and two bolts from each of the tensioner blocks. See "Fig. 20-8: Tensioner Block" on page 16.
- 3. Loosen the four bolts that attach the mechanism support plates to the ramp box. See "Fig. 20-9: Mechanism Mounting" on page 16.
- 4. Disconnect the master link on the LH and RH drive chains and lift chain from sprockets. See "Fig. 20-10: Drive Chain & Sprocket" on page 17.
- Remove the drive sprockets from the main driveshaft by loosening both setscrews in drive sprockets and sliding sprockets off shaft. Retain square keys for reassembly.

#### ™NOTE:

Alternatively, the drive sprockets can remain on the main driveshaft and be removed once the operating mechanism has been moved to a work bench.

- Remove ramp pivot plate/sprockets as follows:
  - a. Remove the shoulder screw that secures the sprocket to the ramp box.
  - Slide out the shoulder bolt, Teflon bushing, and thrust washers, noting the location of the different sized thrust washers.
  - c. Remove the pivot plate/sprocket assembly from the ramp box.




Fig. 20-8: Tensioner Block




Fig. 20-9: Mechanism Mounting






Fig. 20-10: Drive Chain & Sprocket

## 2.7.2.4. Operating Mechanism Removal

## ™NOTE:

The removal of the operating mechanism can be performed while installed in the vehicle or with the ramp box removed from the vehicle. The following procedure describes operating mechanism removal while installed in the vehicle and assumes that the ramp box cover, drive sprockets and chains have been previously removed. Refer to 2.7.2.3. "Drive Sprockets, Chain, & Pivot Plate Removal" on page 16 in this section for procedure to remove these components.

## ™NOTE:

Ensure all work is performed in a clean work area and that all hydraulic hoses and ports are properly protected and capped.

- 1. Unplug the electrical connectors from the motor harness and proximity switch.
- Disconnect and cap the hydraulic lines and ports on the actuating cylinder.
- Remove the four bolts that attach the mechanism support plates to the ramp box.
- 4. Remove the two adjusting bolts and lock nuts from each of the tensioning blocks.
- Remove the four nuts and washers and remove the square cover plate from the LH side of the ramp box.
- 6. Carefully lift the ramp operating mechanism and remove it from the ramp box.

#### ™NOTE:

Slide the LH end of the shaft into the 2 1/4" hole and angle the mechanism so that the ends of the shaft will clear the inside edges of the ramp box.

#### 2.7.2.5. Ramp Power Pack Removal

#### ™NOTE:

Refer to 2.8. "Hydraulic Power Pack & Cylinder" on page 27 in this section for removal procedures.



## 2.7.2.6. Operating Mechanism Disassembly

#### ™NOTE:

Ensure all work is performed in a clean work area and that all hydraulic hoses and ports are properly protected and capped.

- Remove the protective plugs from the actuating cylinder and manually extend the cylinder (deployed position). Reinstall protective caps.
- Remove the proximity switch from the RH side support plate.
- Remove the two adjustment bolts from each of the tensioner blocks and slide blocks off the main driveshaft.
- Relieve chain tension on the actuating cylinder drive sprockets by loosening the adjustment nuts located on either side of the idler sprocket. See "Fig. 20-11: Chain Tension Adjustment" on page 18.

#### MOTE:

DO NOT attempt to loosen the head of the bolt as it is held captive by the side support plates. Always use the hex head nut to adjust chain tension.

- Remove the idler sprocket by pushing out the clevis shaft. Note the location and quantity of thrust washers. Remove the bronze bushing from the bore of the sprocket.
- Remove the two pins that attach the drive chain to the chain spacer block. Remove the chain and spacer block. See "Fig. 20-12: Drive Chain & Spacer Block" on page 19.

## ™NOTE:

The chain spacer block serves to connect the push channel to the drive chain and effectively becomes the chain master link.

- 7. Drive out the spring pin that retains the drive sprocket to the main driveshaft.
- 8. Remove the collar and the spacer from both ends of the main driveshaft.

- Slide the main driveshaft out of the side support plates, noting the orientation of the drive sprocket collar.
- 10. Remove internal snap rings that retain the spherical bearings in the side support plates. Remove bearings from support plates.
- 11. Separate the LH & RH side support plates by removing the upper hex standoff, four through-bolts, spacers, nuts, and washers.

#### ™NOTE:

The fastener located at the top-most hole of the support plates uses a hex-shaped standoff that is threaded at either end and held in place with 10-32 UNF screws.

- 12. Remove the adjusting bolts from each of the side support plates, noting the location and positioning of the Belleville washers.
- 13. Separate the push channel from the actuating cylinder by pressing out the connecting push shaft.




Fig. 20-11: Chain Tension Adjustment




Fig. 20-12: Drive Chain & Spacer Block

## 2.7.3. Assembly

#### 2.7.3.1. Ramp Plate Installation

- Carefully move ramp plate assembly into position so that hinge arm enters ramp box and holes in ramp plate align with holes in pivot plates on ramp box.
- 2. Apply Loctite 243 to screw threads and secure ramp plate to each pivot plate with five Phillips flat head screws.

- Slide the cover onto the ramp box, ensuring that the hinge arm engages the slot in the cover. Secure cover to ramp box with eleven 10-24 screws.
- 4. Manually stow the ramp plate.
- Attach the rubber cover to the bottom of the ramp box using closeout plate and seven 10-24 screws.
- Fasten the rubber flap and trim pieces on each side of the ramp plate using nine 10-32 screws on each side. Ensure that the curved portion of the rubber flap faces downward.

#### 2.7.3.2. Hinge & Cover Installation

- 1. Install new roller on hinge arm, if required, and secure with 8-32 socket head screw.
- Attach spacer and hinge arm assembly to closeout block with two 10-24 socket head screws.
- Assemble the closing bar, hinge assembly, rubber cover, and closeout block and secure together with ten 10-24 socket head screws.
- 4. Position the previously assembled components on the ramp plate, aligning the holes in the trip deflector plate with the holes in the ramp plate.
- Apply Loctite 243 to screw threads and secure components to ramp plate with eleven 10-32 screws. Torque screws to 24 in-lbs.



# 2.7.3.3. Drive Sprockets, Chain, & Pivot Plate Installation

## ™NOTE:

If the operating mechanism was removed from the ramp box, install the side sprockets onto the main driveshaft before installing the mechanism.

 Assemble the ramp pivot plate/sprocket assembly using Teflon bushing, shoulder bolt, and thrust washers. Ensure Teflon bushing is fully seated in sprocket counterbore and the shoulder bolt is lubricated with lithium grease. See "Fig. 20-13: Pivot Plate Installation" on page 21.

## ™NOTE:

Ensure that the bronze thrust washers and shoulder bolt are properly installed. Both washers go between the Teflon bushing and the ramp box. The thin washer faces the Teflon bushing and the thick washer faces the ramp box. The head of the shouldered bolt bears directly against the Teflon bushing.

 Insert assembled ramp pivot plate/sprocket assembly into ramp box. Apply Loctite 243 to the threads of the shoulder bolt and torque bolt to 42 ft-lbs. (57 Nm).

## NOTE:

Ensure that the pivot plate/sprocket assembly rotates freely within the ramp box.

- Install sprockets on either end of main driveshaft ensuring square key is properly located and both setscrews are tightened.
- 4. Fully extend the actuating cylinder to the deployed position.
- 5. Place the LH & RH drive chains onto the sprockets and connect with master link.

#### ™NOTE:

Assemble the master link on the lower run of the chain. The master link location should align with the edge of the pivot plate when the ramp is in the deployed position.

- Position the pivot plate at a downward angle of approximately 9° to represent the ramp plate in the deployed position when connecting the chains. See "Fig. 20-14: Pivot Plate Alignment" on page 21.
- Align the operating mechanism and adjust the chain tension. Refer to 2.7.3.7. "Ramp Mechanism Initial Adjustments" on page 25 in this section for adjustment procedures.
- 8. Move the spacers and collars against the tensioner block and secure in place.






Fig. 20-13: Pivot Plate Installation




Fig. 20-14: Pivot Plate Alignment



#### 2.7.3.4. Operating Mechanism Assembly

## ™NOTE:

The following assembly procedure describes a specific sequence that assembles the mechanism components onto the RH side support plate and then sliding the LH support plate onto the built up assembly. Difficulty with installing the chain spacer block (master link) could occur if this sequence is not followed.

- Partially assemble the LH & RH support plates as follows:
  - Pack the spherical bearings with lithium grease and insert into the bores of the side support plates. Retain the bearings with internal snap rings.

#### ™NOTE:

The internal snap ring has a sharp edge on one side and a smooth rounded edge on the opposite side. Install the snap ring with the smooth rounded edge facing the thrust load (bearing side).

b. Install the adjusting bolts into the sleeves located at the end of each side support plate. The flat on the hex head bolt should seat against the side support plate. Install the Belleville washers and locknut. Leave the adjusting nut in the full slack position at this time. See "Fig. 20-15: Adjusting Bolt Installation" on page 24.

## ™NOTE:

The Belleville washers must be installed in an alternating convex, concave stack arrangement.

- Apply lithium grease to the ends of the push shaft and the slots in the LH & RH side support plates. Assemble the push channel to the rod eye of the actuating cylinder, ensuring that the cylinder is in the fully retracted position.
- 3. Position the push channel against the RH support plate ensuring that the push shaft engages the slot in the RH support plate.
- Assemble the chain spacer block (master link) to the push channel using a pin. Ensure the wide slot end of the spacer block is facing toward the cylinder.

- Connect the end links of the chain to the spacer block using two pins. See "Fig. 20-16: Chain Spacer Block Installation" on page 24.
- Lubricate the bronze bushing with lithium grease and insert into idler sprocket (11T).
- Engage the teeth of the idler sprocket with the chain and position the idler sprocket with two thrust washers against the RH side support plate.

#### MOTE:

Ensure idler sprocket teeth are centered between the side support plates. The small diameter collar on the sprocket should face the RH side support plate.

- 8. Lubricate clevis shaft with lithium grease and insert through idler sprocket.
- 9. Hold the main driveshaft with the keyways facing upward and slide drive sprocket (13T) onto shaft.

## ™NOTE:

The collar on the drive sprocket should face the LH side support plate.

10. Rotate the drive sprocket so that the holes in the collar line up with the hole in the driveshaft. Ensure that the tooth that aligns with the spring pin hole faces downward.

## ™NOTE:

The drive sprocket tooth alignment with respect to the keyways on the end of the shaft must be maintained in order to ensure that the ramp is fully deployed when the actuating cylinder is fully extended. If the drive sprocket is not properly installed on the driveshaft, then the timing between the ramp plate and the actuating cylinder will be incorrect.

- Install spring pin to lock sprocket to driveshaft.
- 12. Slide the driveshaft and sprocket assembly through the RH support plate and bearing. Engage the teeth of the drive sprocket with the chain so that the angle of the shaft keyways and the spring pin are at 71° from horizontal. See "Fig. 20-17: Drive Sprocket Installation" on page 24.
- 13.Insert one hex standoff, four bolts and spacers into the RH side support plate.

## PNOTE:

The hex standoff is located at the uppermost hole on the support plate.

- 14.Install two thrust washers over the clevis shaft on the idler sprocket.
- 15. Slide the LH side support plate and bearing over the main driveshaft and align support plate with the four bolts. Ensure the ends of the push shaft and clevis shaft engage their respective slots in the LH side support plate.
- 16.Install washers and lock nuts on the four through-bolts and tighten.
- 17. Position the hex standoff, located at the upper-most hole, so that the flats on the hex are parallel with the sides of the support plates. This positioning is necessary so as to avoid interference with the access cover plate. Secure the hex standoff using 10-32 UNF socket head screws with lock washers.
- 18. Operate the mechanism from fully retracted to fully extended. A 0.010" feeler

- gauge should fit between the sides of the push channel and the side support plates during the entire retract and extend cycle.
- 19. Slide the collar and spacer over each end of the main driveshaft. Leave loose at this time.

## ™NOTE:

Spacers and collars will be positioned and final tightened during installation.

20.Lubricate the Teflon bushings with lithium grease and insert into tensioner blocks. Slide tensioner blocks onto ends of main driveshaft.

#### RNOTE:

If new bushings are being installed, the holes in the tensioner block will have to be drilled out to original diameter to allow the bolts to clear the O.D. of the bushing.

21. Install the proximity switch so that face of the switch is flush or just slightly set back from the face of the RH side support plate.






Fig. 20-15: Adjusting Bolt Installation




Fig. 20-16: Chain Spacer Block Installation




Fig. 20-17: Drive Sprocket Installation

#### 2.7.3.5. Ramp Power Pack Installation

## ™NOTE:

Refer to 2.8. "Hydraulic Power Pack & Cylinder" on page 27 in this section for installation procedures.

## 2.7.3.6. Operating Mechanism Installation

- Position the operating mechanism inside the ramp box at an angle so that the LH end of the drive shaft enters the 2 1/4" hole in the ramp box. Slide the mechanism into place, centering over the mounting holes.
- Install the LH side cover plate using four nuts and washers.
- Align the tension blocks with the corresponding threaded holes in the ramp box.
   Install two bolts and lock nuts in each tensioner block but do not tighten to adjust chain at this time.
- 4. Snap in the two access plugs at either end of the drive shaft.
- Operate the mechanism so the actuating cylinder is in the fully extended (deployed) position.

#### 2.7.3.7. Ramp Mechanism Initial Adjustments

 Set the drive chain tension by tightening the locknuts on the adjusting bolts equally. Continue to tension the chain until the Belleville washers are compressed nearly flat. Do not over tighten chain.

## ™NOTE:

The clevis shaft must remain perpendicular to the drive chain when chain is being tensioned.

- Adjust the LH & RH drive chains using the adjustment bolts on the tensioner blocks. Tighten the upper and lower bolts equally while at the same time tightening the LH & RH tensioner blocks equally.
- Continue to adjust LH & RH drive chain tension equally until most of the slack is removed. Final tensioning will be performed when the ramp plate is installed.

## ™NOTE:

Maintain the main driveshaft perpendicular to the sides of the ramp box while tensioning the chain. Measure from a point near the LH outer end of the main driveshaft to a point on the face of the ramp box. Measure corresponding points on the RH side and compare measurements with LH side to ensure operating mechanism is mounted squarely.

4. Tighten the two rear (inboard) bolts that secure the mechanism support bracket to the ramp box.

## ™NOTE:

Ramp mechanism final adjustments will be performed with the ramp mechanism installed in the vehicle.



#### 2.7.3.8. Ramp Mechanism Final Adjustments

- Install the ramp box into the vehicle. Refer to 2.6. "Installation" on page 12 in this section for procedure.
- 2. Set the drive chain tension with the ramp plate installed. Manually operate ramp through a couple of deploy and stow cycles while checking for excessive resistance, binding, or jerking during operation.
- If operation is unsatisfactory check for proper alignment of operating mechanism within the ramp box. Refer to 2.7.3.7. "Ramp Mechanism Initial Adjustments" on page 25 in this section for alignment procedure.
- 4. If jerky operation is noted or the ramp flops when coming over the top, there is likely excessive slack in the drive chains. Adjust chain tension as follows:
  - Loosen the four bolts that secure mechanism support bracket to the ramp box.
  - b. Loosen the lock nuts on the tensioner blocks.

- Tighten the LH & RH tensioner bolts equally and in small increments until excessive slack is taken up.
- d. Tighten tension adjusting bolt lock nuts.
- e. Tighten four bolts that secure mechanism support bracket to the ramp box.
- f. Recheck ramp operation.
- 5. Check that the ramp reaches the fully deployed position (9° angle) when the cylinder is fully extended. If the ramp plate does not fully deploy, then recheck the sprocket and chain timing. Refer to 2.7.3.3. "Drive Sprockets, Chain, & Pivot Plate Installation" on page 20 in this section for procedure.
- Operate the ramp hydraulically through several deploy and stow cycles. Confirm proper operation of vehicle interlocks when ramp is deploying.
- Check for correct proximity switch adjustment if interlocks are not functioning. The face of the switch should be flush or slightly recessed with the face of the RH support plate. The gap between the proximity switch and target (push channel) must not exceed 5/32" (4.0 mm).

# **Hydraulic Power Pack & Cylinder**

## 2.8. Hydraulic Power Pack & Cylinder

## 2.8.1. Description

The Hydraulic Power Pack consists of a reservoir, electric motor, pressure relief valve, and a solenoid-operated control valve assembly used to operate the hydraulic actuating cylinder.

# 2.8.2. Hydraulic Power Pack & Cylinder Specifications

Motor: Voltage24 VDC Length (Including connector)250mm ± 6mm (9.84" ± 0.25")
Control Valves: TypeSolenoid Actuated Cartridge Valves - 2P3W Voltage24 VDC
Reservoir:  Material
Pressure Relief Valve: Rating1750 psi

#### 2.8.3. Operation

The Hydraulic motor pumps fluid from the reservoir and forces it through the solenoid valve-controlled ports. Hydraulic fluid actuates the hydraulic cylinder which operates the ramp deploy/stow mechanism.

#### 2.8.4. Maintenance

Refer to the Preventive Maintenance Section of this manual for scheduled maintenance requirements and intervals.

## 2.8.5. Hydraulic Power Pack & Cylinder Troubleshooting

Refer to 2.4. "Wheelchair Ramp Troubleshooting" on page 5 in this section for troubleshooting procedures.

#### 2.8.6. Removal

- Disconnect the solenoid electrical connector and the motor electrical connector. See "Fig. 20-18: Hydraulic Power Pack Assembly" on page 28.
- Disconnect the hydraulic hoses and plug the ports.
- Remove the bolt holding the power pack to the ramp frame and remove the power pack.

#### ™NOTE:

Wiring may be attached with single-use nylon locking straps. Note the location of these straps, and which wires are being bundled together or secured to conduit or frame members, so replacement straps can be properly secured to maintain service integrity.

## ™NOTE:

Refer to your New Flyer Parts Manual for Power Pack replacement parts information.

#### 2.8.7. Installation

- Install power pack and secure with the mounting bolt and washers.
- Remove caps from ports and attach the hydraulic hoses.
- Connect the solenoid electrical connector and the motor electrical connector.
- 4. Secure harness bundles and hoses with nylon straps.






Fig. 20-18: Hydraulic Power Pack Assembly